

---

# 300 SERIES GRAYHOUND

Hot Mix Asphalt Paver  
Operation/Maintenance Manual



## To the Owner & Operator

We have tried to provide information which will give you a clear understanding of equipment construction, function, capabilities and requirements. This information is based on the knowledge and experience of highly qualified people at our company and in our field organization. Proper use of this information will promote high efficiency, maximum service life and low maintenance costs.

We strongly recommend that all persons directly involved with this equipment be familiar with this manual.

The information contained in this manual should not be considered all-inclusive for every application. Questions about specific uses of this equipment should be directed to Cedarapids Inc. Anyone who uses this equipment for any purposes other than its intended use assumes the risk of any danger in doing so.

Respectfully,

Cedarapids Inc.

---



**Warning** - The operators of this equipment must read, understand, and follow all OSHA, federal, state and local regulations regarding the operation of this equipment. This equipment must be used in accordance with all operation and maintenance instructions.

- (1) Read all decals and instruction signs. Know what guards and protective devices are included and see that each is installed and in operational condition. Additional guards and protective devices may be required and must be installed before operating.
- (2) Never maintain, lubricate or adjust equipment while in operation. Turn off key switch and remove the key before doing any maintenance, lubricating, or adjusting. In some cases it may be necessary to disconnect the battery terminals to prevent accidental starting of the equipment.
- (3) Wear a protective mask whenever harmful air pollution exists.
- (4) Use ear plugs whenever noise level is above established limits.

## Table Of Contents

<b>Section 1 -Introduction</b> .....	1 - 1
<b>Cedarapids Paver Manuals</b> .....	1 - 1
<b>Hazard Levels</b> .....	1 - 2
<b>Identification Number Location</b> .....	1 - 3
<b>Lockout Tagout</b> .....	1 - 7
<b>General safety</b> .....	1 - 8
<b>Receiving New Equipment</b> .....	1 - 10
<b>Section 2 -Equipment Description</b> .....	2 - 1
<b>Function and Application</b> .....	2 - 1
<b>Optional Equipment</b> .....	2 - 3
<b>Operator's Console</b> .....	2 - 8
<b>Section 3 -Periodic Maintenance</b> .....	3 - 1
<b>Raising the hood</b> .....	3 - 1
<b>Before Starting Engine</b> .....	3 - 2
<b>Maintenance Checklist</b> .....	3 - 3
<b>Periodic Maintenance</b> .....	3 - 5
1) Fuel Level .....	3 - 5
2) Fuel/Water Separator .....	3 - 5
3) Travel Lever Alignment .....	3 - 6
4) Hydraulic Fluid .....	3 - 6
5) Oil Cooler .....	3 - 7
6) Suction Strainers .....	3 - 7
7) Charge Filters .....	3 - 8
8) Auxiliary Pump Filter .....	3 - 8
9) Hydraulic lines and components .....	3 - 8
10) Air Restriction Indicator .....	3 - 8
11) Air Filter .....	3 - 9
12) Engine Oil .....	3 - 10
13) Engine Oil Filter .....	3 - 11
14) Engine Coolant .....	3 - 11
15) Engine Fan Belt .....	3 - 12
16) Radiator .....	3 - 13
17) Engine Cooling Fan .....	3 - 13
18) Battery .....	3 - 13

---

## Table Of Contents

19) Tire Pressure .....	3 - 15
20) Frame Raise System .....	3 - 16
21) Steel Track Tension .....	3 - 17
21A) Rubber Track Tension .....	3 - 19
22) Track Pivot .....	3 - 19
23) Fire Extinguisher .....	3 - 19
24) Horn .....	3 - 19
25) Pump Drive Belts .....	3 - 19
26) Depth Cranks .....	3 - 22
27) Vibrator Bearings .....	3 - 22
28) Crown Control .....	3 - 22
29) Match Height Assembly .....	3 - 23
30) Extension Slope Assembly .....	3 - 23
31) Final Drive Oil .....	3 - 23
32) Steering Bogie Alignment .....	3 - 23
33) Steering Linkage .....	3 - 24
34) Bogie Beam Bearings .....	3 - 24
35) Front Wheel Bearings .....	3 - 24
36) Bogie Wheel Toe-in .....	3 - 24
37) Conveyor Slat Chains .....	3 - 24
38) Conveyor Bearings .....	3 - 25
39) Auger Bearings .....	3 - 26
40) Feeder Drive Chains .....	3 - 26
41) Conveyor Speed Reducer .....	3 - 27
42) Hood Raise Reservoir .....	3 - 27
43) Operator Console Pivot Bearings .....	3 - 28
44) Tow Arm Nose Roller .....	3 - 28
45) Slope Beam Rod Ends .....	3 - 28
46) Truck Hitch .....	3 - 28
47) Fume Recovery System .....	3 - 29

---

Table Of Contents

**Section 4 -Operating the Tractor** ..... 4 - 1

**Starting the Engine** .....4 - 1

        Engine start-up after stall .....4 - 2

        Jump starting/ charging batteries .....4 - 2

        Emergency towing .....4 - 3

**Loading/Unloading** .....4 - 5

        Driving the Paver off a Trailer .....4 - 5

        Lifting with crane .....4 - 6

**Preparation for transport** .....4 - 8

**Preparing to Pave** .....4 - 9

**Spray Down and Cleaning** .....4 - 13

**Section 5 -Hydraulic System Repair** ..... 5 - 1

**Travel Pumps** .....5 - 2

        Travel Drive Systems .....5 - 2

        High Pressure Adjustment .....5 - 2

**Conveyor Pumps** .....5 - 4

        Conveyor Drive Systems .....5 - 4

        Cleaning a Disabled Paver .....5 - 4

        Checking Conveyor Drive Charge Pressure .....5 - 5

        Checking System Relief Setting .....5 - 5

        Conveyor Neutral Adjustment .....5 - 6

**Vibrator Pump** .....5 - 9

**Auxiliary Systems Pump** .....5 - 10

        Auxiliary System .....5 - 10

        Auxiliary System Pressure Compensator Check .....5 - 10

**Rubber Track Hydraulic System** .....5 - 11

        Checking Rubber Track Hydraulic System .....5 - 13

        Auxiliary System Pump Pressure .....5 - 13

        Pressure Reducing Valves .....5 - 13

        Track Tension Accumulator .....5 - 14

        Track Tension Check Valve and Shut-off Valve .....5 - 14

        Track Tensioning Cylinders .....5 - 15

        Track Take-up Valve .....5 - 16

**Remote Oil Cooler Pump** .....5 - 17

---

## Table Of Contents

<b>Filters</b> .....	5 - 18
Travel Circuit Filters .....	5 - 18
Conveyor Circuit Filters .....	5 - 18
Auxiliary Filter .....	5 - 19
Suction Strainers .....	5 - 19
<b>Solenoid Valves</b> .....	5 - 20
Manual Testing of Solenoid Valves .....	5 - 22
Removing/disassembling Valve Bank .....	5 - 22
<b>Valve Bank Components</b> .....	5 - 23
Throttle Valve .....	5 - 23
Holding Valve .....	5 - 23
Flow Control Valve .....	5 - 23
<b>Assembling Valve Banks</b> .....	5 - 24
<b>Hydraulic System Troubleshooting</b> .....	5 - 26
<b>Hydraulic Schematic</b>	
<b>Electrical Schematic</b>	
<b>Section 6 -Mechanical Maintenance</b> .....	6 - 1
<b>Steel Track Maintenance</b> .....	6 - 1
Steel Track Tensioning .....	6 - 1
Steel Track Installation .....	6 - 2
Steel Track Removal .....	6 - 3
Replacing Steel Track Drive Sprockets .....	6 - 3
Repairing Oscillating Bogie Rollers .....	6 - 4
<b>Rubber Track Maintenance</b> .....	6 - 5
Rubber Track Tension .....	6 - 5
Rubber Track Installation & Removal .....	6 - 5
Rubber Track Re-tensioning .....	6 - 7
Repairing Rubber Track Bogie Wheels .....	6 - 8
Bogie Wheel Bearing Replacement .....	6 - 9
Repairing Rubber Track Front Idler Assembly .....	6 - 11
Bearing Replacement .....	6 - 14
Rubber Track Drive Wheel Replacement .....	6 - 16

---

## Table Of Contents

<b>Slat Conveyors</b> .....	6 - 17
Replacing Slat Conveyor Liners .....	6 - 17
Inverting Slat Bars .....	6 - 17
<b>Augers</b> .....	6 - 18
Cast Augers .....	6 - 18
Re-facing Lined Augers .....	6 - 18
Re-lining Auger Shafts .....	6 - 19
<b>Machine Storage Preparation</b> .....	6 - 20
 <b>Section 7 - Automation (if equipped)</b>	
 <b>Section 8 - Screed (if equipped)</b>	
<b>Appendix A -Torque Specs</b> .....	A-1
<b>Torque Charts</b> .....	A-1

---

Table Of Contents



---

## Cedarapids Paver Manuals

### Section 1 - Introduction

#### Cedarapids Paver Manuals

The following list represents the complete set of manuals available to the owner, operator, and mechanic of a Grayhound paver. All of these manuals are included with each new paver when it ships from the factory. If your manuals are not included with your new paver or if you require additional copies of any of these manuals contact your local Cedarapids dealer.

#### Operation and Maintenance Manual

The Operation and Maintenance manual is intended to be used by both the operator and mechanic.

The operation portion of this manual gives detailed operating and safety instructions for both new and experienced operators. It is intended to give more detailed information than the Pocket Paver Guide.

The maintenance portion of this manual gives detailed information on component locations, test procedures, safety, and routine maintenance. This information expands on the information in Technical manual and Wear Check Guide.

#### Technical Manual

The Technical manual is designed primarily for use by maintenance personnel. It provides detailed troubleshooting procedures and schematics for diagnosing paver breakdowns. Once a problem has been diagnosed, refer to the Operation and Maintenance manual for information on making the repair.

#### Quality Paving Guide

The Quality Paving Guide should be used primarily by paver operators. This manual gives detailed information on setting up the paver to produce the mat surface needed.

#### Wear Check Guide

The Wear Check Guide should be used primarily by maintenance personnel. It contains detailed information for determining when parts require replacement.

#### About the Pocket Paver Guide

The Pocket Paver Guide is a small reference manual designed for use by experienced operators. It contains information needed by the operator for day-to-day operation, adjustment and maintenance of the paver and screed.

#### CIMA Safety Manual

The CIMA Safety Manual is a general manual designed to be used by everyone on a paving job site. This would include operators, laborers, mechanics, truck drivers, etc.

---

## Hazard Levels

### Hazard Levels

The signal words **Danger**, **Warning** and **Caution** are used to identify hazard levels of in this manual. They may also be found on decals located on the equipment. (Figure 1 - 1)



**Caution** - Hazards or unsafe practices which **COULD** result in minor personal injury, minor occupational illness, or minor system or environmental damage.

The signal word **Notice** is used to identify installation, operation, or maintenance information which is important but not hazard related.




Figure 1 - 1 Hazard Level Hierarchy

Definitions for identifying hazard levels and their signal words are provided below:



**Danger** - Immediate hazards which **WILL** result in death, system loss, severe personal injury, severe occupational illness or severe or major system or environmental damage.



**Warning** - Hazards or unsafe practices which **COULD** result in death, system loss, severe personal injury, severe occupational illness or severe or major system or environmental damage.

Identification Number Location

**Identification Number Location**

**Tractor**




Figure 1 - 2 Tractor ID Number Locations

The serial number plate for current model tractors can be found on the left rear frame bulkhead. In addition, the serial number will be stamped into the bulkhead to the right of the serial number plate. On early model tractors, the serial number may be stamped into the bulkhead and covered with the serial number plate. (Figure 1 - 2)

The serial number will also appear on the lubrication decal found on the right rear frame bulkhead.

## Identification Number Location

### Screed

The various Fastach and Stretch screeds carry both a serial number and a module number to simplify identification when ordering parts.

The identification plate bearing both numbers is located on the right-hand screed pull arm on the current Fastach screeds. In addition, the screed module number is stamped on the right-hand pull arm below the identification plate. (Figure 1 - 5)

The plate is on the right-hand tipping frame on the current Stretch screeds. The module number is also stamped directly below the identification plate and on the right-hand main screed frame end plate. (Figure 1 - 6)

On early-model Fastach (Figure 1 - 3) and Stretch (Figure 1 - 4) screeds where the serial number was not included on the screed, the serial number of the tractor must be used when ordering parts for the screed or tractor.

If a Fastach screed is shipped as a single item (to be mounted on a paver in the field) the serial plate will be mounted below the screed identification plate on the right-hand pull arm.

On single-item Stretch screeds the serial plate will be adjacent to the screed identification plate on the right-hand tipping frame.

Refer to the following illustrations for locations of the stamped module numbers and identification.

Identification Number Location




Figure 1 - 3 Early Fastach




Figure 1 - 4 Early Stretch 20

Identification Number Location




Figure 1 - 5 Current Fastach




Figure 1 - 6 Current Stretch 16, 18, & 20

## Lockout Tagout

### Lockout Tagout



**Warning:** Failure to follow good lockout and tagout procedures could result in serious injury or death.

#### What is the purpose of lockout /tagout?

- Prevent the unexpected or accidental start-up of equipment and to notify other workers when a piece of equipment is unsafe to operate.
- Prevent injury to personnel from energy that is stored in devices such as springs, accumulators, hydraulic systems, batteries, etc.

#### How do I lockout and tagout equipment?

- Turn the master key to the OFF position and remove the key.
- Disconnect the batteries.
- Regardless of which lockout method is used, place one or more tags on machine controls or access doors to let other workers know that maintenance is being performed on the machine and/or the machine is unsafe to operate.

#### Who is responsible for establishing and administering a lockout /tagout program?

- The employer must establish a lockout /tagout system of procedures, training and periodic inspection before any employee operates, services, or maintains a piece of equipment.
- All employees are responsible for seeing that equipment is locked out and tagged out according to the employers policies.

#### When is lockout and tagout necessary?

- Any time repairs or maintenance on a machine are to be performed.
- When cleaning or lubricating the machine.
- While clearing blocked or jammed mechanisms.
- Any time that the equipment will be left unattended.

#### Who should apply a lock or tag?

- Any maintenance person who will be working on the equipment.
- The foreman or team leader responsible for the job.
- Anyone who will be working on the equipment.
- If several people will be working on a piece of equipment, each person must apply their own tag.

#### When can a lock or tag be removed?

- After all safety guards are back in place.
- After work is complete and tools are put away.
- After workers are positioned safely for start-up.
- After controls are positioned correctly for start-up and machine is operation ready.

#### Who can remove a lock or tag?

- Only the person who applied a lock or tag can remove it.

## General safety

### General safety

This manual contains important information regarding the operation of your paver. Carefully read the entire manual before attempting to operate the paver.

#### Danger

- Install all auger guards and vibrator covers before operating the paver.
- Never attempt to install or remove any part or assembly when the paver is running.
- Do not allow personnel to stand or walk between the front of the paver and the back of the truck while the paver is operating.
- Attach screed safety cables or lower the screed before performing any inspections, repairs or adjustments to the screed.
- All guards and protective devices must be in place when the paver is being operated or moved.
- Keep all personnel clear of augers when the paver is operating.
- Do not refuel the paver with the engine or screed heater system running. All sparks and open flames must be kept a minimum of 50 feet away from the paver when refueling.
- Do not wash or spray down the screed or tractor with the screed heater system operating.

#### Warning

- Do not operate this equipment until you have been trained in its operation or maintenance. This equipment may only be operated or maintained by trained personnel, who have demonstrated their ability to do so safely.

- Keep this manual for future reference.
- Read, understand and follow all current OSHA, federal, state and local regulations that are applicable to your job and equipment.
- This equipment must be used in accordance with all operation and maintenance instructions.
- All persons involved with this equipment must be familiar with this manual.
- Read, understand, and follow all Danger, Warning, Caution and instruction decals in this book and on the paver.
- When changing the paver configuration or adding equipment to the paver, all additional guards associated with the added equipment must be installed before operating or moving the paver.
- Any changes made to the original design of the paver must be approved by qualified personnel to ensure that the changes include appropriate guarding and provide a safe working environment for all personnel.
- Wear clothing that fits snug to prevent getting caught in moving parts. Loose-fitting clothing should never be worn.
- Mount and dismount the paver from the rear using only the steps, handrails and walkways provided.
- Do not mount the paver when it is moving.
- Allow only the operator on the operator's platform when the paver is in operation.
- Before starting the paver, make sure the brakes are ON, all other systems are OFF and all personnel are clear.

## General safety

- Before leaving operator's seat, always place the brake switch ON, and all other controls or switches in OFF or NEUTRAL position.
- Reduce travel speed when going down step grades to prevent over-speeding.
- Do not allow personnel near the hopper area when the paver is running.

### Caution

- Wear protective mask when harmful air pollution exists.
- Wear safety goggles, gloves and long-sleeve shirts when working near hot asphalt materials.
- Wear ear plugs while paver is running.
- Keep operator's platform, steps and screed walkways clear of all obstructions, tools and other items to prevent tripping or falling.
- To prevent fire hazards, keep the screed and engine basket area free of oil, asphalt and trash buildup.

## Receiving New Equipment

### Receiving New Equipment

Before accepting and unloading a new paver, the consignee must inspect the equipment for evidence of damage or missing parts. This inspection process should be thorough, because once the freight receipt is signed, it is assumed that all of the equipment listed on the receipt was received in good condition.

Make a thorough inventory of all loose components packaged in boxes. A check list is provided in each box listing the components in the box. While performing the inventory, inspect all loose components for damage which may have occurred during transit. Any damage that happens to the equipment in transit is the responsibility of the carrier **not** Cedarapids. Claims for damage must be submitted to the carrier for settlement.

When evidence of damage or loss is discovered, have the driver make a notation on both the carrier's and consignees' copies of the freight bill. Prior to signing the freight bill, take pictures of the damage and identify the truck if possible. The consignee can then sign the bill to acknowledge delivery. The consignee should then have the carrier's terminal manager or his authorized representative make an official inspection of the damage or loss.

Equipment should not be moved from the original receiving point until this official inspection has been made. Good clear photos will verify and explain damage in any claim action which may follow. When the inspection is done, the consignee should file a written damage claim with the carrier's office and should report this action to the area distributor for Cedarapids Inc.

If hidden damage is found after the carrier's representative has gone, do not continue to unpack or move the equipment. Contact the carrier's local

office and have the terminal manger or authorized representative make an immediate personal inspection of the damage. Obtain a written description of the damage, and photos if possible, signed by the representative as proof of a valid claim.

A packet of equipment warranty/start-up information will be sent to the distributor before the equipment leaves the factory. All warranty/start-up forms must be filled out and returned to Cedarapids within **24 hours** after the equipment is received.

## Function and Application

### Section 2 - Equipment Description

#### Function and Application

The paver will lay a uniform high density asphalt mat for highways, roadways, airport runways, parking lots and driveways. It is capable of performing jobs with strict control specifications and high production requirements.

The paver will level and compact mix up to 12" in depth, with mat widths varying from 6' to 30'. Mat depth and width variations are accomplished by adjusting feed controls and adjusting the screed.

#### Operating Principle

The hot mix is dumped by truck into the hopper or picked up by a windrow machine at a rate suitable for continuous paving. While dumping mix, the truck is pushed forward by the paver. (Figure 2 - 1)




Figure 2 - 1 Asphalt Flow

Hot mix is carried by two independently controlled slat conveyors to the augers at the rear of the tractor and in front of the screed. Material feed may be either manually or automatically regulated to maintain an even and consistent "head of material" in front of the screed. Material flow rate is regulated by a combination of varying slat conveyor speed and material gate height. A strike off plate mounted directly in front of the screed bottom meters the material passing under the screed bottom. The screed rides up or floats on the mix to level and smooth the mat. Contour of the mat may be set to a desired slope with the

adjustable screed controls. Screed controls are adjusted manually or automatically to create the desired mat.

The screed has vibrators which perform the initial "ironing" of the mat. Final compaction of the newly laid mat is accomplished by a roller.

The screed has burners that heat the screed bottom close to the temperature of the mix before paving begins. Heating the screed bottom prevents asphalt from sticking to the screed bottom which causes tearing and a poor mat surface.

Function and Application

The screed can be fitted with extensions or extendible strike-offs for paving wide widths or shoulders.

The fume recovery system is designed to collect fumes given off by hot mix asphalt and discharge them away from operator work areas. This system is standard equipment on all Grayhound pavers manufactured after July 1, 1997 (Figure 2 - 2). The system is designed to collect fumes given off by

asphalt mix as it is distributed along the length of the main screed by the spreading augers. The fumes are drawn into a hydraulically driven fan. The fan then blows the fumes into the engine exhaust muffler. Inside the muffler the asphalt fumes are combined with the engine exhaust and discharged through the exhaust pipe. A vacuum gauge indicates amount of vacuum generated in the fan intake manifold.




Figure 2 - 2 Fume Recovery System Overview

Optional Equipment

**Optional Equipment**

**Screed Extension**




Figure 2 - 3 Screed Extension

Screed extensions are furnished in 6", 12", 24" and 36" lengths which make it possible to pave widths up to 30'. Both screed and auger extensions can be quickly attached. It is recommended that auger extensions be 1' less than the screed extensions used. For example; with a 1' screed extension no auger extension is needed, with a 2' screed extension use a 1' auger extension, etc. (Figure 2 - 3)

**Slopeable Hydraulic Strike-off Extension**




Figure 2 - 4 Slopeable Hydraulic Strike-off Extension

Hydraulic strike-off extensions are ideal for parking lots because they reduce or eliminate handwork to bleed out material at driveways, tapers, flush-to-wall work, etc. This reduces the need for extra passes which saves time and makes any paving operation more profitable.

These strike-offs provide a level surface and constant mat depth extendible up to 4' on each side. Strike-off blades are easily adjusted to match main screed strike-offs. Hydraulic slope adjustment simplifies laying drainage contours and other special applications. (Figure 2 - 4)

**Truck Hook**




Figure 2 - 5 Truck Hook

Optional Equipment

The truck wheels ride against the push rollers which pushes the truck ahead of the paver. To prevent the truck from pulling away from the paver while moving down a hill, retractable rollers hook into the inside of the truck wheels. (Figure 2 - 5)

**Bevel Guide Plate**




Figure 2 - 6 Bevel Guide Plate

The adjustable bevel plate bolts to screed end plate to assure a smooth sloping contour on the edge of the mat. Two plates are available: one for 1-1/2" depth and one for 3" depth with bevel angle at 45°. (Figure 2 - 6)

**Automatic Grade and Slope Control**

The grade and slope control enables the paving contractor to lay uniform and smooth mats automatically, regardless of irregularities in the roadway. It also provides precise slope angle for curves in roadway.

**Topcon Grade and Slope Control**




Figure 2 - 7 Topcon Grade and Slope Control

The Topcon grade and slope control system includes sonic grade sensors and a pendulum slope sensor to maintain the desired mat profile. (Figure 2 - 7)

**Night Lighting Kit**

This kit includes four high pressure sodium lamps and a separate generator to light up the work area at night. (Figure 2 - 8)




Figure 2 - 8 Night Lighting Kit

Optional Equipment

**Grade Reference Ski**

Two grade reference ski systems are available; the multi-foot ski and tube ski. The skis are available in 20', 30', and 40' lengths. Skis travel along an existing road surface sensing changes in grade while averaging out bumps. The tube ski consists of a single tube section which rides directly on the road surface. The multi-foot ski consists of a main beam supported by several skid plates. Each skid plate is spring mounted to provide independent movement over irregular surfaces. As the ski passes over bumps each skid plate is deflected independently while the main beam maintains a constant level. This allows the screed to produce a mat with minimal bumps. (Figure 2 - 9)




Figure 2 - 9 Multi-Foot Ski

The over-the-screed ski uses the multi-foot or tube ski in front of the screed to sense changing grade and a skid plate that rides behind the screed on the new mat surface. This system produces the most even mat surface by “averaging” the grade of the existing road surface and the newly laid mat. (Figure 2 - 10)




Figure 2 - 10 Over-the-Screed Ski

**Material Retaining Plates**




Figure 2 - 11 Material Retaining Plates

2' Material Retaining Plates are mounted to the paver frame and extend out toward the end gate during wide width paving. They limit the amount of material that builds up in front of the auger. When auger extensions up to 3' are added to either side of paver, a retaining plate support brace is attached to the screed pull arm. When 4' or more (3-1 ft. sections) extensions are used, an extra support brace is added. (Figure 2 - 11)

Optional Equipment

**Auger Extensions**




Figure 2 - 12 Auger Extensions

As extensions are added to the screed or when a screed or strike-off is extended, auger extensions must be added to move material out the full width of the screed. Auger extensions are available in 1', 3', and 5' lengths. (Figure 2 - 12)

**End Gates**




Figure 2 - 13 End Gates

End Gates are mounted on the end of the screed, extension, or extendible strike-off. They prevent material from spilling out beyond the reach of the screed and form a good edge on the mat. (Figure 2 - 13)

**Cutoff Shoe**




Figure 2 - 14 Cutoff Shoe

Standard cutoff shoes attach to the screed end gate when paving at less than the full width of the screed. The shoe can be adjusted in 1-1/2" increments. (Figure 2 - 14)

Optional Equipment

**Front Wheel Assist**




Figure 2 - 15 Front Wheel Assist

Gives paver up to 50% more tractive effort with the flip of a switch on the operator's control panel on the 351 Paver. (Figure 2 - 15)

**Proportional Material Feed control**




Figure 2 - 16 Proportional Feed Control

A mechanical wand measures the height of the material and adjusts conveyor speed as needed to maintain a uniform head of material in front of the screed. (Figure 2 - 16)

**Sonic Feed control**




Figure 2 - 17 Sonic Feed Control

Adding a Sonic control further automates material feed to the auger. Weather-resistant sensor unit uses sound pulses to measure material height at the auger. Material delivery is regulated to maintain a uniform material head. (Figure 2 - 17)

## Operator's Console

## Operator's Console

The operator's console can be positioned so that the paver can be operated from the left or right seat. To reposition the operator's console:




Figure 2 - 18 Repositioning operator's console

- 1) Lift the locking handle to release the console. (Figure 2 - 18)
- 2) Pull the operator's console toward the center of the paver. When the console is positioned vertically the centering lock will automatically engage.

**Important** - When raising the hood, the operator's console must be locked in the center position to prevent the hood from hitting console.

- 3) Step on the centering lock to release the console and position the console to the desired side of the paver.

Refer to (Figure 2 - 19) and (Figure 2 - 20) for instructions on operating the CR351 console and (Figure 2 - 21) and (Figure 2 - 22) for instructions on operating the CR361 console.

Operator's Console




Figure 2 - 19 CR351 Driver's Console - Units Prior to Sept. 1999

- |                             |                            |                          |
|-----------------------------|----------------------------|--------------------------|
| 1) Oil Temperature Gauge    | 13) Lights                 | 25) Oil Pressure Gauge   |
| 2) Voltmeter                | 14) Flashers               | 26) Brake                |
| 3) Mix Flow Indicators      | 15) Permissive Start       | 27) Engine Coolant Temp. |
| 4) Hopper                   | 16) Travel Speed Range     | 28) Throttle             |
| 5) Truck Hitch              | 17) Screed Extensions      | 29) Horn                 |
| 6) Gates                    | 18) Frame Raise            | 30) Steer Assist         |
| 7) Conveyor Speed           | 19) Engine Start Switch    | 31) Travel Lever         |
| 8) Conveyor                 | 20) Vibrators              | 32) Paver Speed Dial     |
| 9) Fuel Level Gauge         | 21) Screed Lift            |                          |
| 10) Low Engine Oil Pressure | 22) Screed Assist          |                          |
| 11) Hour/Tachometer         | 23) Rear Frame Compensator |                          |
| 12) Audible Alarm Silence   | 24) Differential Lock      |                          |

Operator's Console




Figure 2 - 20 CR351 Driver's Console - Units After Sept. 1999

- |                             |                         |                          |
|-----------------------------|-------------------------|--------------------------|
| 1) Oil Temperature Gauge    | 13) Lights              | 25) Oil Pressure Gauge   |
| 2) Voltmeter                | 14) Flashers            | 26) Brake                |
| 3) Mix Flow Indicators      | 15) Permissive Start    | 27) Engine Coolant Temp. |
| 4) Hopper                   | 16) Travel Speed Range  | 28) Throttle             |
| 5) Truck Hitch              | 17) Screed Extensions   | 29) Horn                 |
| 6) Gates                    | 18) Frame Raise         | 30) Steer Assist         |
| 7) N/A                      | 19) Engine Start Switch | 31) Travel Lever         |
| 8) Conveyor                 | 20) Vibrators           | 32) Paver Speed Dial     |
| 9) Fuel Level Gauge         | 21) Screed Lift         |                          |
| 10) Low Engine Oil Pressure | 22) Screed Assist       |                          |
| 11) Hour/Tachometer         | 23) N/A                 |                          |
| 12) Audible Alarm Silence   | 24) Differential Lock   |                          |

Operator's Console




Figure 2 - 21 CR361 Driver's Console - Units Prior to Sept. 1999

- |                             |                            |                           |
|-----------------------------|----------------------------|---------------------------|
| 1) Oil Temperature Gauge    | 13) Lights                 | 25) Oil Pressure Gauge    |
| 2) Voltmeter                | 14) Flashers               | 26) Brake                 |
| 3) Mix Flow Indicators      | 15) Permissive Start       | 27) Engine Coolant Temp.  |
| 4) Hopper                   | 16) Travel Speed Range     | 28) Throttle              |
| 5) Truck Hitch              | 17) Screed Extensions      | 29) Horn                  |
| 6) Gates                    | 18) Frame Raise            | 30) CR351 Only            |
| 7) Conveyor Speed           | 19) Engine Start Switch    | 31) Travel Switch         |
| 8) Conveyor                 | 20) Vibrators              | 32) Paver Speed Dial      |
| 9) Fuel Level Gauge         | 21) Screed Lift            | 33) Counter Rotate Switch |
| 10) Low Engine Oil Pressure | 22) Screed Assist          |                           |
| 11) Hour/Tachometer         | 23) Rear Frame Compensator |                           |
| 12) Audible Alarm Silence   | 24) CR351 Only             |                           |

Operator's Console




Figure 2 - 22 CR361 Driver's Console - Units After Sept. 1999

- |                             |                         |                          |
|-----------------------------|-------------------------|--------------------------|
| 1) Oil Temperature Gauge    | 13) Lights              | 25) Oil Pressure Gauge   |
| 2) Voltmeter                | 14) Flashers            | 26) Brake                |
| 3) Mix Flow Indicators      | 15) Permissive Start    | 27) Engine Coolant Temp. |
| 4) Hopper                   | 16) Travel Speed Range  | 28) Throttle             |
| 5) Truck Hitch              | 17) Screed Extensions   | 29) Horn                 |
| 6) Gates                    | 18) Frame Raise         | 30) CR351 Only           |
| 7) N/A                      | 19) Engine Start Switch | 31) Travel Switch        |
| 8) Conveyor                 | 20) Vibrators           | 32) Paver Speed Dial     |
| 9) Fuel Level Gauge         | 21) Screed Lift         | 33) N/A                  |
| 10) Low Engine Oil Pressure | 22) Screed Assist       |                          |
| 11) Hour/Tachometer         | 23) N/A                 |                          |
| 12) Audible Alarm Silence   | 24) CR351 Only          |                          |



Operator's Console

- 1) **Oil Temperature Gauge** - Indicates temperature of hydraulic fluid. If fluid temperature exceeds 180° F stop paving and determine cause.
- 2) **Voltmeter** - Indicates battery and alternator condition. (Table 2 - 1)

Reading on Voltmeter	Engine not running or running at idle	Engine running at Full throttle
less than 10 V	Dead or disconnected battery	Dead or disconnected battery
10 V to 12 V	Low battery charge. Constant reading in this area may indicate problems with the charging system.	A voltmeter reading below 12 volts means that the current being drawn for lights, charging the battery, solenoids, etc. exceeds the output of the alternator. Check for a defective battery or a short in the wiring.
12 V to 13 V	Well charged battery in good condition.	When the engine is started the pointer may stay in this area temporarily but should gradually rise above 13 volts as alternator reaches normal output.
13 V to 15 V	Readings in this area while the engine is not running indicate defective voltmeter.	This is where the readings should be when the alternator and battery are in good condition and functioning properly.
Above 15 V	Readings in this area while the engine is not running indicate defective voltmeter.	When the pointer goes above 15 volts, the alternator is putting out too much voltage and should be checked. Continued operation of the engine in this range will damage the battery and solenoid valves.

Table 2 - 1 Voltmeter indications

- 3) **Mix Flow Indicators** - Sensors on the gates cause indicator lights on control panel to light when material is not contacting sensors. Each conveyor has a separate sensor and indicator.
- 4) **Hopper** - The hopper raise switch is spring-loaded to automatically return to the neutral position when released. It must be held in the "Raise" or "Lower" position to control the hopper wings.
- 5) **Truck Hook** - The optional truck hitch holds the truck in position at the front of the paver so little or no material is spilled after a truck is captured. The truck driver does not have to ride the brakes to stay firm against the paver.

The Truck Hook switch is spring-loaded to return to the neutral position when the switch is released. To engage the truck, hold the switch in "Engage" until the truck is in place, then let the switch return to neutral to hydraulically lock the truck. To unhitch, place the switch in the "Release" position.

The truck hook is equipped with an adjustable needle valve on the front bulkhead which controls the speed that the truck hook engages the trucks wheels. Rotate the needle valve clockwise to reduce the engage speed and counterclockwise to engage the truck hook quicker.

- 6) **Gates** - (Standard feeder only) The hopper gates regulate the depth of mix (also called head of material) carried to each auger. The spring-loaded switches must be held in “Raise” or “Lower” until the desired gate height is obtained. When released, the switch returns to neutral.
- 7) **Conveyor Speed** - (Standard feeder only) When the Conveyor Switch is in “Man” mode, the Conveyor Speed dials allow the operator to independently control the speed of the feed conveyors. If your paver is equipped with the optional sonic feed control, the dials are located on the screed mounted control box.
- 8) **Conveyor** - This is a 3-position switch (“Man”, “Off”, “Auto”). If the conveyor switch is set to “Man”, the feeder speed can be varied by rotating the conveyor speed dials mounted on the driver's console or the pile height dial on the feed controller  
  
When the conveyor switch is in the “Auto” position, electronic sensors regulate the material feed system to keep a consistent head of material supplied to the front of the screed.
- 9) **Fuel Level Gauge**
- 10) **Low Engine Oil Pressure Indicator** - This indicator will light when the engine oil pressure falls below 5 PSI. When the engine is first started and the permissive start switch is held on, this indicator will remain lit until the engine oil pressure rises above 5 PSI. Once this indicator goes out the permissive start switch can be released.
- 11) **Hour / Tachometer** - Indicates engine RPM's and operating hours. Full throttle engine speed = 2100 RPM, Idle speed = 950 RPM.

---

## Operator's Console

- 12) **Audible Alarm Silence** - When the Mix Flow Indicators light, an audible alarm will sound to make the operator aware of the problem. When this switch is activated the alarm is silenced. The audible alarm is reset each time the mix flow sensors are reactivated.
- 13) **Lights** - Push up to turn headlights On. Down to turn headlights Off. A rotary switch on each work light changes light from red, white, and off.
- 14) **Flasher** - Push up to turn flashers “On”, down to turn flashers “Off”. On 400 series pavers this switch also turns on the strobe warning light mounted in the rear center of the paver.
- 15) **Permissive Start Switch** - When starting the engine, this switch must be held down until the engine starts and the engine oil pressure rises over 5 PSI and the Engine indicator goes out. If this switch is release before the engine oil pressure reaches 5PSI, the engine will stop.
- 16) **Range** - The range switch on CR361s prior to Sept. 1999 has two positions; “Travel” and “Pave”. The switch on units after Sept. 1999 has three positions; “Travel”, “Pave”, & “Maneuver”.

The CR351 has a three-position switch. Select the “Travel” position for roading or travelling around the job site. Select the “P/2” position for paving in 2-wheel drive. The paver must be stopped before changing from “Travel” to “Pave” or “Pave” to “Travel”



**Warning:** Failure to stop the paver before changing from “Travel” to “Pave” or “Pave” to “Travel” could result in serious injury to anyone riding the paver.

---

## Operator's Console

If the paver is equipped with the optional front wheel assist, switching to the “P/4” position will drive two of the front wheels in addition to the rear wheels. If the paver is not equipped with the optional front wheel assist, switching to the “P/4” position will be the same as switching to the “P/2” position. Engaging the optional front wheel assist will reduce the paver speed by 30%. Stop the paver before switching from “P/2” to “P/4” or from “P/4” to “P/2”.

17) **Screed Extensions** - Used on Stretch model screeds to extend or retract the extensions. On Fastach screeds this switch is used to extend or retract the optional hydraulic sloping strike-off extension.

18) **Frame Raise** - Push up to “Raise” the rear of the paver, down to lower the rear of the paver.

This switch allows the operator to elevate the rear of the tractor to give maximum ground clearance for loading the paver or traveling over rough ground or obstacles. For additional traction during paving, set the clearance at about the halfway point.

When using a heavy screed with extensions or other heavy accessories, it may be necessary to lower the screed to the ground before engaging the Frame Raise system.

19) **Engine** - The engine will start only if the brakes are engaged, the travel lever/switch is in neutral, permissive start switch is engaged, and the Master Key is “On”.

20) **Vibrators** - The vibrator switch will function only when the travel lever/switch is forward. Push up to turn vibrators “On”, down to turn vibrators “Off”.

21) **Screed Lift** - Push up to “Raise” the screed, down to “Lower” the screed, or center for “Neutral”. After the screed is raised to the desired height and the switch is released, it returns to the hold position. The screed is hydraulically locked at that height. While paving, the switch must be set in the “Lower” float position.

22) **Screed Assist** - Pavers equipped with power extending screeds (Fastach II, Stretch 16, Stretch 18, Stretch 20) have a Screed Assist system that allows adjustment of the screed bearing pressure on the mat. Once turned on, the screed assist should be left on. Do not switch the screed assist on and off while the paver is in motion. The screed assist should only be turned on when the screed is resting on the ground and should be turned off prior to raising the screed.



**Warning:** If screed is lowered when the screed assist switch is in the ON position, the screed will drop suddenly. This could cause serious damage to the screed and possibly injure personnel working around the screed.

23) **Rear Frame Compensator** - Units prior to Sept. 1999 only. This feature can be turned on to increase paver traction due to small changes in the road surface conditions. The compensator should only be used when traction slippage occurs.

- 24) **Differential Lock** - CR351 only. In wet or slick conditions one wheel may lose traction and begin to spin. By activating the differential lock switch, both rear wheels will rotate at the same speed regardless of how much traction each wheel has.
- 25) **Engine Oil Pressure Gauge** - Indicates engine oil pressure. Minimum oil pressure = 5 psi. Engine will shut down if engine oil pressure falls below 5 psi and the permissive start switch is not engaged.
- 26) **Brake** - The brake switch engages and releases the brakes. Brakes will not release until sufficient system pressure is built up and the switch is set to the “Release” position. Do not use for routine braking. Use only for parking and emergency stops.
- 27) **Engine Coolant Temperature Gauge** - Indicates engine coolant temperature. Normal operating temperature = 205° F. Engine will shut down if engine coolant temperature exceeds 223° F.
- 28) **Throttle** - The engine has only two speeds. Use “Idle” to start and warm up the engine, hydraulic oil, and screed. Use “Full” position for all other functions. Switch to “Full” only after engine and hydraulic oil have warmed up.
- 29) **Horn** - Push up to sound the horn. When the switch is released, it will return to the “Off” position.
- 30) **Steer Assist** - CR351 only. The steer assist switch is spring loaded to return to center. When the switch is activated to one side or the other, the system slows the inside rear drive motor while continuing to drive the other

---

### Operator's Console

motor at regular speed. This has the effect of abruptly steering the paver in the direction the switch is pushed.

- 31) **Travel Lever/switch** - Moving the travel lever/switch forward or back moves the paver in the desired direction. Paving speed is reached as the lever is moved to full forward or reverse - (CR351 & CR361 w/o steering wheel). This provides a smooth start and eliminates sudden shocks to the hydraulic system.
- 32) **Max Paver Speed** - This dial is used to govern the maximum travel speed of the paver. The travel lever provides variable speed up to the setting on the speed dial.

Maximum speed for the wheeled paver is about 150 feet/minute paving speed (46 meters/minute) and about 12 miles/hour travel speed (20 km/hour).

The steel & rubber track pavers have a maximum paving speed in excess of 150 feet/minute and a maximum travel speed of about 5 miles/hour (9 km/hour) for steel track. The rubber track paver maximum travel speed is about 9 miles/hour (15 km/hour). A setting of five will be about half maximum speed.

With the Max Paver Speed dial at zero and travel lever/switch forward, the paver should not move. This is used to test the auxiliary systems.

- 33) **Counter Rotate Switch** - CR361 units prior to Sept. 1999 only. When this switch is in the counter rotate position, one of the tracks will move in the forward direction and the other will move in the reverse direction. This feature allows the paver to turn at zero turn radius. This switch does not function while the Travel Speed Range switch is in the “Travel” position.

## Section 3 - Periodic Maintenance

### Raising & Lowering the hood

The hood on the Grayhound Paver must be raised to gain access to the engine for daily maintenance. The hood is raised using a hydraulic cylinder which is activated by a lever just under the hood on the right side of the machine in front of the rear wheel or drive sprocket. (Figure 3 - 1)




Figure 3 - 1 Hood Control

To raise the hood:

- 1) Position and lock the operator's console in the center position.
- 2) Turn on the master key switch before activating the hood control. Once the hood raising cylinder is fully extended, the hood safety lever will engage automatically.



**Warning:** Keep all personnel out from under the hood until the hood safety latch is engaged. Failure to follow these instructions could result in death or serious injury.

### Raising & Lowering the hood

- 3) Verify that the hood safety latch is engaged.
- 4) Lower hood onto the safety latch and relieve pressure from the hydraulic cylinder.

If the paver's batteries become discharged, jumper cables must be attached to the solenoid next to the hood raising lever and to the paver frame. (Figure 3 - 2) This will allow the hood raising lever to function in the usual manner.




Figure 3 - 2 Connecting Jumper Cables

To lower the hood:



**Warning:** Keep all personnel out from under the hood while lowering. Failure to follow these instructions could result in death or serious injury.

- 1) Raise hood slightly and disengage hood safety latch.
- 2) Carefully lower hood and relieve pressure from the hydraulic cylinder. (Figure 3 - 2)

## Before Starting Engine

### Before Starting Engine

Before starting the engine, the operator should check the following details personally.

- Verify that all decals are properly adhered to the machine, undamaged, and legible.
- Be sure all safety items (decals, guards, walkways, fire extinguisher, etc.) are in place and properly installed.
- Engine Oil Level should be at the “Full” mark on the dip stick. If engine oil is low, add oil to bring the level up to the “Full” mark. Refer to the engine manual for the correct oil type.
- Coolant Level inside the radiator should be just above the baffle. If not add the correct mixture of antifreeze and water. Do not over fill as excesses will be blown out the over flow. Refer to the engine manual to find the correct antifreeze and water mixture to use for the temperatures found in your working area.
- Hydraulic Oil Level must be checked while the hydraulic oil is cold and the machine is sitting level. If the hydraulic oil level is low, add the correct amounts of make up oil to bring the level to the COLD level on the sight glass.

**Notice:** Over filling the hydraulic tank does not leave enough room in the hydraulic system for thermal expansion when the oil is at running temperature. Excess oil will be blown out the breathers which could cause external radiator clogging.

**Notice:** Do not mix different types of oil. This could lead to unexpected failures.

- Engine Fuel Tank Level should be checked to ensure you have enough fuel to operate the paver for the desired amount of time.

Perform a visual inspection of the complete paver including engine compartment, for any signs of damage or leaks. Do not start the paver until all damage and leaks are repaired.



Maintenance Checklist

**Maintenance Checklist**

Ref.	Item to be checked	8 hrs	40 hrs	250 hrs	500 hrs	1000 hrs	Yearly	As Needed
1	Fuel level	I						F
2	Fuel Filter / Water Separator	D			R			
3	Travel Lever Alignment		I					A
4	Hydraulic Fluid	I/F			R*	R		
5	Oil Cooler	I						C
6	Suction Filters				R			
7	Aux. Pump Supercharge Filter		I		R			
8	Hydraulic lines and components	I						
9	Air Restriction Indicator	I						
10	Air Filter							C/R
11	Engine Oil	I/F		R				
12	Engine Oil Filter			R				
13	Engine Coolant	I/F					R	
14	Fan Belt		I					A
15	Radiator	I						C
16	Engine Cooling Fan	I						
17	Battery		I/F					
18	Tire Pressure		I/F					
19	Frame Raise Eccentric				L			
20	Steel Track Tension		I					A
21	Rubber Track Tension		I					
22	Track Pivot		L					
23	Fire Extinguisher			I				
24	Horn	I						
25	Pump Drive Belts		I					A
26	Depth Cranks			L				
27	Vibrator Bearings	L						
28	Crown Control			L				
29	Match Height Assembly		L					
30	Extension Slope Assembly		L					
31	Final Drive Oil		I/F*			R		
32	Steering Bogie Alignment							I/A

**Key:** I - Inspect                      C - Clean                      R - Replace                      A - Adjust  
 D - Drain                              L - Lubricate                      F - Fill                              \* - Initial change only

Table 3 - 1 Maintenance checklist



Maintenance Checklist

Ref.	Item to be checked	8 hrs	40 hrs	250 hrs	500 hrs	1000 hrs	Yearly	As Needed
33	Steering Linkage			L			I/A	
34	Bogie Beam Bearings			L				
35	Front Wheel Bearings						L	
36	Bogie Wheel Toe In						I/A	
37	Conveyor Slat Chains	I/L	I/A					
38	Conveyor Bearings	L						
39	Auger Bearings	L						
40	Feeder Drive Chain		I					A
41	Conveyor Drive		I					
42	Hood Raise Reservoir			I				
43	Operator Console Pivot Bearings			L				
44	Tow Arm Nose Roller	L						
45	Slope Beam Rod Ends			L				
46	Truck Hitch	C/L						
47	Fume Recovery System	I					I	C

Key: I - Inspect                      C - Clean                      R - Replace                      A - Adjust  
 D - Drain                              L - Lubricate                      F - Fill                              \* - Initial change only

Table 3 - 1 Maintenance checklist (Continued)

Periodic Maintenance

**Periodic Maintenance**

**1) Fuel Level**



**Warning:** Keep away from sparks or open flame while working with fuel.

Check fuel level before each work period to ensure you have enough fuel to operate for the desired period of time. Refer to the engine manufacturers manual to determine what grade of fuel to use for your operating temperature and conditions.

**2) Fuel/Water Separator**



**Warning:** Keep away from sparks or open flame while working with fuel.

**Daily Maintenance**

Drain the water and sediment from the separator daily. (Figure 3 - 3)




Figure 3 - 3 Draining fuel/water separator

Shut off the engine. Use your hand to open the drain valve. Turn the valve counterclockwise approximately 1-1/2 to 2 turns until liquid starts draining slowly. Drain the filter sump of water until clean fuel is visible.

Turn the valve clockwise to close the drain.

**Notice:** Do not over tighten the valve. Over tightening can damage the threads.

**Filter Replacement**

Replace the fuel filter/water separator every 500 hour of operation. Some operating conditions may require replacement at shorter intervals for proper engine operation.

To replace the fuel filters:

- 1) Clean the area around the filter head.
- 2) Remove the filters.
- 3) Clean the gasket surface of the filter head.
- 4) Replace the O-ring.
- 5) Fill new filters with clean fuel and lubricate the O-ring seal with clean lubricating oil.
- 6) Install filters and tighten.

**Notice:** Overtightening may distort the treads or damage the filter element.

### 3) Travel Lever Alignment





Figure 3 - 4 Travel lever alignment

CR351 and older CR361 Grayhound pavers use a travel lever to control travel speed and direction. During normal operation of older CR361 pavers, when the paver is travelling in a straight line over a flat, level surface, both travel levers should be advanced an equal amount. The travel levers need to be brought back into alignment when one travel lever is advanced more than 1/2 of the width of a travel lever more than the other lever. (Figure 3 - 4) Refer to the Technical manual for travel lever adjustment procedures.

When travelling on a grade, on uneven terrain, or when connected to a truck or pickup machine, one travel lever may need to be advanced considerably farther than the other to maintain straight travel. Also, as the speed dial setting is varied, the travel lever position may need to be adjusted to keep the paver traveling in a straight line. In each of these cases the travel levers will need to be adjusted only if one of the travel levers is advanced to the stop before straight travel is achieved. If travel levers

are consistently out of alignment in one direction or the other the travel levers should be adjusted to bring them back into alignment.

### 4) Hydraulic Fluid



**Warning:** Turn off engine & remove key before performing any inspections or maintenance.

Hydraulic oil level must be checked while the hydraulic oil is cold and the machine is sitting level. If the hydraulic oil level is low, add the correct amounts of make up oil to bring the level to the COLD level on the sight glass.

**Notice:** Over filling the hydraulic tank does not leave enough room in the hydraulic system for thermal expansion when the oil is at running temperature. Excess oil will be blown out the breathers which could cause external radiator clogging.


**Notice:** Do not mix different types of oil. This could lead to unexpected failures.

The hydraulic fluid should be drained and replaced with new fluid every 1000 hours of operation. The hydraulic fluid in a new paver or a paver that has just had a new hydraulic pump or motor installed should be replaced after the first 500 hours of operation.

Cedarapids recommends use of a premium anti-wear, ISO Grade 68 hydraulic oil in all Grayhound Pavers. Grayhound Pavers ship from the factory with Texaco Rando HD 68 hydraulic oil. Other approved hydraulic oils in this class are: Amoco AW68; Exxon NUTO H68; Mobil DTE26; Shell Tellus 68; Chevron AW 68.

Periodic Maintenance

5) Oil Cooler



**Warning:** Turn off engine & remove key before performing any inspections or maintenance.

The oil cooler should be checked daily for dirt and other buildup that would restrict the air flow. The paving conditions will determine how often the oil cooler requires cleaning. If severe conditions exist or there are a lot of air-borne contaminants the oil cooler will require more attention. Any fluid leaking from any engine compartment component, hose or tube will find its way into the oil cooler.

If your paver is equipped with the oil cooler mounted in front of the radiator, check between the radiator and oil cooler for buildup. It is recommended that the oil cooler be separated from the radiator to thoroughly clean the radiator and oil cooler.

If your paver is equipped with a remote oil cooler, remove any dirt or debris that will restrict air flow through the oil cooler. Spray water from a garden hose from the bottom side of the oil cooler to the top to remove any dirt or grit that may have settled between the oil cooler fins.

Check for damaged hoses and loose or damaged hose clamps. Replace as required. Check the oil cooler for leaks and the core for damaged or bent fins. Clean and repair as required.

6) Suction Filters

The suction filters should be removed and replaced every 500 hours of operation. To replace filters:

- 1) Clean the cover and top of reservoir to prevent dirt from falling into the hydraulic reservoir.

- 2) Remove screws and lift the cover from the reservoir to gain access to the filters. (Figure 3 - 5)
- 3) Lift off springs and cups from the top of filters and then remove filters from reservoir.
- 4) Install new filters into reservoir.
- 5) Check the condition of cover gasket . If gasket is damaged, install a new one.

**Notice:** Severe pump damage will occur if the strainer cover is not sealed properly. Air will be drawn into the system causing pump cavitation.

- 6) Install cups and springs onto the top of filters.
- 7) Install the cover using Loctite “Ultra-Blue” sealant (P/N 45995-001-30).
- 8) Pressurize reservoir to 10 psi air pressure and check suction lines for leaks. Loosen fittings while under pressure to purge lines.




Figure 3 - 5 Suction Filters

Periodic Maintenance

**7) Auxiliary Pump Supercharge Filter**

The 300 Series Grayhound paver has a spin-on filter that filters oil returning from the vibrator system before directing it to the auxiliary pump or, if the auxiliary pump does not require oil, back to the reservoir. This filter is commonly referred to as the “supercharge filter”. The filter is equipped with an indicator that operates in the green zone when the filter is in good condition and operates in the red zone when the filter is dirty. The indicator should be checked every 40 hours with the engine at full throttle. Do not wait for the indicator to move into the red zone before replacing the filter. The filter should be replaced every 500 hours or when the indicator is operating in the red zone, which ever comes first. (Figure 3 - 6)





Figure 3 - 6 Supercharge Filter

**8) Hydraulic lines and components**

Check all hoses, tubes, and components for leaks, damage, or loose fittings. Check the ground for signs of fluid leakage. Spots of oil soaked dust may

indicate a slow leaking hydraulic component. These leaks should be identified and fixed before operating the equipment.

**9) Air Restriction Indicator**



**Warning:** Turn off engine & remove key before performing any inspections or maintenance.

The engine air cleaner is equipped with an indicator that trips red when it needs service. The indicator should be checked daily to ensure proper servicing. (Figure 3 - 7)




Figure 3 - 7 Air Restriction Indicator

Service the filter elements when the red indicator flag is visible in the window.

After the elements have been serviced, push the button to reset the service indicator.

**10) Air Filter**

**Notice:** Never operate a paver without an air cleaner. Intake air must be filtered to prevent dirt and debris from entering the engine and causing serious and expensive damage.

Periodic Maintenance

Running the paver with an air cleaner that needs replacement does not allow the engine to get the proper amount of air to burn the fuel properly, which reduces engine horsepower and fuel efficiency. (Figure 3 - 8)





Figure 3 - 8 Engine Air Filters

When servicing an air cleaner take precautions not to allow any of the dirt or contamination that would happen to fall off the old element to remain in the filter housing or pass into the air inlet of the engine. Dirt and contamination are one of the biggest reasons for engine wear. Improper cleaning of old air cleaner elements can damage the element and allow dirt and contamination to pass directly into an engine.

Cedarapids does not recommend that air filter elements be cleaned in any way. When the air restriction indicator is operating in the red area the primary element must be replaced. The safety element must be replaced after three primary element changes.

**Notice:** Do not beat, shake, or use high pressure compressed air to remove dirt from an element. These methods can make small cuts in the element material which will allow dirt to enter the engine causing serious and expensive damage to the engine.

**Engine Air Inlet Connections**



**Warning:** Turn off engine & remove key before performing any inspections or maintenance.

Inspect the inlet piping for cracked hoses, loose clamps, or punctures that can allow dirt and debris to enter the engine. Tighten or replace parts as necessary to make sure the air inlet system does not leak. (Figure 3 - 9)




Figure 3 - 9 Air Inlets

The air inlet system includes the piping from the air cleaner to the turbocharger and the piping from the turbo charger to the after cooler or inlet manifold depending on model.

## 11) Engine Oil

### Engine Oil Level




Figure 3 - 10 Checking Engine Oil Level

Never operate the engine with the oil level below the “L” (Low) mark or above the “H” (High) mark on the engine oil dipstick. Wait at least 5 minutes after shutting off the engine to check the oil. This allows time for the oil to drain to the oil pan. (Figure 3 - 10)

**Important:** The engine must be level when checking the oil level to be sure the measurement is correct.

### Changing Engine Oil

Engine oil and filter should be changed at least every 250 hours of operation. Shorter intervals may be required due to operational conditions. Severe conditions require more frequent maintenance.

**Important:** Drain the oil only when it is hot and the contaminants are in suspension.




Figure 3 - 11 Oil Contaminants in Suspension

Operate the engine until the water temperature reaches 60°C [140°F]. Shut the engine off. Remove the oil drain plug and **drain oil into a container** (Figure 3 - 11).



**Caution:** Hot oil can cause personal injury.

Protect the environment: handling and disposal of used engine oil can be subject to federal, state and local law regulation. Use authorized waste disposal facilities, including civic sites and garages providing authorized facilities for the receipt of used engine oil. If in doubt, contact your local authorities or the EPA for guidance as to proper handling of used engine oil.

Refer to the engine manuals for the recommended type and grade of oil to be used.

## 12) Engine Oil Filter

Engine oil and filter should be changed at least every 250 hours of operation. Shorter intervals may be required due to operational conditions. Severe conditions require more frequent maintenance.

Use the appropriate replacement filter for your engine. See your Cedarapids dealer to be sure you are getting the correct oil filter.

Refer to Engine Service and Maintenance manuals for recommended change interval and instructions.

### 13) Engine Coolant

The coolant level must be checked daily. (Figure 3 - 12)



**Warning:** Do not remove the radiator cap from a hot engine. Wait until the temperature is below 50°C [120°F] before removing the pressure cap. Failure to do so can result in personal injury from heated coolant spray or steam. Remove the filler cap slowly to relieve coolant system pressure.




Figure 3 - 12 Hot Coolant Hazard

**Notice:** Do not add cold coolant to a hot engine. Engine castings can be damaged. Allow the engine to cool to below 50°C [120°F] before adding coolant.




Figure 3 - 13 Adding Engine Coolant

Fill the cooling system with coolant to the bottom of the fill neck in the radiator with a 50/50 mixture of antifreeze and clean water. (Figure 3 - 13)





Figure 3 - 14 Do Not Overfill Radiator

**Important:** Do not overfill the radiator. Overfilling does not leave room for thermal expansion. Excess coolant will be forced out of the overflow. (Figure 3 - 14)


### 14) Engine Fan Belt



**Warning:** Turn off engine & remove key before performing any inspections or maintenance.

Periodic Maintenance

15) Radiator



**Warning:** Turn off engine & remove key before performing any inspections or maintenance.




Figure 3 - 15 Engine Drive Belt Damage

Visually inspect the drive belt. Check the belt for intersecting cracks. Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable. Replace the belt if it is frayed or has pieces of material missing. (Figure 3 - 15)

The exterior of the radiator should be checked daily for dirt and other buildup that would restrict the air flow. Paving conditions will determine how often the radiator requires cleaning. If severe conditions exist or there are a lot of air-borne contaminants the radiator will require more attention. Any fluid leaking from any engine compartment component, hose or tube will find its way into the radiator. When cleaning, check between the radiator and oil cooler for buildup. (Figure 3 - 17)




Figure 3 - 16 Checking Belt Tension

Measure the drive belt deflection at the longest span of the belt. (Figure 3 - 16)

**Maximum Deflection** for the Cummins 4BTA & 6BTA engines is 3/8 to 1/2 inch [9.5 to 12.7mm].




Figure 3 - 17 Radiator Damage


Check for damaged hoses and loose or damaged hose clamps. Replace as required. Check the radiator for leaks in the upper and lower radiator sections. Check the radiator core for damaged or bent fins. Clean and repair as required.

Periodic Maintenance

**16) Engine Cooling Fan**



**Warning:** Personal injury can result from a fan blade failure. Pulling or prying on the fan can damage the fan blade and cause fan failure.



**Warning:** Turn off engine & remove key before performing any inspections or maintenance unless specifically instructed to the contrary in this manual.




Figure 3 - 18 Fan Blade Damage

A visual inspection of the cooling fan is required daily. Check for cracks, loose rivets, and bent or loose blades. Check the fan to make sure it is securely mounted. Tighten the bolts if necessary. Replace any fan that is damaged.

**17) Battery**

The battery fluid level should be checked to ensure it is at the correct level.



**Warning:** Do Not allow open flames or sparks near batteries. Battery fumes are highly explosive.



**Warning:** Sulfuric acid in batteries is a poison and could cause severe burns. Avoid contact with skin, eyes, and clothes. When you work around batteries, protect eyes and face from battery fluid and explosion.

**Checking battery fluid levels**

The battery fluid level should be checked to ensure it is at the correct level. If necessary fill the battery with clean water to bring the fluid level up to the bottom of the neck of each battery cell. (Figure 3 - 19)




Figure 3 - 19 Battery fluid levels



**Warning:** Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**



**Caution:** When removing the battery cables, always remove the negative terminal first then the positive terminal. This will reduce the chance of sparking. Also, before performing any welding activity on the equipment, the cables should be removed.



Periodic Maintenance

The battery terminals should be checked for corrosion buildup and tightness of connection. If necessary remove the terminal cable and clean both the battery cable connector and the battery terminal. Reinstall the positive battery cable connector first then the negative and tighten securely. Loose or corroded connections are a prime source of starting problems and other electrical problems.

**Cleaning Batteries**

Make sure all the battery caps are on tight before cleaning the battery. Allowing dirt or baking soda solution into the battery will destroy the battery.

Batteries should be kept clean at all times. Wipe the outside of the battery with a cloth to remove dirt and grime.

Make sure the vent holes in the battery caps are kept open at all times to allow gas to escape from inside the battery.

To clean the battery cable and terminals, remove the battery cables and clean them with a wire brush. Soak the cables and wash the terminals in a solution of baking soda and water. Rinse the cables, battery, and battery compartment with clean water.

**Checking Specific Gravity**

Refer to the instructions included with your tester for specific instructions on how to use your tester.

Under normal temperature conditions, a fully charged battery will have a corrected specific gravity reading of 1.26. If the reading is below 1.2, the battery should be charged.

In very warm weather the full charged reading should be 1.225. In very cold weather the full charged reading should be 1.28.

If a battery becomes drained and has a specific gravity reading below 1.15, jump starting the engine will put a heavy load on the battery and the charging system which could damage the alternator. If the specific gravity reading is below 1.15, charge the battery before using it to start the engine.

**Storing Batteries**

If the paver will be stored for more than 30 days, remove the batter. Make sure the battery is full charged and store the battery in a cool place.

When the battery is stored outside of the paver or while the battery is being charged, never set the battery on a concrete or dirt floor. The battery should be placed on wooden blocks.

**18) Tire Pressure**

The tire pressure should be maintained according to Table 3 - 2 and be equal on each side.

	CR351	CR451	CR551
<b>Tire Pressure</b>	32 psi	32 psi	32 psi

Table 3 - 2 Tire Pressure

The drive tires can be filled with calcium chloride and water in accordance with Table 3 - 3, if necessary, for operational conditions. This capacity puts tires to 75% full.

	CR351	CR451	CR551
<b>Tire Size</b>	18.4 x 26	23.1 x 26	24.5 x 32
<b>Calcium</b>	246 lbs	386 lbs	445 lbs
<b>Water</b>	586 lbs	907 lbs	1060 lbs
<b>US Gallons</b>	70.3	108.7	127.02
<b>Total Weight</b>	823 lbs	1287 lbs	1505 lbs

Table 3 - 3 Tire fluid capacity

Apply Loctite 272 to threads of lug nuts. Torque lug nuts to 267 ft.-lbs.

19) Frame Raise System




Figure 3 - 20 Frame Raise Lubrication

The paver frame raise eccentric should be greased every 500 hours of operation. (Figure 3 - 20)

Some frame raise eccentric plain bearings were assembled with Dow Corning G-N Metal Assembly Paste (P/N 49999-222) and had pipe plugs installed instead of grease fittings.

If a plain bearing is disassembled, re-assemble with Dow Corning G-N Metal Assembly Paste (P/N 49999-222).

If any frame raise eccentric bearing has pipe plugs, remove them, install grease fittings and grease at the 500 hour interval.

### 20) Steel Track Tension

The track tension on Grayhound track pavers can be adjusted to provide the desired track tension. The track has an automatic recoil system that allows the tracks to recoil if a severe impact is encountered then return to previous adjustment point.

#### Checking steel track tension




Figure 3 - 21 Checking Steel Track Tension

Set the brake switch to ON, travel lever/switch to NEUTRAL and speed dial to MIN (0) before performing checks.

The track tension should be visually checked every day before and during paver operation. If the track looks like it may be getting loose, it can be checked by placing a board or straight edge on the track between the front idler and the first top roller. If the gap between the bottom of the board and the top edge of the track is greater than 3/4", the track tension must be adjusted. (Figure 3 - 21)

**Important:** Perform track tension checks and adjustments when the paver is at running temperature. Adjusting track tension when the paver is cold could lead to over-tensioning of the track.

The Grayhound track paver uses a tension cylinder mounted above the final drive that maintains a constant volume of pressurized oil to the track adjusting cylinders. When the track encounters an obstacle, the system is designed to allow the

tensioning idler to recoil rather than stretch or break the track. When the obstacle is cleared the system returns to the previous track tension adjustment.




Figure 3 - 22 Steel Track tension hydraulic circuit

The track tensioning cylinder consists of a cylinder with a rodless piston, a needle valve, and a counterbalance valve. (Figure 3 - 22) The piston keeps the oil from the idler tensioning cylinders separated from the main oil supply. When the track encounters an obstacle it forces oil from the idler cylinders into the bottom side of the tensioning cylinder. When the obstruction is cleared, pressurized oil from the traction charge pump forces the tensioning cylinder down which forces the idler cylinders to move back to the original position.

The needle valve is opened during track tensioning to bring the volume of oil on the bottom side of the tensioning cylinder back to the proper level. The needle valve is kept closed during operation. The counterbalance valve allows oil flow freely from to discharge to tank from the top side of the tension cylinder when the track encounters an obstacle.

Periodic Maintenance

**Steel Track over-pressurizing**

If the track adjusting system is over-pressurizing during operation the following procedure must be performed. It is a good idea to perform this check once each season to verify the tensioning cylinder is in good condition.

**Notice:** Do not run the paver while the system is over-pressurized. Running with an over-pressurized system could damage the track and sprockets.




Figure 3 - 23 Adjusting steel track tension

- 1) Disconnect the line from the “T” port on the track tension cylinder. Install a plug into the disconnected line. (Figure 3 - 23)
- 2) Attach a drain line to the “T” port and run the other end into a bucket.
- 3) Close the needle valve by rotating clockwise.
- 4) Start the engine and run at full throttle.
- 5) If the track was tensioned properly, no oil will flow into the bucket.

- 6) If only a small amount of oil drains into the bucket, the piston and counterbalance valve are working properly and the track will be properly tensioned.
- 7) If oil continues to flow into the bucket, the piston or counterbalance valve is leaking and must be repaired.
- 8) Turn the engine off and reconnect the hydraulic line to the “T” port.

**Tightening Steel Track**

- 1) Start the engine.
- 2) Drive the paver forward very slowly.



**Warning:** Be very careful when reaching over the moving track. Keep feet and loose clothing away from the moving track and rollers.

- 3) Open the needle valve slowly to allow the track to retension. (Figure 3 - 23)
- 4) Close needle valve.
- 5) Stop paver.

**Steel Track Relief Pressure**

In addition to adjusting the track tension, the track relief pressure should be checked at least once each season. Refer to the Paver Technical Manual for information on checking track relief pressure.

### 21) Rubber Track Tension

The tracks on Grayhound rubber track pavers (Figure 3 - 24) do not require periodic adjustment. They are self-adjusted by applying a pre-set hydraulic pressure supplied by the auxiliary pump to the tensioning cylinders. The tracks have an automatic system that allows them to recoil and return to tension if a severe impact is encountered. If tracks appear loose, troubleshoot the track hydraulic system (see Section 5).




Figure 3 - 24 Rubber Track

### 22) Track Pivot




Figure 3 - 25 Track Pivot

The track pivot should be lubricated every 40 hours of operation. (Figure 3 - 25) The rear pivot has a grease fitting and the front pivot should be lubed with heavy grade oil.




Figure 3 - 26 Belt Tension Tester


### 23) Fire Extinguisher

The fire extinguisher should be inspected every 250 hours to ensure the extinguisher is fully charged and has not been damaged.

### 24) Horn

It is essential that the horn is maintained in working order at all times for safety reasons. Before starting the engine each day the horn should be sounded to ensure it is in working order.

### 25) Pump Drive Belts



**Warning:** Turn off engine & remove key before performing any inspections or maintenance.

**Notice -** Do not overtighten belts. Overtightening belts can cause premature belt and/or bearing failure.

**Notice -** Make sure the belt tension gauge is used correctly. Pushing the wrong end of the tester onto the belt will give an incorrect belt tension reading. (Figure 3 - 26)

### Tension Checking Procedure

- 1) Raise Hood
- 2) Loosen belt access covers.
- 3) Position the bottom of the large O-ring on the tester at the deflection indicated in Table 3 - 4. Set the small O-ring on the tester to zero.
- 4) Locate the midpoint on the belt and place the belt end of the tester onto the belt.

**Notice** -The tension tester must be inserted perpendicular to the belt to accurately measure belt tension.

- 5) Place the tester on the belt perpendicular to the belt. Mark the tester at the point where the tester meets the top of the access cover. It may be necessary to place a straightedge over the belt access hole to accurately mark this position.
- 6) Set the large O-ring 1/4" (6.4 mm) above the mark. (Figure 3 - 30)
- 7) Push on the yellow tipped plunger until the bottom of the large O-ring is level with the straightedge.
- 8) Remove the tester and read the belt deflection force in pounds at the small O-ring. Compare this with the value in (Table 3 - 4). If the force is outside the listed limits the belt should be retensioned. (Figure 3 - 27)



Figure 3 - 27 Tester Used Correctly

### Poly Chain Belts

Poly chain belts are designed to provide years of reliable service without stretching. As a result, adjusting the belt tension is **rarely required**. Do not adjust the poly chain belts unless they test below the Minimum setting found in Table 3 - 4.

Tension values for poly chain belts are temperature-sensitive. When installing belts, either new or used, adjust the belts for an 8 to 10 lb setting at 1/4 in deflection when the belts are cold. After the machine is at normal operating temperature (minimum of 2 hours of continuous paving operation), use the values listed in Table 3 - 4.

Periodic Maintenance

Poly Chain Belts			
		Force	Deflection
*At Operating Temperature	Min	18 lbs/8.2 kg	1/4" 6.4 mm
	Max	20 lbs/9.1 kg	
Cold Equipment	Min	8 lbs/ 3.6 kg	
	Max	10 lbs/4.5 kg	

Table 3 - 4 Poly chain belt tension settings

\* **Notice** - Check poly chain belt tension only after the **entire** machine is at operating temperature (minimum of two hours of continuous paving operation).

Do not adjust the belts until they test below the MINIMUM setting when the machine is at normal operating temperatures. Adjusting the belts to the values in Table 3 - 4 when the belts are cold will result in rapid belt failure and possibly damage to pump bearings. Adjust up to (but not exceeding) the MAX setting when the machine is at normal operating temperature.



Figure 3 - 28 Tester Used Correctly




Figure 3 - 29 Tester Used Incorrectly

All poly chain adjustments are to be made at 1/4 inch deflection.

The following illustrations demonstrate the correct and incorrect ways to use the belt tension tester.




Figure 3 - 30 Testing Poly Chain Belts

### 26) Depth Cranks

The screed depth crank assemblies have two lubrication points on each, one on the threaded link and the other on the screed depth crank bearing housing. These should be lubricated every 40 hours of operation. One to two pumps from a hand grease gun is all that is necessary.




Figure 3 - 31 Depth Crank Lubrication

### 27) Vibrator Bearings

The vibrator assemblies have four lubrication points, one on each vibrator bearing. The grease fittings are remote plumbed to the upper lip of the screed frames. They should be lubricated every 8 hours of operation. One to two pumps from a hand grease gun is all that is necessary. (Figure 3 - 32)




Figure 3 - 32 Vibrator Lubrication

### 28) Crown Control

The crown control has two lubrication points one on each turnbuckle assembly. They should be lubricated every 40 hours of operation. One to two pumps from a hand grease gun is all that is necessary. (Figure 3 - 33)




Figure 3 - 33 Crown Control Lubrication

Periodic Maintenance

**29) Match Height Assembly**

The match height assemblies have two lubrication points on each, one on the threaded link and the other on the match height bearing housing. These should be lubricated every 40 hours of operation. One to two pumps from a hand grease gun is all that is necessary.

**30) Extension Slope Assembly**

The extending screed slope assemblies have two lubrication points on each, one on the threaded link and the other on the slope shaft bearing housing. These should be lubricated every 40 hours of operation. One to two pumps from a hand grease gun is all that is necessary.

**31) Final Drive Oil**

The final drive planetary oil level should be checked during the first 40 hours of operation and replaced at 150 hours of operation. Drain, flush and refill every 1000 hours of normal operation.

To check the oil level, rotate the drive until the fill plug is straight up and the level check plug is 90 degrees down from the fill plug. Remove the level check plug. The oil level should be even with the bottom of the level check plug hole. If the oil level is low remove the fill plug and add oil to bring the level up to the bottom of the level check plug hole. (Figure 3 - 34)

**Note** - If oil level is above check plug, verify there is no hydraulic oil in the final drive housing before adding gear oil. Hydraulic oil in this housing indicates leakage from the brake or hydraulic drive motor. Correct this condition before adding gear oil.




Figure 3 - 34 Checking Final Drive Oil Level

Use 80W-90 Gear Oil when adding or replacing final drive oil. Typical brands: Amoco Multipurpose gear Lube 80W-90, Texaco Multipurpose Gear Lube 80W-90, Mobilube HD 80W-90, Exxon Gear Oil GX 80W-90, Shell Spirax HD 80W-90. An ISO Grade 220 EP equivalent gear oil can be substituted for those given above.

**32) Steering Bogie Alignment**

It is normal for the bogie wheel to get slightly out of alignment during normal operation. Driving with misaligned bogie wheels can make steering difficult and increase wear of the bogie tire. (Figure 3 - 35)




Figure 3 - 35 Bogie Wheel Alignment

Periodic Maintenance

If the bogie wheels are angled in or out the wheels will need to be realigned. Realigning the bogie wheels is accomplished without the use of any tools and can be performed any time the paver is parked.

To synchronize the steering bogies:

- 1) Stop the paver and run the engine at full throttle.
- 2) Turn the steering wheel to the left or right until a resistance is felt. Continue turning the steering wheel for 1 to 2 more revolutions.
- 3) Turn steering wheel back to the center position and continue paving.

**33) Steering Linkage**

Lubricate the steering linkage rod ends with a few drops of oil every 250 hours. (Figure 3 - 36)




Figure 3 - 36 Steering linkage lubrication

The steering linkage, rod ends, bushings, bearings and cylinders should be checked seasonally for adjustment and possible wear.

**34) Bogie Beam Bearings**

The bogie beam bearings should be lubricated every 250 hrs.

**35) Front Wheel Bearings**

The wheel and pivot bearings should be checked and repacked with Lithium base, type EP, Grade 2 grease yearly.

**36) Bogie Wheel Toe-in**

Wheel alignment and amount of tow-in should be adjusted as necessary. Normal amount of tow-in required is approximately 1/16 to 1/8 inch. (Figure 3 - 37)




Figure 3 - 37 Bogie Toe-in

**37) Conveyor Slat Chains**

The conveyor chain should be adjusted when 1 inch (25 mm) of sag is visible between the bottom of the paver frame and the top of the conveyor chain. Adjust the chains so the top of the chain is even with the bottom of the frame. (Figure 3 - 38)

Periodic Maintenance

**Notice:** Over tightening the chains increases wear on the conveyor chain, front idlers, drive sprockets and all bearings.





Figure 3 - 38 Conveyor Chain Tension



**Warning:** Turn off engine & remove key before performing the following inspections or maintenance.




Figure 3 - 39 Conveyor Chain Adjuster

To adjust the conveyor chains:

- 1) Release the locking rod between the dual adjuster. (Figure 3 - 39)

- 2) Using the locking rod or a wrench, rotate the left adjuster 1/2 turn.
- 3) Rotate the right adjuster 1/2 turn.
- 4) Repeat procedure of adjusting the left and then the right until the top of the conveyor chain is even with the bottom of the frame.
- 5) Install the locking rod after finished adjusting.

38) Conveyor Bearings




Figure 3 - 40 Rear Inner Conveyor Bearings




Figure 3 - 41 Front Conveyor Fittings




Figure 3 - 42 Rear Outer Conveyor Fittings

The four conveyor bearings on each conveyor should be lubricated every 8 hours of operation with Lithium base, type EP, Grade 2 grease. Two front conveyor bearing fittings on each side are near the bogie wheels or track idler. (Figure 3 - 41) The inner (Figure 3 - 40) and outer (Figure 3 - 42) rear conveyor bearing fittings are mounted on the front and back of the rear bulkhead.

### 39) Auger Bearings

The Auger bearings should be lubricated every 8 hours of operation with Lithium base, type EP, Grade 2 grease. (Figure 3 - 43)




Figure 3 - 43 Auger Bearings

### 40) Feeder Drive Chains

The feeder drive chains should be checked every 40 hours of operation. Check the drive chains for proper tension and wear. Clean the housing and lubricate the chains and spacer with fuel oil from the spray-down hose or with SAE 10 motor oil. A small amount of oil may be left in the housing for lubrication between checks even though the housing is not oil tight.

Periodic Maintenance





Figure 3 - 44 Adjusting feeder drive chain



**Warning:** Turn off engine & remove key before performing the following inspections or maintenance.

- 1) Remove the cap screws holding the feeder drive chain cover. Pull the cover back and off. (Figure 3 - 44)
- 2) Loosen the jam nuts on the feeder drive chain adjuster rods.
- 3) Using the adjuster rods, remove the slack from the chain, but do not over tighten. At the correct tension, the chain should move slightly under thumb pressure.
- 4) After both chains have been tensioned properly, tighten the jam nuts. Replace the cover.

#### 41) Conveyor Drive

The conveyor drive is a direct mounted hydraulic motor with a chain drive sprocket attached. (Figure 3 - 45)




Figure 3 - 45 Conveyor Drive

#### 42) Hood Raise Reservoir




Figure 3 - 46 Hood Raise Reservoir

The hood raise reservoir oil level should be checked periodically. Use AW 68 hydraulic oil in the hood raise reservoir. (Figure 3 - 46)

**43) Operator Console Pivot Bearings**




Figure 3 - 47 Operator Console Pivot Bearings

The operator console pivot should be lubricated every 250 hours of operation. (Figure 3 - 47)

**44) Tow Arm Nose Roller**




Figure 3 - 48 Tow Arm Nose Roller

The tow arm pull point roller should be lubricated every 8 hours of operation. (Figure 3 - 48)

**45) Slope Beam Rod Ends**




Figure 3 - 49 Slope Beam Rod Ends

The slope beam rod ends should be lubricated every 250 hours of operation. (Figure 3 - 49)

**46) Truck Hitch**

The truck hitch should be cleaned as part of the daily cleaning to remove any asphalt that has collected on the truck hook or rollers. Spray the truck hook and rollers with diesel fuel during spraydown.




Periodic Maintenance

**47) Fume Recovery System**

The fume recovery system vacuum indicator should be checked each day before beginning operation. With the engine running at full throttle, the vacuum indicator should register a reading. When the vacuum indicator reading is too low, components of the fume recovery system require maintenance. Refer to (Table 3 - 5) for troubleshooting information.

Problem	Cause	Remedy
Low vacuum reading	Low hydraulic pressure to fume recover fan motor. Damaged, collapsed or disconnected fume recovery hoses between fume recovery fan and muffler. Plugged or collapsed fume recovery hoses between fume recovery fan and muffler.	Refer to paver hydraulic schematic Repair, replace, or reconnect hoses Clean or replace fume recovery hoses.
High vacuum reading	Plugged fume recovery hoses between fume recovery fan and fume recovery hoods.	Clean or replace fume recovery hoses.
Visible fumes escaping from hoods	Fume recovery system not operating properly.	Ensure fume recovery system is completely installed. Check vacuum indicator system.

Table 3 - 5 Fume Recovery System Troubleshooting



- |                         |  |
|-------------------------|--|
| 1 - Vacuum Indicator    | 5 - Fixed Fume Recovery Hood Section       |
| 2 - Muffler             | 6 - Auger Access Hood Section              |
| 3 - Paver Rear Bulkhead | 7 - Proportional Feed Sensor Mounting Hole |
| 4 - Fan                 |  |

Figure 3 - 50 Fume Recover System Components

**Fume Recovery System Repair**

- 1) Check hoses and tubes for cracks, cuts, dents, or collapsed spots. Cuts or cracks may be repairable with duct tape. Repair or replace tubes as needed (Figure 3 - 50).
- 2) Check interior surfaces of hoses and tubes for asphalt buildup. Clean tubes and hoses by soaking in solvent and brushing clean. Hoses and tubes may be more economically replaced than cleaned.
- 3) Disassemble the fan for cleaning using the following procedure (Figure 3 - 51):

- a) Disconnect tubes from left and right hoods and to muffler.
- b) Disconnect hose to vacuum indicator.
- c) Remove four bolts retaining inlet manifold to fan assembly and remove inlet manifold.
- d) Lift off fan housing.
- e) Remove bolt and two washers retaining fan wheel to motor shaft.
- f) Remove fan plate by removing four bolts.

Periodic Maintenance

- 4) The parts removed in the previous step can all be cleaned by soaking in solvent and cleaning with a brush.
- 5) Reassemble fan in reverse order. When installing fan wheel, use Loctite 242 on the bolt and torque to 110 in-lb.

**Note** - Fan housing is sealed with RTV silicone.




Figure 3 - 51 Fume Recovery Fan Disassembly

At least once each year, the system should be thoroughly inspected to ensure proper operation.

- 6) With the engine warmed up, lower the screed and run the engine at full throttle.
- 7) Read the vacuum from the vacuum indicator mounted on the rear bulkhead. If the reading is low or has no reading, the fume recovery tubing may be dirty, plugged, collapsed, damaged, or disconnected.
- 8) Record the vacuum reading and any required maintenance in (Table 3 - 6).





---

Periodic Maintenance

Starting the Engine

**Section 4 - Operating the Tractor**

**Starting the Engine**

- 1) Make sure all personnel are clear of the paver and aware that the paver is going to be started.
- 2) Set the Master Key Switch to the ON position. The Master Key Switch on 300 series pavers can be found inside the compartment door on the left side of the machine. (Figure 4 - 1)




Figure 4 - 1 Master Key Switch Location

- 3) Set the console switches and controls as follows:

Left and Right Feed Conveyors	Off
Vibrators	Off
Screed Assist	Off
Range	Pave
Brake	Engage
Throttle	Idle
Counter Rotate	Normal
Rear Frame Compensator	Off
Paver Speed	"0" (Min.)
Travel Direction	"N" (neutral)

Table 4 - 1 Prestart switch settings

**Important** - The engine will not start if the console switches are not set as indicated in Table 4 - 1 .

- 1) Pull the permissive start switch down and the engine start/stop switch up. The paver should start. If the engine does not start after 30 seconds, release both switches and let the starter cool down before cranking the engine again.

Once the engine starts, release the engine start/stop switch but continue to hold the permissive start switch engaged. If the permissive start switch is released before the engine oil pressure reaches 5 lbs. the engine will stop immediately. This system is designed to protect the engine when the engine oil pressure drops below 5 lbs. or the engine temperature rises above 223 degrees F.

## Starting the Engine

**Important** - After the engine oil pressure is above 5 lbs. and the engine temperature is below 223 degrees F, the Engine light will go out and the permissive start switch can be released.

Once the engine is running, allow it to idle for at least 5 minutes to warm up before bringing the engine throttle to full throttle.

### Engine start-up after stall

Under certain conditions the engine could stall while under load. If the operator attempts to restart the engine immediately after it stalls, the engine will be trying to start under full load. This could overload and damage the starter.

If the engine stalls under load, allow 5 to 10 minutes for the hydraulic system pressures to “leak down” before trying to restart the engine.

### Jump starting/ charging batteries



**Warning:** Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**



**Warning:** Batteries give off explosive hydrogen gas when charging. Keep flame and sparks away from the battery while jump starting or charging.

**Notice:** Grayhound pavers use a 12 Volt electrical system. When jump starting or charging the paver, make sure to use a 12 Volt power source.

1) Raise the hood. Refer to the Raising the Hood section in this manual.

2) Connect the jumper cables to the power source.




Figure 4 - 2 Jumper Cable Connection Points



**Warning:** When jumper cables or a battery charger are connected or disconnected from a battery, a spark will be created when the first cable is disconnected or the last cable is connected. For this reason it is critical that the first cable disconnected and the last cable connected be the negative (-) cable and that this connection be made as far away from the battery as possible.

3) Connect the positive (+) cable to the positive (+) battery terminal or power terminal on the hood raise power pack motor.

4) Connect the negative (-) cable to the paver frame away from the battery. The negative (-) cable should always be connected away from the battery so that any sparks created by making the connection do not ignite the hydrogen gas that is produced by the battery.

5) As soon as the engine starts, remove the jumper cables.

Emergency towing

**Emergency towing**

If your paver becomes disabled and the engine can not be started it may be necessary to tow the paver. Grayhound Pavers have brakes that automatically engage anytime the engine is not running. Before towing a paver the brakes must be released and the travel pumps for each side put into bypass.



**Warning** - Read all of the towing instructions before starting this procedure.



**Warning** - Block or restrain the paver before releasing the brakes. Failure to block or restrain the paver could result in serious injury or death.



**Warning** - When towing the paver using the following procedure, the paver will not have drive, braking, or steering control. Do not travel down steep grades which could cause the paver to collide with the towing vehicle.

- 1) Turn bypass valve on each travel pump counterclockwise slowly 2 turns. (Figure 4 - 3)




Figure 4 - 3 Travel Pump Bypass Valve

- 2) Disconnect brake hoses from brake/range-shift solenoid valve located on right-hand rear of engine (Figure 4 - 4). Place caps on the valve fittings to keep dirt out of the hydraulic system.




Figure 4 - 4 Preparing to release brakes

- 3) Attach a porta-power to open hose ends and pump the pressure up to at least 350 psi to release the brakes (Figure 4 - 5). The brakes can be reapplied by releasing the pressure at the porta-power.




Figure 4 - 5 Releasing Brakes with Porta-power

Loading/Unloading

**Notice:** Maintain a minimum of 350 psi to fully release the brakes. Do not exceed 1500 psi.



**Warning** - Use a chain in good condition that is capable of pulling the paver.

- 4) Open the front conveyor bearing covers.
- 5) Run the chain through the holes shown. (Figure 4 - 6)




Figure 4 - 6 Attaching chain for towing

**Notice:** Attaching chains to the push roller frame or truck hook frame could result in serious and expensive damage.

- 6) Slowly apply tension to chains to start paver moving. Move the paver at a very slow walking pace.

**Notice:** Pulling the paver faster than 25 feet per minute can result in serious and expensive damage to the travel system.

- 7) When the paver is in desired location, release the pressure at the porta-power and reconnect the hoses to the brake valve.
- 8) Close the bypass valves on each travel pump by rotating clockwise until snug against seat. (Figure 4 - 3)
- 9) Tighten to 7 - 10 ft./lbs.

**Loading/Unloading**

**Driving the Paver off a Trailer**

The paver can be loaded or unloaded from various kinds of trailers. When loading or unloading a paver the clearance from the ground to the auger or screed becomes a concern. Some trailers will require construction of a ramp long enough so the augers or screed will not drag on the ground.

**Notice** - Always use the frame raise system to raise the rear of the paver as high as possible before loading or unloading the paver. The screed or augers could be damaged if they drag on the ground.

Grayhound pavers have a Frame Raise feature which allows the rear of the paver to be raised during loading and unloading. The paver should be raised as high as possible for maximum ground clearance during loading or unloading.




Figure 4 - 7 Sufficient ground clearance

## Loading/Unloading




Figure 4 - 8 Insufficient ground clearance

The screed should always be raised and the screed lock hooked when loading or unloading the paver. If the paver cannot be loaded or unloaded without the screed dragging the ground, the screed can be removed.

**Notice** - If the screed is removed, carefully watch the augers to make sure they do not drag on the ground during loading and unloading.

**Notice** - All constructed ramps must be capable of supporting the total machine weight.

**Notice** - Rubber Tracks can be damaged by sharp objects on the surface of ramps or trailer when loading and unloading.

To move the paver on or off a trailer:

- 1) Remove all chains and binders from the paver frame.
- 2) Start the engine.
- 3) Raise the screed and hook the screed lock.
- 4) Use the frame raise system to elevate the rear of the paver as much as possible.

- 5) Have a person on the ground to help guide you on or off the trailer.
- 6) Set the Pave/Travel switch to Pave (P2 on rubber tired models) and Speed Dial to 0.
- 7) Bring the engine to Full throttle.
- 8) Place the brake switch in the Release position.
- 9) Place the Travel Direction switch in the direction needed.
- 10) Slowly increase the setting on the speed dial until the paver starts moving. It is safer to use a slow speed while loading or unloading.

You can use the brake switch to engage the brakes in an emergency.



**Warning** - If the brakes are used to stop a moving paver, the paver will stop suddenly. The brakes should be used to stop the paver only in an emergency.

### Lifting with crane

Ensure the crane and cables to be used are capable of supporting the total machine weight safely.

Attach one cable to each of the two lifting points on the rear of the paver (Figure 4 - 10). Loop a chain through the lifting eyes at the front of the paver and attach it to the crane hook (Figure 4 - 9).

The two rear cables must be of equal length and the front cable/chain must be adjusted to two equal lengths.

Loading/Unloading




Figure 4 - 9 Front lift points




Figure 4 - 10 Rear lift points



**Warning** - Each lifting cable must be hooked to the crane hook independently. Do not loop a single lifting cable through the crane hook and back to a second lifting point.




Figure 4 - 11 Attach cables correctly

Raise the screed and lock it into position. Older Grayhound models have a cable attached to the tow arm that is hooked into the screed hooks on the rear of the tractor. (Figure 4 - 12)




Figure 4 - 12 Screed Cables

Newer units use an integrated screed lock that engages automatically when the screed is fully raised. Stepping on the screed release pedal allows the screed to be lowered. (Figure 4 - 13)




Figure 4 - 13 Screed Lock

The paver engine should not be running while the paver is being lifted by a crane.

### Preparation for transport

- 1) Load the paver onto the trailer or truck.
- 2) Lower the screed onto blocks at each end and in the center of the screed. Never set the screed on nails, rivets, or bolt which could damage the screed bottom.




Figure 4 - 14 Set screed on blocks

### Preparation for transport

- 3) Use the frame raise switch on the operators console to lower the rear of the paver as much as possible.
- 4) Use chains and chain binders to tie the paver down in the front (Figure 4 - 15) and rear (Figure 4 - 16) of the paver.

Chaining directly to the screed, truck hook, or tow arms could damage the equipment. All chains should be secured to the paver frame only.




Figure 4 - 15 Front tie down points




Figure 4 - 16 Rear tie down points

## Preparing to Pave

### Fume Recovery System




Figure 4 - 17 Fume recovery system

The fume recovery system is designed to collect fumes given off by hot mix asphalt and discharge them away from operator work areas. The auger access hood sections can be removed to gain access to the main spreading augers. Refer to (Figure 4 - 17). This may be necessary for cleaning the augers and to check the condition of the augers. The system is designed to meet minimum emission standards with or without the auger access hood sections installed. However, to operate at maximum effectiveness, the auger access hood sections should be installed during operation.

Automatic feed sensor mounting hole covers can be removed to install a proportional feed sensor. If a proportional sensor is not used, the mounting hole covers should be reinstalled.

The fume recovery fan starts automatically when the engine is started and continues to run while the engine runs. The vacuum indicator should be checked each day before starting paving. The indicator should register a vacuum reading with engine running at full throttle. A low or no reading indicates a malfunction in the system. Refer to Section 3 for system troubleshooting.

Preparing to Pave

**Nulling screed**

**Important** - the following information on setting up the screed is only a portion of the information available on the subject. The Quality Paving Guide should be read completely and be kept with the paver for reference on setting up the screed.

When we null a screed, we are adjusting the angle of attack on the screed to 0 in relation to a given or desired depth. This is traditionally done with the use of boards that equal the desired loose mat depth. Then a given amount of nose up attitude is introduced to the screed. The procedure is as follows:

- 1) The boards needed should be equal to the thickness of the loose or unrolled mat. The number needed will depend on the width the screed is set up to pave at. Generally 2 boards at 10' wide, 4 boards at 20' and est. The length of each board should be such that the screed bottom is fully supported from front to tail when set on the boards.




Figure 4 - 18 Nulling the Screed

- 2) Place the boards under the screed as illustrated. Attention should be placed on the grade conditions where the boards will be placed. If a board is placed on a high point or a depression, a false null setting will occur. Additional boards may be needed if you are paving at extended widths to provide support for the screed extensions. (Figure 4 - 18)
- 3) Place the screed lift switch in LOWER position. The screed will lower down and rest on the boards.
- 4) Turn both manual depth cranks on the screed until the screed face is resting flat on the boards. When the screed is resting flat on the boards the hand cranks will have a small area of free rotary movement where little resistance is felt. This indicates a null position.
- 5) After the screed has been nulled, we need to introduce a nose up attitude (initial angle of attack) on the screed. The amount of initial angle of attack is dependent on material design, temperature of material, head of material, tow point position and type of screed. Refer to these subjects for more information. Generally, the amount of initial angle of attack required will be 1 to 2 turns of clockwise rotation on the hand cranks. As paving begins, check the depth of the mat being placed and correct for as necessary. As most contractors work with a limited number of mix designs, the paver crews quickly learn the exact amount of initial angle of attack needed for specific mix designs.

Preparing to Pave

**Joints**

There are two types of joints that are constructed in a paving operation, Longitudinal and Transverse. Proper construction of these joints is important not only in producing a smooth rideable surface but also in how they resist penetration of water, air and other substances that would cause a premature failure of the joint. (Figure 4 - 19)




Figure 4 - 19 Types of Joints

**Transverse Joints**

Transverse joints are created when an existing mat or lane is to be continued. The quality and durability of the joint depends on careful preparation of the existing mat or lane. It is critical that any taper or defective area be removed.

**Important** - The joint area has to be perfectly flat and parallel with the line of paving. If it is not, a depression or bump will be produced.

**Joint Preparation**

The following illustration shows, how an existing mat is checked and the tapered area removed to produce a joint area that is flat and parallel with the line of paving. (Figure 4 - 20)




Figure 4 - 20 Joint Preparation

**Joint Construction**

The next step to proper joint construction is placing boards or lath that equal the amount of compaction in the joint area. Remember compaction rates change due to thickness of material & material design. Once the compaction rate has been determined and the correct thickness of lath has been acquired, place the lath at the edge of the joint to elevate & support the screed to the correct starting level.




Figure 4 - 21 Matching existing mat

The screed should be preheated to the temperature of the material being used. A cold screed will not only tear the surface of the mat being placed but will also have a tendency to come off the joint low,

Preparing to Pave

creating a depression in the mat. Do not over heat the screed bottom, as this will damage or warp the screed bottom.

Back the paver up over the joint and align the screed so the face or mold board is square with the edge of the joint. Lower the screed onto the boards or lath and null the screed. Perform Nulling screed procedure on page 9




Figure 4 - 22 Aligning screed over joint

Once the screed has been nulled and the initial angle of attack has been introduced, the auger chamber should be filled to no more than 1/2 an auger level. Do not over fill the auger chamber, as this is the most common cause of creating a bump just after pulling off a joint. If needed the corner areas on the ends of the screed should be hand filled to prevent force feeding an excessive high head of material in the center areas of the screed.

After filling the auger chamber to the correct level, move the paver forward slowly, allowing the screed operator time to check and correct the depth if necessary. The feeder controls should be set to auto, and feed sensors checked and set to maintain the correct head of material. Once the paver has moved away from the joint area, the joint can be checked and prepared for rolling. The excess or over lap material must be removed, as this material can not be compacted into a cold or existing mat. Do not shovel this over lap material back onto the

fresh mat as this extra material may not be compacted down to the same height as the rest of the joint. This could create a bump.




Figure 4 - 23 Removing overlap material before rolling

Once the over lap material has been removed, the joint should be checked with a good straight edge to ensure the thickness of the new mat is correct. If the new mat does not have enough material thickness at the joint when it is rolled, the density in the area where the new mat joins to the old mat will be low. This could cause a premature joint failure. If there is too much material in the joint area a bump will be produced.

Spray Down and Cleaning

**Spray Down and Cleaning**

**Paver Cleaning Procedure**

Cleaning the paver is extremely important to keep the slat chains and augers free and prevent build-up of asphalt. Clean the paver thoroughly each day or any time the paver will be stopped for an extended period of time.

**Notice:** Hot mix gets hard quickly. Do not allow mix to cool in the hopper. Run conveyors to remove all material from the hopper any time the paver will be stopped for an extended period of time.



**Warning:** Use only environmentally safe solvents to clean paver.



**Warning:** Do not spray solvent in the presence of open flame, sparks, welding arcs, etc. A serious fire or explosion could result.

**Notice:** Keep solvent spray away from all electrical components and engine compartment. Do not spray the paver when it is parked on the mat. Move it to the side of the road for drainage of solvent and dissolved mix. Avoid spraying rubber hoses and cables with solvent as this may cause premature deterioration.

- 1) Run the conveyors until all mix is out of the hopper. Remove any piles or large chunks of mix from the paver and screed.

- 2) Clean all parts which come in contact with hot mix. The paver must be completely cleaned even if the paver was used for a short time.
- 3) Start cleaning at the truck hook/push rollers and work your way to the rear of the machine cleaning the hopper wings, slat conveyors, hopper gates, augers, screed bottom, end gates, strike-offs, etc. (Figure 4 - 24)




Figure 4 - 24 Shaded areas to be sprayed down daily

- 4) Operate slat conveyors during spray down to be sure all slats and chain links are cleaned. After cleaning conveyor slats and chain, spray conveyors with a light oil to lubricate and protect the chains.
- 5) Remove fume recovery system auger access hoods. Spray down surfaces that have come in contact with asphalt. Refer to Section 3 for information on when and how to clean fume recovery system fan and/or tubes.

## Spray Down and Cleaning




Figure 4 - 25 Mechanical feed sensor

- 6) If a mechanical feed sensor is used, clean the wand with solvent and wipe any asphalt off of the feed controller with a cloth dampened with solvent. (Figure 4 - 25)
- 7) Every time the paver is cleaned, the track should be cleaned and sprayed with light oil to lubricate the track pins to prevent them from rusting and binding.
- 8) Clean the material flow sensors mounted on the bottom of the gates. Ensure sensors move freely.

### Generation III Sonic Sensor Cleaning

- 1) Inspect the sensor daily for damage and material buildup. The sensor must be kept clean in order for the sonic control to function properly. The sensor is easily cleaned and if cleaned routinely, problems can be minimized.
- 2) Before cleaning, turn off power to the sonic control. Disconnect sensor cable from control unit and remove sensor from its mount. Install protective caps on all electrical connectors.

**Notice:** Using a sharp or solid object to scrape material from transducer could damage the sensor. If the transducer becomes damaged it will require replacement of the complete sensor. The sensor is permanently sealed and can not be repaired.

- 3) Check transducer daily for material buildup. The transducer can be cleaned with Simple Green cleaning fluid. Place cleaning fluid on a clean rag and rub transducer gently to remove any material. Wipe transducer clean and dry (Figure 4 - 26).




Figure 4 - 26 Cleaning sonic sensor

### Pressure Cleaning

The entire paver can be pressure washed to remove dirt and grease. When pressure washing the paver:

- 1) Do not use a steam cleaner. Steam cleaning can damage seals, bearings, gearboxes, and electrical components.
- 2) Do not use an acid based solvent with the pressure washer. Use only mild detergents or degreasers.

## Spray Down and Cleaning

- 3) Do not spray directly at electrical components, seals, bearings, gearboxes, or hydraulic cylinder rods. Water can be forced into electrical connections or the hydraulic system which could damage the system.
- 4) Do not spray the screed or engine until it is cool. Spraying a hot screed bottom with cold water could warp the screed bottom. Spraying cold water on a hot engine manifold could crack the manifold.
- 5) Use extreme caution when spraying in the engine compartment. The engine compartment is full of electrical and hydraulic components which could be damaged by high pressure water. Use a commercial engine cleaning foam to remove dirt and grease from the engine compartment.
- 6) If you must spray near electrical or hydraulic components, cover the components before spraying.

General Description

**Section 5 - Hydraulic System Repair**


**General Description**

There are six separate hydraulic circuits plus an optional generator drive circuit (on later units) in the Grayhound paver. See (Figure 5 - 2) and (Figure 5 - 2). Two circuits drive the travel motors (one circuit for each drive). Two circuits drive the conveyors (one circuit for each side). One circuit supplies hydraulic power to all auxiliary functions such as hopper wings, truck hook, tow point cylinders, and tow arm cylinders. One circuit supplies oil for the screed vibrators. The optional generator pump supplies oil to drive a hydraulically driven generator. Each circuit has its own pump to develop system pressure and its own motor or cylinder to convert hydraulic pressure and flow into mechanical movement. One reservoir holds hydraulic fluid for all systems and one oil cooler maintains an operable fluid temperature. Older Grayhound pavers use an oil cooler mounted with the engine coolant radiator. Newer Grayhound pavers use a remote mounted oil cooler. The remote oil cooler is mounted to the hood with an electrically driven cooling fan. The remote oil cooler can be installed on older Grayhound pavers if oil temperatures exceed maximum operating temperature.

**Fluid Temperature**


Excessively hot hydraulic fluid is an indicator of trouble developing in the hydraulic system. An operator should make it a habit to check the hydraulic oil temperature reading periodically throughout the day, just as he does the engine oil pressure, coolant temperature, voltage, etc. Normal operating range is 120° to 160°F. Any time the hydraulic fluid temperature approaches or exceeds

180°F, stop paving and determine the cause. Refer to Hydraulic System Troubleshooting in the Paver Technical Manual.



- 1 - Left Travel Pump
- 2 - Left Conveyor Pump
- 3 - Auxiliary Pump
- 4 - Vibrator Pump
- 5 - Right Conveyor Pump
- 6 - Right Travel Pump

Figure 5 - 1 Hydraulic Pumps Early Units



- 1 - Left Travel Pump
- 2 - Left Conveyor Pump
- 3 - Auxiliary Pump
- 4 - Vibrator Pump
- 5 - Right Conveyor Pump
- 6 - Right Travel Pump
- 7 - Generator Drive Pump (Optional)

Figure 5 - 2 Hydraulic Pumps Later Units

Fluid Reservoir:

**Fluid Reservoir:**

The hydraulic fluid reservoir (Figure 5 - 3) serves all hydraulic systems and is located beneath the hood on the left-hand side of the paver. Reservoir fluid capacity is 45 gallons.

A baffle divides the inlet side of reservoir from the outlet side. This baffle reduces oil foaming and air suspended in the oil which can damage the pumps. A breather/fill cap is located on top of the reservoir to release pressure that builds up as the oil heats up and cools down. The breather should be kept clean

to allow air flow through it. A drain plug is located on the bottom of the reservoir to make changing the hydraulic oil convenient.

**Notice:** All filter elements and suction hose fittings should be checked and tightened regularly to avoid leaks and prevent air from entering the hydraulic system. Prolonged operation with air in a hydraulic system will result in damage to a pump and poor system performance.




Figure 5 - 3 Hydraulic Fluid Reservoir & Filters

## Tandem Pumps

### Tandem Pumps

The travel and conveyor circuits are supplied by pumps which are mounted in tandem. (Figure 5 - 4) Right and Left side pumps are identical. The right side tandem pump is rotated on its mounting 180° from the left side tandem pump.

Each tandem pump contains one internal fixed displacement pump which supplies charge oil to both the travel and conveyor sections.




Figure 5 - 4 Tandem Pumps Charge Pressure Ports

### Checking Charge Pressure

It will often be useful to test each pump's charge and case pressure at the same time the high pressure setting is checked. Extremely high case pressure readings could mean restriction in return lines or in the oil cooler. If charge pressure is low, the charge relief valve should be inspected for wear or foreign material. For full repair and

troubleshooting of hydraulic pumps, refer to Hydraulic System Troubleshooting in the Paver Technical Manual.

**Important:** All pressure tests must be made with the hydraulic oil at operating temperature.

## Travel Pumps

To check charge pump pressure:

- 1) Install 600 PSI gauge in charge pressure test port. (Figure 5 - 4)
- 2) Start engine and run at full throttle.
- 3) Read pressure gauge. Pressure should be 390 ±50 PSI.

**Note:** If pressure is low, refer to Hydraulic System Troubleshooting in the Paver Technical Manual.

## Travel Pumps

Each travel motor is supplied by a separate travel pump. Each travel pump is made up of a variable displacement axial piston main pump and a charge pump. The charge pump draws oil from the reservoir and outputs it to the main pump. The main pump supplies 5400 PSI maximum pressure directly to the travel motor. If the pressure reaches 5400 PSI, the relief valves open to bypass fluid to the reservoir. Bypassing fluid over the relief valves for a long period of time will generate excessive heat in the system.

## Travel Drive Systems

The travel drive system permits infinitely variable speed adjustment from zero to maximum with torque available for any normal paving load. The speed will be maintained within the governed allowance whether the paver is pushing a loaded truck uphill or emptying the hopper. There will be no acceleration downhill even when hooked to a loaded truck.

Since each travel drive motor is supplied by its own pump, this provides independent control of each track/wheel. The fluid output of the travel drive

pumps can be reversed so the paver can move either forward or backward without mechanical gear shifting.

To move forward the operator places the Travel Direction Switch or Travel Lever in the forward (F) position and slowly rotates the Speed Dial clockwise. As the Speed Dial is rotated, the Electric Displacement Control (EDC) on the travel pump proportionally increases the angle of the swash plate. The increased swash plate angle increases the length of travel for the pump pistons which increases the speed of the travel motor.

## Travel High Pressure Check

The following procedure is to check each travel pump's high pressure setting:

- 1) Disconnect, cap and plug travel pump high pressure lines at motor bulkhead. (Figure 5 - 5)




Figure 5 - 5 Travel Motor Bulkhead

Travel Pumps

- 2) Install two 10,000 PSI pressure gauges in the high pressure gauge ports. (Figure 5 - 6)

**Important:** All pressure tests must be made with the hydraulic oil at operating temperature.

- 3) Start the engine and run at full throttle.
- 4) Set brake switch to OFF.
- 5) Set speed dial to 0.
- 6) Slowly move travel switch/lever to FORWARD.
- 7) Move speed dial to 5 or 6.

- 8) Read pressure gauge. Pressure should be 5400 PSI.

**Note:** Hold pump on stroke **only** long enough to read gauge. Holding on stroke for an extended length of time generates a lot of heat and may damage the hydraulic system.

- 9) Repeat steps 6 through 8 for REVERSE.

**Note:** If pressure is low, refer to Hydraulic System Troubleshooting in the Paver Technical Manual.




Figure 5 - 6 Travel High Pressure Test Ports

Conveyor Pumps

**Conveyor Pumps**

Each conveyor motor is driven by a separate conveyor pump. Each conveyor pump is made up of a variable displacement main pump and a charge pump. The charge pump draws oil from the reservoir and outputs it to the main pump. The main pump supplies 3400 PSI maximum pressure directly to the conveyor motor. If the pressure goes over 3400 PSI the relief valves open to bypass fluid to the reservoir. Bypassing fluid over the relief valves for a long period of time will generate excessive heat in the system.




Figure 5 - 7 Conveyor High Pressure Test Ports

**Conveyor Drive Systems**

Each slat conveyor/auger combination has its own hydraulic drive. The augers are linked to the slat conveyors by chain drive and are driven by a hydraulic motor with a chain-drive sprocket on the motor output shaft.

**Important:** All pressure tests must be made with the hydraulic oil at operating temperature.

Conveyor Pumps

**Cleaning a Disabled Paver**

If the paver becomes disabled with the hopper full of mix, the mix must be shovelled out of the hopper and the conveyors must be cleaned out before the mix cools.

To remove the mix from the conveyors:




Figure 5 - 8 Conveyor Pump Bypass Valve

- 1) Rotate the conveyor pump bypass valve counterclockwise no more than two turns. (Figure 5 - 8)




Figure 5 - 9 Attach chain to conveyor slat

- 2) Run a chain under the paver from the front to the back. Attach chain to the slat conveyor on the bottom rear of the slat conveyor. (Figure 5 - 9)

- 3) Pull forward on the chain. Once the chain connection point reaches the front of the paver, stop pulling the chain.
- 4) Tow the paver, (as described in Emergency Towing procedure found in Section 4) forward away from the pile of mix, reattach the conveyor chain, and repeat this procedure until the hopper is completely empty.
- 5) Tighten the conveyor pump bypass valves.

Conveyor Pumps

**Conveyor System Relief Setting**

The pressure relief valves for the conveyor pumps are factory set and should bypass fluid at 3400 PSI. Do not attempt to adjust the conveyor relief pressure setting. If load reaches this limit, fluid is bypassed around hydraulic motor and conveyor will stall. The factory setting is adequate for any paving condition. Therefore in the event of a stall, cause of overload should be determined and eliminated.

If a relief valve emits a high-pitched squeal, operator should quickly determine the cause. Continued operation will result in component damage and operating problems.

In the event that the conveyor speed settings are vastly different when each conveyor is doing an identical amount of work, it is probable that the side requiring the higher speed setting has a worn pump or motor. When an equal load situation exists, the pressure gauge readings should be nearly equal.

To test the conveyor high pressure relief setting:

- 1) Raise hopper gates fully open.
- 2) Block slat conveyor firmly and safely with a steel 2 x 4 bar against the hopper gate to prevent movement when power is applied. (Figure 5 - 10)



**Warning** - Extreme care should be taken when blocking conveyors to assure steel 2 x 4 bar does not slip off hopper gate. Personnel should stay clear of hopper area while tests are performed.



Figure 5 - 10 Block Slat Conveyor

- 3) Turn conveyor switches OFF and conveyor speed switch to LOW.
- 4) Install two 10,000 PSI pressure gauges in the high pressure gauge ports. (Figure 5 - 11)
- 5) Start the engine and run at full throttle.

**Notice:** Do not run the pressure over relief any longer than it takes to read the gauge.

Conveyor Pumps

- 6) Turn the conveyor speed dial or pile height dial to zero and move the conveyor switch to MANUAL. The gauge should read 0 psi.
- 7) Slowly rotate the conveyor speed dial or pile height dial clockwise until the gauge pressure increases. The pressure should hold steady at 3400 PSI.

**Note:** Hold pump on stroke **only** long enough to read gauge. Holding on stroke for an extended length of time generates a lot of heat and may damage the hydraulic system.

If pressure is significantly higher or lower than 3400 PSI, the pressure relief valve is defective and must be replaced. If replacement is necessary, refer to pump repair manual in the Paver Technical Manual.

**Notice:** The relief valves are factory set and should not be tampered with except for replacing the entire cartridge. Disassembly may change the setting and cause erratic operation or premature failure.




Figure 5 - 11 Conveyor High Pressure Reliefs

Conveyor Pumps

**Conveyor Neutral Adjustment**

If a slat conveyor movement, or “creep”, is observed when the conveyor switch is OFF, the neutral settings must be readjusted. These are factory set and normally will not need adjustment. If neutral adjustment becomes necessary, perform the following procedure. Refer to (Figure 5 - 12) through (Figure 5 - 15) during this procedure.



**Caution** - All personnel should stay clear of conveyors as they will move during the following adjustment.

- 1) Install a low pressure hose loop (500 psi min.) connecting conveyor pump servo ports. (Figure 5 - 12) This removes the effects of any control pressure on the servo piston.
- 2) Install pressure gauges (10,000 psi) in the system pressure gauge ports (Figure 5 - 11).
- 3) Start the engine and run at full throttle.
- 4) Loosen the lock nut while holding the servo neutral adjustment screw in position (Figure 5 - 13). Turn the adjustment screw until the two system pressure gauge readings are equal.
- 5) Rotate the adjusting screw clockwise until one of the system pressures starts increasing. Note the position “A” of the allen wrench. Rotate the adjusting screw counter-clockwise until system pressure increases in the other gauge. Note the position “B” of the allen wrench. (Figure 5 - 14)




Figure 5 - 12 Conveyor Pump Neutral Adjustment




Figure 5 - 13 Conveyor Pump Servo




Figure 5 - 14 Finding Neutral Position

Conveyor Pumps

- 6) Rotate the servo neutral adjustment screw clockwise half the distance between positions "A" & "B". The pump swash plate should now be in a neutral position. In this position the gauges should read approximately the same pressure.
- 7) While holding the servo neutral adjustment screw from turning, torque lock nut to 13 - 18 ft. lbs.
- 8) Stop the engine and remove the hose loop from the servo ports.




Figure 5 - 15 Electrical Displacement Control

- 9) Disconnect wiring from the Electrical Displacement Control (EDC) at the pump. (Figure 5 - 15)
- 10) Install 300 psi gauges in the servo ports from where the hose loop was just removed.



**Caution** - All personnel should stay clear of conveyors as they will move during the following adjustment.

- 11) Start the engine and run at full throttle.
- 12) Loosen lock nut with 1/2" wrench while holding the EDC neutral adjustment screw in position with a 5/32" allen wrench inserted into the internal hex. (Figure 5 - 15)
- 13) Turn the adjustment screw clockwise until one of the servo pressures starts to increase. Note the position "A" of the allen wrench. (Figure 5 - 14)
- 14) Without removing the allen wrench, rotate the adjusting screw counter-clockwise until the pressure increases in the other gauge. Note the position "B" of the allen wrench.
- 15) Rotate the EDC neutral adjustment screw clockwise half the distance between location "A" & "B". The EDC should now be in a neutral position. In this position the gauges should read approximately the same pressure.
- 16) While holding the adjustment screw from turning, torque the lock nut to 25 - 30 in. lbs.
- 17) Stop the engine.
- 18) Reconnect the wiring to the EDC at the pump.
- 19) Remove all pressure gauges.

Vibrator Pump

**Vibrator Pump**

One fixed displacement gear pump is used in the paver to power the screed vibrators. This pump provides up to 1500 PSI fluid to the screed vibrators at 2100 RPM engine speed. As engine speed is reduced, the pump output rate and pressure capability is reduced.

To check and adjust the vibrator system pressure:

- 20) Disconnect vibrator hoses to the screed at the rear bulkhead.
- 21) Install a 2500 PSI pressure gauge to the test port on the vibrator solenoid valve. (Figure 5 - 16)
- 22) Start the engine and run at full throttle.

- 23) Release the paver's brakes.
- 24) Turn the vibrator switch ON, speed dial to ZERO, and the travel control FORWARD. Gauge should read 1500 PSI.

**Important:** The vibrators do not engage until the travel control is in the forward position.

If the pressure gauge does not read 1500 PSI, do the following:

- 1) Loosen the relief valve adjustment jam nut.
- 2) Rotate the relief valve adjustment screw clockwise until the pressure reads 1500 PSI.
- 3) Tighten the relief valve adjustment jam nut.




Figure 5 - 16 Vibrator Pressure Test

Fume Recovery Hydraulics

**Fume Recovery Hydraulics**

The fume recovery fan hydraulic motor is supplied by the vibrator pump. This pump provides up to 2800 PSI fluid to the fan motor at 2100 RPM engine speed. As engine speed is reduced, the pump output rate and pressure capability is reduced.

To check and adjust the fume recovery system pressure:

- 1) Disconnect, plug hose, and cap fitting on inside of fume recovery pressure relief valve. (Figure 5 - 17)
- 2) Install a 3000 PSI pressure gauge to the test port on the fume recovery pressure relief valve. (Figure 5 - 17)

- 3) Start the engine and run at full throttle.
- 4) Gauge should read 2800 PSI.

**Important:** Do not run any longer than it takes to read the gauge. Oil will heat quickly running over relief.

If the pressure gauge does not read 2800 PSI, do the following:

- 1) Loosen the relief valve adjustment jam nut.
- 2) Rotate the relief valve adjustment screw clockwise until the pressure reads 2800 PSI.
- 3) Tighten the relief valve adjustment jam nut.




Figure 5 - 17 Fume Recovery Pressure Test

## Auxiliary Systems Pump

### Auxiliary System

The auxiliary system consists of a pressure-compensated variable-displacement pump to raise and lower the screed, hopper wings, pull points, frame raise, operate rubber track tensioning system, and engage the truck hook.

Solenoid-operated selector valves are controlled by toggle switches from the operator's console or at the screed. When none of the above functions are being operated, the pump is destroyed to minimize fluid flow while maintaining 2500 psi pressure.

On newer pavers, the auxiliary pump is supplied with supercharged oil from the remote oil cooler drive pump.

### Auxiliary System Pressure Compensator Check

The compensator for the auxiliary system should be set to bypass fluid at 2500 +/- 100 psi.

- 1) Install a pressure gauge (3000 psi) at the auxiliary system test port. (Figure 5 - 18)




Figure 5 - 18 Auxiliary Pressure Test Port

## Auxiliary Systems Pump

- 2) Start the engine and warm up the hydraulic oil. When the engine and oil are warm, move the throttle switch to full.
- 3) Observe the pressure gauge. The pump should maintain 2500 +/- 100 psi at full throttle.
- 4) If the pump will not maintain 2500 psi, rotate the compensator adjustment (Figure 5 - 19) clockwise to increase the pressure or counter-clockwise to reduce the pressure. If pressure cannot be attained, refer to Hot Mix Paver Technical Manual, Pumps-Motors-Drives section for more troubleshooting and repair information.




Figure 5 - 19 Auxiliary Pump

**Note:** When installing a new auxiliary pump, you must adjust the system pressure compensator to obtain the required 2500 psi. **New pumps do not come pre-set.**

Rubber Track Hydraulic System

**Rubber Track Hydraulic System**

The rubber track hydraulic system, see schematic (Figure 5 - 20), provides pressurized oil to the piston ends of track tension cylinders. Each track is independent and supplied by the auxiliary pump.

Pressurized oil is held in the piston end of each track tension cylinder between tension valves and tension cylinders.

When the paver is started, oil is directed from the auxiliary pump to the track tension valves at 2500 psi. When tension pressure needs to be adjusted, oil is then routed to the piston side of the track tension cylinders by opening the tension valve charge cartridge needle valves allowing oil pressure to rise to 2500 psi. An accumulator for each track is placed in the circuit between the tension valve and the piston side of the track tensioning cylinders. The accumulator is pre-charged with dry nitrogen at 2250 psi to allow the track tension cylinders to retract and return if an impact is encountered.




Figure 5 - 20 Rubber Track Hydraulic System Schematic

Rubber Track Hydraulic System




Figure 5 - 21 Rubber Track Hydraulic System Components

---

## Rubber Track Hydraulic System

### Checking Rubber Track Hydraulic System

The rubber track hydraulic system contains components which will automatically maintain track tension (Figure 5 - 21). To check out the system, follow the steps below:

#### Auxiliary System Pump Pressure

First check the auxiliary pump pressure compensator adjustment to be sure the system is set to 2500 +/- 100 psi. See Section 5, page 5-10 for this procedure.

#### Track Tension Accumulator

Check pre-charge of track tension accumulators on each side.

- 1) Install pressure gauge (3000 psi) at test port marked G on the Track Tension Valve (Figure 5 - 21).
- 2) Start and run engine at full throttle.
- 3) Pressure should read 2500 psi.
- 4) Shut engine off. Pressure on gauge should not change.
- 5) Loosen jam nut on discharge cartridge of track tension valve.
- 6) Insert an allen wrench into the adjusting screw, slowly turn it counter-clockwise to open the discharge needle valve and release hydraulic pressure while carefully watching the gauge.
- 7) The pressure reading should drop off slowly until it reaches the accumulator dry nitrogen pre-charge pressure. When the pressure reaches the accumulator pre-charge point, the gauge will drop quickly to 0 psi.

- 8) The gauge reading at the point where it drops quickly to 0 psi should be 2250 psi at 68 degrees F. This reading may be slightly more or less depending the ambient temperature and the hydraulic system temperature.
- 9) If the accumulator dry nitrogen pre-charge is at 2250 psi, then tighten the discharge needle valve screw by turning it clockwise until snug on its seat.
- 10) Re-tighten jam nut on discharge cartridge.
- 11) Charge the tension circuit to 2500 psi as described below.
- 12) If the pressure is below 2250 psi when it drops quickly to 0 psi, re-charge the accumulator with dry nitrogen as described in Track Tension Accumulator Pre-Charging procedure in the Paver Technical Manual, then test again.
- 13) If pressure is above 2250 psi, bleed off some dry nitrogen from the accumulator.
- 14) If the pressure drops steadily all the way to 0 psi and re-charging the accumulator does not work, then replace the accumulator.

#### Track Tension Pressure

Check the track tension pressure on each side.

- 1) Install pressure gauge (3000 psi) at test port marked G on the Track Tension Valve (Figure 5 - 21).
  - 2) Pressure should read 2500 psi.
- If pressure is not to 2500 psi, then do the following:
- 1) Start and run engine at full throttle.

Rubber Track Hydraulic System

- 2) Loosen jam nut on charge cartridge of track tension valve.
- 3) Insert an allen wrench into the adjusting screw, slowly turn it counter-clockwise to open the charge needle valve and allow hydraulic pressure to build to 2500 psi while carefully watching the gauge.
- 4) When the gauge reaches 2500 psi, close the charge needle valve by turning it clockwise until snug on its seat.
- 5) Shut off engine and note pressure.

Pressure should hold at 2500 psi.

**Track Tension Valve Cartridges & Track Tension Cylinder**

If the track tension cylinder bounces during operation as if there is air in the lines, do the following:

- 1) Loosen jam nuts on both charge and discharge cartridges of track tension valve. (Figure 5 - 21)
- 2) Start and run engine at full throttle.
- 3) Insert an allen wrench into the adjusting screws on the needle valves.
- 4) Alternately open and close each needle valve. Start with the discharge and then the charge.
- 5) Do step 4 until air is eliminated.
- 6) Tighten both needle valves snug on their seats.
- 7) Tighten jam nuts on each needle valve.

- 8) Shut off engine and note pressure.

Pressure should hold at 2500 psi.

If pressure does not hold, do the following:

- 1) Remove and cap lines from auxiliary pump-to-tension valve and from tension valve-to-tank. (Figure 5 - 22)



**Caution:** Escaping fluid under pressure can penetrate the skin causing serious injury. Be very careful when disconnecting hydraulic or other lines. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids. Any fluid injected into the skin must be removed immediately by a doctor.




Figure 5 - 22 Track Tension Valve Hydraulic Lines

- 2) Observe pressure on gauge.

Rubber Track Hydraulic System

- 3) If pressure drops from 2500 psi, observe which tension valve cartridge port (charge or discharge) is leaking hydraulic fluid.
- 4) Verify that both tension valve cartridge needle valves are completely shut as described above.
- 5) If one of the cartridge ports leaks, replace that cartridge.
- 6) If none of the cartridge ports is leaking, but the pressure still drops off, check the breather on the track tension cylinder. (Figure 5 - 23)



**Caution:** Escaping fluid under pressure can penetrate the skin causing serious injury. Be very careful when disconnecting hydraulic or other lines. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids. Any fluid injected into the skin must be removed immediately by a doctor.




Figure 5 - 23 Track Tension Cylinder

- 7) If hydraulic fluid is leaking from breather, the cylinder packing or cylinder wall may be damaged. Remove and repair or replace tension cylinder as necessary.
- 8) Remove caps from lines installed in Step 1 above and reinstall lines to tension valve.

Filters

**Filters**

The paver has three hydraulic fluid filters for maximum component protection. There are two travel/conveyor pump suction filters, and one auxiliary pump supercharge filter. (Figure 5 - 24)

**Notice:** Always replace filters with the filter listed in your paver parts book. Using lower quality filters could lead to expensive damage to the hydraulic system.

The auxiliary pump supercharge filter indicator should be checked daily with the engine at full throttle after the oil is warmed. If a filter is used until it is excessively clogged, the filter bypass valve will activate and the indicator on the filter base will indicate in the red. **NEVER** operate with a clogged filter! If the indicator is in the red area, the filter should be replaced. All hydraulic filters should be replaced every 500 hours of operation, when the indicator indicates red, or seasonally, whichever occurs first. Do not wait for an indicator to indicate red before replacing the filter.




Figure 5 - 24 Hydraulic System Filters

Solenoid Valves

**Solenoid Valves**

Solenoid valves mounted on top of each of the valve banks are controlled by toggle switches on the operator’s console. These spool-type valves direct oil flow to and from the various hydraulic cylinders which control the paver and screed.

All of the 4-way, solenoid-operated directional valves used on the paver are identical units. They are double-acting valves with spring return of the spool to the neutral position.

When one of the switch contacts is closed, a 12 VDC solenoid is energized and the spool position is shifted by the plunger to connect internal porting so that pressurized hydraulic fluid flows to one end of the hydraulic cylinder(s). Fluid displaced by the moving cylinder rod flows through aligned ports of the same valve bank to the reservoir.

When the toggle switch is moved to the opposite position, the opposite solenoid is energized and the spool is shifted to reverse the pressure and return flow ports so that the cylinder rod moves in an opposite direction.

When the switch is OFF, the spool is centered in the valve body by coil spring action and all ports connected to cylinders are closed so that no flow to or from the cylinders can occur.

Each solenoid uses a DIN connector which contains an LED. The LED lights when 12 VDC is applied. The first check to make when determining the cause of a hydraulic failure should be to see if the LED lights when the solenoid is energized. Keep in mind this is only a preliminary check; it is possible the LED may be burned out. (Figure 5 - 25)




Figure 5 - 25 DIN Connector LED

If one of the paver functions does not operate, refer to the Technical Manual for troubleshooting and repair information.





Figure 5 - 26 Solenoid Valve Override Button

Solenoid Valves



## Solenoid Valves

**Manual Testing of Solenoid Valves**

If the spool cannot be manually shifted or fails to return by spring action to the OFF position, the valve should be completely dismantled, inspected, cleaned, and tested. If manual shifting succeeds in operating the system, try electrical operation again to see if the coil's magnetic force is strong enough to consistently move and hold the plunger.

**Removing/disassembling Valve Bank**

**Warning:** Before removing any hydraulic hoses or valves make sure the hopper wings, screed, frame raise, and pull point cylinders are lowered as far as possible.




Figure 5 - 27 Typical Valve Bank

When it is necessary to detach and disassemble any of the valves which make up a valve bank assembly, it is necessary that the bank be

disconnected from hydraulic hoses, unbolted from the mounting brackets, and moved to a totally clean work bench area. The detached unit should also be plugged and washed clean externally before any disassembling is started. The following instructions should be used to maintain the frame raise, truck hook, hopper wings, screed lift, left tow point, and right tow point valve banks. Some of the components referred to may not be used on all valve banks. (Figure 5 - 27)

- 1) Remove the screw retaining each of the DIN connectors to the solenoids. Unplug the DIN connector from the solenoid.
- 2) Mark each hose and its companion port on the valve bank with a code that will assure reconnection is made to the correct port when the bank is installed. If hoses and ports are not marked, refer to schematic diagrams for correct connection details.
- 3) As each hose is disconnected, plug the end of the hose and port with a clean plastic plug.
- 4) Remove the nuts which hold the valve bank to the paver and remove the valve bank.

**Notice:** Scrub and rinse the exposed surfaces of the entire valve bank to remove all dirt and place the assembly on a clean working surface.

- 5) Remove the four stud nuts which hold the valve bank together and disassemble the valve bank. Retain all of the O-rings which will be between each of the valve bank components.
- 6) Remove the throttle valve from the valve block.

## Valve Bank Components

### Valve Bank Components

#### Throttle Valve

The throttle valve allows unrestricted flow in one direction and metered or restricted flow in the opposite direction. In the case of screed lift, flow in RAISE direction is unrestricted while return flow in the LOWER direction is restricted by a 3/32" diameter orifice. This permits the screed to raise quickly but to descend at a slower, safe rate.

A drilled poppet is the only moving part in a throttle valve. The valve can be easily inspected for presence of foreign matter in orifice. The orifice can be cleaned using a piece of 1/16" diameter wire and compressed air. If probing succeeds in clearing a blockage, the valve should then be flushed clean with mineral spirits solvent. These same valves are used in the hopper wing circuit.

#### Holding Valve

Hold valves are used on the frame raise, hopper wings, screed lift, and tow point valve banks. If the engine stalls or a hydraulic line breaks between the pressure source and valve, the holding valve locks the cylinder in its current position to prevent the screed, hopper wings, etc. from dropping unexpectedly. When the hydraulic line is repaired and the engine is restarted the valve continues to work normally.



**Warning:** Holding valves do not contain any serviceable or replaceable parts. Do not attempt to disassemble and repair a holding valve cartridge.

A holding valve consists of a valve body and one or more valve spools. If a holding valve is not working properly remove the valve and blow the

valve body and spool off with compressed air. Reinstall the valve. If it still does not work, replace the valve.

#### Flow Control Valve

The flow control valve is used in the tow point and truck hook cylinders to control the speed at which the cylinders move. The valve consists of a valve body with a needle valve cartridge.

To clean the flow control valve, remove the cartridge, blow the valve and valve body out with compressed air, and reinstall the cartridge.

Assembling Valve Banks

**Assembling Valve Banks**

The valve bank should be assembled on a clean lint-free shop towel in a clean work area. All components should be wiped clean before assembly.

- 1) Inspect all O-rings before assembly. Replace any O-rings that are cracked, damaged, dried out, or not flexible.
- 2) Lubricate each O-ring with clean oil or light grease before assembly.
- 3) Place O-rings in the O-ring recesses . Make sure O-rings do not get pinched during assembly.
- 4) Refer to illustrations on the following page for proper orientation of each valve bank component.
- 5) To ensure that each component is properly oriented during assembly, the following procedure should be followed for each component:
  - a) apply a thin coating of oil or grease to the O-rings
  - b) install the next valve stack component on the studs
  - c) remove the component

The O-rings will leave a circular oil mark on the mating valve surface. If the component was installed in the proper orientation the four oil ports in the mating component surface will be centered in the four oil marks left by the O-rings. If the oil marks do not line up with the oil ports, check the orientation of the component and reinstall.



**Caution:** When assembling valve bank, tighten screws alternately, evenly, and with not more than 48 to 60 inch-pounds of torque. It is important that the machined contact surfaces and O-rings make a leak-free contact without excessive screw tightness which can warp the valve body and cause binding of the spool.




Figure 5 - 28 Frame Raise/Screed Lift Valve Bank

Assembling Valve Banks




Figure 5 - 29 Truck Hook/Left Tow Point Valve Bank




Figure 5 - 30 Hopper Wings/Right Tow Point Valve Bank

---

## Hydraulic System Troubleshooting

### Hydraulic System Troubleshooting

For more in-depth information on individual circuits, refer to the Paver Technical Manual.

#### Hydraulic Fluid Overheating

The following factors can cause fluid temperature above 160°F:

- 1) **Low Fluid Level in Supply Tank:** When the fluid level is kept high, more heat is radiated from the tank walls and the circulating (cooling) time is increased. Keep fluid level FULL on the sight gauge, especially when outdoor temperature is high.
- 2) **Cooler Not Functioning Properly:** The flow of hydraulic fluid must be free and unrestricted at all times. The air passages through the radiator and cooler must be kept clear of dirt, fibers, and insects so that an unrestricted flow is assured at all times during engine operation. The cooler is placed ahead of the engine radiator and will therefore become plugged first by airborne foreign matter.

If increased cooling capacity is needed, an auxiliary oil cooler or remote oil cooler system can be installed.

#### Failing Pumps or Motors

In the event that one of the pumps or one of the motors is beginning to fail internally, excessive heat will usually be produced. When this occurs the fluid temperature will become abnormally high. It is recommended that a “touch” test be made immediately in an effort to determine where an internal failure of parts is beginning to occur. The hottest fluid will be passing back to the reservoirs through a case drain hose. It is sometimes possible to touch the fittings of each of these hose lines and

detect an extremely hot one which feels different from the others. If paving can be suspended for a “cooling off” period it is easier to detect the difference at the next start-up as the line from the failing unit will heat up much faster than the others. If a “hot” pump or motor is detected, have the pump or motor serviced immediately.

**Notice:** If the conveyors are not feeding equal quantities of material, the one moving the most material will be slightly hotter than the other. This should be considered in making temperature comparisons. Temperature checks can also be made by taping an accurate indicating thermometer to the case drain fittings.

#### Air in the Systems

Suction force developed by each of the six hydraulic pumps on the paver draws fluid from reservoirs through hose lines to the charge pumps. With all points on these suction lines under negative pressure, air can be drawn in wherever an opening exists. When air is mixed with the fluid entering any of the pumps, an abnormal situation is created and serious operating problems develop.

The charge pumps which force feed the drive pumps cannot develop enough fluid pressure to keep the main pump passages filled with fluid. Pump pressure fluctuates and paver operation becomes jerky and erratic as the pumps cavitate.

#### Causes of Air in System

- 1) Low fluid level in reservoirs. When fluid level approaches tips of suction pipes near bottom of reservoir, air begins to enter along with fluid. Always keep tank filled to sight gauge level.

- 2) Air leakage through an opening at any connection in fluid supply lines to pumps. If gasket at top of a filter element is not sealing properly, air will be drawn in.

### **Locating Air Leaks**

If an air leak is suspected but cannot be located or confirmed, the best way to test for it is by pressurizing the reservoir with air and finding the point of fluid leakage. To do so, remove fill cap and attach an air line which includes a pressure regulator and gauge so that **not more than 15 psi** air pressure will be applied. Any point where fluid leakage occurs under air pressure is a point of air entry.

When fluid leakage is located and stopped, pressurize reservoir to 15 psi, close air inlet valve, and see if system will hold pressure for an hour or two without dropping. This will verify that all leaks have been stopped and air will no longer enter the system when operation is resumed.


Steel Track Maintenance

**Section 6 - Mechanical Maintenance**

**Steel Track Maintenance**

The track is designed to be virtually maintenance free. Proper cleaning and lubrication at the end of each paving day will maintain trouble free operation. However, neglect of the tracks can be expensive. Every time paver is cleaned, the track pins should be sprayed with light oil to lubricate them preventing them from rusting and binding.

The Grayhound track paver uses a tension cylinder mounted above the final drive that maintains a constant volume of pressurized oil to the track adjusting cylinders. When the track encounters an obstacle, the system allows the tensioning idler to recoil rather than stretch or break the track. When the obstacle is cleared the system returns to the previous track tension adjustment.



- 1 - Counterbalance valve
- 2 - Rodless piston cylinder
- 3 - Tensioning cylinder assy.
- 4 - Needle valve
- 5 - Idler tension cylinders

Figure 6 - 1 Track tension hydraulic circuit

The track tensioning cylinder assembly consists of a cylinder with a rodless piston, a needle valve, and a counterbalance valve. (Figure 6 - 1) The piston keeps the oil from the idler tensioning cylinders separated from the main oil supply. When the track encounters an obstacle, it forces oil from the idler

cylinders into the bottom side of the rodless cylinder. When the obstruction is cleared, pressurized oil from the traction charge pump forces the tensioning cylinder down which forces idler cylinders to move back to original position.

The needle valve is used during track tensioning to bring the volume of oil on the bottom side of the rodless cylinder back to the proper level. The counterbalance valve allows oil to flow freely from the top side of the rodless cylinder to the tank when the track encounters an obstacle.

**Steel Track Tensioning**

If the track looks like it may be getting loose, it can be tested by placing a board or straight edge on the track between the front idler and the first top roller. If the gap between the bottom of the board and the top edge of the track is greater than 3/4", the track tension must be adjusted. (Figure 6 - 2)




Figure 6 - 2 Checking track tension

**Important:** Perform track tension checks and adjustments when the paver is at running temperature. Adjusting track tension when the paver is cold could lead to over-tensioning of the track.

Adjust track tension as follows:

- 1) Start the engine.
- 2) Open the needle valve slowly to allow the track to retension. (Figure 6 - 4)

Steel Track Maintenance

3) Drive the paver forward and backward slowly.



**Warning:** Be very careful when reaching over the moving track. Keep feet and loose clothing away from the moving track and rollers.

4) Stop the paver and close needle valve.

5) A properly tensioned track should have a 3/8" to 1/2" gap between a straightedge and the track. (Figure 6 - 3)




Figure 6 - 3 Proper Track Tension



**Warning -** Overtightening the track can cause serious damage to the track, idler or drive.

**Steel Track over-pressurizing**

If the track adjusting system is over-pressurizing during operation, the following procedure must be performed. It is a good idea to perform this check once each season to verify the tensioning cylinder is in good condition.

**Notice:** Do not run the paver while the system is over-pressurized. Running with an over-pressurized system could damage the track and sprockets.




Figure 6 - 4 Bottoming Tension Cylinder

- 1) Disconnect the line from the "T" port on the track tension cylinder. Install a plug into the disconnected line. (Figure 6 - 4)
- 2) Attach a drain line to the "T" port and run the other end into a bucket.
- 3) Close the needle valve by rotating clockwise.
- 4) Start the engine and run at full throttle.
- 5) If the track was tensioned properly, no oil will flow into the bucket.
- 6) If only a small amount of oil drains into the bucket, the piston and counterbalance valve are working properly and track will tension properly.
- 7) If oil continues to flow into the bucket, the piston or counterbalance valve is leaking and must be repaired.
- 8) Turn the engine off and reconnect the hydraulic line to the "T" port.

Steel Track Maintenance

**Steel Track Relief Pressure**

In addition to adjusting the track tension, the track relief pressure should be checked at least once each season. Refer to the Paver Technical Manual for information on checking track relief pressure.

**Steel Track Installation**



**Warning:** When installing or removing the track, keep hands and feet out from under the track/paver.



**Caution:** When disconnecting oil line in the following step, allow oil pressure to bleed off by loosening hose end first. When all pressure has been vented, remove oil line.

- 1) Disconnect the track tensioning oil line from the “T” port on the track tensioning cylinder. (Figure 6 - 4)
- 2) Jack up the track frame until the track can be slid under the bogies. Support the paver with blocking capable of supporting the weight of the paver.




Figure 6 - 5 Place board between sprocket and roller

- 3) Place boards between the sprocket and upper roller as shown. This elevates the track allowing it to clear the upper roller while driving the track toward the idler. (Figure 6 - 5)




Figure 6 - 6 Roll out track

- 4) Place the track under the paver with the end of the track marked OPEN positioned on the sprocket as shown and the other end stretched out in front of paver. (Figure 6 - 6)




Figure 6 - 7 Rotate sprocket to install track

- 5) Start the engine and rotate the sprocket until the end of the track marked OPEN just touches the front idler. (Figure 6 - 7)




Figure 6 - 8 Pull track ends together

- 6) Use a come-a-long or hoist to lift and draw the track ends together. (Figure 6 - 8)
- 7) Place blocks under the track assembly as shown to support loose track end.

- 8) Remove paint from interlocking ribs of master link and lightly grease contact surfaces. Clean bolt holes and threads, and apply anti-seize or grease to track shoe bolts.




Figure 6 - 9 Connecting Master Link

- 9) Connect the ends of the track by installing the master link pin. (Figure 6 - 9)




Figure 6 - 10 Install track pad

- 10) Once the master link is connected, apply Loctite to bolts and install track pads. (Figure 6 - 10)

### Steel Track Removal

To remove the track assembly, perform Track Installation procedures in reverse order.

### Steel Track Maintenance

#### Replacing Steel Track Drive Sprockets

When sprocket teeth are worn, the sprocket can be replaced or turned around to restore sprocket teeth to new condition. Perform the following procedure if sprocket replacement is necessary.

- 1) Rotate the track until the master link is positioned on the sprocket.
- 2) Disconnect the track tensioning oil line from the “T” port on the track tension cylinder. (Figure 6 - 4)

**Important:** After splitting the track, do not remove it completely. Position the track so it will not interfere with sprocket removal.




Figure 6 - 11 Remove link pin to separate track

- 3) Split the track and pull ends away from sprocket. (Figure 6 - 11)
- 4) Remove cap screws securing sprocket and remove sprocket from hub assembly.
- 5) Clean sprocket cap screws and bolt holes and apply Loctite to cap screws.
- 6) Place new or rebuilt sprocket onto hub assembly and secure with cap screws. If desired, the old sprocket can be turned around to utilize the opposite side of teeth.

## Steel Track Maintenance

- 7) Connect the track as shown in the Track Installation Procedure.

### Repairing Oscillating Bogie Rollers

There are three oscillating bogie assemblies which support the weight of the paver on each side. Each bogie contains rollers which are oil-filled and sealed. These rollers should not require attention for entire life of the bearings and oil seals inside.

When a paver has been in service for a long period of time the roller bearings will begin to wear. Severely worn bearings will cause operating problems. At least once each season, each roller should be relieved of all loading and checked for end play, which indicates bearing wear. If roller bearings are worn out (excessive wobbling), the roller assembly should be replaced.

Accumulation of dust and dirt on the roller is an indication that a roller is leaking. If this is detected, the roller should be removed and repaired as described in the following instructions. Do not delay this repair otherwise the roller bearings may be operating without lubrication which will quickly destroy the bearings.

- 1) Break the track as described in the previous section.
- 2) Jack up track frame until the track is completely off the ground and install safety blocks capable of supporting the weight of the paver.
- 3) Remove cap screw and pull the oscillator shaft out. Bogie should fall down to the track.



**Caution:** Roller should be disassembled in a clean environment. Do not allow dirt to contaminate bearings and seals inside roller.




Figure 6 - 12 Track roller

- 4) Remove four lock screws which secures the roller to the bogie. (Figure 6 - 12)
- 5) Remove shaft housing cap.
 

**Important:** Observe the positioning of the seals while removing, the new seals will need to be installed in the same manner.
- 6) Remove polished metal seal and both rubber seals. Drain oil and stand the roller on end with the open end up. Pour one pint of fresh oil along the flat portion of the shaft.
 

**Note:** Rollers are factory-filled with Mobil Glygoyle 30 synthetic oil. Mineral oils are not compatible, so do not mix.
- 7) Install new seals.
- 8) Install shaft housing cap and secure to bogie frame with four lock screws.
- 9) Install bogie assembly in track frame.
- 10) Reconnect track as described in previous section.

Rubber Track Maintenance

**Rubber Track Maintenance**

The rubber track is designed to be virtually maintenance free. Proper cleaning at the end of each paving day will maintain trouble free operation. However, neglect of the rubber tracks can be expensive.

**Rubber Track Tension**

The tracks on Grayhound rubber track pavers (Figure 6 - 13) do not require periodic adjustment. They are adjusted by applying a pre-set hydraulic pressure supplied by the auxiliary pump to the tension cylinders. The tracks have an automatic system that allows them to recoil and return to tension if an impact is encountered. If tracks appear loose, troubleshoot the track hydraulic system (see Section 5).




Figure 6 - 13 Rubber Track

**Rubber Track Installation & Removal**



**Warning:** When installing or removing the track, keep hands and feet out from under the track/paver.

**Removal**

Release the track tension by:

- 1) Shut off engine and remove key from ignition.
- 2) Loosen jam nut on track tension valve discharge cartridge (Figure 6 - 14).

- 3) Insert an allen wrench into the adjusting screw, slowly turn it counter-clockwise to open the shut-off valve and release hydraulic pressure.
- 4) If the track does not go slack, insert a porta-power between the track frame nose plate and the track (Figure 6 - 15) (protecting track from damage by inserting a block of wood or steel plate between ram and track).
- 5) Extend porta-power to loosen track.
- 6) Remove porta-power.




Figure 6 - 14 Release Rubber Track Tension

Rubber Track Maintenance




Figure 6 - 15 Insert Porta-Power

- 7) Jack up track frame until the track will slide out from under the bogies. Support paver with blocking capable of supporting its entire weight.
- 8) Un-bolt and remove screed pull arm.  
(Figure 6 - 16)
- 9) Un-bolt slope beam rod from tow point cylinder mounting assembly.
- 10) Un-bolt tow point cylinder mounting assembly from track frame. Swing assembly out of the way and secure to paver. If desired, disconnect hydraulic hoses to cylinder, plug to prevent contamination, and set assembly aside.
- 11) Un-bolt and remove outer half of drive wheel. Be sure to leave the two bolts holding the inner drive wheel onto hub.
- 12) Un-bolt and remove outer front idler nose plate.
- 13) Rubber track may now be pulled off track frame.

Rubber Track Maintenance




Figure 6 - 16 Rubber Track Removal

## Rubber Track Maintenance

### Rubber Track Installation

- 1) With track removed as described above, clean track frame and wheels of debris, dirt, and asphalt build-up.
- 2) Slide track onto frame making sure center lugs are in alignment between bogie wheels and front idler.
- 3) Install front idler outer nose plate.  
(Figure 6 - 16)
- 4) Install outer half of drive wheel.
- 5) Install tow point cylinder mounting assembly on track frame. If hydraulic hoses were disconnected, re-connect to the appropriate fittings.
- 6) Install slope beam rod back onto tow point cylinder mounting assembly.
- 7) Install screed pull arm.
- 8) Insert an allen wrench into the adjusting screw on shut-off valve cartridge (Figure 6 - 14). Slowly turn it clockwise until the valve seats.
- 9) Tighten jam nut on valve cartridge.
- 10) Track is now ready to be re-tensioned.

### Rubber Track Re-tensioning

- 1) Start engine and run at idle.
- 2) Set brakes to ON and allow the track tensioning system to charge itself.
- 3) The track tensioning cylinders should extend and the track should tighten.
- 4) If the track does not tighten or the system does not operate properly, see Section 5 for troubleshooting procedures.

## Rubber Track Maintenance

### Repairing Rubber Track Bogie Wheels

There are four oscillating bogie wheel assemblies (two on each side) which support the weight of the paver. Each assembly contains four bogie wheels which are fitted with tapered roller bearings packed with roller bearing grease and sealed to prevent the entry of dirt and debris. The bogie wheels should not require attention for the entire life of the bearings and seals.

When a paver has been in service for a long period of time, the roller bearings will begin to wear. Severely worn bearings will cause operating problems. At least once each season, each bogie wheel assembly should be relieved of all loading and each wheel checked for end play. Each bogie wheel should not have any end play, but a preload of .002" - .004".

### Bogie Wheel Assembly Removal

To remove the bogie wheel assemblies for repair or replacement of parts:

- 1) Perform the procedure "Rubber Track Installation & Removal" on page 6 of this section to relieve rubber track tension. Also see (Figure 6 - 14) and (Figure 6 - 15).

**Notice** - It is not necessary to completely remove the track to service the bogie wheel assemblies. The paver must only have the track tension relieved and be raised off the ground far enough for the assemblies to clear the bottom of the track frame and the track center lugs.

- 2) Remove shaft from track frame that holds center bogie wheel assembly to frame (Figure 6 - 17). This will allow the assembly to drop onto the track.
- 3) Remove the bogie wheel assembly by drawing it out over the center lugs of the track.
- 4) Remove the front and rear bogie wheel assemblies, as described above.

**Note:** If the track has been removed, each individual bogie wheel assembly may be removed independently.




Figure 6 - 17 Bogie Wheel Assembly Removal



**Warning:** When removing the bogie wheel assemblies, keep hands and feet clear from between the track and wheel assemblies.

Rubber Track Maintenance

**Bogie Wheel Assembly Installation**

To install bogie wheel assemblies after they have been removed from track frame, simply reverse the process listed in “Bogie Wheel Assembly Removal” on page 10 of this section.

**Bogie Wheel Bearing Replacement**

If it is determined that bearing replacement is necessary, proceed with the following:

**Disassembly**

- 1) Remove bogie wheel assembly as described above. See “Bogie Wheel Assembly Removal” on page 10 and (Figure 6 - 18) below.
- 2) Remove grease cap (12).

- 3) Bend back locking tab on lock washer (10) and remove bearing nut (11).

**Note:** If bearings are to be re-used, keep cups and cones in matched sets as originally installed.

- 4) Slide bogie wheel (3) off hub. The keyed flat washer(9), outer bearing cup (7) and cone (6) will be removed with the wheel as will the inner bearing cup (5).
- 5) Remove inner bearing cone (4) and shaft seal (8).
- 6) Clean all parts with mineral spirits solvent, inspect for damage, and replace as necessary.




Figure 6 - 18 Bogie Wheel Bearings

## Rubber Track Maintenance

### Assembly

The following procedure is for establishing the proper bearing setting (.002” - .004” preload) on the bogie wheels. Refer to (Figure 6 - 18):

- 1) Pack inner (4) and outer (6) bearing cones with grease and set aside.
- 2) If inner cup (5) and/or outer cup (7) are to be new, install them at this time by pressing into bogie wheel housing (3) as shown.
- 3) Slide inner cone (4), packed with grease, into the inner cup (5) and then install the shaft seal (8) by pressing into bogie wheel housing (3) as shown.
- 4) Lubricate lip of seal with a small amount of oil or grease.
- 5) Slide bogie wheel onto shaft making sure not to damage lip of seal. This step is best done with the bogie frame (1) turned so the shaft is in a vertical position.
- 6) Pack the cavity between the bearings with grease.
- 7) Slide outer cone (6), packed with grease, onto shaft.
- 8) Slide keyed flat washer (9) and bearing lock washer (10) onto shaft.
- 9) Install bearing nut (11) and tighten to 50 ft/lbs while rotating bogie wheel. This will seat the bearings.
- 10) Loosen bearing nut until it is finger tight.

**Note:** Take care not to unseat bearings when bearing nut is loosened.

- 11) Tighten bearing nut to 32 ft/lbs while rotating bogie wheel.
- 12) Select one of the locking tabs on the bearing lock washer (10) that is closest to a slot on the bearing nut, and either tighten or loosen nut to align the slot and tab.
- 13) Bend locking tab into slot on bearing nut to lock it in place.
- 14) Install grease cap (12) into bogie wheel housing.

Repeat steps 1 through 14 above for each bogie wheel.

Rubber Track Maintenance

**Repairing Rubber Track Front Idler Assembly**

The front track idlers, (one on each side), provide the mechanism to maintain tension on the tracks. Each idler assembly consists of two idler wheels bolted to the idler housing, a shaft with tapered roller bearings surrounded by a multi-part frame that acts as a push bar and guide to keep the idler aligned in the track frame. The front idler bearings should not have any end play, but a preload of .001” - .003”.

**Front Idler Assembly Removal**

To remove front idler assembly from the track frame:

- 1) Perform the procedure “Rubber Track Installation & Removal” on page 6 of this section.

**Notice** - It is necessary to completely remove the track to allow the front idler to be removed from track frame.

- 2) Remove front nose plate pivot retaining bracket (4) from the paver frame.
- 3) Once the track is removed from machine, remove front nose plate (3).
- 4) Remove cam rollers (6) from idler assembly plates.
- 5) The front idler assembly (5) may now be slid forward out of the slots in track frame and lifted from the machine.




Figure 6 - 19 Front Idler Assembly Removal

## Rubber Track Maintenance

### Front Idler Assembly Repair

If it is determined that bearing replacement is necessary, proceed with the following:

#### Disassembly

- 1) Remove front idler assembly as described above. See “Front Idler Assembly Removal” on page 13 of this section.
- 2) Drive roll pins (12) out of slide blocks (6).
- 3) Remove slide blocks (6) from shaft (5).
- 4) Remove and disassemble side plates (2) and (3) from push bar (4).
- 5) Remove bearing caps (8) from each side of idler housing (7). Seals (11) will remain in caps.  
  
**Note:** If bearings are to be re-used, keep cups and cones in matched sets as originally installed.
- 6) Tap one end of shaft (5) with soft hammer or block of wood to remove bearing cup (10) from the opposite end. Shaft will then come out of idler housing (7) with bearing cones (9) still on shaft.
- 7) Using a punch, remove the remaining bearing cup from the idler housing.
- 8) At this time, if the idler wheels (1) need to be replaced, remove them from idler housing (7) by removing cap screws (16), lock nuts (23), and hardened flat washers (17).
- 9) Clean all parts with mineral spirits solvent, inspect for damage, and replace as necessary.

Rubber Track Maintenance




Figure 6 - 20 Front Idler Assembly Repair

---

 Rubber Track Maintenance
 

---

**Bearing Replacement**

Refer to (Figure 6 - 20) and the following procedure:

**Note:** Use Loctite 272 thread compound on all cap screws.

- 1) Pack bearing cones (9) with grease and set aside.
  - 2) Install new seals (11) into each bearing cap (8) and set aside.
  - 3) Press bearing cones onto shaft (5) and set aside.
  - 4) Press one bearing cup (10) into idler housing.
  - 5) Install one bearing cap (8) onto idler housing and tighten cap screws (18).
  - 6) Slide shaft, with bearings, into idler housing taking care not to damage seal in bearing cap. This step is best done with the idler housing turned so the shaft is inserted in a vertical position.
- Note:** The shaft must be free to rotate.
- 7) Press the other bearing cup into idler housing.
  - 8) Install the other bearing cap with seal (and without shims 20-21-22) onto idler housing.
  - 9) Install two cap screws (18) 180° from each other and tighten in 90° increments. As the two cap screws are tightened, keep the others finger tight to prevent the bearing cap from flexing as it puts pressure on the bearings.
  - 10) While turning the shaft with a torque wrench, continue the tightening until a sudden rapid rise in the torque is seen, then stop.
  - 11) Measure and record the torque reading as the baseline rolling torque. You will need this reading later.
  - 12) Turn the shaft again as above, and continue tightening the two cap screws until a 20 to 55 in/lb increase in rolling torque is achieved.
  - 13) Using either a taper gage or a feeler gage, measure and record the gap, in thousandths of an inch, between the bearing cap and the idler housing. Perform this measurement by the two cap screws 180° apart described above.
  - 14) Average these two measurements.  
 Example - One measurement is .022" and the other is .032".  
 $.022" + .032" = .054"$  divided by 2 = .027"  
 .027" is the thickness of shim stack needed.  
 Refer to the table in (Figure 6 - 20) for combinations to make up the proper thickness shim stack.
  - 15) Remove the bearing cap, install the shim stack, and re-assemble tightening all cap screws to specified torques.
  - 16) Rotate the shaft, measure and record the rolling torque once again. This torque value should be 20 to 55 in/lb greater than the baseline rolling torque recorded in step 11.
  - 17) If this torque value is not achieved, repeat steps 9 through 16.

## Rubber Track Maintenance

### Assembly

Refer to (Figure 6 - 20) and the following procedure to re-assemble the front idler assembly after bearing replacement:

**Note:** Use Loctite 272 thread compound on all cap screws unless otherwise noted.

- 1) If idler wheels (1) have been removed from idler housing (7), install cap screws (16) using G-N assembly paste P/N 49999-222, hardened washers (17), and lock nuts (23).

**Note:** Tighten lock nuts (23) to 250 ft/lb.  
**Do Not** use impact wrench on these nuts.

- 2) Slide side plates (2) and (3) over ends of shaft.
- 3) Install push bar (4) to side plates and leave cap screws (14) finger tight.
- 4) Install slider blocks (6) through side plates and onto shaft (5) aligning each roll pin hole in block with hole in shaft.
- 5) Install roll pins (12) into slider blocks and drive through holes in shaft until flush with edge of blocks.
- 6) Rotate, if necessary, slider blocks to align cap screw holes with holes in side plates.
- 7) Install cap screws (15) and tighten to specified torque.
- 8) Tighten side plate-to-push bar cap screws to specified torque.

Front idler assembly is now ready to be installed back onto track frame.

### Front Idler Assembly Installation

Refer to (Figure 6 - 19) and the following procedure to install assembled front idler in track frame:

**Note:** Use Loctite 272 thread compound on all cap screws.

- 1) Lift front idler assembly and position slider blocks in slots in track frame with push bar toward the rear.
- 2) Slide assembly rearward until holes in side plates line up with slots in track frame.
- 3) Install cam rollers into holes in side plates through slots in track frame and tighten to specified torque.
- 4) Install front nose plate.
- 5) Track may now be installed per “Rubber Track Installation” on page 9.

---

 Rubber Track Maintenance
 

---

**Rubber Track Drive Wheel Replacement**

When replacement of rubber track drive wheels becomes necessary, use the following procedure:

**Removal**

- 1) Follow the instructions in Rubber Track Installation & Removal on page 5 of this section for removing the outer drive wheel and track.
- 2) Once outer drive wheel and track are removed, remove the two remaining cap screws which hold the inner drive wheel to the drive motor hub (Figure 6 - 21) and slide wheel off hub.

**Installation**

- 1) Slide inner drive wheel onto drive motor hub.
- 2) Secure inner drive wheel to motor hub with two cap screws 180° apart from each other, use Loctite 272 and torque to 404 ft.-lbs.
- 3) Install track and outer drive wheel per instructions in Rubber Track Installation on page 7 of this section.

**Note:** Outer drive wheel should be installed with the two larger holes slid over the two cap screws retaining the inner drive wheel and 90° from larger holes in inner drive wheel.

- 4) Install remaining drive wheel bolts, use Loctite 272 and torque to 404 ft.-lbs.




Figure 6 - 21 Drive Wheel Replacement

---

 Slat Conveyors

## Slat Conveyors

### Replacing Slat Conveyor Liners

Liners are bolted to the hopper bed to provide a wearing surface over which the mix is carried. If slat liners are worn out, chances are the chains are as well; inspect and replace or adjust as needed. (Refer to Slat Conveyor Tensioning.)

- 1) Detach screed from tractor. Make sure all electrical cables and hydraulic hoses are disconnected before pulling tractor away (Refer to Screed Section of this manual).
- 2) Elevate the paver to allow an adequate amount of safe working space under the tractor so the liner nuts can be reached. Support the paver with blocking equipment capable of supporting the weight of the paver.




Figure 6 - 22 Replacing hopper liners

- 3) Remove outer front and center front skirt boards. (Figure 6 - 22)
- 4) Remove outer rear and inner rear skirt boards.
- 5) Loosen slat conveyor chain take-ups.

- 6) Remove pin from chain link and break each chain at a point just below the rear drive sprockets.
- 7) Pull the top section of each slat conveyor forward through the hopper. Place slat conveyors on the ground in front of the paver. The return portion of each conveyor (underside of paver) need not be moved unless the slats and chains are to be inverted.
- 8) Unbolt and replace all liner panels which are worn out.
- 9) Reinstall all parts by reversing the disassembly procedure and perform the Slat Conveyor Tensioning procedure.

### Inverting Slat Bars

The slat conveyors consist of two continuous chains linked together by a series of bars. When a slat bar becomes worn on one side the slat bar can be removed and turned over to allow use of the other side.

## Augers

### Augers

#### Cast Augers

Current Grayhound pavers are equipped with cast auger sections. Cast augers provide long service life without the need to resurface the augers as they wear. When the augers are worn, replace the auger sections with new bolt-on sections. (Figure 6 - 23)




Figure 6 - 23 Replacing cast auger sections

#### Re-facing Lined Augers

When augers are severely worn they can be re-faced with special contoured liners made from Ni-hard alloy. The application of these liners restore the augers to near new condition. To apply genuine Cedarapids Ni-hard liners proceed as follows:

- 1) Remove auger from paver.
- 2) Clean auger sections as well as possible, particularly in the weld areas.




Figure 6 - 24 Installing liners

- 3) Use several C-clamps and attach the pieces of liner to the auger face starting at the drive chain end as shown (Figure 6 - 24). By starting at this end, the main wear surface of the section will be covered and any small area not covered will be at the discharge end. Adjust liner pieces to extend 1/8" above the edges of the auger flight as shown (Figure 6 - 25). Be sure the first piece applied is accurately aligned so the remaining liners will fit properly along the flight.

Augers




Figure 6 - 25 Liner cross-section

- 4) Use a low hydrogen weld rod and make a continuous weld along the inside edge "A". (Figure 6 - 25)




Figure 6 - 26 Installing Liners

- 5) Make welds at each of the two pockets "B". (Figure 6 - 26)




Figure 6 - 27 First and last liners require extra weld

- 6) On the first and last liners of each flight make a weld at the exposed edge for extra strength "C". (Figure 6 - 27)

**Important:** The small cracks which develop in the liners from the welding process are normal and should not be considered defects.

**Re-lining Auger Shafts**

When paving with materials that are extremely abrasive, the auger shafts will show severe wear; lining segments can be welded on to the auger shafts to prevent shaft wear. These segments are made of mild steel instead of Ni-hard material for easier application. The rate of shaft wear is never as great as that of the auger flight facing.



---

## Machine Storage Preparation

### Machine Storage Preparation

The following procedures are recommended for conditioning the Cedarapids paver for storage.

- 1) Run all material completely out of the machine.
- 2) Thoroughly clean the complete machine to remove all asphalt.
- 3) Park machine in a shed or well drained area. (Preferably on boards to keep tires or tracks out of mud or standing water.)
- 4) Perform Periodical Maintenance items listed on the periodic maintenance chart found in this manual.
- 5) Thoroughly grease all bearings and bushings. Grease all adjustment bolts on paver and screed.
- 6) Winterize radiator with Anti-freeze to 40° below zero.
- 7) Hang screed on safety cables and retract all hydraulic cylinders so cylinder rods are not exposed.
- 8) Remove batteries, feed controllers and grade/slope controllers. Store in heated area. Store batteries on wood, not concrete.
- 9) Be sure all panel lids and covers are in place. Close tightly to prevent water entry. (Tape around electric panel door to seal).
- 10) Enclose consoles in protective cover. Leave bottom of wrap open to prevent condensation inside. Cover exhaust.
- 11) Remove all books and literature from tool boxes and store inside office or with other stored components.
- 12) Refer to engine manufacturer's specifications for protection of engine.

## Appendix A - Torque Specs

### Torque Charts

The following pages contain charts for use as guides when tightening bolts and nuts. These specifications should be followed unless specific torques are given elsewhere in this manual.

#### Standard Torque Chart

Table A - 1 is a list of recommended torque values for standard bolts. Use this torque chart to avoid overstressing standard nuts and bolts used on Cedarapids equipment. These specifications should be followed unless specific torques are given. Cedarapids uses Grades 2, 5, and 8. The maximum torque values are based on 75% of the specified minimum proof strength of the bolt steel in order to provide a safety factor. The term “lube” applies to cadmium plating and/or application of thread lubricants. Hardened washers should always be used, regardless of whether standard nuts or lock nuts are employed.

#### Metric Torque Chart

Table A - 2 is a list of torque values recommended for metric bolts. The maximum torque values are based on 75% of the specified minimum proof strength. The term “lube” includes the application of thread lubricants, cadmium plating and the use of hardened washers regardless of whether standard or lock nuts are used.



Torque Charts

		S.A.E Grade 2			S.A.E Grade 5			S.A.E Grade 8		
dia. (inches)	pitch (thread/in.)	Torque (ft-lbs)		Clamp Load (lbs)	Torque (ft-lbs)		Clamp Load (lbs)	Torque (ft-lbs)		Clamp Load (lbs)
		Dry	Lube		Dry	Lube		Dry	Lube	
1/4	20	5	4	1310	8	6	2020	12	9	2860
1/4	28	6	5	1500	10	7	2320	14	11	3270
5/16	18	11	9	2160	17	13	3340	25	19	4710
5/16	24	12	10	2390	19	15	3690	27	21	5220
3/8	16	20	15	3190	31	24	4940	44	34	6970
3/8	24	23	17	3620	35	27	5590	49	38	7900
7/16	14	32	25	4380	49	38	6770	70	54	9560
7/16	20	36	27	4890	55	42	7560	78	60	10680
1/2	13	49	38	5850	75	58	9040	106	82	12770
1/2	20	55	42	6590	85	65	10190	120	92	14390
9/16	12	70	54	7500	109	84	11600	150	115	16380
9/16	18	79	60	8370	121	93	12940	170	130	18270
5/8	11	97	75	9320	150	115	14400	210	160	20340
5/8	18	110	85	10560	170	130	16320	240	180	23040
3/4	10	170	130	13770	265	200	21290	375	285	30060
3/4	16	190	145	15380	295	225	23770	415	320	33570
7/8	9	165	125	11430	425	330	29450	605	465	41580
7/8	14	180	140	12590	470	360	32440	665	510	45810
1	8	245	190	14990	640	495	38630	905	695	54540
1	14	270	210	16400	700	540	42260	990	765	59670
1-1/8	7	350	270	18880	790	610	42340	1285	990	68670
1-1/8	12	395	305	21180	890	685	47500	1440	1110	77040
1-1/4	7	495	380	23980	1120	860	53770	1815	1395	87210
1-1/4	12	550	425	26550	1240	950	59550	2010	1545	96570
1-3/8	6	655	500	28580	1465	1130	64100	2380	1830	103950
1-3/8	12	745	570	32540	1670	1285	72980	2710	2085	118350
1-1/2	6	865	665	34770	1945	1495	77970	3160	2430	126450
1-1/2	12	975	750	39120	2190	1685	87740	3555	2735	142290
1-3/4	5	1370	1055	47020	2285	1755	78370	4985	3835	170990
2	4.5	2060	1585	61870	3435	2640	103120	7500	5765	225000
2-1/4	4.5	3015	2320	80430	5025	3865	134060	10960	8435	292500
2-1/2	4	4125	3170	99000	6875	5285	165000	15000	11530	360000
2-3/4	4	5590	4300	122010	9320	7165	203360	17790	13680	388230
3	4	7385	5680	147750	12310	9470	246260	23500	18080	470130

Table A - 1: Torque Values for Standard Hardware



Torque Charts

dia (mm)	pitch (mm)	Property Class = 8.8				Property Class = 10.9				Property Class = 12.9			
		Dry		Lube		Dry		Lube		Dry		Lube	
		(ft-lbs)	N-M	(ft-lbs)	N-M	(ft-lbs)	N-M	(ft-lbs)	N-M	(ft-lbs)	N-M	(ft-lbs)	N-M
10	1.5	37	50	29	39	53	72	41	56	62	84	48	65
10	1.25	39	53	30	41	56	76	43	58	66	89	51	69
12	1.75	65	88	50	68	93	126	71	96	109	148	83	113
12	1.25	71	96	55	75	101	137	78	106	119	161	91	123
14	2	104	141	80	108	148	201	114	155	173	235	133	180
14	1.5	112	152	86	117	160	217	123	167	187	254	144	195
16	2	161	218	124	168	230	312	177	240	269	365	207	280
16	1.5	172	233	132	179	246	334	189	256	287	389	221	300
18	2.50	230	312	177	240	318	431	245	332	372	504	286	388
18	1.5	258	350	199	270	357	484	275	348	418	567	321	435
20	2.5	325	441	250	339	450	610	346	469	525	712	404	548
20	1.5	360	488	277	376	499	677	384	521	583	791	448	607
22	2.5	443	601	341	462	613	831	471	639	716	971	551	747
22	1.5	486	659	374	507	673	913	518	702	786	1066	605	820
24	3	562	762	432	586	777	1054	598	811	908	1231	698	946
24	2	612	830	471	639	847	1149	652	884	990	1342	762	1033
27	3	823	1116	633	858	1139	1544	876	1188	1331	1805	1024	1389
27	2	889	1205	683	926	1229	1667	945	1281	1436	1947	1105	1498

Table A - 2: Torque Values for Metric Hardware



---

Torque Charts