

# **TEREX** **Cedarapids**

---

## **Operation & Maintenance Manual**

---

### **500 SERIES**

#### **Hot Mix Asphalt Paver**

#### **Covers All 552 & 562 Models**



To the Owner & Operator:

We have tried to provide information that gives our customers a clear understanding of equipment construction, function, capabilities and requirements. This information is based on the knowledge and experience of qualified people at our company and in our field organization. Proper use of this information rewards users of our equipment with high efficiency, maximum service life and low maintenance costs. That is why we strongly recommend that anyone using our equipment be familiar with this manual.

Information presented here should not be considered authoritative in every situation. Users will as a matter of course encounter problems and circumstances that raise questions not anticipated here. Such questions should be directed to their distributor or the factory.

Anyone who uses this equipment for any purpose other than that for which it was intended assumes sole responsibility for dangers encountered and injuries sustained as a result of such misuse.

---

**⚠ DANGER**

Federal, state and local safety regulations aim to protect both people and property from accident, injury and harmful exposure. When complied with, such regulations are often effective. Hazards to personnel and property are further reduced when this equipment is used in accordance with all operation and maintenance instructions. Generally:

- (1) Read and heed all danger, warning, caution, and notice decals. Know what guards and protective devices are included and see that each is installed and in operational condition. Additional guards and protective devices may be required and must be installed by the user (owner) before operating.
- (2) Never attempt to maintain, lubricate or adjust this equipment while it is running. Lock out and tag out all energy sources before doing maintenance, cleaning, adjusting or repairing this equipment. Make it impossible for anyone to start this machine while others are working on it or in it.
- (3) Wear personal protective equipment such as hard hats, ear plugs, safety glasses and safety shoes when operating this equipment. Do not wear loose clothing or long hair.
- (4) Think safety and act safely. Stay alert at all times. Eliminate or neutralize potential hazards as soon as you spot them. Never allow anyone to engage in horseplay when near this equipment.

**⚠ DANGER**

Failure to take these precautions will result in death or severe personal injury.

The following warning applies to equipment supplied with lead-acid batteries:

**⚠ WARNING**

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.

**Wash hands after handling.**

The following warning applies to equipment supplied with diesel powered engines:

**⚠ WARNING**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

## Cedarapids Warranty Policy

**Cedarapids Inc.**, hereafter referred to as **Cedarapids**, warrants its new products manufactured and sold worldwide to be free of defects in material or workmanship for a period of one (1) year, or 2000 hours of use, whichever occurs first.

The warranty will commence on the day the equipment is put into operation by the customer for use, whether sold, rented or leased or one (1) year after shipment from the factory, whichever occurs first. **Delivery Inspection forms are required for warranty validation and processing.**

Cedarapids' obligation and liability under this warranty is expressly limited to, at Cedarapids' sole option, repairing or replacing with new or remanufactured parts or components, any part which appears to Cedarapids upon inspection to have been defective in material or workmanship. Such parts shall be provided at no cost to the user, FOB a Cedarapids parts facility.

Cedarapids shall pay, to the extent outlined in the Warranty Reimbursement section, the cost of labor to install any repaired or replaced part provided under this warranty.

This warranty may not apply to component parts or accessories not manufactured by Cedarapids and which carry the warranty of the manufacturer thereof. Furthermore, normal maintenance, adjustments, or maintenance/wear parts are not covered by this warranty.

Cedarapids makes no other warranty, express or implied, and makes no warranty of merchantability or fitness for any particular purpose.

**No employee or representative is authorized to change this warranty unless such change is made in writing and signed by an authorized representative of Cedarapids.**

Cedarapids' obligation under this warranty shall not include duty, taxes, or any other charges whatsoever, or any liability for direct, indirect, incidental, or consequential damage or delay.

If requested by Cedarapids, components or parts for which a warranty claim is made are to be returned to the location designated by Cedarapids.

Improper maintenance, improper use, improper storage, operation beyond rated capacity, operation after discovery of defective or worn parts, or alteration or repair of the equipment by persons not authorized by Cedarapids shall render this warranty null and void. This warranty shall be null and void if parts other than genuine Cedarapids are used in the equipment. Cedarapids reserves the right to inspect the installation of the product and review maintenance procedures to determine if the failure was due to improper maintenance, improper use, operation beyond rated capacity, operation after discovery of defective or worn parts, or alteration or repair by persons not authorized by Cedarapids.

**Replacement Parts Warranty:** Cedarapids warrants the replacement parts ordered from the Parts Department to be free of defect in material or workmanship for a period of 6 months or 1000 hours of operation, whichever occurs first.

**Extended Warranty:** Extended warranties are available for purchase at the time of sale. The terms and conditions of the Extended Warranty will be provided upon request.

**TRANSFERABILITY OF WARRANTY:** The balance, if any, of the original equipment warranty may be transferred to second and subsequent owners provided certain conditions are met. Please contact your local Cedarapids Dealer for additional details if needed.

## Cedarapids Warranty Policy - Continued

### The following items are NOT covered under the Cedarapids Warranty:

- 1) Items sold by any non-authorized Cedarapids Dealers.
- 2) Some components are not covered by Cedarapids warranty, but rather are covered only by the warranty that is provided by the manufacturer. Such components include, but are not limited to, the engines, electric motors, air compressors, air conditioners, batteries, tires etc.
- 3) **Replacement of Assemblies:** Cedarapids has the option to repair or replace any failed part or assembly. It is Cedarapids policy to refuse claims for the replacement of a complete assembly that is field repairable by the replacement or repair of defective part(s) within the assembly.
- 4) **Component Products:** Product that is not genuine Cedarapids parts.
- 5) **Normal Operational Maintenance Services and Wear Parts:** Maintenance services and wear parts are excluded from warranty claims. Maintenance services not covered include, but are not limited to, such items as: sheave adjustments and alignment, screen cloth installation and tensioning, wear liner and chute work, wear or adjustment of jaw and toggle plates, proper tightening of bolts, nuts and pipe fittings, adding or replacing of fluids, filter, breathers, belts, nozzles, screed plates, adjustments of pumps and motors, spark plugs, etc. Wear parts not covered include, but are not limited to, such items as: screen cloth, wear liners, wear of jaw and toggle plates, fluids, filters, breathers, belts, nozzles, screed plates, spark plugs, etc.
- 6) **Transportation Damage:** Any damage caused by carrier handling is a transportation claim and should be filed immediately with the respective carrier.
- 7) **Deterioration:** Repairs of parts exposed to age, storage, weathering, lack of use, demonstration use.
- 8) **Towing or Hauling:** Towing or hauling charges or damages.
- 9) **Lifting Devices:** Crane rentals or other lifting devices.
- 10) **Secondary Failures:** Should the owner or operator continue to operate a machine after it has been noted that a failure has occurred, Cedarapids will not be responsible under the warranty for resultant damage to other parts due to that continued operation.
- 11) **Parts Orders and Minimum Billing Charges:** Special handling and minimum charges for parts items will not be reimbursed.
- 12) **Field Installation:** Proper installation of options and kits is the responsibility of the company performing the work. Cedarapids accepts no warranty responsibility for improper or unauthorized installations.
- 13) **Field Modification:** Only approved modifications and Cedarapids directed retrofits may be made on equipment or attachments to equipment produced by Cedarapids. Approval must be obtained from Cedarapids Service Department prior to the modification being made. Modifications or retrofits that are made without Cedarapids approval will not be covered by warranty.
- 14) **Workmanship of Others:** Cedarapids does not accept responsibility for improper installation or the replacement parts labor costs.
- 15) **Stop and Go Warranty:** Cedarapids does not recognize "Stop and Go" warranties.
- 16) **Machine Improvements or Design Changes:** Cedarapids reserves the right to change any specifications or make design changes without notice. Cedarapids shall not be obligated to make such changes in goods or parts previously delivered or any equipment previously sold to an end user.
- 17) **Incidental or Consequential Damage:** Cedarapids shall not be liable for any Incidental or Consequential Damages of any kind including, but not limited to, lost profits, loss of production, increased overhead, loss of business opportunity, delays in production, costs of replacement components and increased costs of operation that may arise from the breach of this warranty. Customer's sole remedy shall be limited to repair or replacement of the defective part.
- 18) **General Exclusions:** Any product which has, in Cedarapids' judgment, been damaged due to misuse, negligence, loading beyond its normal capacity, alteration, accident, or lack of regular maintenance service. Our obligation under this warranty shall not include any:
  - Equipment operated at speeds other than factory recommendations.
  - Equipment adjusted to any settings other than factory recommendation.
  - Equipment installed by others without Cedarapids Service assistance will not be warranted for the following:
    - Workmanship pertaining to the installation of equipment.
    - Length of time to install the equipment.
    - Instructions given on operating the equipment.
    - Instructions given on maintaining the equipment.
    - Instructions given on troubleshooting the equipment.

[Taken from Cedarapids Warranty Policy Document F/N 22633 Dated (4/01)]

This Page Intentionally Left Blank

---

## Table of Contents

---

### Section 1 - Introduction

|                         |       |
|-------------------------|-------|
| About This Manual ..... | 1 - 1 |
|-------------------------|-------|

### Section 2 - Safety

|                                           |        |
|-------------------------------------------|--------|
| Introduction .....                        | 2 - 1  |
| Symbols and Standards .....               | 2 - 2  |
| Safety Alert Symbol .....                 | 2 - 2  |
| Hazard Classification .....               | 2 - 2  |
| Decals and Icons .....                    | 2 - 3  |
| Decal Locations .....                     | 2 - 4  |
| Danger and Warning Decals .....           | 2 - 5  |
| Personal Safety .....                     | 2 - 7  |
| Management Responsibilities .....         | 2 - 7  |
| Operator Responsibilities .....           | 2 - 7  |
| Work Area Safety .....                    | 2 - 8  |
| Equipment & Tools .....                   | 2 - 8  |
| What is Lockout & Tagout? .....           | 2 - 9  |
| When is Lockout & Tagout required? .....  | 2 - 9  |
| Who must apply a lock & tag? .....        | 2 - 9  |
| When can a lock and tag be removed? ..... | 2 - 9  |
| Who can remove a lock and tag? .....      | 2 - 9  |
| Screed Safety Information .....           | 2 - 10 |
| Training and Knowledge .....              | 2 - 10 |
| Safe Paver Operation .....                | 2 - 10 |

### Section 3 - Set Up and Operation

|                                                |        |
|------------------------------------------------|--------|
| Receiving New Equipment .....                  | 3 - 1  |
| Pre-Operation Check .....                      | 3 - 1  |
| Principle Of Operation .....                   | 3 - 1  |
| Fume Recovery System .....                     | 3 - 3  |
| Operator's Console .....                       | 3 - 4  |
| Optional Equipment .....                       | 3 - 14 |
| Screed Extension .....                         | 3 - 14 |
| Slopeable Hydraulic Strike-off Extension ..... | 3 - 14 |
| Truck Hook .....                               | 3 - 14 |
| Bevel Guide Plate .....                        | 3 - 15 |
| Automatic Grade and Slope Control .....        | 3 - 15 |
| Topcon Grade and Slope Control .....           | 3 - 15 |
| Night Lighting Kit .....                       | 3 - 15 |
| Grade Reference Ski .....                      | 3 - 16 |
| Material Retaining Plates .....                | 3 - 16 |
| Auger Extensions .....                         | 3 - 17 |
| End Gates .....                                | 3 - 17 |

---

## Table of Contents

---

|                                                        |        |
|--------------------------------------------------------|--------|
| Cutoff Shoe .....                                      | 3 - 17 |
| Front Wheel Assist .....                               | 3 - 17 |
| Proportional Material Feed control .....               | 3 - 18 |
| Sonic Feed control .....                               | 3 - 18 |
| <b>Starting the Engine</b> .....                       | 3 - 19 |
| Engine start-up after stall .....                      | 3 - 19 |
| Jump-Starting/Charging Batteries .....                 | 3 - 20 |
| Emergency towing .....                                 | 3 - 20 |
| <b>Loading/Unloading</b> .....                         | 3 - 23 |
| Driving the Paver off a Trailer .....                  | 3 - 23 |
| Lifting With Crane .....                               | 3 - 25 |
| <b>Preparation for transport</b> .....                 | 3 - 26 |
| <b>Preparing to Pave</b> .....                         | 3 - 27 |
| Fume Recovery System .....                             | 3 - 27 |
| Nulling Screed .....                                   | 3 - 28 |
| Joints .....                                           | 3 - 29 |
| Transverse Joints .....                                | 3 - 29 |
| Joint Preparation .....                                | 3 - 29 |
| Joint Construction .....                               | 3 - 29 |
| <b>Rubber Track Operating Hints</b> .....              | 3 - 31 |
| Do Not Allow Asphalt Build-up on Track .....           | 3 - 31 |
| Proper Installation of Material Retaining Plates ..... | 3 - 32 |
| Maneuvering On Hot Asphalt .....                       | 3 - 33 |
| Maneuvering On Uneven Surface .....                    | 3 - 35 |
| Maintenance of Track .....                             | 3 - 37 |
| <b>Spray Down and Cleaning</b> .....                   | 3 - 40 |
| Paver Cleaning Procedure .....                         | 3 - 40 |
| Generation III Sonic Sensor Cleaning .....             | 3 - 41 |
| Pressure Cleaning .....                                | 3 - 41 |
| <br><b>Section 4 - Electrical System</b>               |        |
| <b>Electronic Controlled Fuel System</b> .....         | 4 - 1  |
| General Information .....                              | 4 - 1  |
| <b>Engine Protection System</b> .....                  | 4 - 1  |
| Engine Protection Shutdown .....                       | 4 - 1  |
| Engine Protection Shutdown Override .....              | 4 - 1  |
| <b>Diagnostic Fault Codes</b> .....                    | 4 - 2  |
| Checking For Fault Codes .....                         | 4 - 2  |
| Fault Code Description .....                           | 4 - 3  |
| Display of Fault Codes .....                           | 4 - 3  |
| <b>Paver Electrical Schematics</b> .....               | 4 - 4  |

---

## Table of Contents

---

### Section 5 - Hydraulic System

|                                               |        |
|-----------------------------------------------|--------|
| <b>General Description</b>                    | 5 - 1  |
| Slat Conveyor Pavers Hydraulic Circuits       | 5 - 1  |
| Remix Pavers Hydraulic Circuits               | 5 - 2  |
| Hydraulic Fluid Reservoir                     | 5 - 3  |
| Hydraulic Oil Cooler                          | 5 - 3  |
| Fluid Temperature                             | 5 - 3  |
| <b>Slat Conveyor Pumps</b>                    | 5 - 3  |
| Conveyor Drive Systems                        | 5 - 3  |
| Cleaning a Disabled Paver                     | 5 - 3  |
| Checking Conveyor Drive Charge Pressure       | 5 - 4  |
| Checking System Relief Setting                | 5 - 5  |
| Conveyor Neutral Adjustment                   | 5 - 6  |
| <b>Remix Delivery Auger Pumps</b>             | 5 - 7  |
| Delivery Auger Drive Systems                  | 5 - 7  |
| High Pressure Adjustment                      | 5 - 8  |
| <b>Slat Conveyor Paver Travel Pumps</b>       | 5 - 9  |
| Travel Drive Systems                          | 5 - 9  |
| High Pressure Adjustment                      | 5 - 10 |
| <b>Remix Paver Travel Pumps</b>               | 5 - 11 |
| Travel Drive Systems                          | 5 - 11 |
| Checking System Relief Setting                | 5 - 12 |
| System High Pressure Relief Valve Replacement | 5 - 13 |
| Travel Neutral Adjustment                     | 5 - 14 |
| <b>Spreading Auger Pumps</b>                  | 5 - 16 |
| Spreading Auger Drive Systems                 | 5 - 16 |
| Checking System Relief Setting                | 5 - 16 |
| System High Pressure Relief Valve Replacement | 5 - 17 |
| Spreading Auger Neutral Adjustment            | 5 - 18 |
| <b>Remix Delivery Control</b>                 | 5 - 20 |
| Delivery Control Components                   | 5 - 20 |
| Remix Delivery Control Operation              | 5 - 21 |
| Remix Delivery Control Troubleshooting        | 5 - 22 |
| <b>Slat Conveyor Paver Vibrator Pump</b>      | 5 - 23 |
| <b>Remix Paver Vibrator Pump</b>              | 5 - 24 |
| <b>Auxiliary Systems Pump</b>                 | 5 - 25 |
| Auxiliary System                              | 5 - 25 |
| Auxiliary System Pressure Compensator Check   | 5 - 25 |
| <b>Rubber Track Hydraulic System</b>          | 5 - 26 |
| Checking Rubber Track Hydraulic System        | 5 - 26 |
| Auxiliary System Pump Pressure                | 5 - 26 |
| Pressure Reducing Valves                      | 5 - 26 |
| Track Tension Accumulator                     | 5 - 29 |

---

## Table of Contents

---

|                                                   |        |
|---------------------------------------------------|--------|
| Track Tension Check Valve and Release Valve ..... | 5 - 30 |
| Track Tensioning Cylinders .....                  | 5 - 30 |
| Track Take-up Valve .....                         | 5 - 31 |
| <b>Slat Conveyor Paver Filters</b> .....          | 5 - 32 |
| Travel Circuit Filters .....                      | 5 - 32 |
| Conveyor Circuit Filters .....                    | 5 - 32 |
| Auxiliary Filter .....                            | 5 - 33 |
| <b>Remix Pavers Filters</b> .....                 | 5 - 33 |
| Charge Filter Replacement .....                   | 5 - 33 |
| Auxiliary Filter .....                            | 5 - 34 |
| Paver Suction Strainers .....                     | 5 - 34 |
| <b>Solenoid Valves</b> .....                      | 5 - 35 |
| Manual Testing of Solenoid Valves .....           | 5 - 38 |
| Removing/disassembling Valve Bank .....           | 5 - 38 |
| <b>Valve Bank Components</b> .....                | 5 - 39 |
| Throttle Valve .....                              | 5 - 39 |
| Holding Valve .....                               | 5 - 39 |
| Flow Control Valve .....                          | 5 - 39 |
| Assembling Valve Banks .....                      | 5 - 39 |
| <b>Hydraulic System Troubleshooting</b> .....     | 5 - 42 |
| Hydraulic Fluid Overheating .....                 | 5 - 42 |
| Failing Pumps or Motors .....                     | 5 - 42 |
| Air in the Systems .....                          | 5 - 43 |
| Causes of Air in System .....                     | 5 - 43 |
| Locating Air Leaks .....                          | 5 - 43 |

## Section 6 - Maintenance

|                                                |       |
|------------------------------------------------|-------|
| <b>Raising the hood</b> .....                  | 6 - 1 |
| <b>Before Starting Engine</b> .....            | 6 - 2 |
| <b>Maintenance Checklist</b> .....             | 6 - 3 |
| <b>Periodic Maintenance</b> .....              | 6 - 4 |
| <b>1) Fuel Level</b> .....                     | 6 - 4 |
| <b>2) Fuel/Water Separator</b> .....           | 6 - 4 |
| Daily Maintenance .....                        | 6 - 4 |
| Filter Replacement .....                       | 6 - 5 |
| <b>3) Hydraulic Fluid</b> .....                | 6 - 5 |
| <b>4) Oil Cooler</b> .....                     | 6 - 6 |
| <b>5) Suction Strainers</b> .....              | 6 - 6 |
| <b>6) Charge Filters</b> .....                 | 6 - 7 |
| <b>7) Auxiliary Pump Filter</b> .....          | 6 - 7 |
| <b>8) Hydraulic lines and components</b> ..... | 6 - 7 |
| <b>9) Air Restriction Indicator</b> .....      | 6 - 8 |

---

## Table of Contents

---

|                                           |        |
|-------------------------------------------|--------|
| <b>10) Air Filter</b> .....               | 6 - 8  |
| Engine Air Inlet Connections .....        | 6 - 9  |
| <b>11) Engine Oil</b> .....               | 6 - 9  |
| Engine Oil Level .....                    | 6 - 9  |
| Changing Engine Oil .....                 | 6 - 9  |
| <b>12) Engine Oil Filter</b> .....        | 6 - 10 |
| <b>13) Engine Coolant</b> .....           | 6 - 10 |
| <b>14) Engine Belt</b> .....              | 6 - 11 |
| <b>15) Radiator</b> .....                 | 6 - 12 |
| <b>16) Cooling Fan</b> .....              | 6 - 12 |
| <b>17) Battery</b> .....                  | 6 - 13 |
| Checking battery fluid levels .....       | 6 - 13 |
| Cleaning Batteries .....                  | 6 - 13 |
| Checking Specific Gravity .....           | 6 - 13 |
| Storing Batteries .....                   | 6 - 14 |
| <b>18) Tire Pressure</b> .....            | 6 - 14 |
| <b>19) Frame Raise Eccentric</b> .....    | 6 - 14 |
| <b>20) Steel Track Tension</b> .....      | 6 - 15 |
| Checking steel track tension .....        | 6 - 15 |
| Steel Track over-pressurizing .....       | 6 - 16 |
| Tightening Steel Track .....              | 6 - 17 |
| Steel Track Relief Pressure .....         | 6 - 17 |
| <b>21) Rubber Track Tension</b> .....     | 6 - 17 |
| Rubber Track Maintenance .....            | 6 - 17 |
| <b>22) Track Pivot</b> .....              | 6 - 17 |
| <b>23) Fire Extinguisher</b> .....        | 6 - 18 |
| <b>24) Horn</b> .....                     | 6 - 18 |
| <b>25) Pump Drive Belts</b> .....         | 6 - 18 |
| Tension Checking Procedure .....          | 6 - 18 |
| Poly Chain Belts .....                    | 6 - 20 |
| <b>26) Depth Cranks</b> .....             | 6 - 20 |
| <b>27) Vibrator Bearings</b> .....        | 6 - 21 |
| <b>28) Crown Control</b> .....            | 6 - 21 |
| <b>29) Match Height Assembly</b> .....    | 6 - 21 |
| <b>30) Extension Slope Assembly</b> ..... | 6 - 21 |
| <b>31) Final Drive Oil</b> .....          | 6 - 22 |
| <b>32) Steering Bogie Alignment</b> ..... | 6 - 22 |
| <b>33) Steering Linkage</b> .....         | 6 - 22 |
| <b>34) Bogie Beam Bearings</b> .....      | 6 - 23 |
| <b>35) Front Wheel Bearings</b> .....     | 6 - 23 |

---

## Table of Contents

---

|                                             |        |
|---------------------------------------------|--------|
| 36) Bogie Wheel Toe-in .....                | 6 - 23 |
| 37) Conveyor Slat Chains .....              | 6 - 23 |
| 38) Conveyor Bearings .....                 | 6 - 24 |
| 39) Delivery Auger Clearance .....          | 6 - 25 |
| 40) Delivery Auger Drive - Gear Drive ..... | 6 - 26 |
| 41) Front Delivery Auger Bearings .....     | 6 - 26 |
| 42) Spreading Auger Bearings .....          | 6 - 26 |
| 43) Spreading Auger Drive Chains .....      | 6 - 27 |
| 44) Spreading Auger Speed Reducer .....     | 6 - 27 |
| 45) Feeder Drive Chains .....               | 6 - 28 |
| 46) Conveyor Speed Reducer .....            | 6 - 28 |
| 42) Hood Raise Reservoir .....              | 6 - 29 |
| 48) Operator Console Pivot Bearings .....   | 6 - 29 |
| 49) Tow Arm Nose Roller .....               | 6 - 29 |
| 50) Slope Beam Rod Ends .....               | 6 - 30 |
| 51) Truck Hitch .....                       | 6 - 30 |
| 52) Fume Recovery System .....              | 6 - 30 |
| Fume Recovery System Repair .....           | 6 - 31 |
| <b>Corrective Maintenance</b> .....         | 6 - 34 |
| <b>Steel Track</b> .....                    | 6 - 34 |
| Steel Track Tensioning .....                | 6 - 34 |
| Steel Track over-pressurizing .....         | 6 - 35 |
| Steel Track Relief Pressure .....           | 6 - 36 |
| Steel Track Installation .....              | 6 - 36 |
| Steel Track Removal .....                   | 6 - 37 |
| Replacing Steel Track Drive Sprockets ..... | 6 - 37 |
| Repairing Oscillating Bogie Rollers .....   | 6 - 38 |
| <b>Frame Raise Bushing Repair</b> .....     | 6 - 39 |

---

## Table of Contents

---

|                                                   |        |
|---------------------------------------------------|--------|
| <b>Rubber Track</b> .....                         | 6 - 40 |
| Rubber Track Tension .....                        | 6 - 40 |
| Rubber Track Removal and Installation .....       | 6 - 41 |
| Removal .....                                     | 6 - 41 |
| Rubber Track Installation .....                   | 6 - 42 |
| Rubber Track Re-tensioning .....                  | 6 - 43 |
| Repairing Rubber Track Bogie Wheels .....         | 6 - 44 |
| Bogie Wheel Assembly Removal .....                | 6 - 44 |
| Bogie Wheel Assembly Installation .....           | 6 - 45 |
| Bogie Wheel Bearing Replacement .....             | 6 - 45 |
| Disassembly .....                                 | 6 - 45 |
| Assembly .....                                    | 6 - 45 |
| Repairing Rubber Track Front Idler Assembly ..... | 6 - 47 |
| Front Idler Assembly Removal .....                | 6 - 47 |
| Front Idler Assembly Repair .....                 | 6 - 48 |
| Disassembly .....                                 | 6 - 49 |
| Bearing Replacement .....                         | 6 - 49 |
| Assembly .....                                    | 6 - 50 |
| Front Idler Assembly Installation .....           | 6 - 51 |
| <b>Rubber Track Drive Wheel Replacement</b> ..... | 6 - 51 |
| Removal .....                                     | 6 - 51 |
| Installation .....                                | 6 - 51 |
| <b>Slat Conveyor Paver, Slat Conveyors</b> .....  | 6 - 53 |
| Replacing Slat Conveyor Liners .....              | 6 - 53 |
| Inverting Slat Bars .....                         | 6 - 53 |
| <b>Remix Paver Delivery Augers</b> .....          | 6 - 53 |
| Replacing Auger Liners .....                      | 6 - 53 |
| Replacing Auger Flights .....                     | 6 - 54 |
| <b>Paver Spreading Augers</b> .....               | 6 - 55 |
| Cast Augers .....                                 | 6 - 55 |
| Re-facing Lined Augers .....                      | 6 - 55 |
| Re-lining Auger Shafts .....                      | 6 - 56 |
| <b>Machine Storage Preparation</b> .....          | 6 - 56 |
| <br><b>Appendix A - Torque Specs</b>              |        |
| Torque Charts .....                               | A - 1  |
| <br><b>Appendix B - Electrical Schematics</b>     |        |
| Electrical Schematics .....                       | B - 1  |
| <br><b>Appendix C - Hydraulic Schematics</b>      |        |
| Hydraulic Schematics .....                        | C - 1  |

---

# Table of Contents

---

## About This Manual

---

### Section 1 - Introduction

#### About This Manual

This book is an operation and maintenance manual for the owner or operator of the equipment described within.

We strongly recommend that anyone working with this equipment become familiar with the manual, whether or not you have experience with similar equipment.

This manual will help you understand how to install your equipment, prepare it for operation, and perform normal operation and maintenance tasks.

#### **DANGER**

This manual contains information necessary for proper and safe operation. Carefully read this manual before attempting to operate. Failure to read and heed instructions preceded by a safety-alert symbol can cause death or severe personal injury as well as equipment and environmental damage.

Experience has shown it is to your advantage to keep a copy of this manual where operators can consult it as needed and to have a copy on file in your office, so that shift leaders or supervisors can conveniently refer to it. Additional copies can be ordered through your distributor.

This equipment is precisely engineered, highly functional, and heavy-duty designed to provide years of excellent service performing to customer specifications. We are proud to manufacture this equipment for your use and profit. We also take pride in the quality of our service and replacement parts.

This manual, however, is not a parts catalog and should not be used to order parts. Only your Parts Book, identified with your machine's serial number, is an authoritative source of part numbers and part descriptions for your equipment.

Ongoing improvement of product design may in the future result in changes to some parts. Use part numbers, model numbers and serial numbers from your Parts Book to communicate with your distributor.

## About This Manual

---

This Page Intentionally Left Blank

## Introduction

---

## Section 2 - Safety

### Introduction

This equipment is designed expressly for hot mix paver operations. When our equipment is used for purposes other than those for which it was designed, user assumes sole responsibility for any injuries or damage that may result from said misuse. We emphatically recommend that this equipment be operated only by personnel who are trained in its use.

We make no guarantee, either expressly or by implication, that this equipment meets all local or federal safety regulations. It is the responsibility of those individuals who own and/or operate this machine to verify that all safety regulations are complied with before starting either this unit or any associated equipment.

Symbols and Standards

Symbols and Standards

Important symbols and hazard classification standards relating to safe equipment operation are used throughout this manual. Make sure you read, understand and follow all DANGER, WARNING and CAUTION decals on equipment.

Safety Alert Symbol

The safety alert symbol (Figure 2 - 1) is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Figure 2 - 1 Safety Alert Symbol

Hazard Classification

A multi-tier hazard classification system is used to communicate potential personal injury hazards. The following signal words used with the safety alert symbol indicate a specific level of severity of the potential hazard (Figure 2 - 2). Signal words used without the safety alert symbol relate to property damage and protection only. All are used as attention-getting devices throughout this manual as well as on decals and labels fixed to the machinery to assist in potential hazard recognition and prevention.

|                  |                                                                                                                                                       |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>⚠ DANGER</b>  | <b>DANGER</b> indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.                              |
| <b>⚠ WARNING</b> | <b>WARNING</b> indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.                            |
| <b>⚠ CAUTION</b> | <b>CAUTION</b> indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.                             |
| <b>CAUTION</b>   | <b>CAUTION</b> used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage. |
| <b>NOTICE</b>    | <b>NOTICE</b> indicates information or a company policy that relates directly or indirectly to the safety or protection of property.                  |

Figure 2 - 2 Hazard Classification

## Symbols and Standards

### Decals and Icons

Beneath all safety regulations lies a set of common-sense rules. Everyone who works with or near heavy equipment must be aware of those rules. To foster and maintain such an awareness in our customers, safety decals are fixed on our equipment.

Icons on our safety decals remind both workers and supervisors of common hazards and procedures that, in the course of a busy day, they might otherwise forget. The language of the icons is simple and direct (Figure 2 - 3).


|                                                                                      |                                                                                                                                                                                                                                                                                                    |
|--------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | Place guards around all moving parts on this machine. Never start the machine if those guards are broken or missing.                                                                                                                                                                               |
|    | Keep hands, feet, clothes and hair away from moving belts and sheaves.                                                                                                                                                                                                                             |
|    | Wear hearing protection when you're near this equipment.                                                                                                                                                                                                                                           |
|    | Wear respiratory protection when near this equipment. Rock dust is hard on your lungs.                                                                                                                                                                                                             |
|    | Rock chips sometimes come flying out of equipment. Wear goggles or safety glasses near this equipment.                                                                                                                                                                                             |
|   | Head injury is a hazard around any heavy equipment. Wear your hard hat.                                                                                                                                                                                                                            |
|   | Lockout & Tagout. Equipment may be energized. Lockout and tagout all energy sources prior to performing maintenance or adjustments.                                                                                                                                                                |
|  | Electrocution Hazard. Will cause death, burns and involuntary muscle control. De-energize equipment prior to entry. Entry by authorized trained personnel only. Ground all equipment per all Federal, state, or local electrical codes. Use insulated rubber gloves or other protective equipment. |
|  | Read all the manuals that shipped with your equipment. Maintenance is done more easily and safely when you know what you're doing.                                                                                                                                                                 |

Figure 2 - 3 Safety Pictograms Explained

# Symbols and Standards

## Decal Locations




Figure 2 - 4 Decal Locations - Side Views

# Danger and Warning Decals




Figure 2 - 5 Decal Locations - Front and Rear Views

# Symbols and Standards




Figure 2 - 6 Decal Locations - Fender and Hydraulic Reservoir

## Personal Safety

---

### Personal Safety

This equipment is designed with the safety of all personnel in mind. Never attempt to change, modify, eliminate or bypass any of the safety devices installed at the factory. Guards, covers and shields installed around moving parts at the factory are meant to prevent accidental injury to operators and other personnel. **Do not remove them.**

### DANGER

Sometimes, at a customer's request, equipment is shipped without certain features such as a drive sheave. When this occurs, we attach a warning decal to alert installers that the related guard or other safety feature is missing. In such cases it is the customer's responsibility to guard the machine properly.

We recommend the following basic safety practices:

#### Management Responsibilities

- Make sure that everyone working on or near this equipment is familiar with safety precautions. Have a supervisor at the job site responsible for job safety.
- Give crew members specific safety responsibilities and instruct them to report any unsafe conditions to their supervisor

#### Operator Responsibilities

- Read all danger, warning, caution and notice signs.

- Always lock out and tag out involved energy sources before performing maintenance or adjustments on this equipment. Make it impossible for anyone to start this machine while others work on it or in it.
- Never remove any guard, cover or shield when this equipment is in motion.
- Replace guards, covers and shields when the task for which you removed them is finished.
- Block parts as necessary to prevent their sudden movement while people are working on the machine.
- Never attempt to clear away jammed feed material, discharge material or other stoppage while the machine is running. Stop the equipment, lock out and tag out before touching this machine with your tools or your hands.
- Wear proper personal protective equipment, including eye protection, hard hat and safety shoes, whenever you're near this machine while it is running.
- Dress appropriately in every way. Never wear loose clothes, long hair, coat tails, jewelry, pockets full of tools or any other item that could get caught in moving parts.
- Know where your fellow workers are. Always look around and inside this machine before starting it. Make sure nobody is in the way of moving parts or working on the machine.
- Lift with your legs, not with your back. Keep the weight close to your body. If the load is more than 40 lbs., get someone to help you.
- Never engage in horseplay when near this machine, or any other.
- Report any defective machinery or equipment and unsafe conditions or activity to your boss immediately.

- Don't limit safety practices to the few rules listed here. Think safety and act safely at all times.
- Most of all, know your equipment. Understand the machinery, the conditions under which it operates and what it is capable of doing.

**Work Area Safety**

- Keep the work area as neat and clean as practical.
- Keep all product safety signs clean, clear and current.
- Make sure all electrical equipment is properly grounded. Wet spots near electrical current are especially dangerous.
- Store hazardous materials in restricted access areas and mark them clearly. Federal regulations require special labeling of certain materials.
- Never start an engine in an enclosed space without properly venting the exhaust.
- Do not smoke or allow smoking near fuels and solvents. Never strike a spark or use an open flame near fuels and solvents.
- Store flammable fuels, solvents and gases in secure, well ventilated areas. Never allow fumes to accumulate in the storage area. Use nonflammable solvents for cleaning parts and equipment whenever possible.
- Know where fire extinguishers and other fire-suppression equipment are located. Learn how to use them effectively.
- Be alert and wary around any pressurized system, hydraulic or pneumatic. High-pressure oils and gases are very dangerous.

---

**Personal Safety**

---

**Equipment & Tools**

- Clean tools that are properly labeled and stored are safer tools. Keep your tools in good order.
- Keep drive belts and sheaves in good condition. Frayed belts or cracked sheaves are not only dangerous, they cost you downtime.
- Always use mechanical assistance to lift heavy loads. Never overload a hoist, crane, jack or other lifting device. Check lifting tackle regularly; replace it at the first sign of stretch, fraying or other wear.
- Keep your equipment clean, free of dirt and grease, so that loose, cracked or broken parts are more easily spotted. Replace defective parts as soon as they are discovered.

## **What is Lockout & Tagout?**

---

### **What is Lockout & Tagout?**

Lockout & Tagout is a procedure that's designed to prevent the unexpected or accidental startup of equipment and to alert all workers whenever it is unsafe to operate any piece of equipment. When used as intended, Lockout & Tagout also protects personnel from energy stored in devices such as springs, accumulators, batteries, hydraulic systems, etc.

### **When is Lockout & Tagout required?**

- Any time anyone is maintaining, repairing, lubricating, or, for whatever reason, working on the equipment.
- When the equipment is broken or, for whatever reason, unfit or unsafe to operate.
- While clearing blocked or jammed mechanisms.
- Whenever the equipment is left unattended.

### **Who must apply a lock & tag?**

- Any person working on the equipment.
- Foreman or other person responsible for the work being done.
- If several people are working on a machine at the same time, each person must apply his or her own lock and tag.

### **When can a lock and tag be removed?**

After performing these six steps:

- 1) All safety guards are back in place.
- 2) All work is complete and tools are put away.
- 3) All workers are notified that a lock is being removed.
- 4) All workers are positioned safely for startup.
- 5) Controls are positioned for safe startup.
- 6) The machine is ready for safe operation.

### **Who can remove a lock and tag?**

- Only the person who applied a lock and tag is permitted to remove them.

Lockout & Tagout rules laid out here are generic. To get instructions for your particular workplace, consult your employer's lockout/tagout procedure.

---

## Screed Safety Information

---

### Screed Safety Information

#### Training and Knowledge

Proper training and equipment knowledge is essential to the safe operation of this machine. Carefully read the entire manual before attempting to operate the paver. Keep this manual for future reference.

#### **WARNING**

Do not operate this equipment until you have been trained in its operation or maintenance. This equipment may only be operated or maintained by trained personnel, who have demonstrated their ability to do so safely.

#### Safe Paver Operation

The following safety information concerns the operation of your paver.

#### **DANGER**

- All guards and protective devices must be in place when the paver is being operated or moved.
  - Keep all personnel clear of augers when the paver is operating.
  - Do not refuel the paver with the engine or screed heater system running. All sparks and open flames must be kept a minimum of 50 feet away from the paver when refueling.
  - Do not wash or spray down the screed or tractor with the screed heater system operating.
  - Read, understand and follow all current OSHA, federal, state and local regulations that are applicable to your job and equipment.
  - This equipment must be used in accordance with all operation and maintenance instructions.
  - All persons involved with this equipment must be familiar with this manual.
  - Read, understand, and follow all Danger, Warning, Caution and instruction decals in this book and on the paver.
  - When changing the paver configuration or adding equipment to the paver, all additional guards associated with the added equipment must be installed before operating or moving the paver.
  - Any changes made to the original design of the paver must be approved by qualified personnel to ensure that the changes include appropriate guarding and provide a safe working environment for all personnel.
  - Wear clothing that fits snug to prevent getting caught in moving parts. Loose-fitting clothing should never be worn.
- Install all auger guards and vibrator covers before operating the paver.
  - Never attempt to install or remove any part or assembly when the paver is running.
  - Do not allow personnel to stand or walk between the front of the paver and the back of the truck while the paver is operating.
  - Attach screed safety cables or lower the screed before performing any inspections, repairs or adjustments to the screed.

## Screed Safety Information

---

- Mount and dismount the paver from the rear using only the steps, handrails and walkways provided.
- Do not mount the paver when it is moving.
- Allow only the operator on the operator's platform when the paver is in operation.
- Before starting the paver, make sure the brakes are ON, all other systems are OFF and all personnel are clear.
- Before leaving operator's seat, always place the brake switch ON, and all other controls or switches in OFF or NEUTRAL position.
- Reduce travel speed when going down step grades to prevent over-speeding.
- Do not allow personnel near the hopper area when the paver is running.

**CAUTION**

- Wear protective mask when harmful air pollution exists.
- Wear safety goggles, gloves and long-sleeve shirts when working near hot asphalt materials.
- Wear ear plugs while paver is running.
- Keep operator's platform, steps and screed walkways clear of all obstructions, tools and other items to prevent tripping or falling.
- To prevent fire hazards, keep the screed and engine basket area free of oil, asphalt and trash buildup.

**Screed Safety Information**

---

## Section 3 - Set Up and Operation

### Receiving New Equipment

#### Pre-Operation Check

Before accepting and unloading a new paver, the consignee must inspect the equipment for evidence of damage or missing parts. This inspection process should be thorough, because once the freight receipt is signed, it is assumed that all of the equipment listed on the receipt was received in good condition.

Make a thorough inventory of all loose components packaged in boxes. A check list is provided in each box listing the components in the box. While performing the inventory, inspect all loose components for damage which may have occurred during transit. Any damage that happens to the equipment in transit is the responsibility of the carrier **not** Cedarapids. Claims for damage must be submitted to the carrier for settlement.

When evidence of damage or loss is discovered, have the driver make a notation on both the carrier's and consignees' copies of the freight bill. Prior to signing the freight bill, take pictures of the damage and identify the truck if possible. The consignee can then sign the bill to acknowledge delivery. The consignee should then have the carrier's terminal manager or his authorized representative make an official inspection of the damage or loss.

Equipment should not be moved from the original receiving point until this official inspection has been made. Good clear photos will verify and explain damage in any claim action which may follow. When the inspection is done, the consignee should file a written damage claim with the carrier's office and should report this action to the area distributor for Cedarapids Inc.

---

### Receiving New Equipment

If hidden damage is found after the carrier's representative has gone, do not continue to unpack or move the equipment. Contact the carrier's local office and have the terminal manager or authorized representative make an immediate personal inspection of the damage. Obtain a written description of the damage, and photos if possible, signed by the representative as proof of a valid claim.

A packet of equipment warranty/start-up information will be sent to the distributor before the equipment leaves the factory. All warranty/start-up forms must be filled out and returned to Cedarapids within **24 hours** after the equipment is received.

#### Principle Of Operation

The paver will lay a uniform, high-density, asphalt mat for highways, roadways, airport runways, parking lots and driveways. It is capable of performing jobs with strict control specifications and high production requirements.

The paver will level and compact mix up to 12" in depth, with mat widths varying from 6' to 30'. Mat depth and width variations are accomplished by adjusting feed controls and adjusting the screed.

The hot mix is dumped by truck into the hopper or picked up by a windrow machine at a rate suitable for continuous paving. While dumping mix, the truck is pushed forward by the paver.

For the Slat Conveyor Paver, (Figure 3 - 1) hot mix is carried by two independently controlled slat conveyors to the augers at the rear of the tractor and in front of the screed. Material feed may be either manually or automatically regulated to maintain an even and consistent "head of material" in front of the screed. Material flow rate is regulated by a combination of varying slat conveyor speed and material gate height.

## Principle Of Operation

For the Remix Paver, (Figure 3 - 2) two sets of counter-rotating delivery augers remix the hot mix as it is conveyed to the spreading augers at the rear of the tractor. The speed of each set of delivery augers is controlled independently to maintain the proper level of material. The spreading augers

distribute material along the entire width of the screed. Material feed may be either manually or automatically regulated to maintain an even and consistent “head of material” in front of the screed.




Figure 3 - 1 Slat Conveyor Paver




Figure 3 - 2 Remix Paver

## Fume Recovery System

A strike off plate mounted directly in front of the screed bottom meters the material passing under the screed bottom. The screed rides up or floats on the mix to level and smooth the mat. Contour of the mat may be set to a desired slope with the adjustable screed controls. Screed controls are adjusted manually or automatically to create the desired mat.

The screed bottom flexes at its midpoint into a slight V-shape (negative crown) or into a slight inverted V-shape (positive crown). Such adjustment produces a negative or positive crown on mat for specified water drainage requirements.

The screed has vibrators which perform the initial “ironing” of the mat. Final compaction of the newly laid mat is accomplished by a roller.

The screed has burners that heat the screed bottom close to the temperature of the mix before paving begins. Heating the screed bottom prevents asphalt from sticking to the screed bottom which causes tearing and a poor mat surface.

The screed can be fitted with extensions or extendible strike-offs for paving wide widths or shoulders.

## Fume Recovery System

The fume recovery system is designed to collect fumes given off by hot mix asphalt and discharge them away from operator work areas. This system is standard equipment on all pavers. (Figure 3 - 3) The system is designed to collect fumes given off by asphalt mix as it is distributed along the length of the main screed by the spreading augers. The fumes are drawn into a hydraulically driven fan. The fan then blows the fumes into the engine exhaust muffler. Inside the muffler the asphalt fumes are combined with the engine exhaust and discharged through the exhaust pipe. A vacuum gauge indicates amount of vacuum generated in the fan intake manifold.




Figure 3 - 3 Fume Recovery System Overview

## Operator's Console

---

### Operator's Console

The operator's console can be positioned so that the paver can be operated from the left or right seat. To reposition the operator's console:

- 1) Lift the locking handle to release the console.  
(Figure 3 - 4)




Figure 3 - 4 Repositioning Operator's Console

- 2) Pull the operator's console toward the center of the paver. When the console is positioned vertically the centering lock will automatically engage.

**Important** - When raising the hood, the operator's console must be locked in the center position to prevent the hood from hitting console.

- 3) Step on the centering lock to release the console and position the console to the desired side of the paver.

Refer to (Figure 3 - 5) and (Figure 3 - 6) for instructions on the operator's console for Slat Conveyor Pavers and refer to (Figure 3 - 7) and (Figure 3 - 8) for instructions on the operator's console for Remix Pavers.

## Operator's Console




Figure 3 - 5 Wheeled Slat Conveyor Paver Operator's Console

- |                           |                               |                             |
|---------------------------|-------------------------------|-----------------------------|
| 1) Oil Temperature Gauge  | 13) Lights Switch             | 25) Oil Pressure Gauge      |
| 2) Voltmeter Gauge        | 14) Flasher Switch            | 26) Brake Switch            |
| 3) Mix Flow Indicators    | 15) Eng. Diag. (ON-OFF) Sw.   | 27) Water Temperature Gauge |
| 4) Hopper Switch          | 16) Range Travel Switch       | 28) Throttle Switch         |
| 5) Truck Hitch Switch     | 17) Screed Extension Switches | 29) Horn Switch             |
| 6) Gates Switch           | 18) Rear Frame Switch         | 30) Steer Assist Switch     |
| 7) N/A                    | 19) Engine Switch             | 31) Travel Joy Stick        |
| 8) Feed Override Switches | 20) Vibrators Switch          | 32) Paver Speed Pot         |
| 9) Fuel Level Gauge       | 21) Screed Lift Switch        | 33) Emergency Stop Switch   |
| 10) Alarm Indicators      | 22) Screed Assist Switch      | 34) Fuel Switch             |
| 11) Hour/Tachometer       | 23) Eng. Diag. (INC-DEC) Sw.  |                             |
| 12) Alarm Switch          | 24) Differential Lock Switch  |                             |

## Operator's Console




Figure 3 - 6 Track Slat Conveyor Paver Operator's Console

- |                           |                               |                             |
|---------------------------|-------------------------------|-----------------------------|
| 1) Oil Temperature Gauge  | 13) Lights Switch             | 25) Oil Pressure Gauge      |
| 2) Voltmeter Gauge        | 14) Flasher Switch            | 26) Brake Switch            |
| 3) Mix Flow Indicators    | 15) Eng. Diag. (ON-OFF) Sw.   | 27) Water Temperature Gauge |
| 4) Hopper Switch          | 16) Range Travel Switch       | 28) Throttle Switch         |
| 5) Truck Hitch Switch     | 17) Screed Extension Switches | 29) Horn Switch             |
| 6) Gates Switch           | 18) Rear Frame Switch         | 30) De-Tracker Indicator    |
| 7) N/A                    | 19) Engine Switch             | 31) Travel Switch           |
| 8) Feed Override Switches | 20) Vibrators Switch          | 32) Paver Speed Pot         |
| 9) Fuel Level Gauge       | 21) Screed Lift Switch        | 33) Emergency Stop Switch   |
| 10) Alarm Indicators      | 22) Screed Assist Switch      |                             |
| 11) Hour/Tachometer       | 23) Eng. Diag. (INC-DEC) Sw.  |                             |
| 12) Alarm Switch          | 24) Differential Lock Switch  |                             |

## Operator's Console




Figure 3 - 7 Wheeled Remix Paver Operator's Console

- |                           |                               |                             |
|---------------------------|-------------------------------|-----------------------------|
| 1) Oil Temperature Gauge  | 13) Lights Switch             | 25) Oil Pressure Gauge      |
| 2) Voltmeter Gauge        | 14) Flasher Switch            | 26) Brake Switch            |
| 3) Mix Flow Indicators    | 15) Eng. Diag. (ON-OFF) Sw.   | 27) Water Temperature Gauge |
| 4) Hopper Switch          | 16) Range Travel Switch       | 28) Throttle Switch         |
| 5) Truck Hitch Switch     | 17) Screed Extension Switches | 29) Horn Switch             |
| 6) Remix Switch           | 18) Rear Frame Switch         | 30) Steer Assist Switch     |
| 7) Ratio Pots             | 19) Engine Switch             | 31) Travel Joy Stick        |
| 8) Feed Override Switches | 20) Vibrators Switch          | 32) Paver Speed Pot         |
| 9) Fuel Level Gauge       | 21) Screed Lift Switch        | 33) Emergency Stop Switch   |
| 10) Alarm Indicators      | 22) Screed Assist Switch      | 34) Fuel Switch             |
| 11) Hour/Tachometer       | 23) Eng. Diag. (INC-DEC) Sw.  |                             |
| 12) Alarm Switch          | 24) Differential Lock Switch  |                             |

## Operator's Console




Figure 3 - 8 Track Remix Paver Operator's Console

- |                           |                               |                             |
|---------------------------|-------------------------------|-----------------------------|
| 1) Oil Temperature Gauge  | 13) Lights Switch             | 25) Oil Pressure Gauge      |
| 2) Voltmeter Gauge        | 14) Flasher Switch            | 26) Brake Switch            |
| 3) Mix Flow Indicators    | 15) Eng. Diag. (ON-OFF) Sw.   | 27) Water Temperature Gauge |
| 4) Hopper Switch          | 16) Range Travel Switch       | 28) Throttle Switch         |
| 5) Truck Hitch Switch     | 17) Screed Extension Switches | 29) Horn Switch             |
| 6) Remix Switch           | 18) Rear Frame Switch         | 30) De-Track Indicator      |
| 7) Ratio Pots             | 19) Engine Switch             | 31) Travel Switch           |
| 8) Feed Override Switches | 20) Vibrators Switch          | 32) Paver Speed Pot         |
| 9) Fuel Level Gauge       | 21) Screed Lift Switch        | 33) Emergency Stop Switch   |
| 10) Alarm Indicators      | 22) Screed Assist Switch      |                             |
| 11) Hour/Tachometer       | 23) Eng. Diag. (INC-DEC) Sw.  |                             |
| 12) Alarm Switch          | 24) Differential Lock Switch  |                             |

## Operator's Console

- 1) **Oil Temperature Gauge** - Indicates temperature of hydraulic fluid. If fluid temperature exceeds 180° F stop paving and determine cause.
- 2) **Voltmeter** - Indicates battery and alternator condition. (Table 3 - 1)

| Reading on Voltmeter | Engine not running or running at idle                                                             | Engine running at Full throttle                                                                                                                                                                                       |
|----------------------|---------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| less than 10 V       | Dead or disconnected battery                                                                      | Dead or disconnected battery                                                                                                                                                                                          |
| 10 V to 12 V         | Low battery charge. Constant reading in this area may indicate problems with the charging system. | A voltmeter reading below 12 volts means that the current being drawn for lights, charging the battery, solenoids, etc. exceeds the output of the alternator. Check for a defective battery or a short in the wiring. |
| 12 V to 13 V         | Well charged battery in good condition.                                                           | When the engine is started the pointer may stay in this area temporarily but should gradually rise above 13 volts as alternator reaches normal output.                                                                |
| 13 V to 15 V         | Readings in this area while the engine is not running indicate defective voltmeter.               | This is where the readings should be when the alternator and battery are in good condition and functioning properly.                                                                                                  |
| Above 15 V           | Readings in this area while the engine is not running indicate defective voltmeter.               | When the pointer goes above 15 volts, the alternator is putting out too much voltage and should be checked. Continued operation of the engine in this range will damage the battery and solenoid valves.              |

Table 3 - 1 Voltmeter indications

- 3) **Mix Flow Indicators** - Sensors on the gates cause indicator lights on control panel to light when material is not contacting sensors. Each conveyor has a separate sensor and indicator.
- 4) **Hopper Switch** - The hopper raise switch is spring-loaded to automatically return to the neutral position when released. It must be held in the "Raise" or "Lower" position to control the hopper wings.
- 5) **Truck Hitch Switch** - The optional truck hitch switch holds the truck in position at the front of the paver so little or no material is spilled after a truck is captured. The truck driver does not have to ride the brakes to stay firm against the paver.

The Truck Hitch switch is spring-loaded to return to the neutral position when the switch is released. To engage the truck, hold the switch in "Engage" until the truck is in place, then let the switch return to neutral to hydraulically lock the truck. To unhitch, place the switch in the "Release" position.

The truck hook is equipped with an adjustable needle valve on the front bulkhead which controls the speed that the truck hook engages the trucks wheels. Rotate the needle valve clockwise to reduce the engage speed and counterclockwise to engage the truck hook quicker.

## Operator's Console

---

6) **Gates Switch (Slat Conveyor Paver) -** (Standard feeder only) The hopper gates regulate the depth of mix carried to each auger. The spring-loaded switches must be held in "Raise" or "Lower" until the desired gate height is obtained. When released, the switch returns to neutral.

6) **Remix Switches (Delivery Augers, Remix Paver) -** When in "MANUAL" or "AUTO" position, delivery auger speed is controlled by the Delivery Auger Speed control (item 7). When in "OFF" position, delivery augers stop.

7) **Ratio Pots (Auger Speed, Remix Paver) -** Adjusts the speed of the delivery augers relative to the speed of the spreading augers.

8) **Feed Switch-** This is a 3-position switch. If this switch is set to "Off" (center position), the spreading conveyors or augers stop.

If this switch is set to the "Auto" position, the spreading conveyors or augers are allowed to run. Slat conveyor speed is constant. Auger speed can be regulated by the "Ratio" controls.

When this switch is in the "Override" position, the spreading conveyors or augers run at full speed unless the Screed Assist switch is in "OFF" position.

9) **Fuel Level Gauge -** This gauge displays quantity of fuel remaining in the tank(s).

### 10) Indicators

**STOP -** When lit, stop paver. Used in conjunction with the "Engine Diag." switches - Flashes twice to alert driver to an engine emergency fault diagnostic condition.

**WARNING -** When lit, investigate abnormal engine condition. Used in conjunction with the "Engine Diag." switches - Flashes twice to alert driver to an engine maintenance fault diagnostic condition.

**MAINTENANCE -** When lit, indicates engine oil low condition.

**WATER IN FUEL -** When lit, indicates that moisture has been sensed in fuel filter.

**WAIT TO START -** When lit, not all engine pre-starting conditions met. Wait to start paver, until this indicator goes out.

11) **Hour / Tachometer Meter -** Indicates engine RPM's and operating hours. Full throttle engine speed = 2100 RPM, Idle speed = 950 RPM.

12) **Alarm Switch-** When the Mix Flow Indicators light, an audible alarm sounds to make the operator aware of the problem. When this switch is activated the alarm is silenced. The audible alarm is reset each time the mix flow sensors are reactivated.

## Operator's Console

---

13) **Lights Switch**- Push up to turn headlights on “High”, down for “Low”, or center for “Off”. Work lights are turned on when the switch is in “High” or “Low” setting. A rotary switch on each work light changes light from red, white, and off.

14) **Flasher Switch**- Push up to turn flashers “On”, down to turn flashers “Off”. On 400 series pavers this switch also turns on the strobe warning light mounted in the rear center of the paver.

15) **Engine Diagnostic ON-OFF Switch** - Used to locate engine faults. When activated, will cause “Stop” or “Warning” indicator to flash on and off. Count the number of flashes to identify the fault code. Each fault code has three digits. The activated indicator flashes the number of the first digit, then the second, then the third. (For fault codes and their meanings, refer to the fault code table in the accompanying Cummins engine manual.) This is repeated for as long as this switch is ON. If no engine faults exist, with this switch on, both “STOP” and “WARNING” remain lit, until it is turned “OFF”.

16) **Range Switch** - The range switch has three positions:

Track Paver - “Travel”, “Pave”, and “Maneuver”.

Wheeled Paver - “Travel”, “P/2”, and “P/4”.

“Travel” - Both Paver types. Use for roading or traveling around the job site.

“Pave” - Track Paver. Use for straight paving.

“Maneuver” - Track Paver. Use for paving on a curve.

“P/2” - Wheeled Paver. Use the “P/2” position for paving in normal drive.

“P/4” - Wheeled Paver. (If paver not equipped with this option, it operates the same as for “P/2”.) Use the “P/4” position to change to front wheel assist. Engaging the optional front wheel assist will reduce the paver speed by 30%.

The paver must be stopped before changing from “Travel” to “Pave”, “P/2”, or “P/4”, or back the opposite way.

### **WARNING**

Failure to stop the paver before changing from “Travel” to “Pave”(“P/2 or “P/4”), or the opposite way, could result in serious injury to anyone riding the paver.

17) **Screed Extension Switches**- Used on Stretch model screeds to extend or retract the extensions. On Fastach screeds this switch is used to extend or retract the optional hydraulic sloping strike-off extension.

18) **Rear Frame Switch** - Push up to “Raise” the rear of the paver, down to lower the rear of the paver.

This switch allows the operator to elevate the rear of the tractor to give maximum ground clearance for loading the paver or traveling over rough ground or obstacles. For additional traction during paving, set the clearance at about the halfway point.

When using a heavy screed with extensions or other heavy accessories, it may be necessary to lower the screed to the ground before engaging the Frame Raise system.

---

**Operator's Console**

---

- 19) **Engine Switch** - The engine will start only if the brakes are engaged, the travel lever/switch is in neutral, and the Master Key is "On".
- 20) **Vibrators Switch** - The vibrator switch will function only when the travel lever/switch is forward. Push up to turn vibrators "On", down to turn vibrators "Off".
- 21) **Screed Lift Switch** - Push up to "Raise" the screed, down to "Lower" the screed, or center for "Neutral". After the screed is raised to the desired height and the switch is released, it returns to the hold position. The screed is hydraulically locked at that height. While paving, the switch must be set in the "Lower" float position.
- 22) **Screed Assist Switch** - Pavers equipped with power extending screeds (Fastach II, Stretch 16, Stretch 18, Stretch 20) have a Screed Assist system that allows adjustment of the screed bearing pressure on the mat. Once turned on, the screed assist should be left on. Do not switch the screed assist on and off while the paver is in motion. The screed assist should only be turned on when the screed is resting on the ground and should be turned off prior to raising the screed.

**NOTICE**

If the screed is raised when the screed assist switch is in the ON position the screed could drop suddenly, seriously damaging the screed.

- 23) **Engine Diagnostic (INC-DEC) Switch** - This spring-loaded switch incrementally or decrementally identifies multiple faults, using three-digit coded, unique, numerical flashing for each, identified fault. It is used in conjunction with the Eng. Diag. ON-OFF switch, (15) above, to identify multiple faults. Pushing it to INC, advances fault identification from the initial fault code to the second one. This remains true, until the switch returns to the mid position. Pushing it a second time advances it to a third fault. This can be repeated, until all individual fault codes have been flashed. Letting the switch return to the mid position and pushing it up again after all fault codes have been flashed causes the last fault code to be repeated. After fault codes have been incremented beyond the initial one, pushing the switch down to the DEC position causes the fault codes to be decremented, one at a time, in the same way as for the INC switch position.
- 24) **Differential Lock Switch** - (Wheeled paver) In wet or slick conditions one wheel could lose traction and begin to spin. By activating the optional differential lock switch, both rear wheels will rotate at the same speed regardless of how much traction each wheel has.
- 24) **Override Switch** - (Track paver) When pushed forward and held, overrides travel switch direction command, and enables opposite direction travel, in case of de-tracking. Opposite-direction movement is enabled only for as long as this switch is held in the forward position.
- 25) **Engine Oil Pressure Gauge** - Indicates engine oil pressure. Minimum oil pressure = 5 psi. Engine will shut down if engine oil pressure falls below 5 psi and the permissive start switch is not engaged.

## Operator's Console

---

26) **Brake Switch** - The brake switch engages and releases the brakes. Brakes will not release until sufficient system pressure is built up and the switch is set to the "Release" position. Do not use for routine braking. Use only for parking and emergency stops.

27) **Water Temperature Gauge** - Indicates engine coolant temperature. Normal operating temperature = 205° F. Engine will shut down if engine coolant temperature exceeds 223° F.

28) **Throttle Switch** - The engine has only two speeds. Use "Idle" to start and warm up the engine, hydraulic oil, and screed. Use "Full" position for all other functions. Switch to "Full" only after engine and hydraulic oil have warmed up.

29) **Horn Switch** - Push up to sound the horn. When the switch is released, it will return to the "Off" position.

30) **Steer Assist** - (Wheeled paver) The steer assist switch is spring-loaded to return to center. When the switch is activated to one side or the other, the system slows the inside rear drive motor while continuing to drive the other motor at regular speed. This has the effect of abruptly steering the paver in the direction the switch is pushed.

30) **De - Tracked Indicator** - (Track paver) Indicates when paver de-tracked condition/correction situation exists.

31) **Travel Lever** - (Wheeled paver) Moving the lever forward or back moves the paver in the desired direction. Speed is increased as the lever is moved more forward or reverse. This provides a smooth start and eliminates sudden shocks to the hydraulic system.

31) **Travel Switch** - (Track paver) Moving the switch forward or back moves the paver in the desired direction.

32) **Paver Speed** - This dial is used to govern the maximum travel speed of the paver. The travel lever (wheeled paver) provides variable speed up to the setting on the speed dial.

Maximum speed for the wheeled paver is about 150 feet/minute paving speed (46 meters/minute) and about 12 miles/hour travel speed (20 km/hour).

The track pavers have a maximum paving speed in excess of 150 feet/minute and a maximum travel speed of about 5 miles/hour (9 km/hour) for steel track. The rubber track paver maximum travel speed is about 10 miles/hour (16 km/hour). A setting of five will be about half maximum speed.

With the Max Paver Speed dial at zero and travel lever/switch forward, the paver should not move. This is used to test the auxiliary systems.

33) **Emergency Stop Switch** - This push-button switch, when activated, immediately shuts down all paver systems.

34) **Fuel Switch** - (Wheeled paver) This switch transfers fuel flow and fuel level indication between the left and right-hand fuel tanks.

## Optional Equipment

### Optional Equipment

#### Screed Extension

Screed extensions are furnished in 6", 12", 24" and 36" lengths which make it possible to pave widths up to 30'. Both screed and auger extensions can be quickly attached. It is recommended that auger extensions be 1' less than the screed extensions used. For example; with a 1' screed extension no auger extension is needed, with a 2' screed extension use a 1' auger extension, etc. (Figure 3 - 9)




Figure 3 - 9 Screed Extension

#### Slopeable Hydraulic Strike-off Extension

Hydraulic strike-off extensions are ideal for parking lots because they reduce or eliminate handwork to bleed out material at driveways, tapers, flush-to-wall work, etc. This reduces the need for extra passes which saves time and makes any paving operation more profitable.

These strike-offs provide a level surface and constant mat depth extendible up to 4' on each side. Strike-off blades are easily adjusted to match main screed strike-offs. Hydraulic slope adjustment simplifies laying drainage contours and other special applications. (Figure 3 - 10)




Figure 3 - 10 Slopeable Hydraulic Strike-off Extension

#### Truck Hook

The truck wheels ride against the push rollers which pushes the truck ahead of the paver. To prevent the truck from pulling away from the paver while moving down a hill, retractable rollers hook into the inside of the truck wheels. (Figure 3 - 11)




Figure 3 - 11 Truck Hook

### Bevel Guide Plate

The adjustable bevel plate bolts to screed end plate to assure a smooth sloping contour on the edge of the mat. Two plates are available: one for 1-1/2" depth and one for 3" depth with bevel angle at 45°. (Figure 3 - 12)




Figure 3 - 12 Bevel Guide Plate

### Automatic Grade and Slope Control

The grade and slope control enables the paving contractor to lay uniform and smooth mats automatically, regardless of irregularities in the roadway. It also provides precise slope angle for curves in roadway.

## Optional Equipment

### Topcon Grade and Slope Control

The Topcon grade and slope control system includes sonic grade sensors and a pendulum slope sensor to maintain the desired mat profile. (Figure 3 - 13)




Figure 3 - 13 Topcon Grade and Slope Control

### Night Lighting Kit

This kit includes four high pressure sodium lamps and a separate generator to light up the work area at night. (Figure 3 - 14)




Figure 3 - 14 Night Lighting Kit

## Optional Equipment

### Grade Reference Ski

Two grade reference ski systems are available; the multi-foot ski and tube ski. The skis are available in 20', 30', and 40' lengths. Skis travel along an existing road surface sensing changes in grade while averaging out bumps. The tube ski consists of a single tube section which rides directly on the road surface. The multi-foot ski consists of a main beam supported by several skid plates. Each skid plate is spring mounted to provide independent movement over irregular surfaces. As the ski passes over bumps, each skid plate is deflected independently, while the main beam maintains a constant level. This allows the screed to produce a mat with minimal bumps. (Figure 3 - 15)




Figure 3 - 15 Multi-Foot Ski

The over-the-screed ski uses the multi-foot or tube ski in front of the screed to sense changing grade and a skid plate that rides behind the screed on the new mat surface. This system produces the smoothest mat surface by “averaging” the grade of the existing road surface and the newly laid mat. (Figure 3 - 16)




Figure 3 - 16 Over-the-Screed Ski

### Material Retaining Plates

Two-foot (2') Material Retaining Plates are mounted to the paver frame and extend out toward the end gate during wide width paving. They limit the amount of material that builds up in front of the auger. When auger extensions up to Three feet (3') are added to either side of the paver, a retaining plate support brace is attached to the screed pull arm. When four feet (4'), or more (3ea. 1-ft. sections), extensions are used, an extra support brace is added. (Figure 3 - 17)




Figure 3 - 17 Material Retaining Plates

## Auger Extensions

As extensions are added to the screed or when a screed or strike-off is extended, auger extensions must be added to move material out the full width of the screed. Auger extensions are available in one, three, and five-foot lengths. (Figure 3 - 18)




Figure 3 - 18 Auger Extensions

## End Gates

End Gates are mounted on the end of the screed, extension, or extendable strike-off. They prevent material from spilling out beyond the reach of the screed and form a good edge on the mat. (Figure 3 - 19)




Figure 3 - 19 End Gates

## Optional Equipment

### Cutoff Shoe

Standard cutoff shoes attach to the screed end gate when paving at less than the full width of the screed. The shoe can be adjusted in 1-1/2" increments. (Figure 3 - 20)




Figure 3 - 20 Cutoff Shoe

### Front Wheel Assist

Gives paver up to 50% more tractive effort with the flip of a switch on the operator's control panel on the Wheeled Paver. (Figure 3 - 21)




Figure 3 - 21 Front Wheel Assist

## Optional Equipment

### Proportional Material Feed control

A mechanical wand measures the height of the material and adjusts conveyor speed as needed to maintain a uniform head of material in front of the screed. (Figure 3 - 22)




Figure 3 - 22 Proportional Feed Control

### Sonic Feed control

Adding a Sonic control further automates material feed to the auger. Weather-resistant sensor unit uses sound pulses to measure material height at the auger. Material delivery is regulated to maintain a uniform material head. (Figure 3 - 23)




Figure 3 - 23 Sonic Feed Control

## Starting the Engine

### Starting the Engine

- 1) Make sure all personnel are clear of the paver and aware that the paver is going to be started.
- 2) Set the Master Switch to the ON position. The Master Switch can be accessed through an access door in the hood on the left side of the operator platform. (Figure 3 - 24) “Wait To Start” indicator becomes lit.




Figure 3 - 24 Master Switch Platform Location

- 3) Set the console switches and controls as follows:

|                                        |               |
|----------------------------------------|---------------|
| Left and Right Feed Conveyors          | Off           |
| Vibrators                              | Off           |
| Screed Assist                          | Off           |
| Range - Track Paver<br>- Wheeled Paver | Pave<br>P/2   |
| Brake                                  | Engage        |
| Throttle                               | Idle          |
| Rear Frame                             | mid-position  |
| Paver Speed                            | “Min.”        |
| Travel Direction                       | “N” (neutral) |

Table 3 - 2 Prestart switch settings

### NOTICE

The engine will not start if the console switches are not set as indicated in Table 3 - 2 .

- 1) After the “Wait To Start” indicator goes out, push the spring-loaded Engine Start/Stop switch up. Engine will start cranking. If the engine does not start after 30 seconds, release the switch, and let the starter cool down before cranking the engine again.
- 2) Once the engine starts, release the Engine Start/Stop switch - Switch returns to the mid-position..

After engine start, allow it to idle for at least 5 minutes to warm up before bringing the engine to full throttle.

### Engine start-up after stall

Under certain conditions the engine could stall while under load.

### CAUTION

Attempting to restart the engine immediately after it stalls, could overload and damage the starter.

If the engine stalls under load, allow 5 to 10 minutes for the hydraulic system pressures to “leak down” before trying to restart the engine.

## Starting the Engine

### Jump-Starting/Charging Batteries

#### ⚠ WARNING

Batteries give off explosive hydrogen gas when charging. Keep flame and sparks away from the battery while jump-starting or charging.

#### NOTICE

452/462 pavers use a 12-Volt electrical system. When jump starting or charging the paver, make sure to use a 12 Volt power source.

- 1) Raise the hood. Refer to the Raising the Hood section in this manual.
- 2) Connect the jumper cables to the power source. (Figure 3 - 25)




Figure 3 - 25 Jumper Cable Connection Points

#### ⚠ WARNING

It is critical that the last cable connected and the first cable disconnected be the negative (-) cable. Make the negative (-) cable connection as far away from the battery as possible. Connecting and disconnecting jumper cables or a battery charger to and from a battery could cause a spark and ignite the hydrogen gas that is produced by the battery.

- 3) Connect the positive (+) cable to the positive (+) battery terminal or power terminal on the hood raise power pack motor.
- 4) Connect the negative (-) cable to the paver frame away from the battery. The negative (-) cable should always be connected away from the battery.
- 5) As soon as the engine starts, remove the jumper cables.

### Emergency towing

If your paver becomes disabled, and the engine can not be started, it may be necessary to tow the paver. Pavers have a parking brake that automatically engages anytime the engine is not running. Before towing a paver, the brakes must be released, and the travel pumps put into bypass.

#### ⚠ WARNING

Read all of the towing instructions before starting this procedure.

## Starting the Engine

### **⚠WARNING**

Block or restrain the paver before releasing the brakes. Failure to block or restrain the paver could result in serious injury or death.

### **⚠WARNING**

When towing the paver using the following procedure, the paver will not have drive, braking, or steering control. Do not travel down steep grades which could cause the paver to collide with the towing vehicle.

#### **Slat Conveyor Pavers:**

- 1) Loosen bypass locking nut with 1-1/16" wrench (middle hex nut on bypass/multi-function valve). (Figure 3 - 26)
- 2) Insert an allen wrench into the internal hex.
- 3) With 1-1/4" wrench, hold the large hex portion of bypass/multi-function valve from rotating.
- 4) Open both travel pump bypass valves by rotating allen wrench 3 turns counter clockwise.




Figure 3 - 26 Travel Pump Bypass Valves (Slat Conveyor)

## Starting the Engine

### Remix Pavers:

- 1) Insert an allen wrench into the internal hex of each system check relief valve plug and remove plugs. (Figure 3 - 27)
- 2) Remove valve poppet assemblies from each port and set aside in a clean, safe place.
- 3) Reinstall plugs on each port.
- 4) (Not used.)




Figure 3 - 27 Travel Pump Bypass (Remix)

### All Pavers:

- 5) Disconnect tube from brake solenoid valve located on rear bulkhead, right hand side. (Figure 3 - 28) Place a cap on the valve fitting to keep dirt out of the hydraulic system.




Figure 3 - 28 Preparing to release brakes

- 6) Attach a porta-power to open hose end and pump the pressure up to at least 350 psi to release the brakes. (Figure 3 - 29) The brakes can be reapplied by releasing the pressure at the porta-power.




Figure 3 - 29 Releasing Brakes with Porta-power

## Loading/Unloading

### NOTICE

Maintain a minimum of 350 psi to fully release the brakes. Do not exceed 1500 psi.

### WARNING

Use a chain in good condition that is capable of pulling the paver.

- 7) Open the front conveyor bearing covers.
- 8) Run the chain through the holes shown. (Figure 3 - 30)




Figure 3 - 30 Attaching chain for towing

### NOTICE

Attaching chains to the push roller frame or truck hook frame could result in serious and expensive damage.

- 9) Slowly apply tension to chains to start paver moving. Move the paver at a very slow walking pace.

### NOTICE

Pulling the paver faster than 25 feet per minute can result in serious and expensive damage to the travel system.

- 10) When the paver is in desired location, release the pressure at the porta-power and reconnect the hose to the brake valve.
- 11) Close the travel pump bypass valves by rotating clockwise until snug against seat. (Figure 3 - 26)
- 12) Tighten lock nuts.

## Loading/Unloading

### Driving the Paver off a Trailer

The paver can be loaded or unloaded from various kinds of trailers. When loading or unloading a paver the clearance from the ground to the auger or screed becomes a concern. Some trailers will require construction of a ramp long enough so the augers or screed will not drag on the ground.

### NOTICE

Always use the frame raise system to raise the rear of the paver as high as possible before loading or unloading the paver. The screed or augers could be damaged if they drag on the ground.

Pavers have a Frame Raise feature which allows the rear of the paver to be raised during loading and unloading. The paver should be raised as high as possible for maximum ground clearance during loading or unloading. (Figure 3 - 31) and (Figure 3 - 32)




Figure 3 - 31 Sufficient ground clearance




Figure 3 - 32 Insufficient ground clearance

The screed should always be raised and the screed lock hooked when loading or unloading the paver. If the paver cannot be loaded or unloaded without the screed dragging the ground, the screed can be removed.

### NOTICE

If the screed is removed, carefully watch the augers to make sure they do not drag on the ground during loading and unloading.

### NOTICE

All constructed ramps must be capable of supporting the total machine weight.

## Loading/Unloading

### NOTICE

Rubber Tracks can be damaged by sharp objects on the surface of ramps or trailer when loading and unloading.

To move the paver on or off a trailer:

- 1) Remove all chains and binders from the paver frame.
- 2) Start the engine.
- 3) Raise the screed and hook the screed lock.
- 4) Use the frame raise system to elevate the rear of the paver as much as possible.
- 5) Have a person on the ground to help guide you on or off the trailer.
- 6) Set the Pave/Travel switch to Pave (P2 on rubber tired models) and Speed Dial to 0.
- 7) Bring the engine to Full throttle.
- 8) Place the brake switch in the Release position.
- 9) Place the Travel Direction switch in the direction needed.
- 10) Slowly increase the setting on the speed dial until the paver starts moving. It is safer to use a slow speed while loading or unloading.

You can use the brake switch to engage the brakes in an emergency.

## Loading/Unloading

### ⚠ WARNING

If the brakes are used to stop a moving paver, the paver will stop suddenly. The brakes should be used to stop the paver only in an emergency.

### Lifting With Crane

Ensure the crane and cables to be used are capable of safely supporting the total machine weight.

Attach one cable to each of the two lifting points on the rear of the paver. (Figure 3 - 33) Loop a chain through the lifting eyes at the front of the paver and attach it to the crane hook. (Figure 3 - 34)

The two rear cables must be of equal length and the front cable/chain must be adjusted to two equal lengths.




Figure 3 - 33 Rear lift points




Figure 3 - 34 Front lift points

### ⚠ WARNING

Each lifting cable must be hooked to the crane hook independently. (Figure 3 - 35) Do not loop a single lifting cable through the crane hook and back to a second lifting point.




Figure 3 - 35 Attach cables correctly

Attach the lifting device to the integrated screed lock. (Figure 3 - 36)




Figure 3 - 36 Screed Lock

Raise the screed - the lock engages automatically when the screed is fully raised.

To lower the screed, step on the screed release pedal.

**CAUTION**

Do not run the paver engine while lifting the paver by a crane.

## Preparation for transport

- 1) Load the paver onto the trailer or truck.
- 2) Lower the screed onto blocks at each end and in the center of the screed. (Figure 3 - 37) Never set the screed on nails, rivets, or bolt which could damage the screed bottom.

## Preparation for transport




Figure 3 - 37 Set screed on blocks

- 3) Use the frame raise switch on the operators console to lower the rear of the paver as much as possible.
- 4) Use chains and chain binders to tie the paver down in the front (Figure 3 - 38) and rear (Figure 3 - 39) of the paver.

Chaining directly to the screed, truck hook, or tow arms could damage the equipment. All chains should be secured to the paver frame only.




Figure 3 - 38 Front tie down points




Figure 3 - 39 Rear tie down points

## Preparing to Pave

### Preparing to Pave

#### Fume Recovery System

The fume recovery system is designed to collect fumes given off by hot mix asphalt and discharge them away from operator work areas.

(Figure 3 - 40). The system is designed to meet minimum emission standards.

Automatic feed sensor mounting hole covers can be removed to install a proportional feed sensor. If a proportional sensor is not used, the mounting hole covers should be reinstalled.

The fume recovery fan starts automatically when the engine is started and continues to run while the engine runs. The vacuum indicator should be checked each day before starting paving. The indicator should register a vacuum reading with engine running at full throttle. A low or no reading indicates a malfunction in the system. Refer to Section 6 for troubleshooting.




Figure 3 - 40 Fume recovery system

## Preparing to Pave

### Nulling Screed

#### NOTICE

The following is partial information on setting up the screed. The Quality Paving Guide should be read completely and be kept with the paver for reference on setting up the screed.

Typically, when a screed is nulled, its angle of attack is adjusted to 0 in relation to a specific depth. This is traditionally done with the use of boards that equal the desired loose mat depth. Then a given amount of nose up attitude is introduced to the screed. The procedure is as follows:

- 1) The boards needed should be equal to the thickness of the loose or unrolled mat. The number needed will depend on the width at which the screed is set up to pave. Generally two (2) boards at 10' wide, four (4) boards at 20', etc. The length of each board should be such that the screed bottom is fully supported from front to tail when set on the boards.
- 2) Place the boards under the screed as illustrated. Attention should be placed on the grade conditions where the boards will be placed. If a board is placed on a high point or a depression, a false null setting will occur. Additional boards may be needed if you are paving at extended widths to provide support for the screed extensions. (Figure 3 - 41)
- 3) Place the screed lift switch in LOWER position. The screed will lower down and rest on the boards.
- 4) Turn both manual depth cranks on the screed until the screed face is resting flat on the boards. When the screed is resting flat on the boards the hand cranks will have a small area of free rotary movement where little resistance is felt. This indicates a null position.
- 5) After the screed has been nulled, we need to introduce a nose up attitude (initial angle of attack) on the screed. The amount of initial angle of attack is dependent on material design, temperature of material, head of material, tow point position and type of screed. Refer to these subjects for more information. Generally, the amount of initial angle of attack required will be 1 to 2 turns of clockwise rotation on the hand cranks. As paving begins, check the depth of the mat being placed and correct for as necessary. As most contractors work with a limited number of mix designs, the paver crews quickly learn the exact amount of initial angle of attack needed for specific mix designs.




Figure 3 - 41 Nulling the Screed

## Joints

There are two types of joints that are constructed in a paving operation, Longitudinal and Transverse. Proper construction of these joints is important not only in producing a smooth rideable surface but also in how they resist penetration of water, air and other substances that would cause a premature failure of the joint. (Figure 3 - 42)




Figure 3 - 42 Types of Joints

## Transverse Joints

Transverse joints are created when an existing mat or lane is to be continued. The quality and durability of the joint depends on careful preparation of the existing mat or lane. It is critical that any taper or defective area be removed.

### NOTICE

The joint area has to be perfectly flat and parallel with the line of paving. If it is not, a depression or bump will be produced.

## Joint Preparation

The following illustration shows, how an existing mat is checked and the tapered area removed to produce a joint area that is flat and parallel with the line of paving. (Figure 3 - 43)

## Preparing to Pave




Figure 3 - 43 Joint Preparation

## Joint Construction

The next step to proper joint construction is placing boards or lath that equal the amount of compaction in the joint area. (Figure 3 - 44) Remember compaction rates change due to thickness of material & material design. Once the compaction rate has been determined and the correct thickness of lath has been acquired, place the lath at the edge of the joint to elevate & support the screed to the correct starting level.




Figure 3 - 44 Matching existing mat

The screed should be preheated to the temperature of the material being used. A cold screed will not only tear the surface of the mat being placed but will also have a tendency to come off the joint low, creating a depression in the mat. Do not over heat the screed bottom, as this will damage or warp the screed bottom.

Back the paver up over the joint and align the screed (Figure 3 - 45), so the face or mold board is square with the edge of the joint. Lower the screed onto the boards or lath and null the screed. Perform Nulling Screed procedure on page 28.




Figure 3 - 45 Aligning screed over joint

Once the screed has been nulled and the initial angle of attack has been introduced, the auger chamber should be filled to no more than 1/2 an auger level. Do not over fill the auger chamber, as this is the most common cause of creating a bump just after pulling off a joint. If needed the corner areas on the ends of the screed should be hand filled to prevent force feeding an excessive high head of material in the center areas of the screed.

After filling the auger chamber to the correct level, move the paver forward slowly, allowing the screed operator time to check and correct the depth if necessary. The feeder controls should be set to auto, and feed sensors checked and set to maintain the correct head of material. Once the paver has moved away from the joint area, the joint can be checked and prepared for rolling. The excess or over lap material must be removed, as this material can not be compacted into a cold or existing mat. (Figure 3 - 46) Do not shovel this overlap material back onto the fresh mat as this extra material might not be compacted down to the same height as the rest of the joint. This could create a bump.

## Preparing to Pave




Figure 3 - 46 Removing overlap material before rolling

Once the over lap material has been removed, the joint should be checked with a good straight edge to ensure the thickness of the new mat is correct. If the new mat does not have enough material thickness at the joint when it is rolled, the density in the area where the new mat joins to the old mat will be low. This could cause a premature joint failure. If there is too much material in the joint area a bump will be produced.

## Rubber Track Operating Hints

### Rubber Track Operating Hints

The following are some specific considerations for operation of asphalt pavers equipped with rubber tracks. While not all-inclusive, following these recommendations should reduce the risk of problems and improve rubber track durability and reliability. (Figure 3 - 47)

### Do Not Allow Asphalt Build-up on Track

During paving, asphalt sometimes flows down to the rear drive wheel and become packed between the track and wheel. This may cause the following problems:

- Oil in the asphalt will cause the rubber in the track to soften and reduce the durability.
- Aggregate will abrade the rubber in the track and shorten its life.
- Asphalt material build-up in the undercarriage will cause additional tension on the track.




Figure 3 - 47 Asphalt on Track & Wear

## Rubber Track Operating Hints

---

### Proper Installation of Material Retaining Plates

Machines are shipped with the material retaining plates as shown in (Figure 3 - 48). To work properly, the plates must have the bottom edge of the plate below the bottom edge of the machine frame bulkhead and be extended.



Figure 3 - 48 Material Plate As Shipped

Before paving begins, loosen nuts, slide plate out from frame and re-tighten nuts to hold plate in position. (Figure 3 - 49)



Figure 3 - 49 Material Plate Extended Maneuvering On Hot Asphalt

## Rubber Track Operating Hints

### Maneuvering On Hot Asphalt

Pavers are not normally operated on newly paved hot asphalt as it will damage the surface of the mat. (Figure 3 - 50) There may however be certain conditions when this becomes unavoidable. If it is necessary to drive on newly paved asphalt, be aware this could be problematic.




Figure 3 - 50 De-tracking

## Rubber Track Operating Hints

Generally, “de-tracking” occurs when the paver turns. If rubbing marks are noted on track frame, check track inner surfaces for signs of scarring caused by temporary de-tracking. To avoid “de-tracking”, it is recommended:

- **Do not turn on or near hot asphalt.** Move to a cold area and turn there. If turning on the hot asphalt is necessary, use forward as much as permissible and keep the turn gradual in as large an arc as possible. Maneuvering should be done at as slow a speed as possible.
- **Do not park on hot asphalt.** (Figure 3 - 51) High temperature can deteriorate the track rubber. It is recommended to remain on the hot area of asphalt **no longer than twenty (20) minutes.**




Figure 3 - 51 Do Not Park On Hot Asphalt

## Rubber Track Operating Hints

### Maneuvering On Uneven Surface

Uneven terrain such as curbs, concrete ridges or joints of paved and unpaved surfaces (step in elevation) may affect machine maneuverability. One concern is the stress concentration caused by the sharp edges of the surface and another is when a track is parallel to an edge. (Figure 3 - 52) and (Figure 3 - 53)

### CAUTION

If a turn is attempted on an edge, track damage or “de-tracking” could occur.




Figure 3 - 52 Steps in Elevation & Uneven Surfaces

- Do not turn on or near sharp edges of uneven surfaces.** It is best to make a turn while on an even surface. If a turn is made with a portion of the track on an edge or the track comes into contact with an edge during the turn, it could cause a cut, tear, or even “de-tracking”. If this situation is unavoidable, keep the turn gradual in as large an arc as possible, at slow speed, in forward and with a spotter to watch the track safety.
- Do not approach a step in elevation at a sharp angle.** If it is necessary to move from one level of elevation to another, it is recommended the approach angle should be more than 45 degrees. The best method is to go perpendicular to it.
- Do not park on a step in elevation.** When parking, make sure the tracks are not resting on an edge or any sharp object. This may cause damage to the track.

## Rubber Track Operating Hints




Figure 3 - 53 Damage From Steps in Elevation & Uneven Surfaces

## Rubber Track Operating Hints

### Maintenance of Track

To maintain and preserve the life of the rubber track it is important to follow these recommendations:

- **Do not use solvents to wash the rubber track.** Solvents including kerosene, gasoline, diesel fuel, or oils cannot be used to wash the surface of track rubber. The track rubber absorbs these solvents and will gradually soften and reduce its durability. Soap and water are recommended for cleaning the rubber track.

### NOTICE

If you scrape the rubber track surface to clean it, be careful to not damage or cut it when cleaning.

- **Covering track for long term outdoor storage.** Rubber is affected by exposure to sunlight (ozone). Covering the track with something like a vinyl sheet if the machine is idle for an extended length of time, such as over Winter, will help keep the surface in good condition. (Figure 3 - 54) This is especially true where the rubber is bent and stretched around wheels.




Figure 3 - 54 Cover Track for Outdoor Storage

## Rubber Track Operating Hints

- **Releasing Paver Track Tension for long term storage.** As is true for covering the track, releasing the track tension when the machine is idle for an extended length of time, such as over Winter, will prolong its life.

### NOTICE

Before releasing track tension, make sure machine is parked on level ground.

- 1) Shut off engine and remove key from ignition.
- 2) Loosen jam nut on tension release valve cartridge (Figure 3 - 55).
- 3) Insert an allen wrench into the adjusting screw, slowly turn it counter-clockwise to open the valve and release hydraulic pressure.




Figure 3 - 55 Release 400 & 500 Series Rubber Track Tension

- 4) Insert an allen wrench into the adjusting screw and turn it clockwise to close the valve.
- 5) Tighten jam nut on tension release valve cartridge (Figure 3 - 55).
- 6) Repeat for the other track.

The 400 and 500 series pavers will require the tracks to be re-tensioned after removal from long term storage. They are automatically tensioned when the engine is started. See procedure in Section 6.

- **Check track alignment.** Rubber track undercarriage component alignment is very important to the life of the track. An easy, quick check is to inspect the track center lugs. (Figure 3 - 56) If one side is worn more than the other side, one or more of the following conditions could exist. Factors such as asphalt build-up on the track inner surface, road crown, track tensioning, etc. If any of the above is present, correct the situation before excessive track wear occurs.



Figure 3 - 56 Rubber Track Alignment

- **Visual Inspection.** Unlike pneumatic tires, the rubber track is not as sensitive to chippings and cracks on the surface unless they extend to the separation of rubber from belt. The rubber track is not a 100% maintenance free product. The following items will be helpful to maintain and inspect your rubber tracks: (Figure 3 - 57)
- 1) Record track serial numbers.
  - 2) Record the date and hour meter reading when you mount tracks on machine.
  - 3) Periodically check condition of tread, guide lugs, and inner surface for wear, cracks, chipping and chunking.

## Rubber Track Operating Hints

- 4) Periodically check that any steel cable or ply cord are not exposed.
- 5) Periodically check that track is properly tensioned. A loose track could cause de-tracking. (Refer to Tension information in the Operation and Maintenance Manual.




Figure 3 - 57 Rubber Track Identification

You may use the following table (Table 3 - 3) to record the information off the tracks on your machine.

| Data                  | Right    | Left     |
|-----------------------|----------|----------|
| Machine Serial Number |          |          |
| Hour Meter Reading    |          |          |
| Date of Track 1st Use |          |          |
| Track Width           |          |          |
| Number of Pitches     |          |          |
| Pitch                 | 6 inches | 6 inches |
| Track Serial Number   |          |          |

Table 3 - 3 Rubber Track Data

## Spray Down and Cleaning

### Spray Down and Cleaning

#### Paver Cleaning Procedure

Cleaning the paver is extremely important to keep the chains and augers free and prevent build-up of asphalt. Clean the paver thoroughly each day or any time the paver will be stopped for an extended period of time.

#### NOTICE

Hot mix gets hard quickly. Do not allow mix to cool in the hopper. Run remix augers to remove all material from the hopper any time the paver will be stopped for an extended period of time.

#### ⚠ WARNING

Use only environmentally safe solvents to clean paver.

#### ⚠ WARNING

Do not spray solvent in the presence of open flame, sparks, welding arcs, etc. A serious fire or explosion could result.

#### NOTICE

Keep solvent spray away from all electrical components, rubber parts and engine compartment. Do not spray the paver when it is parked on the mat. Move it to the side of the road for drainage of solvent and dissolved mix. Avoid spraying rubber

hoses, cables, tires and/or rubber tracks with solvent as this may cause premature deterioration.

- 1) Run slat conveyors/remix augers until all mix is out of the hopper. Remove any piles or large chunks of mix from the paver and screed.
- 2) Clean all parts which come in contact with hot mix. The paver must be completely cleaned, even if the paver was used for a short time.
- 3) Start cleaning at the truck hook/push rollers and work your way to the rear of the machine cleaning the hopper wings, slat conveyors/remix augers, hopper gates, spreading augers, screed bottom, end gates, strike-offs, etc. (Figure 3 - 58)




Figure 3 - 58 Shaded areas to be sprayed down daily

## Spray Down and Cleaning

- 4) Operate slat conveyors/remix augers during spray-down, to be sure all surfaces are cleaned.
- 5) Spray down surfaces that have come in contact with asphalt. Refer to Section 6 for information on when and how to clean fume recovery system fan and/or tubes.
- 6) If a mechanical feed sensor is used, clean the wand with solvent and wipe any asphalt off of the feed controller with a cloth dampened with solvent. (Figure 3 - 59)




Figure 3 - 59 Mechanical feed sensor

- 7) Every time the paver is cleaned, the steel track should be cleaned and sprayed with light oil to lubricate the track pins to prevent them from rusting and binding.

### Generation III Sonic Sensor Cleaning

- 1) Inspect the sensor daily for damage and material buildup. The sensor must be kept clean in order for the sonic control to function properly. The sensor is easily cleaned and if cleaned routinely, problems can be minimized.
- 2) Before cleaning, turn off power to the sonic control. Disconnect sensor cable from control unit and remove sensor from its mount. Install protective caps on all electrical connectors.

### NOTICE

Using a sharp or solid object to scrape material from transducer could damage the sensor. Damage to the transducer requires replacement of the complete sensor. The sensor is permanently sealed and can not be repaired.

- 3) Check transducer daily for material buildup. The transducer can be cleaned with Simple Green cleaning fluid. Place cleaning fluid on a clean rag and rub transducer gently to remove any material. Wipe transducer clean and dry. (Figure 3 - 60)




Figure 3 - 60 Cleaning sonic sensor

### Pressure Cleaning

The entire paver can be pressure-washed to remove dirt and grease. When pressure washing the paver:

- 1) Do not use a steam cleaner. Steam cleaning can damage seals, bearings, gearboxes, and electrical components.
- 2) Do not use an acid-based solvent with the pressure washer. Use only mild detergents or degreasers.

## **Spray Down and Cleaning**

---

- 3) Do not spray directly at electrical components, seals, bearings, gearboxes, or hydraulic cylinder rods. Water can be forced into electrical connections or the hydraulic system which could damage the system.
- 4) Do not spray the screed or engine until it is cool. Spraying a hot screed bottom with cold water could warp the screed bottom. Spraying cold water on a hot engine manifold could crack the manifold.
- 5) Use extreme caution when spraying in the engine compartment. The engine compartment is full of electrical and hydraulic components which could be damaged by high pressure water. Use a commercial engine cleaning foam to remove dirt and grease from the engine compartment.
- 6) If you must spray near electrical or hydraulic components, cover the components before spraying.

## Section 4 - Electrical System

### Electronic Controlled Fuel System

#### General Information

The engine control system is an electronically operated fuel control system that also provides many operator and equipment features.

The base functions of the control system include fueling and timing control, limiting the engine speed operating range between low and high-idle set points, and reducing exhaust emissions while optimizing engine performance.

The control system uses inputs from the operator and its sensors to determine the fueling and timing required to operate at the desired engine speed. The control system also utilizes a number of sensors to provide information on engine operating parameters.

The electronic control module (ECM) is the control center of the system. It processes all of the inputs and sends commands to the fuel system and engine and equipment control devices.

The ECM performs diagnostic tests on most of its circuits and will activate a fault code if a problem is detected in one of these circuits. Along with the fault code identifying the problem, a snapshot of the engine's operating parameters at the time of fault activation is also stored in memory.

Some fault codes will cause a diagnostic lamp to activate to signal the operator.

### Electronic Controlled Fuel System

---

#### Engine Protection System

The engine is equipped with an engine protection system which monitors critical engine temperatures and pressures and will log diagnostic faults when an over or under normal operation condition occurs. If an out-of-range condition exists and engine derate action is to be initiated, the operator will be alerted by a WARNING lamp. The WARNING lamp will blink or flash when out-of-range conditions continue to worsen. When the STOP lamp is illuminated, the operator **must** pull to the side of the work area, when it is safe to do so, to reduce the possibility of engine damage.

#### NOTICE

Engine power and speed will be gradually reduced depending on the level of severity of the observed condition until the engine shuts down.

#### Engine Protection Shutdown

This feature automatically shuts off the engine when the temperature, pressure, or coolant level sensors indicate the engine is operating over or under normal operating conditions.

The STOP lamp will flash for 30 seconds prior to shutdown to alert the operator.

#### Engine Protection Shutdown Override

This feature allows the operator to re-start the engine after an automatic shutdown. Prior to engine shutdown, the STOP lamp will flash for 30 seconds to notify the operator that the engine is about to shut down. After the shutdown, the operator can re-start but will only be able to run for 30 more seconds before another shutdown.

## Diagnostic Fault Codes

The control system can show and record operation anomalies that present themselves as fault codes. These codes will make troubleshooting easier. The fault codes are recorded in the ECM. They can be read using the fault lamps on the operator's console or with the Cummins INSITE™ service tool.

### NOTICE

Not all engine or control system anomalies are shown as fault codes.

There are three types of system codes:

- Engine electronic control system fault codes
- Engine protection system fault codes
- Engine maintenance indicator codes (not active at this time)

All fault codes recorded will either be active (fault code is currently active on engine) or inactive (fault code was active at some time, but is not active at the moment).

Most of the electronic fault codes will light a lamp when they are active. There are three possible lamps that can be lit when a fault is active:

- The WARNING lamp is yellow and indicates the need to repair the fault at the first available opportunity.
- The STOP lamp is red and indicates the need to stop the engine as soon as it can be safely done. The engine should remain shut down until the fault can be repaired.
- The MAINTENANCE lamp is yellow, but is not active at this time.

There are two other lamps connected with this system:

- The WATER IN FUEL lamp.

## Diagnostic Fault Codes

- The WAIT TO START lamp.

See panel layout with switches and indicator lamps below (Figure 4 - 1).

See Item 10) Indicators page 3-10 for descriptions.




Figure 4 - 1 Engine Diagnostic Switches and Lights

### Checking For Fault Codes

- 1) With the engine start switch in the STOP position, move the engine diagnostic ON/OFF switch to the ON position.
- 2) Next turn the engine start switch to the START position.

If no active fault codes are recorded, both the WARNING and STOP diagnostic lights will come on and stay on.

If active fault codes are recorded, both lights will come on momentarily, then begin to flash the code of the recorded fault or faults.

## Diagnostic Fault Codes

### Fault Code Description

The fault code will flash in the following sequence:

- 1) The WARNING lamp will flash.
- 2) After a 1 to 2 second pause, the STOP lamp will flash out the number of the recorded fault code. There will be a 1 to 2 second pause between each number.

- 3) When the number has finished flashing from the STOP lamp, the WARNING lamp will appear again.

This three-digit code will repeat in the same sequence. (Figure 4 - 2)




Figure 4 - 2 Example Fault Code Sequences

### Display of Fault Codes

The lamps flash each fault code out two times before advancing to the next code.

To skip to the next fault code sooner:

- 1) Move the engine diagnostic ON/OFF switch to the ON position.
- 2) Next, move the engine diagnostic INC/DEC switch to the INC position momentarily and let it return to neutral.
- 3) To advance to the next fault code, repeat step 2 above.
- 4) To go back to the previous fault code, move the engine diagnostic INC/DEC switch to the DEC position momentarily and let it return to neutral.

If only one active fault is recorded, the control system will continuously display the same fault code, even when the switch is moved to the INC or DEC position.

### NOTICE

When not using the diagnostic system, turn the engine diagnostic ON/OFF switch to the OFF position. If the switch is left in the ON position, the ECM will not log some faults.

The explanation and correction of the fault codes are explained in the engine manufacturer's Troubleshooting and Repair Manual. Please contact your nearest engine distributor for further information.

## **Paver Electrical Schematics**

---

### **Paver Electrical Schematics**

To find the paver electrical schematics, refer to Appendix B.

## General Description

### Section 5 - Hydraulic System

#### General Description

##### Slat Conveyor Pavers Hydraulic Circuits

The separate hydraulic circuits in the Slat Conveyor Paver are supplied by the pumps shown below in (Figure 5 - 1).

Two pumps drive the travel motors (one circuit for each drive). This includes the front wheel assist on tire pavers with this equipment.

Two pumps drive the conveyors (one circuit for each side).

One pump supplies all auxiliary functions such as hopper wings, truck hook, tow point cylinders, tow arm cylinders, steering cylinders, frame raise cylinders, screed assist (if equipped) and screed lift cylinders.

One tandem pump supplies the fume recovery fan motor and screed vibrators from one section as well as the engine and hydraulic cooling fan from the other section. This pump is mounted and driven directly off the engine front gear housing.

The optional generator pump supplies the generator drive motor circuit if the paver is equipped with an electric screed or a generator to power lights or other electrical devices. This pump is added to the right side pump stack.




Figure 5 - 1 Slat Conveyor Paver Hydraulic Pumps

General Description

Remix Pavers Hydraulic Circuits

The separate hydraulic circuits in the Remix Paver are supplied by the pumps shown below in (Figure 5 - 2).

Two pumps drive the travel motors (one circuit for each drive). This includes the front wheel assist on tire pavers with this equipment.

Two pumps drive the delivery augers (one circuit for each side).

Two pumps drive the spreading augers (one circuit for each side).

One pump supplies all auxiliary functions such as hopper wings, truck hook, tow point cylinders, tow arm cylinders, steering cylinders, frame raise cylinders, screed assist (if equipped) and screed lift cylinders.

One tandem pump supplies the fume recovery fan motor and screed vibrators from one section as well as the engine and hydraulic cooling fan from the other section. This pump is mounted and driven directly off the engine front gear housing.

The optional generator pump supplies the generator drive motor circuit if the paver is equipped with an electric screed or a generator to power lights or other electrical devices. This pump is added to the right side pump stack.




Figure 5 - 2 Remix Paver Hydraulic Pumps

### Hydraulic Fluid Reservoir

The reservoir holds hydraulic fluid for all systems, and one cooler maintains an operable fluid temperature. It is located beneath the hood at the front of the engine compartment and under the hydraulic pump stacks. The reservoir fluid capacity is 75 gallons. Baffles divide the inlet sides from the outlet sides. The baffles reduce oil foaming and air suspended in the oil which can damage pumps. A breather is located on the top of the reservoir to release pressure that builds up as the oil heats up and cools down. The breather should be kept clean to allow air flow through it.

A drain hose is connected to the reservoir to make changing the hydraulic fluid convenient. The hose is mounted to the rear bulkhead of the paver. When draining the reservoir, remove as much of the old fluid as possible.

#### NOTICE

All filter elements and suction hose fittings should be checked and tightened regularly to avoid leaks and prevent air from entering the hydraulic system. Prolonged operation with air in a hydraulic system will result in damage to a pump and poor system performance.

### Hydraulic Oil Cooler

The pavers use a remote-mounted oil cooler, mounted to the hood, with a hydraulically driven cooling fan to maintain an operable fluid temperature.

### Fluid Temperature

Excessively hot hydraulic fluid is an indicator of trouble developing in the hydraulic system. An operator should make it a habit to check the hydraulic oil temperature reading periodically

## Slat Conveyor Pumps

---

throughout the day, just as he does the engine oil pressure, coolant temperature, voltage, etc. Normal operating range is 120° to 160°F. Any time the hydraulic fluid temperature approaches or exceeds 180°F, stop paving, determine the cause and correct as necessary.

### Slat Conveyor Pumps

Each conveyor motor is driven by a separate conveyor pump. Each conveyor pump is made up of a variable displacement main pump and a charge pump. The charge pump draws oil from the reservoir and outputs the oil at 340 PSI minimum (380 PSI on right side for Rubber Track only). The oil is filtered and routed into the intake of the main pump. The main pump supplies 3800 PSI maximum pressure directly to the conveyor motor. If the pressure goes over 3800 PSI the relief valves open and bypass fluid to the reservoirs.

### Conveyor Drive Systems

Each slat conveyor/auger combination has its own hydraulic drive. The augers are linked to the slat conveyors by chain drive. A speed reducer is located between motor and the chain drive.

#### NOTICE

All pressure tests must be made with the hydraulic oil at operating temperature.

### Cleaning a Disabled Paver

If the paver becomes disabled with the hopper full of mix, the mix must be shovelled out of the hopper and the conveyors must be cleaned out before the mix cools.

To remove the mix from the conveyors:

## Slat Conveyor Pumps

- 1) Rotate the conveyor pump bypass valve counterclockwise no more than two turns. (Figure 5 - 3)




Figure 5 - 3 Conveyor Pump Bypass Valve

- 2) Run a chain under the paver from the front to the rear. Attach chain to the slat at the bottom rear. (Figure 5 - 4)




Figure 5 - 4 Attach chain to conveyor slat

- 3) Raise flow gates to around 10".
- 4) Pull forward on the chain. Once the chain connection point reaches the front of the paver, stop pulling the chain.
- 5) Tow the paver forward away from the pile of mix, reattach the conveyor chain, and repeat this procedure until the hopper is completely empty.
- 6) Tighten the conveyor pump bypass valves.

### Checking Conveyor Drive Charge Pressure

Check pressure at output port on charge filter. (Figure 5 - 5) The pressure should be 385 +/- 45 psi at FULL throttle.




Figure 5 - 5 Charge Pressure Test Ports

If not, remove charge pressure relief valve. (Figure 5 - 6) Inspect for foreign material holding the poppet open, and for scoring or wear on the poppet and seat in the housing. The charge relief valve does not contain any repairable parts. If the valve is worn or damaged or if the correct pressure cannot be achieved, the valve must be replaced.




Figure 5 - 6 Charge Pressure Relief Valve

## Slat Conveyor Pumps

### Checking System Relief Setting

The pressure relief valves for the conveyor pumps are factory set and should bypass fluid at 3800 +/- 200 psi. Do not attempt to adjust the conveyor relief pressure setting. If load reaches this limit, fluid is bypassed around hydraulic motor and conveyor will stall. The factory setting is adequate for any paving condition. Therefore in the event of a stall, cause of overload should be determined and eliminated.

Should a relief valve emit a high-pitched squeal, operator should quickly determine the cause. Continued operation will result in component damage and operating problems.

In the event that the conveyor speed settings are vastly different when each conveyor is doing an identical amount of work, it is probable that the side requiring the higher speed setting has a worn pump or motor. When an equal load situation exists, the pressure gauge readings should be nearly equal.

To test the high pressure relief setting:

- 1) Block slat conveyor firmly and safely with a 2 x 6 across the hopper gate to prevent any force against the gate. Run two lengths of 2 x 6 from this cross piece to one of the slats that is far enough away to minimize any slipping or buckling tendency when power is applied. The slat should be blocked at each end and the blocks should be nailed to the cross piece to prevent any movement.
- 2) Turn conveyor switches OFF and conveyor speed switch to LOW.
- 3) Install pressure gauges at the high pressure ports on conveyor pump. (Figure 5 - 7)




Figure 5 - 7 High Pressure Test Port/Relief Valve

- 4) Run engine at full throttle.

### NOTICE

Do not run the pressure over relief any longer than it takes to read the gauge.

- 5) Turn the conveyor speed dial or pile height dial to zero and move the conveyor switch to MANUAL. The gauge should read 0 psi. Slowly rotate the conveyor speed dial or pile height dial clockwise until the gauge pressure increases. The pressure should hold steady at 4100 psi. If the pressure is significantly higher or lower than 4100 psi, the pressure relief valve is defective and must be replaced.

### NOTICE

The relief valves are factory set and should not be tampered with except for replacing the entire cartridge. Disassembly may change the setting and cause erratic unit operation or premature failure.

## Slat Conveyor Pumps

### Conveyor Neutral Adjustment

Should a slat conveyor “creep” when the conveyor switch is OFF, the neutral setting must be readjusted. These are factory set and normally will not need adjustment. If neutral adjustment becomes necessary, perform the following procedure. Refer to (Figure 5 - 8) through (Figure 5 - 11) during this procedure.




Figure 5 - 8 Conveyor Pump Ports




Figure 5 - 9 Conveyor Pump Ports (Alternate View)

- 1) Install a low pressure line (500 psi min.) connecting servo port “F” (Figure 5 - 8) and servo port “G” (Figure 5 - 9). This removes the effects of any control pressure on the servo piston.
- 2) Install pressure gauges (10,000 psi) in the system pressure gauge ports (Figure 5 - 8). Start the engine and run at full throttle.
- 3) Loosen the lock nut while holding the servo neutral adjustment screw in position (Figure 5 - 9). Turn the servo neutral adjustment screw until the two system pressure gauge readings are equal.
- 4) Rotate the servo neutral adjusting screw clockwise until one of the system pressures starts increasing. Note the position “A” of the hex wrench. Rotate the servo neutral adjusting screw counter-clockwise until system pressure increases in the other gauge. Note the position “B” of the internal hex wrench. (Figure 5 - 10)




Figure 5 - 10 Servo Neutral Position

- 5) Rotate the servo neutral adjusting screw clockwise half the distance between positions “A” & “B”. The control should now be in a neutral position. In this position the gauges should read the same pressure (case pressure.)

- 6) While holding the servo neutral adjustment screw from turning, torque the servo lock nut 13 to 18 ft. lbs. Stop the engine and remove the servo cross-port line.




Figure 5 - 11 Electrical Displacement Control

- 7) Disconnect the Electrical Displacement Control at the pump controller. (Figure 5 - 11) Install a 300 psi gauge in the “F” (Figure 5 - 8) and “G” (Figure 5 - 9) servo ports.

### **⚠WARNING**

All personnel should be prepared for slat conveyors to creep during the following adjustment.

- 8) Start the engine and run at full throttle.
- 9) Loosen lock nut with 1/2” wrench and slowly rotate the control neutral adjustment screw on the EDC control clockwise, with 5/32” internal hex wrench, until the pressure is equal on both servo gages. (Figure 5 - 8)

## **Remix Delivery Auger Pumps**

- 10) Turn the control neutral adjustment screw clockwise until one of the system pressures starts to increase. Note the position “A” of the internal hex wrench.
- 11) Without removing the internal hex wrench, rotate the control neutral adjusting screw counter-clockwise until the pressure increases in the other gauge. Note the position “B” of the internal hex wrench.
- 12) Rotate the control neutral adjusting screw clockwise half the distance between location “A” & “B”. The control should now be in a neutral position. In this position the gauges should read the same pressure (case pressure.) (Figure 5 - 10)
- 13) While holding the control neutral adjustment screw from turning, torque the servo lock nut 25 to 30 in. lbs.
- 14) Stop the engine and connect the control input. Remove all pressure gages.

## **Remix Delivery Auger Pumps**

Each delivery auger pump drives two counter-rotating remix deliver augers. Each pump is made up of a variable displacement axial piston main pump and a charge pump. The charge pump draws oil from the reservoir and outputs the oil at 350 PSI minimum. The oil is filtered and routed into the intake of the main pump. The main pump supplies 5000 PSI maximum pressure directly to the two delivery auger motors. If the pressure goes over 5000 PSI the pump is destroked to reduce the flow rate and maintain the 5000 PSI pressure setting.

### **Delivery Auger Drive Systems**

The delivery auger drive system permits infinitely variable speed adjustment. Delivery auger speed is varied in two ways. First, the speed of the delivery

## Remix Delivery Auger Pumps

augers in AUTOMATIC can be adjusted proportionally to the speed of the spreading augers by adjusting the Remix Ratio control knobs on the operator console. Second, the delivery augers in MANUAL can be controlled independently from the spreading augers.

Pump displacement is controlled by the Electric Displacement Control (EDC). As the demand for more hot mix at the spreading augers increases, the EDC on the deliver auger pump proportionally increases the angle of the pump swashplate. The increased swashplate angle increases the length of travel for the pumps pistons which in turn increases the speed of the deliver auger motors.

### High Pressure Adjustment

#### **⚠ WARNING**

To perform this procedure safely requires two people. One person will make the adjustments and the other person will need to be at the control panel at all times.

The multi-function valve has two functions. 1) It determines the high pressure setting. 2) It allows the oil to bypass the pump. This second function is not used on remix pavers.

Each delivery auger pump has two multi-function valves. One for forward, and the other for reverse.

The pressure limiter and high pressure relief valve pressure setting are both adjusted by the multi-function valve. To set the high pressure limit:

- 1) Disconnect the high pressure line at the bulkhead fitting and plug the line. (Figure 5 - 12)




Figure 5 - 12 Plug High Pressure Line

- 2) Install two 10,000 PSI pressure gauges in the high pressure gauge ports. (Figure 5 - 13)




Figure 5 - 13 Install Pressure Gauges

- 3) Start the engine and run at full throttle.
- 4) Loosen locking nut (smallest hex on multi-function valve) on one of the pressure adjustments. (Figure 5 - 14)




Figure 5 - 14 Multi-function Valve Adjustments

- 5) Insert an internal hex wrench into the pressure adjusting screw.
- 6) Move the Feed Conveyor Override switch on the operator console to the OVERRIDE position. The pressure readings on one of the pressure gauges should rise and remain steady when it reaches the pressure limiter setting.
- 7) Rotate the pressure adjusting screw with the internal hex wrench, until a 5000 PSI reading is reached on the pressure gauge.

### NOTICE

Clockwise rotation of the pressure adjustment screw will increase the pressure setting, counterclockwise rotation will decrease the pressure setting. Each complete rotation of the pressure adjusting screw changes the pressure setting by 1350 PSI.

## Slat Conveyor Paver Travel Pumps

- 8) While holding the internal hex wrench and pressure adjusting screw in the same position, tighten the pressure adjusting screw lock nut to 12 in. lbs. Do not over-torque.
- 9) Release the Feed Conveyor Override switch on the operator console. The pressure in the high pressure circuit should return to the charge pressure setting. To verify the actual pressure setting, move the Feed Conveyor Override switch to OVERRIDE while watching the pressure gauge. The pressure should return to the 5000 PSI setting.
- 10) Return the Feed Conveyor Override switch to STOP and shut off the engine.

## Slat Conveyor Paver Travel Pumps

Each travel motor is supplied by a separate travel pump. Each travel pump is made up of a variable displacement axial piston main pump and a charge pump. The charge pump draws oil from the reservoir and outputs the oil at 340 PSI minimum. The oil is filtered and routed into the intake of the main pump. The main pump supplies 6100 PSI maximum pressure directly to the travel motor. If the pressure reaches 6100 PSI, the pump destrokes to reduce the flow rate and maintain the 6100 PSI pressure setting.

### Travel Drive Systems

The travel drive system permits infinitely variable speed adjustment from zero to maximum with torque available for any normal paving load. The speed will be maintained within the governed allowance whether the paver is pushing a loaded truck uphill or emptying the hopper. There will be no acceleration downhill even when hooked to a loaded truck.

## Slat Conveyor Paver Travel Pumps

Since each travel drive motor is supplied by its own pump, this provides independent control of each track/wheel. The fluid output of the travel drive pumps can be reversed so the paver can move either forward or backward without mechanical gear shifting.

To move forward the operator places the Travel Direction Switch or Travel Lever in the forward (F) position and slowly rotates the Speed Dial clockwise. As the Speed Dial is rotated, the Electric Displacement Control (EDC) on the travel pump proportionally increases the angle of the swash plate. The increased swash plate angle increases the length of travel for the pump pistons which increases the speed of the travel motor.

### High Pressure Adjustment

#### **⚠WARNING**

To perform this procedure safely requires two people. One person will make the adjustments and the other person will need to be at the control panel at all times.

The multi-function valve has two functions. 1) It determines the high pressure setting. 2) It allows oil to bypass the pump so the paver can be towed.

Each travel pump has two multi-function valves. One for the forward travel circuit, and the other for the reverse travel circuit.

The pressure limiter and high pressure relief valve pressure setting are both adjusted by the multi-function valve. To set the high pressure limit:

- 1) Lock the paver's brakes.
- 2) Install two 10,000 PSI pressure gauges in the high pressure gauge ports. (Figure 5 - 15)




Figure 5 - 15 Install Pressure Gauges

- 3) Start the engine and run at full throttle.
- 4) Loosen locking nut (smallest hex on multi-function valve) on one of the pressure adjustments. (Figure 5 - 16)




Figure 5 - 16 Multi-function Valve Adjustments

- 5) Insert an internal hex wrench into the pressure adjusting screw.

- 6) Move the direction control on the operators console to the forward direction. Slowly increase the speed setting on the speed dial. The pressure readings on the pressure gauges should rise slowly and remain steady when it reaches the pressure limiter setting. If the pressure reading does not change, move the direction control on the operators console to the reverse direction and repeat this step.
- 7) Rotate the pressure adjusting screw with the internal hex wrench, until 5500 PSI (6550 PSI on Rubber Track only) is reached on the pressure gauge.  
  
**Important:** Clockwise rotation of the pressure adjustment screw will increase the pressure setting, counterclockwise rotation will decrease the pressure setting. Each complete rotation of the pressure adjusting screw changes the pressure setting by 1350 PSI.
- 8) While holding the internal hex wrench and pressure adjusting screw in the same position, tighten the pressure adjusting screw lock nut to 12 in. lbs. Do not over-torque.
- 9) Return the speed dial on the operator console to zero. The pressure in the high pressure circuit should return to the charge pressure setting. To verify the actual pressure setting, increase the setting on the speed dial while watching the pressure gauge. The pressure should return to the 5500 PSI (6550 PSI on Rubber Track only).
- 10) Return the speed dial to zero and shut off the engine.
- 11) Repeat this procedure to adjust the reverse circuit pressure. The travel direction control on the operator console must be moved to the

---

## Remix Paver Travel Pumps

---

reverse setting rather than the forward setting and all adjustments will be made to the reverse pressure adjustment. Pressure should be 5500 PSI (6100 PSI on Rubber Track only).

### Remix Paver Travel Pumps

Each travel motor is driven by a separate pump. Each travel pump is made up of a variable displacement main pump and a charge pump. The charge pump draws oil from the reservoir and outputs the oil at 295 PSI minimum. The oil is filtered and routed into the intake of the main pump. The main pump supplies 5550 PSI maximum pressure directly to the traction motor. If the pressure goes over 5550 PSI the relief valves open and bypass fluid to the reservoirs.

### Travel Drive Systems

The travel drive system permits infinitely variable speed adjustment from zero to maximum with torque available for any normal paving load. The speed will be maintained within the governed allowance whether the paver is pushing a loaded truck uphill or emptying the hopper. There will be no acceleration downhill even when hooked to a loaded truck.

Each travel drive motor is supplied by its own pump, providing independent control of each track/wheel. The fluid output of the travel drive pumps can be reversed so the paver can move either forward or backward without mechanical gear shifting.

To move forward the operator places the Travel Direction Switch or Travel Lever in the forward(F) position and slowly rotates the Speed Dial clockwise. As the Speed Dial is rotated the Electric Displacement Control (EDC) on the travel pump proportionally increases the angle of the swashplate. The increased swashplate angle

## Remix Paver Travel Pumps

increases the length of travel for the pumps pistons which in turn increases the speed of the travel motor.

### Checking System Relief Setting

The pressure relief valves for travel pumps are factory set and should bypass fluid at 5550 +/- 200 psi. The relief valve settings should not be tampered with, except for replacing the entire valve. If load reaches this limit, fluid is bypassed around hydraulic motor and drive motor will stall. The factory setting is adequate for any paving condition. Therefore in the event of a stall, cause of overload should be determined and eliminated.

Should a relief valve emit a high-pitched squeal, operator should quickly determine the cause. Continued operation will result in component damage and operating problems.

To test the high pressure relief setting:

- 1) Stop engine and remove Master key.
- 2) Engage the paver brakes.
- 3) At the operator's console, turn the Paver Speed control to Min., and set the Travel Joy Stick or Switch to N (neutral).

### **WARNING**

Prior to installing gages, ensure that all pressure has been released from the travel pumps by doing step 3, above. Doing step 4 without first releasing pressure from the travel pumps can result in serious, personal injury.

- 4) Install a 10,000 psi pressure gauge into each of the two high pressure ports on travel pump. (Figure 5 - 17)




Figure 5 - 17 High Pressure Test Ports

- 5) Start engine and run at full throttle.

### **NOTICE**

Do not run the engine at full throttle for any longer than it takes to read the gauge.

- 6) The pressure gauges should read 0 psi:
  - a) Move the Travel Joy Stick or Switch on the operator's console to the forward direction.
  - b) Slowly increase the setting (cw from Min to Max) on the Paver Speed control.

The pressure reading on the associated pressure gauge should rise slowly and remain steady when it reaches the relief setting (approx. 5,500 psi).

- c) Turn the Paver Speed control ccw to Min.

Gages should again read 0 psi.

- d) Move the Travel Joy Stick or Switch to the reverse direction.

## Remix Paver Travel Pumps

The pressure reading on the associated pressure gauge should rise slowly and remain steady when it reaches the relief setting (approx. 5,500 psi).

If the pressure reading of either gage is significantly higher or lower than 5,550 psi, the associated high pressure relief valve is defective and must be replaced.

### NOTICE

The high pressure relief valves are factory set and should not be tampered with, except for replacing the entire cartage. Disassembly of the valve can change the setting and cause erratic unit operation or premature failure.

### System High Pressure Relief Valve Replacement

The high pressure relief valves (Figure 5 - 18) may be removed for cleaning and installation of fresh O-rings.




Figure 5 - 18 High Pressure Relief Valves

- 1) Remove the valve seat plugs from the pump housing. (Figure 5 - 19)




Figure 5 - 19 Relief Valve Replacement

- 2) Remove relief valve assembly from pump housing. The smaller end of each conical spring is crimped to retain it on the relief valve. Do not remove.
- 3) Inspect the valves and mating seats in the special plugs for damage or foreign material.
- 4) Install a new outer O-ring, new backup ring, and new inner O-ring on each valve seat plug.

- 5) Check that the conical springs are properly retained on the relief valves. Install the high pressure relief valve assemblies into the pump housing.

### NOTICE

The conical springs **MUST** be correctly positioned on the relief valves after installation for proper pump operation.

- 6) Install the valve seat plugs into the pump housing and torque valve seats to 40-95 Nm (30-70 ft-lb).

### Travel Neutral Adjustment

Should the tractor “creep” when the Travel Switch/ Lever is in the Neutral position, the pump neutral setting must be readjusted. These are factory set and normally will not need adjustment. If neutral adjustment becomes necessary, perform the following procedure.

- 1) Ensure that the paver engine is off, and engage the Brake switch on the operator console.
- 2) At the operator’s console, turn the Paver Speed control to Min., and set the Travel Joy Stick or Switch to N (neutral).

### WARNING

Prior to installing gages, ensure that all pressure has been released from the travel pumps by doing step 3, above. Doing step 4 without first releasing pressure from the travel pumps can result in serious, personal injury.

## Remix Paver Travel Pumps

- 3) Install a low pressure line (minimum 500 psi) connecting port “M4” and port “M5”. (Figure 5 - 20) and (Figure 5 - 21) This removes the effects of any control pressure on the servo piston.
- 4) Install pressure gauges (10,000 psi) in the system pressure gauge ports “M1” & “M2”. (Figure 5 - 20) Start the engine and run at full throttle.




Figure 5 - 20 M1, M2, and M5 Traction Pump Ports

- 5) Using 17mm and 7mm (hex) wrenches, loosen the pump neutral adjustment seal lock nut while holding the pump neutral adjustment screw in position. (Figure 5 - 21) Move the pump neutral adjustment screw cw and ccw, until the two system pressure gauge readings are equal.

## Remix Paver Travel Pumps




Figure 5 - 21 M4 Traction Pump Port

- 5) Rotate the pump neutral adjusting screw: (Figure 5 - 22)
  - a) First cw, until one or the other system pressure gauge starts increasing. This is position "A" of the hex wrench - note/mark it.
  - b) Then ccw, until the other system pressure gauge starts increasing. This is position "B" of the internal hex wrench.




Figure 5 - 22 Pump Neutral Position

- 6) Rotate the pump neutral adjusting screw clockwise half the distance between positions "A" & "B". The control should now be in a neutral position. In this position the gauges should read the same pressure (case pressure.)
- 7) While holding the pump neutral adjustment screw from turning, torque the pump lock nut 21 to 37 ft. lbs. Stop the engine.




Figure 5 - 23 Electrical Displacement Control

- 8) Disconnect the Electrical Displacement Control at the pump controller. (Figure 5 - 23)
- 9) Start the engine and run at full throttle.
- 10) Loosen control neutral adjustment lock nut with 17mm wrench and slowly rotate the control neutral adjustment screw clockwise, with 5mm internal hex wrench, until the pressure is equal on both gages. (Figure 5 - 20)
- 11) Turn the control neutral adjustment screw cw, until one a system pressure gauge starts to increase. This is position "A" of the internal hex wrench. Note/mark it. (Figure 5 - 22)

- 11) Turn the control neutral adjustment screw ccw, until the other system pressure gauge starts to increase. This is position “B” of the internal hex wrench. Note/mark it. (Figure 5 - 22)
- 12) Rotate the control neutral adjusting screw clockwise half the distance between location “A” & “B”. The control should now be in a neutral position. In this position the gauges should read the same pressure (case pressure.) (Figure 5 - 22)
- 13) While holding the control neutral adjustment screw from turning, torque the control neutral lock nut 10 to 18 ft. lbs.
- 14) Stop the engine and connect the cable to the EDC. Remove all pressure gages.

## Spreading Auger Pumps

Each spreading auger motor is driven by a separate pump. Each spreading auger pump is made up of a variable displacement main pump and a charge pump. The charge pump draws oil from the reservoir and outputs the oil at 205 PSI minimum. The oil is filtered and routed into the intake of the main pump. The main pump supplies 3330 PSI maximum pressure directly to the spreading auger motor. If the pressure goes over 3330 PSI the relief valves open and bypass fluid to the reservoirs.

## Spreading Auger Drive Systems

The spreading auger drive system permits infinitely variable speed adjustment from zero to maximum. The feed control system constantly measures material pile height in front of the screed and adjusts the spreading auger speed to maintain a consistent level of material in front of the screed.

Pump displacement is controlled by the Electric Displacement Control (EDC). As the demand for more hot mix at the screed increases, the EDC on

## Spreading Auger Pumps

the deliver auger pump proportionally increases the angle of the pump swashplate. The increased swashplate angle increases the length of travel for the pumps pistons which in turn increases the speed of the deliver auger motors.

## Checking System Relief Setting

The pressure relief valves for spreading auger pumps are factory set and should bypass fluid at 3330 +/- 200 psi. The relief valve settings should not be tampered with, except for replacing the entire valve. If load reaches this limit, fluid is bypassed around hydraulic motor and auger will stall. The factory setting is adequate for any paving condition. Therefore in the event of a stall, cause of overload should be determined and eliminated.

Should a relief valve emit a high-pitched squeal, operator should quickly determine the cause. Continued operation will result in component damage and operating problems.

To test the high pressure relief setting:

- 1) Stop engine and remove Master key.
- 2) Disconnect high pressure line to the spreading auger hydraulic motor and plug line. (Figure 5 - 24)




Figure 5 - 24 Spreading Auger Hydraulic Motor

## Spreading Auger Pumps

- 3) Install pressure gauges to the high pressure ports on spreading auger pump. (Figure 5 - 25)




Figure 5 - 25 High Pressure Test Ports

- 4) Start engine and run at full throttle.

### NOTICE

Do not run the pressure over relief any longer than it takes to read the gauge.

- 5) The pressure gauges should read 0 psi. Move the Feed Conveyor Override switch on the operator console to the OVERRIDE position. The pressure readings on one of the pressure gauges should rise and remain steady when it reaches the pressure limiter setting. If the pressure is significantly higher or lower than 3330 psi, the pressure relief valve is defective and must be replaced. (Figure 5 - 26)




Figure 5 - 26 High Pressure Relief Valves

### NOTICE

The relief valves are factory set and should not be tampered with except for replacing the entire valve. Disassembly of the valve can change the setting and cause erratic unit operation or premature failure.

### System High Pressure Relief Valve Replacement

The high pressure relief valve may be removed for cleaning and installation of fresh O-rings. (Figure 5 - 27)

- 1) Remove the valve seat plugs from the pump housing.

## Spreading Auger Pumps




Figure 5 - 27 Relief Valve Replacement

- 2) Remove relief valve assembly from pump housing. The smaller end of each conical spring is crimped to retain it on the relief valve. Do not remove.
- 3) Inspect the valves and mating seats in the special plugs for damage or foreign material.
- 4) Install a new outer O-ring, new backup ring, and new inner O-ring on each valve seat plug.

- 5) Check that the conical springs are properly retained on the relief valves. Install the high pressure relief valve assemblies into the pump housing.

**Notice** - The conical springs **MUST** be correctly positioned on the relief valves after installation for proper pump operation.

- 6) Install the valve seat plugs into the pump housing and torque 40-95 Nm (30-70 ft-lb).

## Spreading Auger Neutral Adjustment

Should the spreading augers “creep” when both Feed Override switches are in the OFF position, the pump neutral setting must be readjusted. These are factory set and normally will not need adjustment. If neutral adjustment becomes necessary, perform the following procedure. (Figure 5 - 28), (Figure 5 - 29), (Figure 5 - 30), (Figure 5 - 31), and (Figure 5 - 32)




Figure 5 - 28 M1, M2, M5 Spreading Auger Pump Ports

## Spreading Auger Pumps




Figure 5 - 29 M4 Spreading Auger Pump Ports

- 1) Disconnect high pressure line to the spreading auger hydraulic motor and plug line. (Figure 5 - 30)




Figure 5 - 30 Spreading Auger Hydraulic Motor

- 2) Install a low pressure line (500 psi min.) connecting port "M4" and port "M5". (Figure 5 - 28) and (Figure 5 - 29) This removes the effects of any control pressure on the servo piston.

- 3) Install pressure gauges (10,000 psi) in the system pressure gauge ports "M1" & "M2". (Figure 5 - 28) Start the engine and run at full throttle.
- 4) Loosen the 13mm hex pump neutral adjustment seal lock nut while holding the pump neutral adjustment screw in position. (Figure 5 - 29) Turn the 5mm hex pump neutral adjustment screw until the two system pressure gauge readings are equal.
- 5) Rotate the pump neutral adjusting screw:
  - a) First cw, until one system pressure gauge starts increasing. This is the "A" position of the hex wrench. Note/mark it.
  - b) Then ccw, until the other system pressure gauge starts increasing. This is position "B" of the internal hex wrench. Note/mark it.




Figure 5 - 31 Pump Neutral Position

- 6) Rotate the pump neutral adjusting screw cw, half the distance between positions "A" & "B". The control should now be in a neutral position. In this position the gauges should read the same pressure (case pressure.)

- 7) While holding the pump neutral adjustment screw from turning, torque the pump lock nut 15 to 19 ft. lbs. (Figure 5 - 29) Stop the engine.
- 8) Disconnect the Electrical Displacement Control at the pump controller. (Figure 5 - 32)




Figure 5 - 32 Electrical Displacement Control

- 8) Start the engine and run at full throttle.
- 9) Loosen control neutral adjustment lock nut with 17mm wrench and slowly rotate the control neutral adjustment screw clockwise, with 5mm internal hex wrench, until the pressure is equal on both gages. (Figure 5 - 28)
- 10) Turn the control neutral adjustment screw:
  - a) First cw, until one system pressure gauge starts to increase. This is position “A” of the internal hex wrench. Note/mark it. (Figure 5 - 31)
  - b) Next, turn the control neutral adjusting screw ccw, until the other system pressure gauge starts to increase. This is position “B” of the internal hex wrench. Note/mark it.

## Remix Delivery Control

- 12) Rotate the control neutral adjusting screw clockwise half the distance between location “A” & “B”. The control should now be in a neutral position. In this position the gauges should read the same pressure (case pressure.) (Figure 5 - 31)
- 13) While holding the control neutral adjustment screw from turning, torque the lock nut 10 to 18 ft. lbs.
- 14) Stop the engine and connect the cable to the EDC. Remove all pressure gages.

## Remix Delivery Control

### Delivery Control Components

Numbers assigned to the following paragraphs correspond to the numbers in (Figure 5-33).

- 1) Controller W/Ind. Lights: Programmed to process electrical signals coming from speed and pressure sensors and ratio pot, then output signals to delivery auger pump EDC. Indicator lights provide troubleshooting assistance.
- 2) Feed Interface Module: Provides a relay contact between controller output and spreading auger pump EDC coil. This relay pulls in via AUTO-OFF-MANUAL Switch.
- 3) AUTO-OFF-MANUAL Switch: Sends 12 VDC signal to controller to select mode of operation.
- 4) Ratio Pot: Sends 0.5 - 4.5 VDC signal to controller.
- 5) Speed Sensor: Located on spreading auger motor and provides pulse signal to controller to allow AUTO operation.

## Remix Delivery Control




Figure 5 - 33 Remix Delivery Control Components

- 6) Pressure Sensor: Located on rear bulkhead in delivery auger motor pressure circuit and provides 0.5 - 4.5 VDC to controller indicating 0 to 10,000 PSI of hydraulic pressure.
- 0.5 VDC @ 0 PSI
  - 2.5 VDC @ 5000 PSI
  - 4.5 VDC @ 10,000 PSI
- 3) Pressure sensor on delivery auger motor is active and will limit horsepower when needed.

### AUTO-OFF-MANUAL Switch in AUTO

- Ratio dial setting determines the speed of the delivery augers in relation to the spreading auger speed. (0 - 100% of spreading auger speed range)
- Delivery augers start and stop with the spreading augers no matter what mode the spreading augers are operating. (MANUAL, AUTO, or OVERRIDE)
- Delivery auger speed is based on spreading auger speed and ratio setting.

### Remix Delivery Control Operation

#### AUTO-OFF-MANUAL Switch in MANUAL

- Ratio dial operates strictly as a speed control.
- Operates whether spreading augers are ON or Off.

## Remix Delivery Control

---

- 4) Set ratio dial to maintain a uniform head of material (one half auger level).
- 5) Spreading auger RPM should remain constant with this setting.
- 6) Pressure sensor on delivery auger motor is active and will limit horsepower when needed.

### Remix Delivery Control Troubleshooting

The delivery augers are controlled by the remix feed controllers mounted in the main electrical box. (Figure 5 - 33)

If replacement of a controller becomes necessary, simply remove the old one and plug in the new one. No adjustment is needed.

Refer to the electrical schematic supplied with your machine and the following information to assist in troubleshooting this system. Also, the chart below (Figure 5 - 34) gives a guide to reading the status of the indicator lights on the controllers.

- 1) Controller: Sensor power output wire 284 (LH) and 294 (RH) should have 5VDC. If low voltage, check for defective sensor, ratio pot, or grounded wiring.
- 2) Ratio Pot: Provides range of 0.5 to 4.5VDC to controller.
  - a) 0.5VDC at MIN
  - b) 2.5VDC at 50% dial setting
  - c) 4.5VDC at MAX
- 3) AUTO-OFF-MANUAL Switch: Provides 12VDC to controller to select mode of operation and supplies power to the controller eliminating need for feed interface module on valve output.
- 4) Speed Sensor: Located on spreading auger motor, provides pulse signal to controller to allow AUTO operation.
- 5) Pressure Sensor: Located on rear bulkhead in delivery auger motor pressure circuit, provides a range of 0.5 to 4.5VDC to controller.
  - a) 0.5VDC at 0 PSI
  - b) 0.7VDC at 500 PSI
  - c) 0.9VDC at 1000 PSI
  - d) 2.5VDC at 5000 PSI
  - e) 4.5VDC at 10,000 PSI

## Slat Conveyor Paver Vibrator Pump


|  | INDICATOR LIGHT | COLOR  | LIGHT STATUS           | ERROR CODE                       | ERROR DESCRIPTION                                                                                         |
|-----------------------------------------------------------------------------------|-----------------|--------|------------------------|----------------------------------|-----------------------------------------------------------------------------------------------------------|
|                                                                                   | Power           | Green  | On Solid               | N/A                              | Indicates Power to Controller                                                                             |
|                                                                                   | System          | Green  | On Solid               | N/A                              | Indicates +5 VDC Output to Controller                                                                     |
|                                                                                   | Mode            | Yellow | Blinking               | 1 Blink / 2 Seconds              | Program is Running Correctly                                                                              |
|                                                                                   | Mode            | Yellow | Blinking               | 10 Blinks / 1 Second             | Controller Needs Replacement (No Program Loaded)                                                          |
|                                                                                   | Mode            | Yellow | Not Blinking On or Off | Light Completely Off or On Solid | Program Not Running Correctly. Cycle Power Off and back on. (If problem still exists, replace controller) |
|                                                                                   | Status          | Red    | Blinking               | 1110                             | Pressure signal out of range (defective wiring or sensor)                                                 |
|                                                                                   | Status          | Red    | Blinking               | 0100                             | Ratio Pot signal out of range (defective wiring or speed sensor)                                          |
|                                                                                   | Status          | Red    | Blinking               | 0110                             | Spreading Auger not running (defective wiring or speed sensor)                                            |

Figure 5 - 34 Remix Controller Troubleshooting

## Slat Conveyor Paver Vibrator Pump

One fixed displacement gear pump is used in the paver to power the screed vibrators. This pump provides up to 1500 PSI fluid to the screed vibrators at 2100 RPM engine speed. As engine speed is reduced, the pump output rate and pressure capability is reduced.

To check and adjust the vibrator system pressure:

- 1) Disconnect vibrator hoses at the rear bulkhead.
- 2) Install a 2500 PSI pressure gauge to the test port on the vibrator solenoid valve. (Figure 5 - 35)
- 3) Start the engine and run at full throttle.
- 4) Release the paver's brakes.
- 5) Turn the vibrator switch ON, speed dial to zero, and the travel control forward.




Figure 5 - 35 Slat Conveyor Vibrator Pressure Test Port

**NOTICE**

The vibrators do not engage until the travel control is in the forward position.

- 6) If the pressure gauge does not read 1500 PSI loosen the relief valve adjustment. Rotate the relief valve adjustment until the pressure reads 1500 PSI. Tighten the relief valve adjustment.

**Remix Paver Vibrator Pump**

One fixed displacement gear pump is used in the paver to power the screed vibrators and remote oil cooler (ROC) fan. This pump provides up to 2800 PSI fluid to the remote oil cooler fan and 1500 PSI fluid to the vibrators at 2500 RPM. As engine speed is reduced, the pump output rate and pressure capability is reduced.

To check and adjust the remote oil cooler fan system pressure:

- 1) Disconnect and plug the high pressure line to remote oil cooler fan motor. (Figure 5 - 36)




Figure 5 - 36 ROC Pressure Adjustment

**Remix Paver Vibrator Pump**

- 2) Install a 3000 PSI gauge to the ROC fan test port.
- 3) Start the engine and run at full throttle.
- 4) If the pressure gauge does not read 2800 PSI +/- 100, loosen the ROC fan relief adjustment valve. Rotate the valve until pressure reads 2800 PSI. Tighten relief valve adjustment.

- 5) Remove gauges and reconnect plumbing.

To check and adjust the vibrator system pressure:

- 1) Disconnect vibrator hoses at the rear bulkhead.
- 2) Install a 3000 PSI pressure gauge to the test port on the vibrator solenoid valve. (Figure 5 - 37)




Figure 5 - 37 Remix Vibrator Pressure Test Port

- 3) Start the engine and run at full throttle.
- 4) Release the paver's brakes.
- 5) Turn the vibrator switch ON, speed dial to zero, and the travel control forward.

## Auxiliary Systems Pump

### NOTICE

The vibrators do not engage until the travel control is in the forward position.

- 5) If the pressure gauge does not read 1500 PSI loosen the relief valve adjustment. Rotate the relief valve adjustment until the pressure reads 1500 PSI. Tighten the relief valve adjustment.

## Auxiliary Systems Pump

### Auxiliary System

The auxiliary system consists of a pressure-compensated variable-displacement pump to raise and lower the screed, hopper wings, pull points, frame raise, operate rubber track hydraulic system, and engage the truck hook.

Solenoid-operated selector valves are controlled by toggle switches from the operator's console or at the screed. When none of the above functions are being operated, the pump is destroyed to minimize fluid flow while maintaining 2500 psi pressure.

On newer pavers, the auxiliary pump is supplied with supercharged oil from the remote oil cooler drive pump.

### Auxiliary System Pressure Compensator Check

The compensator for the auxiliary system should be set to bypass fluid at 2500 +/- 100 psi.

- 1) Install a pressure gauge (3000 psi) at the auxiliary pump filter test port. (Figure 5 - 38)




Figure 5 - 38 Auxiliary Pressure Test Port

- 2) Start the engine and warm up the hydraulic oil. When the engine and oil are warm, move the throttle switch to full.
- 3) Observe the pressure gauge. The pump should maintain 2500 +/- 100 psi at full throttle.
- 4) If the pump will not maintain 2500 psi, rotate the compensator adjustment (Figure 5 - 39) clockwise to increase the pressure or counter-clockwise to reduce the pressure. If pressure cannot be attained, refer to Hot Mix Paver Technical Manual, Pumps-Motors-Drives section for more troubleshooting and repair information.




Figure 5 - 39 Auxiliary Pump

### NOTICE

When installing a new auxiliary pump, you must adjust the system pressure compensator to obtain the required 2500 psi. **New pumps do not come pre-set.**

## Rubber Track Hydraulic System

The rubber track hydraulic system, see schematic (Figure 5 - 40) maintains a constant volume of pressurized oil to the piston ends of track tension cylinders. Each track is independent and supplied by the auxiliary pump.

When the paver is started, oil is directed from the auxiliary pump to the pressure reducing valves. Oil pressure is reduced from 2500 psi to 1900 psi and directed on to the take-up valves where two separate sections, a charging/isolation cartridge and a direction sensing cartridge, route the oil to the track tension tension release valves connected to the track tensioning cylinders. A check valve and accumulator for each track are placed between the take-up valve charging/isolation cartridge and the

## Rubber Track Hydraulic System

piston side of the track tension release valve. The accumulator is pre-charged with dry nitrogen at 1800 psi to allow the track tensioning cylinders to retract and return if a severe impact is encountered.

### Checking Rubber Track Hydraulic System

The rubber track hydraulic system contains components which will automatically maintain track tension (Figure 5 - 41). To check out the system, follow the steps below:

#### Auxiliary System Pump Pressure

First check the auxiliary pump pressure compensator adjustment to be sure the system is set to 2500 +/- 100 psi. See Section 5, page 5-10 for this procedure.

#### Pressure Reducing Valves

Check the pressure reducing valves on each side (Figure 5 - 42).

- 1) Install pressure gauge (3000 psi) at each test port.
- 2) Start and run engine at full throttle.
- 3) Pressure should read 1900 psi. If not, confirm that the Auxiliary System Pump is putting out 2500 +/- 100 psi as described above.
- 4) Adjust pressure on reducing valve by loosening jam nut on the valve cartridge, insert an allen wrench into the adjusting screw, and turn the screw clockwise to increase pressure, or counter-clockwise to decrease pressure.
- 5) If 1900 psi still cannot be attained, replace pressure reducing valve.

## Rubber Track Hydraulic System




Figure 5 - 40 Rubber Track Hydraulic System Schematic - (Shown in Reverse)

# Rubber Track Hydraulic System




Figure 5 - 41 Rubber Track Hydraulic System Components

## Rubber Track Hydraulic System




Figure 5 - 42 Pressure Reducing Valves

### Track Tension Accumulator

Check pre-charge of track tension accumulators on each side. (Figure 5 - 43)




Figure 5 - 43 Track Tension Accumulator

- 1) Install pressure gauge (3000 psi) at test port marked BTM on the Track Tension Release Valve (Figure 5 - 44).
- 2) Start and run engine at full throttle.
- 3) Pressure should read 1900 to 2200 psi.
- 4) Shut engine off. Pressure on gauge should not change.




Figure 5 - 44 Track Tension Release Valve

- 5) Loosen jam nut on tension release valve cartridge.
- 6) Insert an allen wrench into the adjusting screw, slowly turn it counter-clockwise to open the tension release valve and release hydraulic pressure while carefully watching the gauge.
- 7) The pressure reading should drop off slowly until it reaches the accumulator dry nitrogen pre-charge pressure. When the pressure reaches the pre-charge point, the gauge will drop quickly to 0 psi.
- 8) The gauge reading at the point where it drops quickly to 0 psi should be 1800 psi at 68 degrees F. This reading may be slightly more or less depending the ambient temperature and the hydraulic system temperature.
- 9) If the accumulator dry nitrogen pre-charge is at 1800 psi, then tighten the tension release valve screw by turning it clockwise until snug on its seat.
- 10) Re-tighten jam nut on tension release valve cartridge.

- 11) If the pressure is below 1800 psi when it drops quickly to 0 psi, re-charge the accumulator with dry nitrogen as described in Track Tension Accumulator Pre-Charging procedure in the Paver Technical Manual, then test again.
- 12) If the pressure drops steadily all the way to 0 psi and re-charging the accumulator does not work, then replace the accumulator.

### Track Tension Check Valve and Release Valve

Check the operation of the check valve and tension release valve on each side.

- 1) Install pressure gauge (3000 psi) at test port marked BTM on the tension release valve (Figure 5 - 44).
- 2) Start and run engine at full throttle.
- 3) Pressure should read 1900 to 2200 psi.
- 4) Shut off the engine.
- 5) Remove the hose going to the check valve and plug the end of the hose (Figure 5 - 43).

### CAUTION

Escaping fluid under pressure can penetrate the skin causing serious injury. Be very careful when disconnecting hydraulic or other lines. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids. Any fluid injected into the skin must be removed immediately by a doctor.

- 6) Check the gauge reading to see if it drops off.

## Rubber Track Hydraulic System

---

- 7) If the gauge reading drops off and oil is leaking from the check valve, replace the check valve.
- 8) If the gauge reading drops off, no oil is leaking from the check valve and the tension release valve is closed, replace the tension release valve.
- 9) Re-test as described above until gauge reading does not drop off.
- 10) Re-install the hose to the check valve.

### Track Tensioning Cylinders

Check track tensioning cylinders on each side.

- 1) With engine off, remove lines from tension release valve to the rod ends of the cylinders (Figure 5 - 45).

### CAUTION

Escaping fluid under pressure can penetrate the skin causing serious injury. Be very careful when disconnecting hydraulic or other lines. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids. Any fluid injected into the skin must be removed immediately by a doctor.

- 2) Cap the fittings on the tension release valves.
- 3) Start and run engine at full throttle.
- 4) With the paver in reverse, brakes released, and the paver moving, there should be no oil leaking from the cylinder rod ports.

- 5) If oil is leaking from the cylinder(s) rod ports, the cylinder(s) must be repaired or replaced.




Figure 5 - 45 Track Tensioning Cylinders

### Track Take-up Valve

Check track take-up valve on each side.

- 1) Install pressure gauge (3000 psi) at test ports marked BTM and ROD on the tension release valve (Figure 5 - 44).
- 2) Start and run engine at full throttle.
- 3) With the paver in travel mode, in forward, brakes released, and the paver moving, there should be 1900 psi at the ROD port and 1900 - 2200 psi at the BTM port.

### NOTICE

To achieve the pressure readings in forward, some resistance/load must be present. Travel up a slight incline if necessary. Slowly increase speed until take-up valve shifts.

## Rubber Track Hydraulic System

- 4) With the paver in reverse or stopped, brakes released, and on level ground, there should be 1900 psi at the BTM port only.
- 5) Shut the engine off.
- 6) With the engine off, the pressure on the BTM port should hold at 1900 psi.
- 7) If the pressure bleeds off, check the tension release valve as described above.
- 8) The take-up valve charges the BTM port side of the track tension cylinders each time the brakes are applied. To check this operation:
- 9) Start and run engine at full throttle.
- 10) Place your hand on the hose running to the check valve (Figure 5 - 43).
- 11) Have another person at the paver console cycle the brake switch on and off several times.
- 12) Each time the brakes are applied, you should be able to feel the hose pulse.
- 13) If you cannot feel it pulse, remove the accumulator charging cartridge assembly (Figure 5 - 46), inspect, clean, and re-install in valve body.
- 14) Perform the above test once again.
- 15) If you still cannot feel a pulse in the hose, replace the cartridge assembly in the take-up valve.




Figure 5 - 46 Track Take-up Valve

## Slat Conveyor Paver Filters

The paver has five hydraulic fluid filters and two suction strainers for maximum component protection. There are two travel circuit charge filters, two conveyor drive charge filters, and one auxiliary pump filter.

### NOTICE

Always replace filters with the filter listed in your paver parts book. Using lower quality filters could lead to expensive damage to the hydraulic system.

The charge filter indicators should be checked daily with the engine at full throttle after the oil is warmed. If a charge filter is used until it is excessively clogged, the filter bypass valve will

## Slat Conveyor Paver Filters

activate and the indicators on the filter base will indicate in the red. **NEVER** operate with a clogged filter! If the indicator is in the red area, the filter should be replaced. All hydraulic filters should be replaced every 500 hours of operation, when the indicator indicates red, or seasonally, whichever occurs first. Do not wait for the indicator to indicate red before replacing the filter.

### Travel Circuit Filters

Two filters mounted on the rear bulkhead filter the fluid coming from the charge section of the travel pump then the fluid returns to the main section of the travel pump. Each filter has an indicator on its base that trips from green to red when the filter is clogged and requires replacement. Filters are replaced by rotating case counterclockwise and removing. To install a new filter, lubricate the O-ring with clean oil and make sure the rubber O-ring is positioned properly on top of filter. (Figure 5 - 47)




Figure 5 - 47 Charge Filters

### Conveyor Circuit Filters

Two filters mounted on the rear bulkhead filter the fluid coming from the charge section of the conveyor pump then the fluid returns to the main section of the conveyor pump. Each filter has an

indicator on its base that trips from green to red when the filter is clogged and requires replacement. Filters are replaced by rotating case counterclockwise and removing. To install a new filter, lubricate the O-ring with clean oil and make sure the rubber O-ring is positioned properly on top of filter. (Figure 5 - 47)

### Auxiliary Filter

There is one high pressure auxiliary filter located on the left side of paver on the front bulkhead. This filter consists of filter cap, filter element, and screw-in bowl. To change filter, remove bowl, replace element and reinstall bowl. (Figure 5 - 48)




Figure 5 - 48 Auxiliary filter

### Remix Pavers Filters

The paver has seven hydraulic fluid filters and two suction strainers for maximum component protection. There are two travel circuit charge filters, two delivery auger drive charge filters, two spreading auger drive charge filters and one auxiliary pump filter.

### Remix Pavers Filters

#### NOTICE

Always replace filters with the filter listed in your paver parts book. Using lower quality filters could lead to expensive damage to the hydraulic system.

The charge filter indicators should be checked daily with the engine at full throttle after the oil is warmed. If a charge filter is used until it is excessively clogged, the filter bypass valve will activate and the indicators on the filter base will indicate in the red. **NEVER** operate with a clogged filter! If the indicator is in the red area, the filter should be replaced. All hydraulic filters should be replaced every 500 hours of operation, when the indicator indicates red, or seasonally, whichever occurs first. Do not wait for the indicator to indicate red before replacing the filter.

### Charge Filter Replacement

Two filters mounted on the rear bulkhead filter the fluid from the charge section of the pump and returns the fluid to the main section of the pump. Each filter has an indicator on the base that trips from green to red when the filter is clogged and requires replacement. Filters are replaced by rotating case counterclockwise and removing. To install a new filter, lubricate the O-ring with clean oil and make sure the rubber O-ring is positioned properly on top of filter. (Figure 5 - 49)




Figure 5 - 49 Charge Filters

### Auxiliary Filter

There is one high pressure auxiliary filter located on the left side of paver on the front bulkhead. This filter consists of filter cap, filter element, and screw-in bowl. To change filter, remove bowl, replace element and reinstall bowl. (Figure 5 - 50)




Figure 5 - 50 Auxiliary filter

## Remix Pavers Filters

### Paver Suction Strainers

The suction strainers (Figure 5 - 51) should be removed and cleaned every 500 hours of operation. To clean the suction strainers:

- Clean the cover and suction manifold to prevent dirt from falling into the hydraulic reservoir.
- Remove the cover from the suction manifold to gain access to the strainer.
- Remove the strainer from the suction manifold. Be careful not to knock contaminants off the outside of the strainer as it is removed from the manifold.




Figure 5 - 51 Suction Strainer

- Clean the strainer with compressed air. Solvent can be used if needed.
- Install the strainer in the suction manifold.
- Check the condition of the O-ring seal and replace if damaged.

**NOTICE**

Severe pump damage will occur if the strainer cover is not sealed properly. Air will be drawn into the system causing pump cavitation.

- g) Install the cover.
- h) Pressurize reservoir with 10 psi of compressed air to check suction lines for leakage. To purge lines, loosen fittings slightly while under pressure and retighten.

**Solenoid Valves**

Solenoid valves mounted on top of each of the valve banks are controlled by toggle switches on the operator's console. These spool-type valves direct oil flow to and from the various hydraulic cylinders which control the paver and screed.

All of the 4-way, solenoid-operated directional valves used on the paver are identical units. They are double-acting valves with spring return of the spool to the neutral position.

When one of the switch contacts is closed, a 12 VDC solenoid is energized and the spool position is shifted by the plunger to connect internal porting so that pressurized hydraulic fluid flows to one end of the hydraulic cylinder(s). Fluid displaced by the moving cylinder rod flows through aligned ports of the same valve bank to the reservoir.

When the toggle switch is moved to the opposite position, the opposite solenoid is energized and the spool is shifted to reverse the pressure and return flow ports, so that the cylinder rod moves in an opposite direction.

**Solenoid Valves**

When the switch is OFF, the spool is centered in the valve body by coil spring action and all ports connected to cylinders are closed so that no flow to or from the cylinders can occur.

Each solenoid uses a DIN connector which contains an LED. The LED lights when 12 VDC is applied. The first check to make when determining the cause of a hydraulic failure should be to see if the LED lights when the solenoid is energized. Keep in mind this is only a preliminary check; it is possible the LED may be burned out. (Figure 5 - 52)




Figure 5 - 52 DIN Connector LED

If one of the paver functions does not operate, refer to the Technical Manual for troubleshooting and repair information.

## Solenoid Valves





Figure 5 - 53 Solenoid Valve Override Button

## Solenoid Valves



## Solenoid Valves

### Manual Testing of Solenoid Valves

If the spool cannot be manually shifted or fails to return by spring action to the OFF position, the valve should be completely dismantled, inspected, cleaned, and tested. If manual shifting succeeds in operating the system, try electrical operation again to see if the coil's magnetic force is strong enough to consistently move and hold the plunger.

### Removing/disassembling Valve Bank

#### ⚠ WARNING

Before removing any hydraulic hoses or valves make sure the hopper wings, screed, frame raise, and pull point cylinders are lowered as far as possible.

When it is necessary to detach and disassemble any of the valves which make up a valve bank assembly, it is necessary that the bank be disconnected from hydraulic hoses, unbolted from the mounting brackets, and moved to a totally clean work bench area. The detached unit should also be plugged and washed clean externally before any disassembling is started. The following instructions should be used to maintain the frame raise, truck hook, hopper wings, screed lift, left tow point, and right tow point valve banks. Some of the components referred to may not be used on all valve banks. (Figure 5 - 54)

- 1) Remove the screw retaining each of the DIN connectors to the solenoids. Unplug the DIN connector from the solenoid.
- 2) Mark each hose and its companion port on the valve bank with a code that will assure reconnection is made to the correct port when

the bank is installed. If hoses and ports are not marked, refer to schematic diagrams for correct connection details.

- 3) As each hose is disconnected, plug the end of the hose and port with a clean plastic plug.
- 4) Remove the nuts which hold the valve bank to the paver and remove the valve bank.

**Notice:** Scrub and rinse the exposed surfaces of the entire valve bank to remove all dirt and place the assembly on a clean working surface.

- 5) Remove the four stud nuts which hold the valve bank together and disassemble the valve bank. Retain all of the O-rings which will be between each of the valve bank components.
- 6) Remove the throttle valve from the valve block.




Figure 5 - 54 Typical Valve Bank

## Valve Bank Components

### Throttle Valve

The throttle valve allows unrestricted flow in one direction and metered or restricted flow in the opposite direction. In the case of screed lift, flow in RAISE direction is unrestricted while return flow in the LOWER direction is restricted by a 3/32" diameter orifice. This permits the screed to raise quickly but to descend at a slower, safe rate.

A drilled poppet is the only moving part in a throttle valve. The valve can be easily inspected for presence of foreign matter in orifice. The orifice can be cleaned using a piece of 1/16" diameter wire and compressed air. If probing succeeds in clearing a blockage, the valve should then be flushed clean with mineral spirits solvent. These same valves are used in the hopper wing circuit.

### Holding Valve

Holding valves are used on the frame raise, hopper wings, screed lift, and tow point valve banks. If the engine stalls or a hydraulic line breaks between the pressure source and valve, the holding valve locks the cylinder in its current position to prevent the screed, hopper wings, etc. from dropping unexpectedly. When the hydraulic line is repaired and the engine is restarted the valve continues to work normally.

### **⚠WARNING**

Holding valves do not contain any serviceable or replaceable parts. Do not attempt to disassemble and repair a holding valve cartridge.

A holding valve consists of a valve body and one or more valve spools. If a holding valve is not working properly remove the valve and blow the

## Valve Bank Components

---

valve body and spool off with compressed air. Reinstall the valve. If it still does not work, replace the valve.

### Flow Control Valve

The flow control valve is used in the tow point and truck hook cylinders to control the speed at which the cylinders move. The valve consists of a valve body with a needle valve cartridge.

To clean the flow control valve, remove the cartridge, blow the valve and valve body out with compressed air, and reinstall the cartridge.

### Assembling Valve Banks

The valve bank should be assembled on a clean lint-free shop towel in a clean work area. All components should be wiped clean before assembly. For specific valve bank illustrations, refer to (Figure 5 - 55), (Figure 5 - 56), and (Figure 5 - 57).

- 1) Inspect all O-rings before assembly. Replace any O-rings that are cracked, damaged, dried out, or not flexible.
- 2) Lubricate each O-ring with clean oil or light grease before assembly.
- 3) Place O-rings in the O-ring recesses . Make sure O-rings do not get pinched during assembly.
- 4) Refer to illustrations on the following page for proper orientation of each valve bank component.
- 5) To ensure that each component is properly oriented during assembly the following procedure should be done for each component:
  - a) apply a thin coating of oil or grease to the O-rings

## Valve Bank Components

b) install the next valve stack component on the studs

c) remove the component

The O-rings will leave a circular oil mark on the mating valve surface. If the component was installed in the proper orientation the four oil ports in the mating component surface will be centered in the four oil marks left by the O-rings. If the oil marks do not line up with the oil ports, check the orientation of the component and reinstall.

### ⚠ CAUTION

When assembling valve bank, tighten screws alternately, evenly, and with not more than 48 to 60 inch-pounds of torque. It is important that the machined contact surfaces and O-rings make a leak-free contact without excessive screw tightness which can warp the valve body and cause binding of the spool.




Figure 5 - 55 Frame Raise/Screed Lift Valve Bank

## Valve Bank Components




Figure 5 - 56 Truck Hook/Left Tow Point Valve Bank




Figure 5 - 57 Hopper Wings/Right Tow Point Valve Bank

## Hydraulic System Troubleshooting

---

### Hydraulic System Troubleshooting

For more in depth information refer to the Paver Technical Manual.

#### Hydraulic Fluid Overheating

The following factors can cause fluid temperature above 160°F:

- 1) **Low Fluid Level in Supply Tank:** When the fluid level is kept high more heat is radiated from the tank walls and the circulating (cooling) time is increased. Keep fluid level FULL on the sight gauge, especially when outdoor temperature is high.
- 2) **Cooler Not Functioning Properly:** The flow of hydraulic fluid must be free and unrestricted at all times. The air passages through the radiator and cooler must be kept clear of dirt, fibers, and insects so that an unrestricted flow of air is assured at all times during engine operation. The radiator and cooler are placed in the top of the hood above the engine with a hydraulically driven suction type cooling fan moving air through from above. Keep the louvers above the radiator and cooler free from obstructions.

#### Failing Pumps or Motors

In the event that one of the pumps or one of the motors is beginning to fail internally, excessive heat will usually be produced. When this occurs the fluid temperature will become abnormally high. It is recommended that a “touch” test be made immediately in an effort to determine where an internal failure of parts is beginning to occur. The hottest fluid will be passing back to the reservoirs through a case drain hose. It is sometimes possible to touch the fittings of each of these hose lines and detect an extremely hot one which feels different from the others. If paving can be suspended for a “cooling off” period it is easier to detect the difference at the next start-up as the line from the failing unit will heat up much faster than the others. If a “hot” pump or motor is detected, have the pump or motor serviced immediately.

#### NOTICE

If the conveyors are not feeding equal quantities of material, the one moving the most material will be slightly hotter than the other. This should be considered in making temperature comparisons. Temperature checks can also be made by taping an accurate indicating thermometer to the case drain fittings.

## Hydraulic System Troubleshooting

---

### Air in the Systems

The suction force developed by each of the six hydraulic pumps on the paver draws the fluid from reservoirs through hose lines to the charge pumps. With all points on these suction lines under negative pressure, air can be drawn in wherever an opening exists. When air is mixed with the fluid entering any of the pumps, an abnormal situation is created and serious operating problems develop.

The charge pumps which force feed the drive pumps cannot develop enough fluid pressure to keep the main pump passages filled with fluid. Pump pressure fluctuates and paver operation becomes jerky and erratic as the pumps cavitate.

### Causes of Air in System

- 1) Low fluid level in reservoirs. When fluid level approaches tips of suction pipes near bottom of reservoir, air begins to enter along with fluid. Always keep tank filled to sight gauge level.
- 2) Air leakage through an opening at any connection in fluid supply lines to pumps. If gasket at top of a filter element is not sealing properly, air will be drawn in.

### Locating Air Leaks

If an air leak is suspected but cannot be located or confirmed, the best way to test for it is by pressurizing the reservoir with air and finding the point of fluid leakage. To do so, remove both breather fill caps and attach an air line which includes a pressure regulator and gauge so that **not more than 15 psi** air pressure will be applied. Any point where fluid leakage occurs under air pressure is a point of air entry.

When fluid leakage is located and stopped, pressurize reservoir to 15 psi, close air inlet valve, and see if system will hold pressure for an hour or two without dropping. This will verify that all leaks have been stopped and air will no longer enter the system when operation is resumed. Remove plugs from fill holes and replace with breather fill caps.

## Hydraulic System Troubleshooting

---

This Page Intentionally Left Blank

## Raising the hood

### Section 6 - Maintenance

#### Raising the hood

The paver's hood must be raised to gain access to the engine for daily maintenance. The hood is raised using a hydraulic cylinder which is activated by a lever just under the hood on the right side of the machine in front of the rear wheel or drive sprocket. (Figure 6 - 1)




Figure 6 - 1 Hood Control

To raise the hood:

- 1) Position and lock the operator's console in the center position.
- 2) Turn on the master key switch before activating the hood control. Once the hood raising cylinder is fully extended, the hood safety lever will engage automatically.

#### **⚠WARNING**

Keep all personnel out from under the hood until the hood safety latch is engaged. Failure to follow these instructions could result in death or serious injury.

- 3) Verify that the hood safety latch is engaged.

If the paver's batteries become discharged, jumper cables must be attached to the solenoid next to the hood raising lever and to the paver frame. (Figure 6 - 2) This will allow the hood raising lever to function in the normal manner.




Figure 6 - 2 Connecting Jumper Cables

## Before Starting Engine

---

### **⚠WARNING**

Keep all personnel out from under the hood until the hood safety latch is engaged. Failure to follow these instructions could result in death or serious injury.

To lower the hood, release the hood safety latch and activate the hood raising lever. (Figure 6 - 2)

### **Before Starting Engine**

Before starting the engine, the operator should check the following details personally.

- Verify that all decals are properly adhered to the machine, undamaged, and legible.
- Be sure all safety items (decals, guards, walkways, fire extinguisher, etc.) are in place and properly installed.
- Engine Oil Level should be at the “Full” mark on the dip stick. If engine oil is low, add oil to bring the level up to the “Full” mark. Refer to the engine manual for the correct oil type.
- Coolant Level inside the radiator should be just above the baffle. If not add the correct mixture of antifreeze and water. Do not over fill as excesses will be blown out the over flow. Refer to the engine manual to find the correct antifreeze and water mixture to use for the temperatures found in your working area.
- Hydraulic Oil Level must be checked while the hydraulic oil is cold and the machine is sitting level. If the hydraulic oil level is low, add the correct amounts of make up oil to bring the level to the COLD level on the sight glass.

### **NOTICE**

Over filling the hydraulic tank does not leave enough room in the hydraulic system for thermal expansion when the oil is at running temperature. Excess oil will be blown out the breathers which could cause external radiator clogging.

### **NOTICE**

Do not mix different types of oil. This could lead to unexpected failures.

- Engine Fuel Tank Level should be checked to ensure you have enough fuel to operate the paver for the desired amount of time.

Perform a visual inspection of the complete paver including engine compartment, for any signs of damage or leaks. Do not start the paver until all damage and leaks are repaired.

## Maintenance Checklist

### Maintenance Checklist

| Ref. | Item to be checked             | 8 hrs | 40 hrs | 250 hrs | 500 hrs | 1000 hrs | Yearly | As Needed |
|------|--------------------------------|-------|--------|---------|---------|----------|--------|-----------|
| 1    | Fuel level                     | I     |        |         |         |          |        | F         |
| 2    | Fuel Filter / Water Separator  | D     |        |         | R       |          |        |           |
| 3    | Hydraulic Fluid                | I/F   |        |         | R*      | R        |        |           |
| 4    | Oil Cooler                     | I     |        |         |         |          |        | C         |
| 5    | Suction Strainers              |       |        |         | C       |          |        |           |
| 6    | Charge Filters                 |       | I      |         | R       |          |        |           |
| 7    | Auxiliary Pump Filter          |       |        |         | R       |          |        |           |
| 8    | Hydraulic lines and components | I     |        |         |         |          |        |           |
| 9    | Air Restriction Indicator      | I     |        |         |         |          |        |           |
| 10   | Air Filter                     |       |        |         |         |          |        | C/R       |
| 11   | Engine Oil                     | I/F   |        | R       |         |          |        |           |
| 12   | Engine Oil Filter              |       |        | R       |         |          |        |           |
| 13   | Engine Coolant                 | I/F   |        |         |         |          | R      |           |
| 14   | Engine Belt                    |       | I      |         |         |          |        | A         |
| 15   | Radiator                       | I     |        |         |         |          |        | C         |
| 16   | Engine Cooling Fan             | I     |        |         |         |          |        |           |
| 17   | Battery                        |       | I/F    |         |         |          |        |           |
| 18   | Tire Pressure                  |       | I/F    |         |         |          |        |           |
| 19   | Frame Raise Eccentric          |       |        |         | L       |          |        |           |
| 20   | Steel Track Tension            |       | I      |         |         |          |        | A         |
| 21   | Rubber Track Tension           |       | I      |         |         |          |        |           |
| 22   | Track Pivot                    |       | L      |         |         |          |        |           |
| 23   | Fire Extinguisher              |       |        | I       |         |          |        |           |
| 24   | Horn                           | I     |        |         |         |          |        |           |
| 25   | Pump Drive Belts               |       | I      |         |         |          |        | A         |
| 26   | Depth Cranks                   |       |        | L       |         |          |        |           |
| 27   | Vibrator Bearings              | L     |        |         |         |          |        |           |
| 28   | Crown Control                  |       |        | L       |         |          |        |           |
| 29   | Match Height Assembly          |       | L      |         |         |          |        |           |
| 30   | Extension Slope Assembly       |       | L      |         |         |          |        |           |
| 31   | Final Drive Oil                |       | I/F*   |         |         | R        |        |           |
| 32   | Steering Bogie Alignment       |       |        |         |         |          |        | I/A       |
| 33   | Steering Linkage               |       |        | L       |         |          | I/A    |           |
| 34   | Bogie Beam Bearings            |       |        | L       |         |          |        |           |

**Key:**      I - Inspect      C - Clean      R - Replace      A - Adjust  
                  D - Drain      L - Lubricate      F - Fill      \* - Initial change only

Table 6 - 1 Maintenance checklist

## Periodic Maintenance

| Ref. | Item to be checked                | 8 hrs | 40 hrs | 250 hrs | 500 hrs | 1000 hrs | Yearly | As Needed          |
|------|-----------------------------------|-------|--------|---------|---------|----------|--------|--------------------|
| 35   | Front Wheel Bearings              |       |        |         |         |          | L      |                    |
| 36   | Bogie Wheel Toe In                |       |        |         |         |          | I/A    |                    |
| 37   | Conveyor Slat Chains              | I/L   | I/A    |         |         |          |        |                    |
| 38   | Conveyor Bearings                 | L     |        |         |         |          |        |                    |
| 39   | Delivery Auger Clearance          |       | I      |         |         |          |        | A (Every 120 hrs.) |
| 40   | Delivery Auger Drive - Gear Drive |       | I/F*   |         |         | R        |        |                    |
| 41   | Front Delivery Auger Bearings     | L     |        |         |         |          |        |                    |
| 42   | Spreading Auger Bearings          | L     |        |         |         |          |        |                    |
| 43   | Spreading Auger Drive Chains      |       | I/A    |         |         |          |        | A                  |
| 44   | Spreading Auger Speed Reducer     |       | I/F*   |         |         | R        |        |                    |
| 45   | Feeder Drive Chains               |       | I      |         |         |          |        | A                  |
| 46   | Conveyor Speed Reducer            |       | I/F*   |         |         | R        |        |                    |
| 47   | Hood Raise Reservoir              |       |        | I       |         |          |        |                    |
| 48   | Operator Console Pivot Bearings   |       |        | L       |         |          |        |                    |
| 49   | Tow Arm Nose Roller               | L     |        |         |         |          |        |                    |
| 50   | Slope Beam Rod Ends               |       |        | L       |         |          |        |                    |
| 51   | Truck Hitch                       | C/L   |        |         |         |          |        |                    |
| 52   | Fume Recovery System              | I     |        |         |         |          | I      | C                  |

**Key:** I - Inspect      C - Clean      R - Replace      A - Adjust  
D - Drain      L - Lubricate      F - Fill      \* - Initial change only

Table 6 - 1 Maintenance checklist (Continued)

## Periodic Maintenance

Numerical values assigned to the paragraphs that follow directly relate to the numbers in the “Ref.” column of (Table 6 - 1), above.

### 1) Fuel Level



Keep away from sparks or open flame while working with fuel.

Check fuel level before each work period to ensure you have enough fuel to operate for the desired period of time. Refer to the engine manufacturers manual to determine what grade of fuel to use for your operating temperature and conditions.

### 2) Fuel/Water Separator

#### Daily Maintenance

Drain the water and sediment from the separator daily. (Figure 6 - 3)




Figure 6 - 3 Draining fuel/water separator

Shut off the engine. Use your finger to push up on the drain valve until liquid starts draining slowly. Drain the filter sump of water until clean fuel is visible.

Release the valve to close the drain.

### NOTICE

Check the valve after draining to make sure it does not leak.

### Filter Replacement

Replace the fuel filter/water separator every 500 hour of operation. Some operating conditions may require replacement at shorter intervals for proper engine operation.

To replace the fuel filters:

- 1) Clean the area around the filter head.
- 2) Remove the filters.

## 3) Hydraulic Fluid

- 3) Clean the gasket surface of the filter head.
- 4) Replace the O-ring.
- 5) Fill new filters with clean fuel and lubricate the O-ring seal with clean lubricating oil.
- 6) Install filters and tighten.

### NOTICE

Overtightening may distort the treads or damage the filter element.

## 3) Hydraulic Fluid

### ⚠ WARNING

Turn off engine & remove key before performing any inspections or maintenance.

Hydraulic oil level must be checked while the hydraulic oil is cold and the machine is sitting level. If the hydraulic oil level is low, add the correct amounts of make up oil to bring the level to the COLD level on the sight glass.

### NOTICE

Overfilling the hydraulic tank does not leave enough room in the hydraulic system for thermal expansion when the oil is at running temperature. Excess oil will be blown out the breathers which could cause external radiator clogging.

**NOTICE**

Do not mix different types of oil. This could lead to unexpected failures.

The hydraulic fluid should be drained and replaced with new fluid every 1000 hours of operation. The hydraulic fluid in a new paver or a paver that has just had a new hydraulic pump or motor installed should be replaced after the first 500 hours of operation.

Cedarapids recommends use of a premium anti-wear, ISO Grade 68 hydraulic oil in all pavers. Pavers ship from the factory with Texaco Rando HD 68 hydraulic oil. Other approved hydraulic oils in this class are: Amoco AW68; Exxon NUTO H68; Mobil DTE26; Shell Tellus 68; Chevron AW 68.

**4) Oil Cooler****⚠ WARNING**

Turn off engine & remove key before performing any inspections or maintenance.

The oil cooler should be checked daily for dirt and other buildup that would restrict the air flow. The paving conditions will determine how often the oil cooler requires cleaning. If severe conditions exist or there are a lot of air-borne contaminants the oil cooler will require more attention. Any fluid leaking from any engine compartment component, hose or tube may find its way into the oil cooler.

**4) Oil Cooler**

Remove any dirt or debris that will restrict air flow through the oil cooler. Spray water from a garden hose from the bottom side of the oil cooler to the top to remove any dirt or grit that may have settled between the oil cooler fins.

Check for damaged hoses and loose or damaged hose clamps. Replace as required. Check the oil cooler for leaks and the core for damaged or bent fins. Clean and repair as required.

**5) Suction Strainers**

The suction strainers should be removed and cleaned every 500 hours of operation. To clean the suction strainers:

- 7) Clean the cover and suction manifold to prevent dirt from falling into the hydraulic reservoir.
- 8) Remove the cover from the suction manifold to gain access to the strainer. (Figure 6 - 4)




Figure 6 - 4 Suction Strainer

- 9) Remove the strainer from the suction manifold. Be careful not to knock contaminants off the outside of the strainer as it is removed from the manifold.
- 10) Clean the strainer with compressed air. Solvent can be used if needed.
- 11) Install the strainer in the suction manifold.
- 12) Check the condition of the O-ring seal. If the seal is damaged, install a new seal.

### NOTICE

Severe pump damage will occur if the strainer cover is not sealed properly. Air will be drawn into the system causing pump cavitation.

- 13) Install the cover.
- 14) Pressurize reservoir to 10 psi air pressure and check suction lines for leaks. Loosen fittings while under pressure to purge lines.

## 6) Charge Filters

The paver has two charge filters that protect the traction hydraulic circuits and two charge filters that protect the conveyor hydraulic circuits. Each charge filter is equipped with an indicator that operates in the green zone when the filter is in good condition and operates in the red zone when the filter is dirty. The indicators should be checked every 40 hours with the engine at full throttle. Do not wait for the indicator to move into the red zone before replacing the filters. The filters should be replaced every 500 hours or when the indicator is operating in the red zone, whichever comes first. (Figure 6 - 5)

## 6) Charge Filters




Figure 6 - 5 Charge Oil Filters

## 7) Auxiliary Pump Filter

There is one high pressure auxiliary filter located on the left side of paver on the front bulkhead. This filter consists of filter cap, filter element, and screw-in bowl. To change filter, remove bowl, replace element and reinstall bowl. (Figure 6 - 6)




Figure 6 - 6 Auxiliary filter

## 8) Hydraulic lines and components

Check all hoses, tubes, and components for leaks, damage, or loose fittings. Check the ground for signs of fluid leakage. Spots of oil soaked dust may

## 9) Air Restriction Indicator

indicate a slow leaking hydraulic component. These leaks should be identified and fixed before operating the equipment.

### 9) Air Restriction Indicator

#### **WARNING**

Turn off engine & remove key before performing any inspections or maintenance.

The engine air cleaner is equipped with an indicator that trips red when it needs service. The indicator should be checked daily to ensure proper servicing. (Figure 6 - 7)




Figure 6 - 7 Air Restriction Indicator

Service the filter element when the red indicator flag is visible in the window.

After the air cleaner has been serviced, push the button to reset the service indicator.

### 10) Air Filter

Running the paver with an air cleaner that needs replacement does not allow the engine to get the proper amount of air to burn the fuel properly, which reduces engine horsepower and fuel efficiency. (Figure 6 - 8)

#### **NOTICE**

Never operate a paver without an air cleaner. Intake air must be filtered to prevent dirt and debris from entering the engine and causing serious and expensive damage.




Figure 6 - 8 Engine Air Filter

When servicing an air cleaner take precautions not to allow any of the dirt or contamination that would happen to fall off the old element to remain in the filter housing or pass into the air inlet of the engine. Dirt and contamination are one of the biggest reasons for engine wear. Improper cleaning of old air cleaner elements can damage the element and allow dirt and contamination to pass directly into an engine.

Cedarapids does not recommend that air filter elements be cleaned in any way. When the air restriction indicator is operating in the red area the primary element must be replaced. The safety element must be replaced after three primary element changes.

**NOTICE**

Do not beat, shake, or use high pressure compressed air to remove dirt from an element. These methods can make small cuts in the element material which will allow dirt to enter the engine causing serious and expensive damage to the engine.

**Engine Air Inlet Connections****WARNING**

Turn off engine & remove key before performing any inspections or maintenance.

Inspect the inlet piping for cracked hoses, loose clamps, or punctures that can allow dirt and debris to enter the engine. Tighten or replace parts as necessary to make sure the air inlet system does not leak. (Figure 6 - 9)




Figure 6 - 9 Air Inlets

The air inlet system includes the piping from the air cleaner to the turbocharger and the piping from the turbo charger to the after cooler or inlet manifold depending on model.

**11) Engine Oil****11) Engine Oil****Engine Oil Level**

Never operate the engine with the oil level below the “L” (Low) mark or above the “H” (High) mark on the engine oil dipstick. (Figure 6 - 10) Wait at least 5 minutes after shutting off the engine to check the oil. This allows time for the oil to drain to the oil pan.

**NOTICE**

The engine must be level when checking the oil level to be sure the measurement is correct.




Figure 6 - 10 Checking Engine Oil Level

**Changing Engine Oil**

Engine oil and filter should be changed at least every 250 hours of operation. Shorter intervals may be required due to operational conditions. Severe conditions require more frequent maintenance.

**NOTICE**

Drain the oil only when it is hot and the contaminants are in suspension. (Figure 6 - 11)




Figure 6 - 11 Oil Contaminants in Suspension

Operate the engine until the engine coolant temperature reaches 60°C [140°F]. Shut the engine off. Remove the oil drain plug and **drain oil into a container.**

### ⚠ CAUTION

Hot oil can cause personal injury.

Protect the environment: handling and disposal of used engine oil can be subject to federal, state and local law regulation. Use authorized waste disposal facilities, including civic sites and garages providing authorized facilities for the receipt of used engine oil. If in doubt, contact your local authorities or the EPA for guidance as to proper handling of used engine oil.

Refer to the engine manuals for the recommended type and grade of oil to be used.

## 12) Engine Oil Filter

Engine oil and filter should be changed at least every 250 hours of operation. Shorter intervals may be required due to operational conditions. Severe conditions require more frequent maintenance.

Use the appropriate replacement filter for your engine. See your Cedarapids dealer to be sure you are getting the correct oil filter.

## 12) Engine Oil Filter

Refer to Engine Service and Maintenance manuals for recommended change interval and instructions.

## 13) Engine Coolant

The coolant level must be checked daily. (Figure 6 - 12)

### ⚠ WARNING

Do not remove the radiator cap from a hot engine. Wait until the temperature is below 50°C [120°F] before removing the pressure cap. Failure to do so can result in personal injury from heated coolant spray or steam. Remove the filler cap slowly to relieve coolant system pressure.




Figure 6 - 12 Hot Coolant Hazard

### NOTICE

Do not add cold coolant to a hot engine. Engine castings can be damaged. Allow the engine to cool to below 50°C [120°F] before adding coolant.

Fill the cooling system with coolant to the bottom of the fill neck in the radiator with a 50/50 mixture of antifreeze and clean water. (Figure 6 - 13)




Figure 6 - 13 Adding Engine Coolant

**Important:** Do not overfill the radiator. Overfilling does not leave room for thermal expansion. Excess coolant will be forced out of the overflow. (Figure 6 - 14)




Figure 6 - 14 Do Not Overfill Radiator

## 14) Engine Belt

### **⚠WARNING**

Turn off engine & remove key before performing any inspections or maintenance.

## 14) Engine Belt

Visually inspect the drive belt. Check the belt for intersecting cracks. Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable. Replace the belt if it is frayed or has pieces of material missing. (Figure 6 - 15)




Figure 6 - 15 Engine Drive Belt Damage

Measure the drive belt deflection at the longest span of the belt. (Figure 6 - 16)

**Maximum Deflection** for the Cummins 4BTA & 6BTA engines is 3/8 to 1/2 inch [9.5 to 12.7mm].




Figure 6 - 16 Checking Belt Tension

## 15) Radiator

### 15) Radiator

#### ⚠WARNING

Turn off engine & remove key before performing any inspections or maintenance.

The exterior of the radiator should be checked daily for dirt and other buildup that would restrict the air flow. Paving conditions will determine how often the radiator requires cleaning. If severe conditions exist or there are a lot of air-borne contaminants the radiator will require more attention. Any fluid leaking from any engine compartment component, hose or tube may find its way into the radiator. When cleaning, check between the radiator and other components for buildup.

Check for damaged hoses and loose or damaged hose clamps. (Figure 6 - 17) Replace as required. Check the radiator for leaks in the upper and lower radiator sections. Check the radiator core for damaged or bent fins. Clean and repair as required.




Figure 6 - 17 Radiator Damage

### 16) Cooling Fan

#### ⚠WARNING

Personal injury can result from a fan blade failure. Pulling or prying on the fan can damage the fan blade and cause fan failure.

#### ⚠WARNING

Turn off engine & remove key before performing any inspections or maintenance unless specifically instructed to the contrary in this manual.

A visual inspection of the cooling fan is required daily. Check for cracks and bent or loose blades. Check the fan to make sure it is securely mounted. Tighten the bolts if necessary. Replace any fan that is damaged.

## 17) Battery

### 17) Battery

The battery fluid level should be checked to ensure it is at the correct level.

#### ⚠ WARNING

Do Not allow open flames or sparks near batteries. Battery fumes are highly explosive.

#### ⚠ WARNING

Sulfuric acid in batteries is a poison and could cause severe burns. Avoid contact with skin, eyes, and clothes. When you work around batteries, protect eyes and face from battery fluid and explosion.

#### Checking battery fluid levels

The battery fluid level should be checked to ensure it is at the correct level. If necessary fill the battery with clean water to bring the fluid level up to the bottom of the neck of each battery cell. (Figure 6 - 18)




Figure 6 - 18 Battery fluid levels

#### ⚠ CAUTION

When removing the battery cables, always remove the negative terminal first then the positive terminal. This will reduce the chance of sparking.

The battery terminals should be checked for corrosion buildup and tightness of connection. If necessary remove the terminal cable and clean both the battery cable connector and the battery terminal. Reinstall the positive battery cable connector first then the negative and tighten securely. Loose or corroded connections are a prime source of starting problems and other electrical problems.

#### Cleaning Batteries

Make sure all the battery caps are on tight before cleaning the battery. Allowing dirt or baking soda solution into the battery will destroy the battery.

Batteries should be kept clean at all times. Wipe the outside of the battery with a cloth to remove dirt and grime.

Make sure the vent holes in the battery caps are kept open at all times to allow gas to escape from inside the battery.

To clean the battery cable and terminals, remove the battery cables and clean them with a wire brush. Soak the cables and wash the terminals in a solution of baking soda and water. Rinse the cables, battery, and battery compartment with clean water.

#### Checking Specific Gravity

Refer to the instructions included with your tester for specific instructions on how to use your tester.

## 18)Tire Pressure

Under normal temperature conditions, a fully charged battery will have a corrected specific gravity reading of 1.26. If the reading is below 1.2, the battery should be charged.

In very warm weather the full charged reading should be 1.225. In very cold weather the full charged reading should be 1.28.

If a battery becomes drained and has a specific gravity reading below 1.15, jump starting the engine will put a heavy load on the battery and the charging system which could damage the alternator. If the specific gravity reading is below 1.15, charge the battery before using it to start the engine.

### Storing Batteries

If the paver will be stored for more than 30 days, remove the batter. Make sure the battery is full charged and store the battery in a cool place.

When the battery is stored outside of the paver or while the battery is being charged, never set the battery on a concrete or dirt floor. The battery should be placed on wooden blocks.

## 18)Tire Pressure

Tire pressure for all paver tires should be maintained at 32 psi. The drive tires can be filled with calcium chloride and water in accordance with Table 6 - 2, if necessary, for operational conditions. This capacity puts tires to 75% full.

|                     |           |
|---------------------|-----------|
| <b>Tire Size</b>    | 24.5 x 32 |
| <b>Calcium</b>      | 445 lbs   |
| <b>Water</b>        | 1060 lbs  |
| <b>US Gallons</b>   | 127.02    |
| <b>Total Weight</b> | 1505 lbs  |

Table 6 - 2 Tire fluid capacity

Apply Loctite 272 to threads of lug nuts. Torque lug nuts to 267 ft.-lbs.

## 19) Frame Raise Eccentric

The paver frame raise eccentric should be greased every 500 hours of operation. (Figure 6 - 19)

Some frame raise eccentric plain bearings were assembled with Dow Corning G-N Metal Assembly Paste (P/N 49999-222) and had pipe plugs installed instead of grease fittings.

If a plain bearing is disassembled, re-assemble with Dow Corning G-N Metal Assembly Paste (P/N 49999-222).

If any frame raise eccentric bearing has pipe plugs, remove them, install grease fittings and grease at the 500 hour interval.

## 20) Steel Track Tension




Figure 6 - 19 Frame Raise Lubrication

## 20) Steel Track Tension

The track tension on Track Pavers can be adjusted to provide the desired track tension. The track has an automatic recoil system that allows the tracks to recoil if an impact is encountered then return to previous adjustment point.

### Checking steel track tension

Set the brake switch to ON, travel lever/switch to NEUTRAL and speed dial to MIN (0) before performing checks.

The track tension should be visually checked every day before and during paver operation. If the track looks like it may be getting loose, it can be tested by placing a board or straight edge on the track between the front idler and the first top roller. If the

gap between the bottom of the board and the top edge of the track is greater than 3/4", the track tension must be adjusted. (Figure 6 - 20)

### NOTICE

Perform track tension checks and adjustments when the paver is at operating temperature. Adjusting track tension when the paver is cold could lead to over-tensioning of the track.




Figure 6 - 20 Checking Steel Track Tension

## 20) Steel Track Tension

The Track Paver uses a tension cylinder mounted above the final drive that maintains a constant volume of pressurized oil to the track adjusting cylinders. When the track encounters an obstacle, the system is designed to allow the tensioning idler to recoil, rather than stretch or break the track. When the obstacle is cleared the system returns to the previous track tension adjustment.

The track tensioning cylinder consists of a cylinder with a rodless piston, a needle valve, and a counterbalance valve. (Figure 6 - 21) The piston keeps the oil from the idler tensioning cylinders separated from the main oil supply. When the track encounters an obstacle it forces oil from the idler cylinders into the bottom side of the tensioning cylinder. When the obstruction is cleared, pressurized oil from the traction charge pump forces the tensioning cylinder down which forces the idler cylinders to move back to the original position.




Figure 6 - 21 Steel Track tension hydraulic circuit

The needle valve is used during track tensioning to bring the volume of oil on the bottom side of the tensioning cylinder back to the proper level. The counterbalance valve allows oil flow freely from the top side of the tension cylinder when the track encounters an obstacle.

### Steel Track over-pressurizing

If the track adjusting system is over-pressurizing during operation the following procedure must be performed. It is a good idea to perform this check once each season to verify the tensioning cylinder is in good condition.

### NOTICE

Do not run the paver while the system is over-pressurized. Running with an over-pressurized system could damage the track and sprockets.

- 1) Disconnect the line from the "T" port on the track tension cylinder. Install a plug into the disconnected line. (Figure 6 - 22)




Figure 6 - 22 Adjusting Steel Track Tension

- 2) Attach a drain line to the "T" port and run the other end into a bucket.
- 3) Close the needle valve by rotating clockwise.
- 4) Start the engine and run at full throttle.

- 5) If the track was tensioned properly, no oil will flow into the bucket.
- 6) If only a small amount of oil drains into the bucket, the piston and counterbalance valve are working properly and the track will be properly tensioned.
- 7) If oil continues to flow into the bucket, the piston or counterbalance valve is leaking and must be repaired.
- 8) Turn the engine off and reconnect the hydraulic line to the “T” port.

### Tightening Steel Track

- 1) Start the engine.
- 2) Drive the paver forward very slowly.

### **⚠ WARNING**

Be very careful when reaching over the moving track. Keep feet and loose clothing away from the moving track and rollers.

- 3) Open the needle valve slowly to allow the track to retension. (Figure 6 - 22)
- 4) Close needle valve and stop paver.

### Steel Track Relief Pressure

In addition to adjusting the track tension, the track relief pressure should be checked at least once each season. Refer to the Paver Technical Manual for information on checking track relief pressure.

## 21) Rubber Track Tension

### 21) Rubber Track Tension

The tracks on Rubber-Track Pavers (Figure 6 - 23) do not require periodic adjustment. They are self-adjusted by applying a pre-set hydraulic pressure supplied by the auxiliary pump to the tensioning cylinders. The tracks have an automatic system that allows them to recoil and return to tension if a severe impact is encountered. If tracks appear loose, troubleshoot the track hydraulic system (see Section 5).




Figure 6 - 23 Rubber Track

### Rubber Track Maintenance

The rubber track is designed to be virtually maintenance free. Proper cleaning at the end of each paving day will maintain trouble free operation. However, neglect of the rubber tracks can be expensive.

### 22) Track Pivot

The track pivot should be lubricated every 40 hours of operation. (Figure 6 - 24) The rear pivot has a grease fitting and the front pivot should be lubed with heavy grade oil.




Figure 6 - 24 Track Pivot

## 23) Fire Extinguisher

### 23) Fire Extinguisher

The fire extinguisher should be inspected every 250 hours to ensure the extinguisher is fully charged and has not been damaged.

### 24) Horn

It is essential that the horn is maintained in working order at all times for safety reasons. Before starting the engine each day the horn should be sounded to ensure it is in working order.

### 25) Pump Drive Belts

Turn off engine & remove key before performing any inspections or maintenance.

#### NOTICE

Do not overtighten belts. Overtightening belts can cause premature belt and/or bearing failure.

#### NOTICE

Make sure the belt tension gauge is used correctly. Pushing the wrong end of the tester onto the belt will give an incorrect belt tension reading.

#### WARNING




Figure 6 - 25 Belt Tension Tester

#### Tension Checking Procedure

- 1) Raise Hood
- 2) Loosen belt access covers.
- 3) Position the bottom of the large O-ring on the tester at the deflection indicated in Table 6 - 3. Set the small O-ring on the tester to zero.

|                           |     | Force         | Deflection     |
|---------------------------|-----|---------------|----------------|
| *At Operating Temperature | Min | 18 lbs/8.2 kg | 1/4"<br>6.4 mm |
|                           | Max | 20 lbs/9.1 kg |                |
| Cold Equipment            | Min | 8 lbs/ 3.6 kg |                |
|                           | Max | 10 lbs/4.5 kg |                |

Table 6 - 3 Pump Belt Tension Settings

- 1) Locate the midpoint on the belt and place the belt end of the tester onto the belt.

## 25) Pump Drive Belts

### NOTICE

The tension tester must be inserted perpendicular to the belt to accurately measure belt tension.

- 2) For correct placement and use of tester, refer to (Figure 6 - 26), (Figure 6 - 27), (Figure 6 - 28), and (Figure 6 - 29). Place the tester on the belt perpendicular to the belt. Mark the tester at the point where the tester meets the top of the access cover. It may be necessary to place a straight edge over the belt access hole to accurately mark this position.



Figure 6 - 26 Tester Used Correctly (top view)




Figure 6 - 27 Tester Used Correctly (side view)



Figure 6 - 28 Tester Used Incorrectly




Figure 6 - 29 Testing Poly Chain Belts

- 3) Set the large O-ring 1/4" (6.4 mm) above the mark. (Figure 6 - 25)
- 4) Push on the yellow tipped plunger until the bottom of the large O-ring is level with the straightedge.
- 5) Remove the tester and read the belt deflection force in pounds at the small O-ring. Compare this with the value in (Table 6 - 3). If the force is outside the listed limits the belt should be retensioned.

### Poly Chain Belts

Poly chain belts are designed to provide years of reliable service without stretching. As a result, adjusting the belt tension is **rarely required**. Do not adjust the poly chain belts unless they test below the Minimum setting found in Table 6 - 3.

Tension values for poly chain belts are temperature-sensitive. When installing belts, either new or used, adjust the belts for an 8 to 10 lb setting at 1/4 in deflection when the belts are cold. After the machine is at normal operating temperature (minimum of 2 hours of continuous paving operation), use the values listed in Table 6 - 3.

## 26) Depth Cranks

### NOTICE

Check poly chain belt tension only after the **entire** machine is at operating temperature (minimum of two hours of continuous paving operation).

Do not adjust the belts until they test below the MINIMUM setting when the machine is at normal operating temperatures. Adjusting the belts to the values in Table 6 - 3 when the belts are cold will result in rapid belt failure and possibly damage to pump bearings. Adjust up to (but not exceeding) the MAX setting when the machine is at normal operating temperature.

All poly chain adjustments are to be made at 1/4 inch deflection. For correct placement and use of tester, refer to (Figure 6 - 26), (Figure 6 - 27), (Figure 6 - 28), and (Figure 6 - 29).

## 26) Depth Cranks

The screed depth crank assemblies have two lubrication points on each, one on the threaded link and the other on the screed depth crank bearing housing. These should be lubricated every 40 hours of operation. Table 6 - 30 One to two pumps from a hand grease gun is all that is necessary.




Figure 6 - 30 Depth Crank Lubrication

## 27) Vibrator Bearings

The vibrator assemblies have four lubrication points, one on each vibrator bearing. The grease fittings are remote plumbed to the upper lip of the screed frames. They should be lubricated every 8 hours of operation. One to two pumps from a hand grease gun is all that is necessary. (Figure 6 - 31)




Figure 6 - 31 Vibrator Lubrication

## 28) Crown Control

The crown control has two lubrication points one on each turnbuckle assembly. They should be lubricated every 40 hours of operation. One to two pumps from a hand grease gun is all that is necessary. (Figure 6 - 32)

## 27) Vibrator Bearings




Figure 6 - 32 Crown Control Lubrication

## 29) Match Height Assembly

The match height assemblies have two lubrication points on each, one on the threaded link and the other on the match height bearing housing. These should be lubricated every 40 hours of operation. One to two pumps from a hand grease gun is all that is necessary.

## 30) Extension Slope Assembly

The extending screed slope assemblies have two lubrication points on each, one on the threaded link and the other on the slope shaft bearing housing. These should be lubricated every 40 hours of operation. One to two pumps from a hand grease gun is all that is necessary.

### 31) Final Drive Oil

The final drive planetary oil level should be checked during the first 40 hours of operation and replaced at 150 hours of operation. Drain, flush and refill every 1000 hours of normal operation.

To check the oil level, rotate the drive until the fill plug is straight up and the level check plug is 90 degrees down from the fill plug. Remove the level check plug. The oil level should be even with the bottom of the level check plug hole. If the oil level is low remove the fill plug and add oil to bring the level up to the bottom of the level check plug hole. (Figure 6 - 33)

#### NOTICE

Verify there is no hydraulic oil in the final drive housing before adding gear oil. Hydraulic oil in this housing indicates leakage from the brake or hydraulic drive motor.




Figure 6 - 33 Checking Final Drive Oil Level

Use 80W-90 Gear Oil when adding or replacing final drive oil. Typical brands: Amoco Multipurpose gear Lube 80W-90, Texaco Multipurpose Gear Lube 80W-90, Mobilube HD

### 31) Final Drive Oil

80W-90, Exxon Gear Oil GX 80W-90, Shell Spirax HD 80W-90. An ISO Grade 150 EP oil can be substituted for those given above.

### 32) Steering Bogie Alignment

It is normal for the bogie wheel to get slightly out of alignment during normal operation. Driving with misaligned bogie wheels can make steering difficult and increase wear of the bogie tire. (Figure 6 - 34)




Figure 6 - 34 Bogie Wheel Alignment

If the bogie wheels are angled in or out the wheels will need to be realigned. Realigning the bogie wheels is accomplished without the use of any tools and can be performed any time the paver is parked.

To synchronize the steering bogies:

- 1) Stop the paver and run the engine at full throttle.
- 2) Turn the steering wheel to the left or right until a resistance is felt. Continue turning the steering wheel for 1 to 2 more revolutions.
- 3) Turn steering wheel back to the center position and continue paving.

### 33) Steering Linkage

Lubricate the steering linkage rod ends every 250 hours. (Figure 6 - 35)




Figure 6 - 35 Steering linkage lubrication

The steering linkage, rod ends, bushings, bearings and cylinders should be checked seasonally for adjustment and possible wear.

### 34) Bogie Beam Bearings

The bogie beam bearings should be lubricated every 250 hrs.

### 35) Front Wheel Bearings

The wheel and pivot bearings should be checked and repacked with Lithium base, type EP, Grade 2 grease yearly.

### 36) Bogie Wheel Toe-in

Wheel alignment and amount of tow-in should be adjusted as necessary. Normal amount of tow-in required is approximately 1/16 to 1/8 inch. (Figure 6 - 36)

## 34) Bogie Beam Bearings




Figure 6 - 36 Bogie Wheel Toe-in

## 37) Conveyor Slat Chains

The conveyor chain should be adjusted when 1 inch (25 mm) of sag is visible between the bottom of the paver frame and the top of the conveyor chain. Adjust the chains so the top of the chain is even with the bottom of the frame. (Figure 6 - 37)

### NOTICE

Over tightening the chains increases wear on the conveyor chain, front idlers, drive sprockets and all bearings.




Figure 6 - 37 Conveyor Chain Tension

## 38) Conveyor Bearings

### **⚠WARNING**

Turn off engine & remove key before performing the following inspections or maintenance.

To adjust the conveyor chains:

- 4) Release the locking rod between the dual adjuster. (Figure 6 - 38)




Figure 6 - 38 Conveyor Chain Adjuster

- 5) Using the locking rod or a wrench, rotate the left adjuster 1/2 turn.
- 6) Rotate the right adjuster 1/2 turn.
- 7) Repeat procedure of adjusting the left and then the right until the top of the conveyor chain is even with the bottom of the frame.
- 8) Install the locking rod after finished adjusting.

## 38) Conveyor Bearings

The four conveyor bearings on each conveyor should be lubricated every 8 hours of operation with Lithium base, type EP, Grade 2 grease. Two front conveyor bearing fittings on each side are near the bogie wheels or track idler. (Figure 6 - 39) The inner (Figure 6 - 45) and outer (Figure 6 - 41) rear conveyor bearing fittings are mounted on the front and back of the rear bulkhead.




Figure 6 - 39 Front Conveyor Fittings




Figure 6 - 40 jRear Inner Conveyor Fittings




Figure 6 - 41 Rear Outer Conveyor Fittings

### 39) Delivery Auger Clearance

As the delivery auger wears the spacing between the auger flighting and liner will increase. This spacing should be the same on both ends and greater than the largest aggregate diameter used in the asphalt mix. Inspect at 40 hours of operation and adjust every 120 hours of operation.

#### NOTICE

Recommended clearance is 1 - 1/4" min. to 1 - 3/4" max. (Figure 6 - 42)




Figure 6 - 42 Delivery Auger Adjustment

### 39) Delivery Auger Clearance

To adjust auger spacing: (Figure 6 - 43)

- 9) Loosen four drive retaining bolts on gearbox and reposition drive end augers.
- 10) Next, loosen hopper end of augers retaining bolts and reposition augers.
- 11) Make sure augers are positioned to recommended clearance between 1 - 1/4" min. to 1 - 3/4" max. at both ends of augers.
- 12) Tighten all bolts to lock in place.




Figure 6 - 43 Setting Auger to Liner Spacing

#### 40) Delivery Auger Drive - Gear Drive

Each delivery auger gear drive speed reducer oil level should be checked every 40 hours and replaced every 1000 hours of operation. The oil is at the correct level when the oil is just above the sight glass (check at style A or B). (Figure 6 - 44)

Use 80W-90 gear oil in the speed reducer. Typical brands: Amoco Multipurpose gear Lube 80W-90, Texaco Multipurpose Gear Lube 80W-90, Mobilube HD 80W-90, Exxon Gear Oil GX 80W-90, Shell Spirax HD 80W-90. An ISO Grade 150 EP oil can be substituted for those given above.




Figure 6 - 44 Delivery Auger Drive Gear Drive

#### 40) Delivery Auger Drive - Gear Drive

#### 41) Front Delivery Auger Bearings

The front delivery auger bearing on each of the four augers should be lubricated every 8 hours of operation with Lithium base, type EP, Grade 2 grease. (Figure 6 - 45)




Figure 6 - 45 Front Delivery Auger Fittings

#### 42) Spreading Auger Bearings

The spreading auger bearings should be lubricated every 8 hours of operation with Lithium base, type EP, Grade 2 grease. (Figure 6 - 46)




Figure 6 - 46 Spreading Auger Bearings

### 43) Spreading Auger Drive Chains

The spreading auger drive chains should be checked every 40 hours of operation. Check the drive chains for proper tension and wear. Check the bronze spacer washer between the auger drive sprockets for wear. Clean the housing and lubricate the chains and spacer with fuel oil from the spray-down hose or with SAE 10 motor oil. A small amount of oil may be left in the housing for lubrication between checks even though the housing is not oil tight.

#### ⚠WARNING

Turn off engine & remove key before performing the following inspections or maintenance.

- 13) Remove the cap screws holding the spreading auger drive chain cover. Pull the cover back and off. (Figure 6 - 47)




Figure 6 - 47 Adjusting Spreading Auger Drive Chain

- 14) Loosen the jam nuts on the drive chain adjuster rods.

### 43) Spreading Auger Drive Chains

- 15) Using the adjuster rods, remove the slack from the chain, but do not over tighten. At the correct tension, the chain should move slightly under thumb pressure.
- 16) After both chains have been tensioned properly, tighten the jam nuts. Replace the cover.

### 44) Spreading Auger Speed Reducer

#### ⚠WARNING

Turn off engine & remove key before performing the following inspections or maintenance.

The spreading auger speed reducer oil level should be checked in the first 40 hours and replaced every 1000 hours of operation. The oil is at the correct level when the oil is level with the bottom threads of the level check plug. (Figure 6 - 48)




Figure 6 - 48 Spreading Auger Speed Reducer

Use 80W-90 gear oil in the spreading auger speed reducer. Typical brands: Amoco Multipurpose gear Lube 80W-90, Texaco Multipurpose Gear Lube 80W-90, Mobilube HD 80W-90, Exxon Gear Oil GX 80W-90, Shell Spirax HD 80W-90. An ISO Grade 150 EP oil can be substituted for those given above.

## 45) Feeder Drive Chains

The feeder drive chains should be checked every 40 hours of operation. Check the drive chains for proper tension and wear. Clean the housing and lubricate the chains with fuel oil from the spray-down hose or with SAE 10 motor oil. A small amount of oil may be left in the housing for lubrication between checks even though the housing is not oil tight. Check for asphalt mix build-up inside case and remove if present.

### ⚠WARNING

Turn off engine & remove key before performing the following inspections or maintenance.

- 17) Remove the cap screws holding the feeder drive chain cover. Pull the cover back and off. (Figure 6 - 49)

## 45) Feeder Drive Chains




Figure 6 - 49 Adjusting feeder drive chain

- 18) Loosen the jam nuts on the feeder drive chain adjuster rods.
- 19) Using the adjuster rods, remove the slack from the chain, but do not over tighten. At the correct tension, the chain should move slightly under thumb pressure.
- 20) After both chains have been tensioned properly, tighten the jam nuts. Replace the cover.

## 46) Conveyor Speed Reducer

### ⚠WARNING

Turn off engine & remove key before performing the following inspections or maintenance.

The conveyor speed reducer oil level should be checked in the first 40 hours and replaced every 1000 hours of operation. The oil is at the correct level when the oil is level with the bottom threads of the level check plug. (Figure 6 - 50)




Figure 6 - 50 Conveyor Speed Reducer

Use 80W-90 gear oil in the conveyor speed reducer. Typical brands: Amoco Multipurpose gear Lube 80W-90, Texaco Multipurpose Gear Lube 80W-90, Mobilube HD 80W-90, Exxon Gear Oil GX 80W-90, Shell Spirax HD 80W-90. An ISO Grade 150 EP oil can be substituted for those given above.

## 42) Hood Raise Reservoir

The hood raise reservoir oil level should be checked periodically. Use AW 68 hydraulic oil in the hood raise reservoir. (Figure 6 - 51)




Figure 6 - 51 Hood Raise Reservoir

## 42) Hood Raise Reservoir

## 48) Operator Console Pivot Bearings

The operator console pivot should be lubricated every 250 hours of operation. (Figure 6 - 52)




Figure 6 - 52 Operator Console Pivot Bearings

## 49) Tow Arm Nose Roller

The tow arm pull point roller should be lubricated every 8 hours of operation. (Figure 6 - 53)




Figure 6 - 53 Tow Arm Nose Roller

50) Slope Beam Rod Ends

50) Slope Beam Rod Ends

The slope beam rod ends should be lubricated every 250 hours of operation. (Figure 6 - 54)




Figure 6 - 54 Slope Beam Rod Ends

51) Truck Hitch

The truck hitch should be cleaned as part of the daily cleaning to remove any asphalt that has collected on the truck hook or rollers. Spray the truck hook and rollers with diesel fuel during spraydown.

52) Fume Recovery System

The fume recovery system vacuum indicator should be checked each day before beginning operation. With the engine running at full throttle, the vacuum indicator should register a reading. When the vacuum indicator reading is too low, components of the fume recovery system require maintenance. Refer to (Table 6 - 4) for troubleshooting information.


| Problem                           | Cause                                                                                                                                                                                                                                 | Remedy                                                                                                             |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| Low vacuum reading                | Low hydraulic pressure to fume recover fan motor.<br>Damaged, collapsed or disconnected fume recovery hoses between fume recovery fan and muffler.<br>Plugged or collapsed fume recovery hoses between fume recovery fan and muffler. | Refer to paver hydraulic schematic<br>Repair, replace, or reconnect hoses<br>Clean or replace fume recovery hoses. |
| High vacuum reading               | Plugged fume recovery hoses between fume recovery fan and fume recovery hoods.                                                                                                                                                        | Clean or replace fume recovery hoses.                                                                              |
| Visible fumes escaping from hoods | Fume recovery system not operating properly.                                                                                                                                                                                          | Ensure fume recovery system is completely installed.<br>Check vacuum indicator system.                             |

Table 6 - 4 Fume Recovery System Troubleshooting

## 52) Fume Recovery System

### Fume Recovery System Repair

- 1) Check hoses and tubes for cracks, cuts, dents, or collapsed spots. Cuts or cracks may be repairable with duct tape. Repair or replace tubes as needed (Figure 6 - 55).
- 2) Check interior surfaces of hoses and tubes for asphalt buildup. Clean tubes and hoses by soaking in solvent and brushing clean. Hoses and tubes may be more economically replaced than cleaned.
- 3) Disassemble the fan for cleaning using the following procedure (Figure 6 - 56):
  - a) Disconnect tubes from left and right hoods and to muffler.
  - b) Disconnect hose to vacuum indicator.
  - c) Remove four bolts retaining inlet manifold to fan assembly and remove inlet manifold.
  - d) Lift off fan housing.
  - e) Remove bolt and two washers retaining fan wheel to motor shaft.
  - f) Remove fan plate by removing four bolts.



1 - Vacuum Indicator

2 - Muffler

3 - Paver Rear Bulkhead

4 - Fan

5 - Fixed Fume Recovery Hood Section

6 - Proportional Feed Sensor Mounting Hole

Figure 6 - 55 Fume Recover System Components

- 4) The parts removed in the previous step can all be cleaned by soaking in solvent and cleaning with a brush.
- 5) Reassemble fan in reverse order. When installing fan wheel, use Loctite 242 on the bolt and torque to 110 in-lb.

---

## 52) Fume Recovery System

---

### NOTICE

Fan housing is sealed with RTV silicone.

At least once each year, the system should be thoroughly inspected to ensure proper operation.




Figure 6 - 56 Fume Recovery Fan Disassembly

- 6) With the engine warmed up, lower the screed and run the engine at full throttle.
- 7) Read the vacuum from the vacuum indicator mounted on the rear bulkhead. If the reading is low or has no reading, the fume recovery tubing may be dirty, plugged, collapsed, damaged, or disconnected.
- 8) Record the vacuum reading and any required maintenance in (Table 6 - 5).

52) Fume Recovery System

Table 6 - 5 Fume Recovery System Maintenance Log

| Date | Vacuum Indicator Reading | Maintenance Performed /Notes |
|------|--------------------------|------------------------------|
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |
|      |                          |                              |

## Corrective Maintenance

### Corrective Maintenance


#### Steel Track

The track is designed to be virtually maintenance free. Proper cleaning and lubrication at the end of each paving day will maintain trouble free operation. However, neglect of the tracks can be expensive. Every time paver is cleaned, the track pins should be sprayed with light oil to lubricate them preventing them from rusting and binding.

The track paver uses a tension cylinder mounted above the final drive that maintains a constant volume of pressurized oil to the track adjusting cylinders. When the track encounters an obstacle, the system allows the tensioning idler to recoil rather than stretch or break the track. When the obstacle is cleared the system returns to the previous track tension adjustment.

The track tensioning cylinder assembly consists of a cylinder with a rodless piston, a needle valve, and a counterbalance valve. (Figure 6 - 21) The piston keeps the oil from the idler tensioning cylinders separated from the main oil supply. When the track encounters an obstacle, it forces oil from the idler cylinders into the bottom side of the rodless cylinder. When the obstruction is cleared, pressurized oil from the traction charge pump forces the tensioning cylinder down which forces idler cylinders to move back to original position.

The needle valve is used during track tensioning to bring the volume of oil on the bottom side of the rodless cylinder back to the proper level. The counterbalance valve allows oil to flow freely from the top side of the rodless cylinder to the tank when the track encounters an obstacle.



- |                               |                             |
|-------------------------------|-----------------------------|
| 1 - Counterbalance valve      | 4 - Needle valve            |
| 2 - Rodless piston cylinder   | 5 - Idler tension cylinders |
| 3 - Tensioning cylinder assy. |                             |

Figure 6 - 57 Track tension hydraulic circuit

#### Steel Track Tensioning

If the track looks like it may be getting loose, it can be tested by placing a board or straight edge on the track between the front idler and the first top roller. If the gap between the bottom of the board and the top edge of the track is greater than  $\frac{3}{4}$ ", the track tension must be adjusted. (Figure 6 - 58)




Figure 6 - 58 Checking track tension

### NOTICE

Perform track tension checks and adjustments when the paver is at running temperature. Adjusting track tension when the paver is cold could lead to over-tensioning of the track.

Adjust track tension as follows:

- 1) Start the engine.

## Steel Track

- 2) Open the needle valve slowly to allow the track to retension. (Figure 6 - 60)
- 3) Drive the paver forward and backward slowly.

### ⚠ WARNING

Be very careful when reaching over the moving track. Keep feet and loose clothing away from the moving track and rollers.

- 4) Stop the paver and close needle valve.
- 5) A properly tensioned track should have a 3/8" to 1/2" gap between a straightedge and the track. (Figure 6 - 59)




Figure 6 - 59 Proper Track Tension

### ⚠ WARNING

Overtightening the track can cause serious damage to the track, idler or drive.

### Steel Track over-pressurizing

If the track adjusting system is over-pressurizing during operation, the following procedure must be performed. It is a good idea to perform this check once each season to verify the tensioning cylinder is in good condition.

### NOTICE

Do not run the paver while the system is over-pressurized. Running with an over-pressurized system could damage the track and sprockets.

- 1) Disconnect the line from the "T" port on the track tension cylinder. Install a plug into the disconnected line. (Figure 6 - 60)
- 2) Attach a drain line to the "T" port and run the other end into a bucket.
- 3) Close the needle valve by rotating clockwise.
- 4) Start the engine and run at full throttle.
- 5) If the track was tensioned properly, no oil will flow into the bucket.
- 6) If only a small amount of oil drains into the bucket, the piston and counterbalance valve are working properly and track will tension properly.




Figure 6 - 60 Bottoming Tension Cylinder

- 7) If oil continues to flow into the bucket, the piston or counterbalance valve is leaking and must be repaired.
- 8) Turn the engine off and reconnect the hydraulic line to the “T” port.

### Steel Track Relief Pressure

In addition to adjusting the track tension, the track relief pressure should be checked at least once each season. Refer to the Paver Technical Manual for information on checking track relief pressure.

### Steel Track Installation

#### ⚠ WARNING

When installing or removing the track, keep hands and feet out from under the track/paver.

#### ⚠ CAUTION

When disconnecting oil line in the following step, allow oil pressure to bleed off by loosening hose end first. When all pressure has been vented, remove oil line.

- 1) Disconnect the track tensioning oil line from the “T” port on the track tensioning cylinder. (Figure 6 - 60)
- 2) Jack up the track frame until the track can be slid under the bogies. Support the paver with blocking capable of supporting the weight of the paver.

### Steel Track

- 3) Place boards between the sprocket and upper roller as shown. This elevates the track allowing it to clear the upper roller while driving the track toward the idler. (Figure 6 - 61)




Figure 6 - 61 Place board between sprocket and roller

- 4) Place the track under the paver with the end of the track marked OPEN positioned on the sprocket as shown and the other end stretched out in front of paver. (Figure 6 - 62)




Figure 6 - 62 Roll out track

- 5) Start the engine and rotate the sprocket until the end of the track marked OPEN just touches the front idler. (Figure 6 - 63)




Figure 6 - 63 Rotate sprocket to install track

- 6) Use a come-a-long or hoist to lift and draw the track ends together. (Figure 6 - 64)
- 7) Place blocks under the track assembly as shown to support loose track end.




Figure 6 - 64 Pull track ends together

- 8) Remove paint from interlocking ribs of master link and lightly grease contact surfaces. Clean bolt holes and threads, and apply anti-seize or grease to track shoe bolts.
- 9) Connect the ends of the track by mating the two halves of the master link. (Figure 6 - 65)




Figure 6 - 65 Connecting Master Link

- 10) Once the master link is connected, apply Loctite to bolts and install track pads. (Figure 6 - 66)

## Steel Track




Figure 6 - 66 Install track pad

### Steel Track Removal

To remove the track assembly, perform Track Installation procedures in reverse order.

### Replacing Steel Track Drive Sprockets

When sprocket teeth are worn, the sprocket can be replaced or turned around to restore sprocket teeth to new condition. Perform the following procedure if sprocket replacement is necessary.

- 1) Rotate the track until the master link is positioned on the sprocket.
- 2) Disconnect the track tensioning oil line from the "T" port on the track tension cylinder. (Figure 6 - 60)

### NOTICE

After splitting the track, do not remove it completely. Position the track so it will not interfere with sprocket removal.

- 3) Split the track and pull ends away from sprocket. (Figure 6 - 67)
- 4) Remove cap screws securing sprocket and remove sprocket from hub assembly.
- 5) Clean sprocket cap screws and bolt holes and apply Loctite to cap screws.




Figure 6 - 67 Remove link pin to separate track

- 6) Place new or rebuilt sprocket onto hub assembly and secure with cap screws. If desired, the old sprocket can be turned around to utilize the opposite side of teeth.
- 7) Connect the track as shown in the Track Installation Procedure.

### Repairing Oscillating Bogie Rollers

There are four oscillating bogie assemblies which support the weight of the paver on each side. Each bogie contains two rollers which are oil-filled and sealed. These rollers should not require attention for entire life of the bearings and oil seals inside.

When a paver has been in service for a long period of time the roller bearings will begin to wear. Severely worn bearings will cause operating problems. At least once each season, each roller should be relieved of all loading and checked for end play, which indicates bearing wear. If roller bearings are worn out (excessive wobbling), the roller assembly should be replaced.

Accumulation of dust and dirt on the roller is an indication that a roller is leaking. If this is detected, the roller should be removed and repaired as described in the following instructions. Do not delay this repair otherwise the roller bearings may be operating without lubrication which will quickly destroy the bearings.

## Steel Track

- 1) Break the track as described in the previous section.
- 2) Jack up track frame until the track is completely off the ground and install safety blocks capable of supporting the weight of the paver.
- 3) Remove cap screw and pull the oscillator shaft out. Bogie should fall down to the track.

### CAUTION

Roller should be disassembled in a clean environment. Do not allow dirt to contaminate bearings and seals inside roller.

- 4) Remove four lock screws which secure the roller to the bogie. (Figure 6 - 68)
- 5) Remove shaft housing cap.




Figure 6 - 68 Track roller

## Frame Raise Bushing Repair

### NOTICE

Observe the positioning of the seals while removing, the new seals will need to be installed in the same manner.

- 6) Remove polished metal seal and both rubber seals. Drain oil and stand the roller on end with the open end up. Pour one pint of fresh oil along the flat portion of the shaft.

**Note:** Rollers are factory-filled with Mobil Glygoyle 30 synthetic oil. Mineral oils are not compatible, so do not mix.

- 7) Install new seals.
- 8) Install shaft housing cap and secure to bogie frame with four lock screws.
- 9) Install bogie assembly in track frame.
- 10) Reconnect track as described in previous section.

### Frame Raise Bushing Repair

The cylinders on the 500 Series frame raise mechanism are held in place on the top by a bushing. A special tool, P/N 9704-800-31, has been designed to simplify the process of removing these bushings. (Figure 6 - 69)




Figure 6 - 69 Bushing removal tool




Figure 6 - 70 Remove bolt

- 1) Remove the bolt retaining the bushing to the frame. (Figure 6 - 70)




Figure 6 - 71 Install bushing removal tool

- 2) Install and tighten the bushing removal tool into the bolt hole. (Figure 6 - 71)




Figure 6 - 72 Pump grease into bushing removal tool

- 3) Pump grease into the bushing removal tool fitting. As grease is pumped in, the bushing will be pushed out of frame. Continue to pump grease until grease leaks out around the bottom of the bushing. (Figure 6 - 72)




Figure 6 - 73 Remove tool and bushing

- 4) Remove the bushing removal tool and the bushing. (Figure 6 - 73)

## Rubber Track




Figure 6 - 74 Remove bushing from tool

- 5) Remove the bushing from the bushing removal tool. (Figure 6 - 74)

## Rubber Track

The rubber track is designed to be virtually maintenance free. Proper cleaning at the end of each paving day will maintain trouble free operation. However, neglect of the rubber tracks can be expensive.

### Rubber Track Tension

The tracks on rubber track pavers (Figure 6 - 75) do not require periodic adjustment. They are self-adjusted by applying a pre-set hydraulic pressure supplied by the auxiliary pump to the tensioning cylinders. The tracks have an automatic system that allows them to recoil and return to tension if an impact is encountered. If tracks appear loose, troubleshoot the track hydraulic system (see Section 5).




Figure 6 - 75 Rubber Track

## Rubber Track

### Rubber Track Removal and Installation

#### **⚠ WARNING**

When installing or removing the track, keep hands and feet out from under the track/paver.

#### Removal

Release the track tension by:

- 1) Shut off engine and remove key from ignition.
- 2) Loosen jam nut on tension release valve cartridge (Figure 6 - 76).




Figure 6 - 76 Release Rubber Track Tension

- 3) Insert an allen wrench into the adjusting screw, slowly turn it counter-clockwise to open the valve and release hydraulic pressure.
- 4) Insert a porta-power between the track frame nose plate and the track (Figure 6 - 77) (protecting track from damage by inserting a block of wood or steel plate between ram and track).




Figure 6 - 77 Insert Porta-Power

- 5) Extend porta-power to loosen track.
- 6) Remove porta-power.
- 7) Jack up track frame until the track will slide out from under the bogies. Support paver with blocking capable of supporting its entire weight.
- 8) Un-bolt and remove screed pull arm.
- 9) Un-bolt slope beam rod from tow point cylinder mounting assembly.
- 10) Un-bolt tow point cylinder mounting assembly from track frame. Swing assembly out of the way and secure to paver. If desired, disconnect hydraulic hoses to cylinder, plug to prevent contamination, and set assembly aside.
- 11) Un-bolt and remove outer half of drive wheel.
- 12) Un-bolt and remove outer front idler nose plate.
- 13) Rubber track may now be pulled off track frame.

## Rubber Track

---

### Rubber Track Installation

- 1) With track removed as described above, clean track frame and wheels of debris, dirt, and asphalt build-up.
- 2) Slide track onto frame making sure center lugs are in alignment between bogie wheels and front idler.
- 3) Install front idler outer nose plate (Figure 6 - 78).
- 4) Install outer half of drive wheel.
- 5) Install tow point cylinder mounting assembly on track frame. If hydraulic hoses were disconnected, re-connect to the appropriate fittings.
- 6) Install slope beam rod back onto tow point cylinder mounting assembly.
- 7) Install screed pull arm.
- 8) Insert an allen wrench into the adjusting screw on tension release valve cartridge (Figure 6 - 76). Slowly turn it clockwise until the valve seats.
- 9) Tighten jam nut on valve cartridge.
- 10) Track is now ready to be re-tensioned.

## Rubber Track




Figure 6 - 78 Rubber Track Removal

### Rubber Track Re-tensioning

- 1) Start engine and run at idle.
- 2) Set brakes to ON and allow the track tensioning system to charge itself.
- 3) The track tensioning cylinders should extend and the track should tighten.
- 4) If the track does not tighten or the system does not operate properly, see Section 5 for troubleshooting procedures.

---

## Rubber Track

---

### Repairing Rubber Track Bogie Wheels

There are six oscillating bogie wheel assemblies (three on each side) which support the weight of the paver. Each assembly contains four bogie wheels which are fitted with tapered roller bearings packed with roller bearing grease and sealed to prevent the entry of dirt and debris. The bogie wheels should not require attention for the entire life of the bearings and seals.

When a paver has been in service for a long period of time, the roller bearings will begin to wear. Severely worn bearings will cause operating problems. At least once each season, each bogie assembly should be relieved of all loading and each wheel checked for end play. Each bogie wheel should not have any end play, but a preload of .002" - .004".

### Bogie Wheel Assembly Removal

To remove the bogie wheel assemblies for repair or replacement of parts:

- 1) Perform Release Track Tension of this section. See "Rubber Track Removal and Installation" on page 41. Also see (Figure 6 - 76) and (Figure 6 - 77).

### NOTICE

It is not necessary to completely remove the track to service the bogie wheel assemblies. The paver must only have the track tension relieved and be raised off the ground far enough for the assemblies to clear the bottom of the track frame and the track center lugs.

### ⚠ WARNING

When removing the bogie wheel assemblies, keep hands and feet clear from between the track and wheel assemblies.

- 2) Remove shaft from track frame that holds center bogie wheel assembly to frame (Figure 6 - 79). This will allow the assembly to drop onto the track.
- 3) Remove the bogie wheel assembly by drawing it out over the center lugs of the track.
- 4) Remove the front and rear bogie wheel assemblies, as described above, after the center assembly has been removed.

### NOTICE

If the track has been removed, each individual bogie wheel assembly may be removed without first removing the center assembly.




Figure 6 - 79 Bogie Wheel Assembly Removal

### Bogie Wheel Assembly Installation

To install bogie wheel assemblies after they have been removed from track frame, simply reverse the process listed in See “Bogie Wheel Assembly Removal” on page 44. of this section.

### Bogie Wheel Bearing Replacement

If it is determined that bearing replacement is necessary, proceed with the following: (Figure 6 - 80)

### Disassembly

- 1) Remove bogie wheel assembly as described above. See “Bogie Wheel Assembly Removal” on page 44.
- 2) Remove grease cap (12).

### Rubber Track

- 3) Bend back locking tab on lock washer (10) and remove bearing nut (11).

### NOTICE

If bearings are to be re-used, keep cups and cones in matched sets as originally installed.

- 4) Slide bogie wheel (3) off hub. The keyed flat washer(9), outer bearing cup (7) and cone (6) will be removed with the wheel as will the inner bearing cup (5).
- 5) Remove inner bearing cone (4) and shaft seal (8).
- 6) Clean all parts with mineral spirits solvent, inspect for damage, and replace as necessary.

### Assembly

The following procedure is for establishing the proper bearing setting (.002” - .004” preload) on the bogie wheels. (Figure 6 - 80):

- 1) Pack inner (4) and outer (6) bearing cones with grease and set aside.
- 2) If inner cup (5) and/or outer cup (7) are to be new, install them at this time by pressing into bogie wheel housing (3) as shown.
- 3) Slide inner cone (4), packed with grease, into the inner cup (5) and then install the shaft seal (8) by pressing into bogie wheel housing (3) as shown.
- 4) Lubricate lip of seal with a small amount of oil or grease.

## Rubber Track




Figure 6 - 80 Bogie Wheel Bearings

5) Slide bogie wheel onto shaft making sure not to damage lip of seal. This step is best done with the bogie frame (1) turned so the shaft is in a vertical position.

6) Pack the cavity between the bearings with grease.

7) Slide outer cone (6), packed with grease, onto shaft.

8) Slide keyed flat washer (9) and bearing lock washer (10) onto shaft.

9) Install bearing nut (11) and tighten to 50 ft/lbs while rotating bogie wheel. This will seat the bearings.

10) Loosen bearing nut until it is finger tight.

### NOTICE

Take care not to unseat bearings when bearing nut is loosened.

11) Tighten bearing nut to 32 ft/lbs while rotating bogie wheel.

12) Select one of the locking tabs on the bearing lock washer (10) that is closest to a slot on the bearing nut, and either tighten or loosen nut to align the slot and tab.

13) Bend locking tab into slot on bearing nut to lock it in place.

14) Install grease cap (12) into bogie wheel housing.

Repeat steps 1 through 14 above for each bogie wheel.

## Rubber Track

### Repairing Rubber Track Front Idler Assembly

The front track idlers, (one on each side), provide the mechanism to maintain tension on the tracks. Each idler assembly consists of two idler wheels bolted to the idler housing, a shaft with tapered roller bearings surrounded by a multi-part frame that acts as a push bar and guide to keep the idler aligned in the track frame. The front idler bearings should not have any end play, but a preload of .001" - .003".

### Front Idler Assembly Removal

To remove front idler assembly from the track frame: (Figure 6 - 81)

- 1) Perform the procedureSee "Rubber Track Removal and Installation" on page 41. of this section.

### NOTICE

It is necessary to completely remove the track to allow the front idler to be removed from track frame.

- 2) Remove front nose plate pivot retaining bracket (4) from the paver frame.
- 3) Once the track is removed from machine, remove front nose plate (3).
- 4) Remove cam rollers (6) from idler assembly plates.
- 5) The front idler assembly (5) may now be slid forward out of the slots in track frame and lifted from the machine.




Figure 6 - 81 Front Idler Assembly Removal

## Rubber Track

### Front Idler Assembly Repair

If it is determined that bearing replacement is necessary, proceed with the following: (Figure 6 - 82)




Figure 6 - 82 Front Idler Assembly Repair

---

## Rubber Track

---

### Disassembly

- 1) Remove front idler assembly as described above. See “Front Idler Assembly Removal” on page 47. of this section.
- 2) Drive roll pins (12) out of slide blocks (6).
- 3) Remove slide blocks (6) from shaft (5).
- 4) Remove and disassemble side plates (2) and (3) from push bar (4).
- 5) Remove bearing caps (8) from each side of idler housing (7). Seals (11) will remain in caps.

#### NOTICE

If bearings are to be re-used, keep cups and cones in matched sets as originally installed.

- 6) Tap one end of shaft (5) with soft hammer or block of wood to remove bearing cup (10) from the opposite end. Shaft will then come out of idler housing (7) with bearing cones (9) still on shaft.
- 7) Using a punch, remove the remaining bearing cup from the idler housing.
- 8) At this time, if the idler wheels (1) need to be replaced, remove them from idler housing (7) by removing cap screws (16), lock nuts (23), and hardened flat washers (17).
- 9) Clean all parts with mineral spirits solvent, inspect for damage, and replace as necessary.

### Bearing Replacement

Refer to (Figure 6 - 82) and the following procedure:

#### NOTICE

Use Loctite 272 thread compound on all cap screws.

- 1) Pack bearing cones (9) with grease and set aside.
- 2) Install new seals (11) into each bearing cap (8) and set aside.
- 3) Press bearing cones onto shaft (5) and set aside.
- 4) Press one bearing cup (10) into idler housing.
- 5) Install one bearing cap (8) onto idler housing and tighten cap screws (18).
- 6) Slide shaft, with bearings, into idler housing taking care not to damage seal in bearing cap. This step is best done with the idler housing turned so the shaft is inserted in a vertical position.

#### NOTICE

The shaft must be free to rotate.

- 7) Press the other bearing cup into idler housing.
- 8) Install the other bearing cap with seal (and without shims 20-21-22) onto idler housing.

## Rubber Track

- 9) Install two cap screws (18) 180° from each other and tighten in 90° increments. As the two cap screws are tightened, keep the others finger tight to prevent the bearing cap from flexing as it puts pressure on the bearings.
- 10) While turning the shaft with a torque wrench, continue the tightening until a sudden rapid rise in the torque is seen, then stop.
- 11) Measure and record the torque reading as the baseline rolling torque. You will need this reading later.
- 12) Turn the shaft again as above, and continue tightening the two cap screws until a 20 to 55 in/lb increase in rolling torque is achieved.
- 13) Using either a taper gage or a feeler gage, measure and record the gap, in thousandths of an inch, between the bearing cap and the idler housing. Perform this measurement by the two cap screws 180° apart described above.
- 14) Average these two measurements.  
Example - One measurement is .022" and the other is .032".  
 $.022" + .032" = .054"$  divided by 2 = .027"  
.027" is the thickness of shim stack needed.  
Refer to the table in (Figure 6 - 82) for combinations to make up the proper thickness shim stack.
- 15) Remove the bearing cap, install the shim stack, and re-assemble tightening all cap screws to specified torques.
- 16) Rotate the shaft, measure and record the rolling torque once again. This torque value should be 20 to 55 in/lb greater than the baseline rolling torque recorded in step 11.

- 17) If this torque value is not achieved, repeat steps 9 through 16.

### Assembly

Refer to (Figure 6 - 82) and the following procedure to re-assemble the front idler assembly after bearing replacement:

#### NOTICE

Use Loctite 272 thread compound on all cap screws unless otherwise noted.

- 1) If idler wheels (1) have been removed from idler housing (7), install cap screws (16) using G-N assembly paste P/N 49999-222, hardened washers (17), and lock nuts (23).

#### NOTICE

Tighten lock nuts (23) to 250 ft/lb. **Do Not** use impact wrench on these nuts.

- 2) Slide side plates (2) and (3) over ends of shaft.
- 3) Install push bar (4) to side plates and leave cap screws (14) finger tight.
- 4) Install slider blocks (6) through side plates and onto shaft (5) aligning each roll pin hole in block with hole in shaft.
- 5) Install roll pins (12) into slider blocks and drive through holes in shaft until flush with edge of blocks.
- 6) Rotate, if necessary, slider blocks to align cap screw holes with holes in side plates.

7) Install cap screws (15) and tighten to specified torque.

8) Tighten side plate-to-push bar cap screws to specified torque.

Front idler assembly is now ready to be installed back onto track frame.

### Front Idler Assembly Installation

Refer to (Figure 6 - 81) and the following procedure to install assembled front idler in track frame:

#### NOTICE

Use Loctite 272 thread compound on all cap screws.

- 1) Lift front idler assembly and position slider blocks in slots in track frame with push bar toward the rear.
- 2) Slide assembly rearward until holes in side plates line up with slots in track frame.
- 3) Install cam rollers into holes in side plates through slots in track frame and tighten to specified torque.
- 4) Install front nose plate.
- 5) Track may now be installed per See “Rubber Track Installation” on page 42.

### Rubber Track Drive Wheel Replacement

When replacement of rubber track drive wheels becomes necessary, use the following procedure:

### Rubber Track Drive Wheel Replacement

#### Removal

- 1) Follow the instructions in Rubber Track Installation & Removal on page 5 of this section for removing the outer drive wheel and track.
- 2) Once outer drive wheel and track are removed, remove the two remaining cap screws which hold the inner drive wheel to the drive motor hub (Figure 6 - 83) and slide wheel off hub.

#### Installation

- 1) Slide inner drive wheel onto drive motor hub.
- 2) Secure wheel to motor hub with two cap screws 180° apart from each other, use Loctite 272 and torque to 404 ft.-lbs.
- 3) Install track and outer drive wheel per instructions in Rubber Track Installation on page 40 of this section.
- 4) Install remaining drive wheel bolts, use Loctite 272 and torque to 404 ft.-lbs.

#### NOTICE

Outer drive wheel must be installed with the two larger holes 180° apart from each other aligned and slid over the two cap screws retaining the inner drive wheel.

## Rubber Track Drive Wheel Replacement




Figure 6 - 83 Drive Wheel Replacement

## Slat Conveyor Paver, Slat Conveyors

### Replacing Slat Conveyor Liners

Liners are bolted to the hopper bed to provide a wearing surface over which the mix is carried. If slat liners are worn out, chances are the chains are as well; inspect and replace or adjust as needed. (Refer to Slat Conveyor Tensioning.)

- 1) Detach screed from tractor. Make sure all electrical cables and hydraulic hoses are disconnected before pulling tractor away (Refer to Screed Section of this manual).
- 2) Elevate the paver to allow an adequate amount of safe working space under the tractor so the liner nuts can be reached. Support the paver with blocking equipment capable of supporting the weight of the paver.
- 3) Remove outer front and center front skirt boards. (Figure 6 - 84)
- 4) Remove outer rear and inner rear skirt boards.
- 5) Loosen slat conveyor chain take-ups.
- 6) Remove pin from chain link and break each chain at a point just below the rear drive sprockets.
- 7) Pull the top section of each slat conveyor forward through the hopper. Place slat conveyors on the ground in front of the paver. The return portion of each conveyor (underside of paver) need not be moved unless the slats and chains are to be inverted.
- 8) Unbolt and replace all liner panels which are worn out.

## Slat Conveyor Paver, Slat Conveyors

- 9) Reinstall all parts by reversing the disassembly procedure and perform the Slat Conveyor Tensioning procedure.




Figure 6 - 84 Replacing hopper liners

### Inverting Slat Bars

The slat conveyors consist of two continuous chains linked together by a series of bars. When a slat bar becomes worn on one side the slat bar can be removed and turned over to allow use of the other side.

## Remix Paver Delivery Augers

### Replacing Auger Liners

Liners are bolted to the hopper bed to provide a wearing surface over which the mix is carried. Inspect and replace auger liners as needed.

- 1) Detach screed from tractor. Make sure all electrical cables and hydraulic hoses are disconnected before pulling tractor away (Refer to Screed Section of this manual).
- 2) Elevate the paver to allow an adequate amount of safe working space under the tractor so the liner nuts can be reached. Support the paver with blocking equipment capable of supporting the weight of the paver.

## Remix Paver Delivery Augers

- 3) To replace liners, remove bolts retaining liner panels and slide liners out the back of the paver. New liners can be installed in reverse order. (Figure 6 - 85)




Figure 6 - 85 Replacing Delivery Auger Liners and Flights

### Replacing Auger Flights

Worn or damaged auger flights will require either the complete auger replacement by removing from the paver or installation of a field repair kit consisting of one pitch of 10" diameter auger flight. The field repair kit is only for repairing flight at the discharge end of the auger. Separate kits for right and left pitch augers must be used.

## Paver Spreading Augers

### Paver Spreading Augers

#### Cast Augers

Pavers are equipped with cast auger sections. Cast augers provide long service life without the need to resurface the augers as they wear. When the augers are worn, replace the auger sections with new bolt-on sections. (Figure 6 - 86)




Figure 6 - 86 Replacing cast auger sections

#### Re-facing Lined Augers

When augers are severely worn they can be re-faced with special contoured liners made from Ni-hard alloy. The application of these liners restore the augers to near new condition. To apply genuine Cedarapids Ni-hard liners proceed as follows:

- 1) Remove auger from paver.
- 2) Clean auger sections as well as possible, particularly in the weld areas.
- 3) Use several C-clamps and attach the pieces of liner to the auger face starting at the drive chain end as shown (Figure 6 - 87). By starting at this end, the main wear surface of the section will be covered and any small area not covered will be at the discharge end. Adjust liner pieces to extend 1/8" above the edges of

the auger flight as shown (Figure 6 - 88). Be sure the first piece applied is accurately aligned so the remaining liners will fit properly along the flight.




Figure 6 - 87 Installing liners

- 4) Use a low hydrogen weld rod and make a continuous weld along the inside edge "A". (Figure 6 - 88)




Figure 6 - 88 Liner cross-section

- 5) Make welds at each of the two pockets "B". (Figure 6 - 89)




Figure 6 - 89 Installing Liners

- 6) On the first and last liners of each flight make a weld at the exposed edge for extra strength "C". (Figure 6 - 90)

### NOTICE

The small cracks which develop in the liners from the welding process are normal and should not be considered defects




Figure 6 - 90 First and last liners require extra weld

## Machine Storage Preparation

### Re-lining Auger Shafts

When paving with materials that are extremely abrasive, the auger shafts will show severe wear; lining segments can be welded on to the auger shafts to prevent shaft wear. These segments are made of mild steel instead of Ni-hard material for easier application. The rate of shaft wear is never as great as that of the auger flight facing.

### Machine Storage Preparation

The following procedures are recommended for conditioning the Cedarapids paver for storage.

- 1) Run all material completely out of the machine.
- 2) Thoroughly clean the complete machine to remove all asphalt.
- 3) Park machine in a shed or well drained area. (Preferably on boards to keep tires or tracks out of mud or standing water.)
- 4) Perform Periodical Maintenance items listed on the periodic maintenance chart found in this manual.
- 5) Thoroughly grease all bearings and bushings. Grease all adjustment bolts on paver and screed.
- 6) Winterize radiator with Anti-freeze to 40° below zero.
- 7) Hang screed on safety cables and retract all hydraulic cylinders so cylinder rods are not exposed.
- 8) Remove batteries, feed controllers and grade/slope controllers. Store in heated area. Store batteries on wood, not concrete.

## Machine Storage Preparation

---

- 9) Be sure all panel lids and covers are in place. Close tightly to prevent water entry. (Tape around electric panel door to seal).
- 10) Enclose consoles in protective cover. Leave bottom of wrap open to prevent condensation inside. Cover exhaust.
- 11) Remove all books and literature from tool boxes and store inside office or with other stored components.
- 12) Refer to engine manufacturer's specifications for protection of engine.

**Machine Storage Preparation**

---

**Appendix A - Torque Specs**

**Torque Charts**

The following pages contain charts for use as guides when tightening bolts and nuts. These specifications should be followed unless specific torques are given elsewhere in this manual.

**Standard Torque Chart**

Table A - 1 is a list of recommended torque values for standard bolts. Use this torque chart to avoid overstressing standard nuts and bolts used on Cedarapids equipment. These specifications should be followed unless specific torques are given. Cedarapids uses Grades 2, 5, and 8. The maximum torque values are based on 75% of the specified minimum proof strength of the bolt steel in order to provide a safety factor. The term “lube” applies to cadmium plating and/or application of thread lubricants. Hardened washers should always be used, regardless of whether standard nuts or lock nuts are employed.

**Metric Torque Chart**

Table A - 2 is a list of torque values recommended for metric bolts. The maximum torque values are based on 75% of the specified minimum proof strength. The term “lube” includes the application of thread lubricants, cadmium plating and the use of hardened washers regardless of whether standard or lock nuts are used.

## Torque Charts

|                  |                       | S.A.E Grade 2   |      |                     | S.A.E Grade 5   |      |                     | S.A.E Grade 8   |       |                     |
|------------------|-----------------------|-----------------|------|---------------------|-----------------|------|---------------------|-----------------|-------|---------------------|
| dia.<br>(inches) | pitch<br>(thread/in.) | Torque (ft-lbs) |      | Clamp<br>Load (lbs) | Torque (ft-lbs) |      | Clamp<br>Load (lbs) | Torque (ft-lbs) |       | Clamp<br>Load (lbs) |
|                  |                       | Dry             | Lube |                     | Dry             | Lube |                     | Dry             | Lube  |                     |
| 1/4              | 20                    | 5               | 4    | 1310                | 8               | 6    | 2020                | 12              | 9     | 2860                |
| 1/4              | 28                    | 6               | 5    | 1500                | 10              | 7    | 2320                | 14              | 11    | 3270                |
| 5/16             | 18                    | 11              | 9    | 2160                | 17              | 13   | 3340                | 25              | 19    | 4710                |
| 5/16             | 24                    | 12              | 10   | 2390                | 19              | 15   | 3690                | 27              | 21    | 5220                |
| 3/8              | 16                    | 20              | 15   | 3190                | 31              | 24   | 4940                | 44              | 34    | 6970                |
| 3/8              | 24                    | 23              | 17   | 3620                | 35              | 27   | 5590                | 49              | 38    | 7900                |
| 7/16             | 14                    | 32              | 25   | 4380                | 49              | 38   | 6770                | 70              | 54    | 9560                |
| 7/16             | 20                    | 36              | 27   | 4890                | 55              | 42   | 7560                | 78              | 60    | 10680               |
| 1/2              | 13                    | 49              | 38   | 5850                | 75              | 58   | 9040                | 106             | 82    | 12770               |
| 1/2              | 20                    | 55              | 42   | 6590                | 85              | 65   | 10190               | 120             | 92    | 14390               |
| 9/16             | 12                    | 70              | 54   | 7500                | 109             | 84   | 11600               | 150             | 115   | 16380               |
| 9/16             | 18                    | 79              | 60   | 8370                | 121             | 93   | 12940               | 170             | 130   | 18270               |
| 5/8              | 11                    | 97              | 75   | 9320                | 150             | 115  | 14400               | 210             | 160   | 20340               |
| 5/8              | 18                    | 110             | 85   | 10560               | 170             | 130  | 16320               | 240             | 180   | 23040               |
| 3/4              | 10                    | 170             | 130  | 13770               | 265             | 200  | 21290               | 375             | 285   | 30060               |
| 3/4              | 16                    | 190             | 145  | 15380               | 295             | 225  | 23770               | 415             | 320   | 33570               |
| 7/8              | 9                     | 165             | 125  | 11430               | 425             | 330  | 29450               | 605             | 465   | 41580               |
| 7/8              | 14                    | 180             | 140  | 12590               | 470             | 360  | 32440               | 665             | 510   | 45810               |
| 1                | 8                     | 245             | 190  | 14990               | 640             | 495  | 38630               | 905             | 695   | 54540               |
| 1                | 14                    | 270             | 210  | 16400               | 700             | 540  | 42260               | 990             | 765   | 59670               |
| 1-1/8            | 7                     | 350             | 270  | 18880               | 790             | 610  | 42340               | 1285            | 990   | 68670               |
| 1-1/8            | 12                    | 395             | 305  | 21180               | 890             | 685  | 47500               | 1440            | 1110  | 77040               |
| 1-1/4            | 7                     | 495             | 380  | 23980               | 1120            | 860  | 53770               | 1815            | 1395  | 87210               |
| 1-1/4            | 12                    | 550             | 425  | 26550               | 1240            | 950  | 59550               | 2010            | 1545  | 96570               |
| 1-3/8            | 6                     | 655             | 500  | 28580               | 1465            | 1130 | 64100               | 2380            | 1830  | 103950              |
| 1-3/8            | 12                    | 745             | 570  | 32540               | 1670            | 1285 | 72980               | 2710            | 2085  | 118350              |
| 1-1/2            | 6                     | 865             | 665  | 34770               | 1945            | 1495 | 77970               | 3160            | 2430  | 126450              |
| 1-1/2            | 12                    | 975             | 750  | 39120               | 2190            | 1685 | 87740               | 3555            | 2735  | 142290              |
| 1-3/4            | 5                     | 1370            | 1055 | 47020               | 2285            | 1755 | 78370               | 4985            | 3835  | 170990              |
| 2                | 4.5                   | 2060            | 1585 | 61870               | 3435            | 2640 | 103120              | 7500            | 5765  | 225000              |
| 2-1/4            | 4.5                   | 3015            | 2320 | 80430               | 5025            | 3865 | 134060              | 10960           | 8435  | 292500              |
| 2-1/2            | 4                     | 4125            | 3170 | 99000               | 6875            | 5285 | 165000              | 15000           | 11530 | 360000              |
| 2-3/4            | 4                     | 5590            | 4300 | 122010              | 9320            | 7165 | 203360              | 17790           | 13680 | 388230              |
| 3                | 4                     | 7385            | 5680 | 147750              | 12310           | 9470 | 246260              | 23500           | 18080 | 470130              |

Table A - 1: Torque Values for Standard Hardware

## Torque Charts

|             |               | Property Class = 8.8 |      |          |     | Property Class = 10.9 |      |          |      | Property Class = 12.9 |      |          |      |
|-------------|---------------|----------------------|------|----------|-----|-----------------------|------|----------|------|-----------------------|------|----------|------|
| dia<br>(mm) | pitch<br>(mm) | Dry                  |      | Lube     |     | Dry                   |      | Lube     |      | Dry                   |      | Lube     |      |
|             |               | (ft-lbs)             | N-M  | (ft-lbs) | N-M | (ft-lbs)              | N-M  | (ft-lbs) | N-M  | (ft-lbs)              | N-M  | (ft-lbs) | N-M  |
| 10          | 1.5           | 37                   | 50   | 29       | 39  | 53                    | 72   | 41       | 56   | 62                    | 84   | 48       | 65   |
| 10          | 1.25          | 39                   | 53   | 30       | 41  | 56                    | 76   | 43       | 58   | 66                    | 89   | 51       | 69   |
| 12          | 1.75          | 65                   | 88   | 50       | 68  | 93                    | 126  | 71       | 96   | 109                   | 148  | 83       | 113  |
| 12          | 1.25          | 71                   | 96   | 55       | 75  | 101                   | 137  | 78       | 106  | 119                   | 161  | 91       | 123  |
| 14          | 2             | 104                  | 141  | 80       | 108 | 148                   | 201  | 114      | 155  | 173                   | 235  | 133      | 180  |
| 14          | 1.5           | 112                  | 152  | 86       | 117 | 160                   | 217  | 123      | 167  | 187                   | 254  | 144      | 195  |
| 16          | 2             | 161                  | 218  | 124      | 168 | 230                   | 312  | 177      | 240  | 269                   | 365  | 207      | 280  |
| 16          | 1.5           | 172                  | 233  | 132      | 179 | 246                   | 334  | 189      | 256  | 287                   | 389  | 221      | 300  |
| 18          | 2.50          | 230                  | 312  | 177      | 240 | 318                   | 431  | 245      | 332  | 372                   | 504  | 286      | 388  |
| 18          | 1.5           | 258                  | 350  | 199      | 270 | 357                   | 484  | 275      | 348  | 418                   | 567  | 321      | 435  |
| 20          | 2.5           | 325                  | 441  | 250      | 339 | 450                   | 610  | 346      | 469  | 525                   | 712  | 404      | 548  |
| 20          | 1.5           | 360                  | 488  | 277      | 376 | 499                   | 677  | 384      | 521  | 583                   | 791  | 448      | 607  |
| 22          | 2.5           | 443                  | 601  | 341      | 462 | 613                   | 831  | 471      | 639  | 716                   | 971  | 551      | 747  |
| 22          | 1.5           | 486                  | 659  | 374      | 507 | 673                   | 913  | 518      | 702  | 786                   | 1066 | 605      | 820  |
| 24          | 3             | 562                  | 762  | 432      | 586 | 777                   | 1054 | 598      | 811  | 908                   | 1231 | 698      | 946  |
| 24          | 2             | 612                  | 830  | 471      | 639 | 847                   | 1149 | 652      | 884  | 990                   | 1342 | 762      | 1033 |
| 27          | 3             | 823                  | 1116 | 633      | 858 | 1139                  | 1544 | 876      | 1188 | 1331                  | 1805 | 1024     | 1389 |
| 27          | 2             | 889                  | 1205 | 683      | 926 | 1229                  | 1667 | 945      | 1281 | 1436                  | 1947 | 1105     | 1498 |

Table A - 2: Torque Values for Metric Hardware

**Torque Charts**

---


Electrical Schematics

Appendix B - Electrical Schematics

Electrical Schematics

The following pages contain The electrical schematics for the various configurations of the 500 Series Pavers





NOTE:  
SEE SHEET 2 OF 2 FOR ADDITIONAL CONTROLS


4494-105-21      Page 1 of 4      4/03

452/552 Paver


Electrical Schematic

9704-417-36, 9704-417-55, 9704-417-54

CONTINUED TO PAGE 2 OF SCHEMATIC









VIEW E-E

VIEW C-C


VIEW D-D



VIEW A-A



VIEW B-B



NOTE:  
SEE SHEET 2 OF 2 FOR ADDITIONAL CONTROLS

4494-105-22

Page 1 of 4


4/03


462/562 Paver

Electrical Schematic


9704-417-39, 9704-417-56, 9704-417-54

CONTINUED TO PAGE 2 OF SCHEMATIC








- NOTES:
- 1. PERMISSIVE START, CAL-RUN, SCREED ASSIST, VIBRATORS, LIGHTS, & FLASHERS.
  - 2. SPRAY ALL CONNECTIONS WITH PERMATEX "FORM-A-SEAL" AFTER FINAL ASSEMBLY.
  - 3. ALIGN PUNCH MARKS ON STEER SENSOR AND ALIGN STEERING WHEEL WITH PUNCH MARKS BEFORE INSTALLING DECAL ON SPOKE.
  - 4. INSTALL DIODES ON DIRECTION AND RANGE SWITCH WITH BANDED END AWAY FROM WIRE #3.
  - 5. MARK ASSEMBLY WITH APPROPRIATE PART NO. AND REV LEVEL.



| ITEM | PART NO./ PATTERN NO. | DESCRIPTION              | REQ. | ITEM | PART NO./ PATTERN NO. | DESCRIPTION                 | REQ. | ITEM | QTY | PART NO./PATTERN NO. | DESCRIPTION                 | REQ. |
|------|-----------------------|--------------------------|------|------|-----------------------|-----------------------------|------|------|-----|----------------------|-----------------------------|------|
| 68   |                       | END BARRIER AB #1492-EB3 | 2    | 46   | 07504-086             | MACH SCREW- #10-32 X 1/2"   | 1    | 1    |     | 09704-505-97         | CONSOLE- TRACK              | 1    |
| 69   |                       | RAIL AB #199-DR1         | 28"  | 47   | 07504-052             | MACH SCREW- #8-32 X 1/2"U   | 4    | 2    |     | 04494-105-12         | EMBLEM-TRACK                | 1    |
| 70   |                       | TERM. GND AB #1492-WG4   | 4    | 48   | 07383-034             | CAPSCREW- 3/8"NC X 1/2"     | 4    | 3    |     | 09704-376-34         | HARNESS-TRACK CONSOLE       | 1    |
| 71   | 46260-005-32          | MARKER AB #1492-SM6-12   | .8   | 49   | 07383-022             | CAPSCREW-5/16"NC X 1"       | 2    | 4    |     | 46061-525-22         | CONTROLLER- TRACK STEERING  | 1    |
|      |                       |                          |      | 50   | 07437-135             | MACH SCREW- 1/4"NC X 3/4"   | 2    | 5    |     | 46061-525-21         | SENSOR- STEER               | 1    |
|      |                       |                          |      | 51   | 07014-017             | WASHER- 5/16"               | 2    | 6    |     | 04418-857            | EMBLEM-CAL/RUN              | 1    |
|      |                       |                          |      | 52   | 07014-003             | WASHER- 3/8" LOCK           | 4    | 7    |     | 09704-416-50         | POTMETER- SPEED             | 1    |
|      |                       |                          |      | 53   | 07014-002             | WASHER- 5/16" LOCK          | 2    | 8    |     | 09704-416-48         | BRACKET- SWITCH MOUNTING    | 1    |
|      |                       |                          |      | 54   | 07012-024             | HEX NUT- 5/16"NC            | 2    | 9    |     | 09704-411-34         | CABLE-LH                    | 1    |
|      |                       |                          |      | 55   | 07438-023             | WASHER-#10 SHKP LK          | 4    | 10   |     | 09704-411-35         | CABLE-RH                    | 1    |
|      |                       |                          |      | 56   | 07438-022             | WASHER-#8 SHKP LK SINT      | 4    | 11   |     | 45865-002-41         | GAUGE- OIL PRESSURE         | 1    |
|      |                       |                          |      | 57   | 07440-23              | HEX NUT- #10NF              | 1    | 12   |     | 45865-003-16         | GAUGE- OIL TEMP             | 1    |
|      |                       |                          |      | 58   | 07440-008             | HEX NUT #8 NC               | 4    | 13   |     | 45865-003-17         | GAUGE- WATER TEMP           | 1    |
|      |                       |                          |      | 59   | 46275-001-02          | WIRE LUG-14/16 EYE          | 9    | 14   |     | 45915-012-08         | GAUGE- FUEL LEVEL           | 1    |
|      |                       |                          |      | 60   | 07383-075             | CAPSCREW, 1/2-NC X 2-3/4"   | 2    | 15   |     | 46225-001-24         | METER- VOLTMETER 12VDC      | 1    |
|      |                       |                          |      | 61   | 07012-027             | HEX NUT 1/2"NC              | 4    | 16   |     | 46225-010-17         | METER- TACH/HOUR            | 1    |
|      |                       |                          |      | 62   | 07014-005             | LOCK WASHER 1/2"            | 2    | 17   |     |                      | TERM. AB #1492-W4           | 72   |
|      |                       |                          |      | 63   | 07455-012             | SHOULDER SCREW- 3/8" X 5/8" | 2    | 18   |     | 46260-501-03         | JUMPER- SWITCH BLOCK        | 5    |
|      |                       |                          |      | 64   | 07012-024             | HEX NUT- 5/16"-NC           | 2    | 19   |     |                      | JUMPER- 2POS AB #1492-CJ6-2 |      |
|      |                       |                          |      | 65   | 07014-002             | LOCK WASHER- 5/16"          | 2    | 20   |     | 46200-009-06         | SWITCH- TOGGLE 1TL1-2       | 7    |
|      |                       |                          |      | 66   | 46270-500-37          | LENS- AMBER                 | 6    | 21   |     |                      |                             |      |
|      |                       |                          |      | 67   | 46085-401-46          | E-STOP                      | 1    | 22   |     | 46200-009-11         | SWITCH- TOGGLE 1TL1-6       | 3    |
|      |                       |                          |      |      |                       |                             |      | 23   |     | 46200-009-18         | SWITCH- TOGGLE 2TL1-3       | 1    |
|      |                       |                          |      |      |                       |                             |      | 24   |     | 46200-009-21         | SWITCH- TOGGLE 2TL1-7       | 8    |
|      |                       |                          |      |      |                       |                             |      | 25   |     | 46200-009-40         | SWITCH- TOGGLE 2TL1-5       | 3    |
|      |                       |                          |      |      |                       |                             |      | 26   |     | 46200-009-41         | SWITCH- TOGGLE 2TL1-50      | 1    |
|      |                       |                          |      |      |                       |                             |      | 27   |     | 46200-009-62         | SWITCH- TOGGLE 4TL1-10D     | 1    |
|      |                       |                          |      |      |                       |                             |      | 28   |     | 46200-009-63         | SWITCH- TOGGLE 2TL1-1A      | 1    |
|      |                       |                          |      |      |                       |                             |      | 29   |     | 46270-005-09         | LIGHT KIT- METER            | 5    |
|      |                       |                          |      |      |                       |                             |      | 30   |     | 46270-005-10         | LIGHT KIT- 12VDC            | 1    |
|      |                       |                          |      |      |                       |                             |      | 31   |     | 46270-002-44         | LAMP- 14VDC                 | 8    |
|      |                       |                          |      |      |                       |                             |      | 32   |     | 46270-500-36         | LENS- RED JEWEL             | 2    |
|      |                       |                          |      |      |                       |                             |      | 33   |     | 46061-500-62         | SOCKET                      | 8    |
|      |                       |                          |      |      |                       |                             |      | 34   |     | 46010-001-29         | ALARM- SIGNAL               | 1    |
|      |                       |                          |      |      |                       |                             |      | 35   |     | 46010-600-09         | EMBLEM- STEERING WHEEL      | 1    |
|      |                       |                          |      |      |                       |                             |      | 36   |     | 09704-502-98         | WHEEL- STEERING             | 1    |
|      |                       |                          |      |      |                       |                             |      | 37   |     | 45259-517-07         | NUT- 7/8"                   | 1    |
|      |                       |                          |      |      |                       |                             |      | 38   |     | 46026-015-14         | CONNECTOR-1 1/4" 90DEG.     | 2    |
|      |                       |                          |      |      |                       |                             |      | 39   |     | 46195-001-04         | LOCKNUT 1 1/4"              | 2    |
|      |                       |                          |      |      |                       |                             |      | 40   |     | 46075-500-05         | KNOB- 1" DIA                | 1    |
|      |                       |                          |      |      |                       |                             |      | 41   |     | 46325-002-43         | RELAY- AUTOMOTIVE           | 1    |
|      |                       |                          |      |      |                       |                             |      | 42   |     | 46955-001-43         | DIODE- 600V 6A              | 4    |
|      |                       |                          |      |      |                       |                             |      | 43   |     | 45890-100-06         | SEAL NUT- 3/8"NEF X 32 28   | 1    |
|      |                       |                          |      |      |                       |                             |      | 44   |     | 45890-100-29         | NUT- 1/4" SELF RETAINING    | 2    |
|      |                       |                          |      |      |                       |                             |      | 45   |     | 45890-800-31         | EDGING - 1/16" -B-2-ALUM    | 4.7" |



VIEW A-A



VIEW B-B


Hydraulic Schematics

Appendix C - Hydraulic Schematics

Hydraulic Schematics

The following pages contain The hydraulic schematics for the various configurations of the 500 Series Pavers





|             | MOTOR MAX | MOTOR MIN | RATIO |  |
|-------------|-----------|-----------|-------|--|
| CR452       | 6.53      | 2.15      | 59.1  |  |
| CR552       | 6.53      | 1.97      | 66.3  |  |
| CR462R/562R | 9.76      | 2.75      | 35.9  |  |

