



OPERATIONS, SERVICE AND PARTS MANUAL



LB PERFORMANCE MODEL FB-90 BROOM

Manual No. 1006042-01

Disclaimer

All information, illustrations and specifications in this manual are based on the latest information available at the time of publishing. The illustrations used in this manual are intended as representative reference views only. Moreover, because of our continuous product improvement policy, we may modify information, illustrations and/or specifications to explain and/or exemplify a product, service or maintenance improvement. We reserve the right to make any change at any time without notice.

VT LeeBoy, Inc., VT LeeBoy, LeeBoy, and LB Performance are all the same entity and are used interchangeably.

© 2011 LeeBoy, Inc.

LeeBoy reserves all copyright and other rights in this manual and the manual's content. No part of this manual may be reproduced or used in any way - without the written permission of LeeBoy, except as necessary to operate LeeBoy equipment.

<u>Introduction</u>	1
<u>Safety</u>	2
<u>General Information</u>	3
<u>Specifications</u>	4
<u>Component Location</u>	5
<u>Operation</u>	6
<u>Maintenance</u>	7
<u>Troubleshooting</u>	8
<u>Schematics</u>	9
<u>Illustrated Parts List (IPL)</u>	10

Table of Contents



	Page
Table of Contents	iv
Introduction	1-1
Safety	2-1
Safety Precautions	2-3
Location Of Safety Decals	2-6
General Information	3-1
Limited Warranty Policy	3-2
Warranty	3-2
Limitations	3-2
Items Not Covered	3-3
Contact Information	3-3
Record Of Ownership	3-3
Other Limitations	3-3
Nameplates	3-4
Broom Nameplates	3-4
Engine Nameplate	3-4
Specifications	4-1
General Information	4-2
Engine	4-2
Electrical System	4-2
Hydraulic System	4-2
Specifications	4-3
Component Location	5-1
Instrument Panel	5-2
Steering Console	5-4
Broom Control Console	5-6
Heat & Air Conditioning Controls	5-8
Windshield Wiper, Defrost & Dome Light Controls	5-10
Defroster Fan	5-12
Hydraulic Brush Lift Lock	5-12
Operation	6-1
Pre-Operation	6-2
Pre-Operation Checklist	6-2
Starting The Engine	6-2
Preliminary	6-2



Table of Contents

Engine Start-Up & Operation	6-2
Stopping the Engine	6-3
System Controls	6-3
Brush Operation	6-4
Brush Swing Switches	6-4
Brush Lift/float Control Switch	6-4
Brush Down Pressure Control	6-4
Brush Forward/Reverse Control Switch	6-4
Brush Speed	6-4
Sweeping Guidelines	6-5
Dust Suppression System	6-5
Transporting The Broom	6-5
Broom Tie Downs	6-6
Maintenance	7-1
General Information	7-2
Routine Maintenance	7-2
General Information	7-2
Broom Lubrication	7-2
Periodic Maintenance	7-3
Periodic Maintenance Schedule	7-3
Torque Specifications	7-4
General Information	7-4
Inch Fasteners	7-5
Hydraulic Fittings	7-6
Full Torque Nut Coupling Installation	7-7
Maintenance Schedule	7-12
General Information	7-12
Preparing The Broom For Maintenance	7-12
Checks And Adjustments	7-12
Engine Maintenance	7-12
Neutral Start System	7-12
Cold Weather Starting	7-13
Engine Belts	7-13
Fuel and Fluids	7-13
Air Intake System	7-14
Radiator and Coolant	7-15

Table of Contents



Battery	7-15
Electrical Maintenance	7-16
Lighting	7-17
Hydraulic System Maintenance	7-18
Hydraulic Fluid	7-18
Hydraulic Oil Requirements	7-18
Hydraulic Reservoir	7-18
Hydraulic System Checks	7-19
Pumps And Motors	7-20
Adjusting Priority Relief Valve	7-20
Adjusting Brush Drive Relief Valve	7-20
Broom System Maintenance	7-21
Brush Watering System	7-21
Chassis & Running Gear Maintenance	7-22
Drive Shaft	7-22
Tires and Wheels	7-22
Axles and Brakes	7-22
Storage	7-23
Preparing For Long Term Storage	7-23
Periodic Maintenance During Storage	7-24
Removing Broom From Storage	7-24
Decal Installation	7-25
Troubleshooting	8-1
General Information	8-2
Troubleshooting Charts	8-2
Schematics	9-1
Illustrated Parts List (IPL)	10-1
Introduction	10-2
Frame	10-4
Drive Axle Assembly	10-6
Drive Shaft Assembly	10-8
Axle Assembly, Steering	10-10
Brush Head Frame	10-12
Core Assembly	10-14
Shaft Assembly	10-16
Hydraulic Assemblies	10-18

Motor Mount Assemblies	.10-20
Brush Head Labels	.10-22
Lift Linkage	.10-24
Water Spray Tank And Mounting	.10-26
Dust Suppression System	.10-28
Engine Subassembly, Kubota	10-30
Engine Subassembly, Kubota (continued)	.10-32
Exhaust Group	.10-34
Air Cleaner, Kubota	10-36
Engine Cover Assembly	10-38
Fuel Tank Assembly	.10-40
Radiator/cooler Assembly	.10-42
Air Conditioning/Heater Group	.10-44
Cab Air Conditioning/Heater Kit (1 Of 2)	.10-46
Cab Air Conditioning/Heater Kit (2 Of 2)	.10-48
Cab Frame, Glass And Door	.10-50
Cab Door Hold And Striker	.10-52
Windshield Wiper Panel	.10-54
Windshield Wiper Motor	.10-56
Entrance Door Assembly	.10-58
Standard Seat	10-60
Optional Spring Seat	.10-62
Steering Wheel Assembly	.10-64
Control Handle And Throttle Linkage	10-66
Instrument Panel	10-68
Fuse Panel Sub-assembly	.10-70
Lights And Mirrors	.10-72
Park Brake	.10-74
Hydraulic Brake	.10-76
Brush Hydraulics And Manifold	.10-78
Steering Orbitrol And Manifold	10-80
Hydrostatic Pump And Motor	.10-82
Hydraulic Filter And Cooler Hoses	.10-84
Hydraulic Tank	10-86
Alphabetical Parts Index	10-88



NOTES



Section 1

INTRODUCTION

Thank you for purchasing the LB Performance Model FB-90 Broom. We wish you many years of safe and efficient operation of your broom.

READ THIS MANUAL PRIOR TO OPERATING the broom. This manual is an important part of the broom and should be kept with the broom at all times in the dedicated storage container on the broom. Even though you may be familiar with similar equipment, you **MUST** read and understand this manual before operating this unit. Reading the manual will help you and others avoid injury and help prevent any damage to the broom. If this manual becomes lost or damaged, contact your authorized LB Performance Dealer immediately to order a replacement. See Contact Information on page 3-3.

This manual is intended as a guide for the safe and efficient use of the broom. This manual covers the procedures for proper operation and maintenance of the broom. This manual contains information that was available at the time of printing.

This manual provides information for use by the equipment operator under the following headings:

Safety—See Section 2 for important safety guidelines information.

General Information—See Section 3 for important warranty, contact, and Broom Nameplate information.

Specifications—See Section 4 for all major system specifications and typical torque value tables.

Component Location—See Section 5 for general overview of controls and major components.

Operation—See Section 6 for control functionality and normal broom operation.

Maintenance—See Section 7 for basic preventive maintenance and repair procedures.

Troubleshooting—See Section 8 for problem descriptions and recommended solution tables.

Electrical—See Section 9 for schematic diagrams of electrical wiring.

Illustrated Parts List—See Section 10 for illustrations, descriptions and part numbers of available service parts.



NOTES



Section 2

SAFETY

This manual provides important information to familiarize you with safe operating and maintenance procedures. Even though you may be familiar with similar equipment, you **MUST** read and understand this manual before operating this Broom and follow its instructions when operating the LB Performance Model FB-90 Broom.

Safety is everyone's business and is our top concern. Knowing the guidelines covered in this section and in Section 1 will help ensure your safety, the safety of those around you and the broom's proper operation. **LOOK FOR THESE SYMBOLS WHICH POINT OUT ITEMS OF EXTREME IMPORTANCE TO THE SAFETY OF YOU AND YOUR COWORKERS. READ AND UNDERSTAND THOROUGHLY. HEED THE WARNING AND FOLLOW THE INSTRUCTIONS.** Keep safety labels in good condition. If safety labels become missing or damaged, replacement safety labels are available from your LB Performance Dealer.



DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates a situation which can cause damage to the equipment, personal property and/or the environment, or cause the LB Performance Model FB-90 Broom to operate improperly.

NOTE: Indicates a procedure, practice, or condition that should be followed in order for the broom or component to function in the manner intended.

SAFETY PRECAUTIONS

CAUTION

The safety messages that follow have CAUTION level hazards.

Pre-Operation Hazard



- Never permit anyone to service or operate the LB Performance Model FB-90 Broom without proper training.
- Read and understand this Operation Manual before operating or servicing the engine to ensure that safe operating practices and maintenance procedures are followed.
- Safety signs and labels are additional reminders for safe operating and maintenance techniques.
- Contact LB Performance or an authorized LB Performance Dealer for additional training.
- Make sure you are aware of all laws and regulations that are in effect where the broom is operated. Make sure you have all necessary licenses to operate the broom.

WARNING

The safety messages that follow have WARNING level hazards.

Crush Hazard

Keep bystanders away from work area before and during operation.

Modification Hazard

Never modify the LB Performance Model FB-90 Broom without written consent of LB Performance. Any modification can affect the safe operation of the broom and may cause personal injury or death.

Exposure Hazard

Always wear personal protective equipment, including appropriate clothing, gloves, work shoes, and eye and hearing protection, as required by the task at hand.



Explosion Hazard



- While the engine is running or the battery is charging, hydrogen gas is being produced and can be easily ignited. Keep the area around the battery well-ventilated and keep sparks, open flame and any other form of ignition out of the area.
- Always disconnect the negative (-) battery cable before servicing the broom.
- Do not start the engine by shorting the starter circuit or any other starting method not stated in this manual. Only use the starting procedure as described in this manual to start the engine.
- Never charge a frozen battery. Always slowly warm the battery to room temperature before charging.

Fire and Explosion Hazard

- Diesel fuel is flammable and explosive under certain conditions.
- Never use a shop rag to catch the fuel.
- Wipe up all spills immediately.
- Never refuel with the engine running.
- Store any containers containing fuel in a well-ventilated area, away from any combustibles or sources of ignition.

Fire Hazard



- Have appropriate safety equipment available. Have all fire extinguishers checked periodically for proper operation and/or readiness.
- Always read and follow safety-related precautions found on containers of hazardous substances like parts cleaners, primers, sealants and sealant removers.
- Undersized wiring systems can cause an electrical fire.

WARNING

The safety messages that follow have **WARNING** level hazards.

Exhaust Hazard



All internal combustion engines create carbon monoxide gas during operation and special precautions are required to avoid carbon monoxide poisoning:

- Never block windows, vents or other means of ventilation if the LB Performance Model FB-90 Broom is operating in an enclosed area.
- Always ensure that all connections are tightened to specifications after repair is made to the exhaust system.

Entanglement / Sever Hazard



- Verify there are no people, obstacles or other equipment near the LB Performance Model FB-90 Broom before starting the engine. Sound the horn as a warning before starting the engine.

- Always stop the engine before beginning service.

- If the engine must be serviced while it is operating, remove all jewelry, tie back long hair and keep hands, other body parts and clothing away from moving/rotating parts.

- Verify that all broom guards and covers are attached properly to the broom before starting the engine. Do not start the engine if any guards or covers are not properly installed on the broom.

- If you must run the engine during maintenance procedures, make sure you have a helper to keep bystanders clear of the broom and make observations of moving parts as requested by the operator.

- Always turn the start switch to the OFF position after operation is complete and remove the key from the switch. Keep the key in your possession when the broom is not operating.

- Attach a "Do Not Operate" tag near the key switch while performing maintenance on the equipment.

- Never operate the engine while wearing a headset to listen to music or radio because it will be difficult to hear the warning signals.

- Always start the engine or operate the controls while you are seated in the operators seat.

Alcohol and Drug Hazard



Never operate the engine while under the influence of alcohol or drugs, or when ill.

Piercing Hazard



- Avoid skin contact with high-pressure hydraulic fluid or diesel fuel spray caused by a hydraulic or fuel system leak such as a broken hydraulic hose or fuel injection line. High-pressure hydraulic fluid or fuel can penetrate your skin and result in serious injury. If you are exposed to high-pressure hydraulic fluid or fuel spray, obtain prompt medical treatment.

- Never check for a hydraulic fluid or fuel leak with your hands. Always use a piece of wood or cardboard. Have your authorized LB Performance Dealer or distributor repair the damage.

Flying Object Hazard



Always wear eye protection when cleaning the LB Performance Model FB-90 Broom with compressed air or high-pressure water. Dust, flying debris, compressed air, pressurized water or steam may injure your eyes.

Coolant Hazard



Wear eye protection and rubber gloves when handling engine coolant. If contact with the eyes or skin should occur, flush eyes and wash immediately with clean water.

Burn Hazard



- Some of the engine surfaces become very hot during operation and shortly after shutdown.
- Keep hands and other body parts away from hot engine surfaces.
- Handle hot components with heat-resistant gloves.

CAUTION

The safety messages that follow have CAUTION level hazards.

Poor Lighting Hazard

Ensure that the work area is adequately illuminated.

Always install wire cages on portable safety lights.

Tool Hazard

Always use tools appropriate for the task at hand and use the correct size tool for loosening or tightening LB Performance Model FB-90 Broom parts.

NOTICE

The safety messages that follow have NOTICE level hazards.

Any part which is found defective as a result of inspection or any part whose measured value does not satisfy the standard or limit must be replaced.

Always tighten components to the specified torque. Loose parts can cause LB Performance Model FB-90 Broom damage or cause it to operate improperly.

Only use replacement parts approved by LB Performance. Other replacement parts may affect warranty coverage.



Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.


Clean all accumulated dirt and debris away from the body of the broom and its components before you inspect the broom or perform preventive maintenance procedures or repairs. Operating a broom with accumulated dirt and debris will cause premature wear of broom components. Accumulated dirt and debris also hinders effective broom inspection.

Retrieve any tools or parts that may have dropped inside of the broom to avoid improper broom operation.

Dispose of hazardous materials in accordance with all applicable laws and regulations. Never dispose of hazardous materials by dumping them into a sewer, on the ground, or into groundwater or waterways.

If any alert indicator illuminates during broom operation, stop the engine immediately. Determine the cause and repair the problem before continuing to operate the broom.

LOCATION OF SAFETY DECALS



Left Side Safety Labels and Safety Label Locations

Figure 2-1



Figure 2-2



NOTES



Section 3

GENERAL INFORMATION

LIMITED WARRANTY POLICY

Warranty

1. Subject to the limitations, exclusions, and claims procedures set forth herein, LB Performance warrants [to the first retail purchaser] that this product will be free from [substantial] defects in materials and workmanship during the warranty period.
2. If a defect in material or workmanship is found, your authorized LB Performance Dealer is to be notified during the warranty period. LB Performance and its authorized Dealer will repair or replace any part or component of the unit or part that fails to conform to the warranty during the warranty period.
3. The warranty period will begin on the initial start-up, training and delivery of the unit by the Dealer to the customer, and will expire after twelve (12) months following the delivery of the paver to the first retail purchaser.
4. Manufacturers' Warranties: Engines are warranted by their manufacturers and may have warranty coverage that differs from that of LB Performance. LB Performance does not warrant any engine.
5. Replacement parts furnished by LB Performance are covered for the remainder of the warranty period applicable to the unit or component in which such parts are installed.
6. LB Performance has the right to repair any component or part before replacing it with a new one.
7. All new replacement parts purchased by a LB Performance Dealer will carry a six-month warranty.
8. This Limited Warranty is governed by the laws of the State of North Carolina.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED, STATUTORY AND IMPLIED WARRANTIES APPLICABLE TO UNITS, ENGINES, OR PARTS INCLUDING WITHOUT LIMITATION, ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR AGAINST INFRINGEMENT.

Limitations

LB Performance has no obligation for:

1. Any defects caused by misuse, misapplication, negligence, accident or failure to maintain or use in accordance with the most current operating instructions.
2. Unauthorized alterations.
3. Defects or failures caused by any replacement parts or attachments not manufactured by or approved by LB Performance.
4. Failure to conduct normal maintenance and operating service including, without limitation, providing lubricants, coolant, fuel, tune-ups, inspections or adjustments.
5. Unreasonable delay, as established by LB Performance, in making the applicable units or parts available upon notification of a service notice ordered by same.
6. Warranty Responsibility: The warranty responsibility on all engines rests with the manufacturer of the engine.
7. Warranty and Parts Support: LB Performance may have support agreements with some engine manufacturers for warranty and parts support. However, LB Performance does not warrant the engine.
8. This Limited Warranty sets forth your sole remedy in connection with the sale or use of the LB Performance product covered by this Limited Warranty.
9. This Limited Warranty extends only to the first retail purchaser, and is not transferable.
10. In the event any portion of this Limited Warranty shall be determined to be invalid under any applicable law, such provision shall be deemed null and void and the remainder of the Limited Warranty shall continue in full force and effect.



Items Not Covered

LB Performance is not responsible for the following:

1. All used units or used parts of any kind.
2. Repairs due to normal wear and tear or brought about by abuse or lack of maintenance of the Broom.
3. Attachments not manufactured or installed by LB Performance.
4. Liability for incidental or consequential damages of any type including, but not limited to, lost profits or expenses of acquiring replacement equipment.
5. Miscellaneous charges.

Other Limitations

IN NO EVENT, WHETHER AS A RESULT OF BREACH OF CONTRACT OR WARRANTY OR ALLEGED NEGLIGENCE OR LIABILITY WITHOUT FAULT, SHALL LB PERFORMANCE BE LIABLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING, WITHOUT LIMITATION, LOSS OF PROFIT OR REVENUE, COST OF CAPITAL, COST OF SUBSTITUTED EQUIPMENT, FACILITIES OR SERVICES, DOWNTIME COSTS, LABOR COSTS OR CLAIMS OF CUSTOMERS, PURCHASERS OR LESSEES FOR SUCH DAMAGES. IN NO EVENT WILL WARRANTY COMPENSATION, OR OTHER DAMAGES AVAILABLE FROM LB Performance, EXCEED THE PURCHASE PRICE OF THE PRODUCT.

CONTACT INFORMATION

For information regarding parts and repairs about your LB Performance product, first contact the dealer you purchased your product from.

If you have a persistent problem your dealer is unable to resolve, contact LB Performance directly.

Record dealer information in the space provided. For additional information about LB Performance, please visit: www.lbperformancepaving.com

Sales Representative: _____

Dealership Name: _____

Dealership Address: _____

Dealership Phone: _____

RECORD OF OWNERSHIP

Please fill out the following information and use it when you need to contact LB Performance for service, parts or literature.

Broom Model Number: _____

Broom Serial Number: _____

Engine Model Number: _____

Engine Serial Number: _____

Date of Purchase: _____


NAMEPLATES

Broom Nameplates

Nameplates (Figure 3-1, 1) contain the specific model number and serial number used to identify the components for any parts or service information.

Engine Nameplate

The engine nameplate (Figure 3-1, 3) contains the specific model number and serial number used to identify the engine for any parts or service information.



Broom Nameplate Location

Figure 3-1

1 - Sweepster Brush Nameplate

2 - FB-90 Nameplate

3 - Engine Nameplate



Section 4

SPECIFICATIONS

GENERAL INFORMATION

The descriptions and specifications provided in this section are applicable to the LB Performance Model FB-90 Broom. This section contains a description of how the major components operate. It also includes specifications for the major system components. Included in this section are broom weights, dimensions, performance, and major system specifications for the broom.

Engine

The LB Performance Model FB-90 Broom uses a four-cylinder, water cooled diesel engine to drive the hydraulic pump and the auxiliary pump for steering and broom control.

An electric fuel prime pump mounted to the engine draws diesel fuel from the fuel tank. The fuel tank is mounted below the operator's platform by the left side engine cover.

An air cleaner mounted on the top of the engine filters intake air before use by the engine. The air cleaner removes fine particles such as dust, sand, chaff, and lint from the air.

A pre-cleaner mounted on top of the air cleaner assembly removes larger particles of dirt and debris before the air enters the air filter elements. The pre-cleaner relieves the load on the air filter elements and allows longer intervals between servicing. The materials trapped by the pre-cleaner are deposited in the pre-cleaner bowl.

As air is taken into the air cleaner assembly, a cyclone type action deposits some of the fine particles in the evacuator mounted on the bottom of the air cleaner housing. The evacuator is held closed during engine operation by suction. When the engine is shut off the weight of the debris helps to open the rubber flaps allowing the debris to fall out. The rubber flaps can also be squeezed together for cleaning.

Primary and secondary fuel filters remove contaminants from the diesel fuel before the fuel flows to the injection pump for injection into the engine combustion chamber.

A radiator mounted at the rear of the broom cools the engine. As coolant flows through the radiator, airflow from the engine-driven fan removes heat from the coolant.

Refer to the engine manufacturer's manual for a complete description of the engine.

Electrical System

The electrical system is powered by a 12-volt battery mounted inside the a fender mounted battery box. The battery produces 12 volts DC and maintains 1050 cold cranking amperes (CCA). An engine-mounted alternator capable of 90 amperes charging capacity keeps the battery charged during normal operation.

The battery charge rate can be monitored using a voltmeter mounted in the instrument panel.

Hydraulic System

The LB Performance Model FB-90 Broom is a fully hydrostatic, self-propelled unit. The Hydrostatic Drive System and Hydraulic System, which powers the steering and broom drive, have one common oil reservoir.

Hydrostatic Drive System

This system propels the LB Performance Model FB-90 Broom forward and reverse with dynamic braking. The system consists of a variable displacement pump driven off the rear of the diesel engine. This pump provides power to a fixed displacement motor. The motor drives a mechanical front axle through a drive shaft.

Hydrostatic Drive Control

Control for the Drive System is provided by a manually operated lever at the driver's platform, located on the right side of the seat. A neutral position, which activates a neutral start switch, is included between forward and reverse directions of the control lever. This provides for easy and safe starting of the LB Performance Model FB-90 Broom.

NOTICE LB Performance Model FB-90 Broom components can be damaged when decelerating or changing direction rapidly. Doing so may cause excess heat and pressure in the hydrostatic drive system.

Steering & Brush Hydraulic System

A hydraulic pump, which is directly connected to the Hydrostatic System pump, provides hydraulic flow to a manifold. This manifold has a priority flow divider which provides priority flow to the steering system and the brush lift and swing valves at approximately 5 gallons per minute. Excess flow from the pump provides power for the brush drive motor. The steering flow ALWAYS receives the priority flow so it is always powered.

Steering

Steering is performed by a hydraulically powered orbital system and operated by a steering wheel. In the event of a hydraulic power failure, the LB Performance Model FB-90 Broom can still be steered.

Brush Control

The brush drive speed is regulated by the engine speed. Brush lift, swing, and forward/reverse are controlled by push buttons on the travel control lever.

The buttons operate solenoid controlled hydraulic valves.

SPECIFICATIONS

The specifications provided in this section are applicable to the LB Performance Model FB-90 Broom. Included in this section are broom weights, dimensions, performance, and torque values for both metric and standard inch fasteners.

Table 4-1. Engine

ITEM	SPECIFICATION
Model:	Kubota, V3600-T-E3B
Emission Regulation:	Tier 3 / Stage III A
Type:	Vertical 4-Cycle, Liquid Cooled Diesel
Bore & Stroke:	98 mm (3.86 in.) x 120 mm (4.72 in.)
Displacement	3.62 L (221 cu. in.)
Combustion System:	Direct Injection
Power@2500 RPM:	63.0 kW (84.5 HP)
Maximum Speed:	2400 - 2500 RPM
Intake System:	Turbocharged
Oil Filter:	986537-03
Fuel Filter:	982080-02
Air Filter, Primary (Dry-Type):	38385-01
Air Filter, Secondary (Cartridge):	38385-02

Table 4-2. Electrical

ITEM	SPECIFICATION
Battery:	One Maintenance Free
Ampere Hour Rating:	1050 CCA
Voltage:	12V
Alternator Voltage:	12V, Negative Ground
Output Amperage:	90 Amps


Table 4-3. Dimensions

ITEM	SPECIFICATION
Weight:	3,402 kg (7,500 lb)
Overall Length (with water tank):	5.92 m (19 ft. 5 in.)
Overall Length (without water tank):	4.93 m (16 ft. 2 in.)
Overall Height:	2.67 m (8 ft. 9 in.)
Overall Width (Brush at 40°):	2.41 m (7 ft. 11 in.)

Specifications



ITEM	SPECIFICATION
Tread Width (Front and Rear):	1.55 m (5 ft. 1in.)
Wheelbase:	1.73 m (5 ft. 8 in.)
Turning Radius (Inside):	91 cm (3 ft.)
Turning Radius (Outside):	3.33 m (10 ft. 11in.)
Ground Clearance:	30 cm (12 in.)



Outline Dimensions Drawing

Figure 4-1

Table 4-4. Drive System Specifications

ITEM	SPECIFICATION
Transmission:	Hydrostatic
Steering:	Hydraulic, Orbital Motor, 14 LPM (3.7 GPM) priority flow at 10342 kPa (103 bar, 1500 psi)
Rear Axle:	Heavy-Duty, Truck-Type, Oscillating
Tires:	225/75R16, Load E
Tire Inflation Pressure	345 kPa (3.45 bar, 50 psi)
Travel Speed (Infinitely Variable):	0 to 35 km/h (0 to 22 mph)
Hydrostatic Pump Model and Manufacturer:	Sauer/Danfoss Series 90
Hydrostatic Pump Displacement:	75 cc (4.57 CIR)
Hydrostatic Motor Model and Manufacturer:	Sauer/Danfoss Series 90
Hydrostatic Motor Displacement:	100 cc (6.1 CIR)
Hydraulic Fluid:	Citgo A/W All-Temp VG32
Hydraulic Return Filter:	10-Micron Spin-On Cartridge (P/N 72543)
Hydraulic Charge Filter:	7-Micron Spin-On Cartridge (P/N 34463)
Hydraulic Strainer:	In-Tank (P/N 33148)

ITEM	SPECIFICATION
Hydraulic Oil Cooler:	Flow-Thru
Front Axle, Differential, Full-Float:	7.17:1 Ratio
Brakes:	Drum-Type Hydraulic, Duo-Servo

Table 4-5. System Capacity

ITEM	SPECIFICATION
Fuel:	132 L (34.8 gal)
Engine Lube Oil:	14.2 L (15 qt) KUBOTA
Hydraulic Oil Reserve:	90.9 L (24 gal)
Axle:	2.78 L (94 oz) Each

Table 4-6. Brush Operating System

ITEM	SPECIFICATION
Pump (Gear-Type):	91 LPM (24 GPM), 20684 kPa (207 bar, 3,000 psi)
Motor (Gerotor-Type):	Direct Drive
Brush Core (Welded Steel):	25 cm x 2.13 m (10 in. x 7 ft.)
Brush Filler (Wafer-Type):	25 cm x 92 cm (10 in. x 36 in.)
Brush Cover (Steel):	140°, Full Length
Brush Speed:	200 RPM maximum, Variable w/Engine RPM
Brush Angle:	40°, Left or Right
Brush Down Pressure Control:	Hydraulic, Fully Adjustable
Brush Watering System:	Poly Tank, 1@ 284 liters (150 gallons) Strainer, 12 Volt Diaphragm-Type Pump

Table 4-7. Cab Specifications

ITEM	SPECIFICATION
ROPS Cab:	OSHA & SAE Certified
Windshield Wiper (Front):	12 Volt, 2-Speed
Defroster Fan (Front):	12 Volt, Variable Speed
Seat:	Padded with Seat Belt
Horn:	12 Volt, Automotive-Type
Back-up Alarm:	97 db +/- 4 db at 122 cm (4 ft.)
Air Conditioning:	6,448 Watt (22,000 Btu/Hr) Capacity
Heater:	8,793 Watt (30,000 Btu/Hr) Capacity
Lights:	Turn Indicators, Tail Lights, Work Lights, Stop Lights
Mirrors:	West Coast
Instrumentation:	Oil Pressure, Coolant Temperature, Fuel Gauge, Voltmeter, Hourmeter, and Tachometer

Table 4-8. Optional Equipment

ITEM	SPECIFICATION
Defroster Fan (Rear):	12 Volt, Variable Speed
Windshield Wiper (Rear):	12 Volt, 2-Speed
Windshield Washer (Front or Rear):	12 Volt
Seat:	Suspension, Adjustable, with Seat Belt
Mirrors:	Inside Rear View
Engine Pre-Cleaner:	Standard or Turbo-Type
Instrumentation:	Hydraulic Oil Temperature, Engine Warning Light

Table 4-9. Lubricant Types

ITEM	SPECIFICATION
Engine Oil:	15W-40
Hydraulic Oil:	Citgo A/W All-Temp VG32
Grease:	Shell Avania EP Grease or Equivalent
Axle:	Gear Lube 90W



Section 5

COMPONENT LOCATION

INSTRUMENT PANEL




Figure 5-1

1 - Tachometer

2 - Park Brake Light

3 - Fuel Gauge

4 - Oil Pressure Gauge

5 - Temperature Gauge

6 - Voltmeter

7 - Check Engine Light

8 - Hour Meter



Component Location

Tachometer (1)

Displays engine speed in revolutions per minute (RPM).

Park Brake Light (2)

(Red Warning Light) Indicates that park brake is set.

Fuel Gauge (3)

Displays fuel level in the fuel tank.

Oil Pressure Gauge (4)

Displays engine oil pressure in pounds per square inch (psi).

Temperature Gauge (5)

Displays engine coolant temperature.

Voltmeter (6)

Displays the condition of the battery charging system.

Check Engine Light (7)

(Red Warning Light) Indicates engine malfunction. Check major components and fluid levels. Service immediately.

Hour Meter (8)

Displays total broom work hours.

STEERING CONSOLE




Figure 5-2

- 1 - Steering Wheel
- 2 - Directional Arrows
- 3 - Turn Signal Switch

- 4 - Ignition Switch
- 5 - Brake Master Cylinder
- 6 - Service Brake Pedal



Component Location

Steering Wheel (1)

Controls right and left steering function of the rear wheels.

Directional Arrows (2)

(Green Flashing Light) Indicates left/right turn as selected with Turn Signal Switch.

Turn Signal Switch (3)

Activates the left and right turn signals. Switch up for right turn, switch down for left turn.

Ignition Switch (4)

Used to start and stop the engine and activate switched power circuits.

Brake Master Cylinder (5)

Pressurizes the brake system.

Service Brake Pedal (6)

Used to slow and stop the broom.

BROOM CONTROL CONSOLE




Figure 5-3

- | | |
|--|----------------------------------|
| 1 - Park Brake Lever | 8 - Brush Watering System Switch |
| 2 - Brush Swing LT Switch | 9 - Beacon Light Switch |
| 3 - Brush Lift/Float Control | 10 - Rear Light Switch |
| 4 - Brush Swing RT Switch | 11 - Front Light Switch |
| 5 - Joystick / Transmission Selector Lever | 12 - Brush Down Pressure Control |
| 6 - Brush FWD/REV Control | 13 - Throttle Control Knob |
| 7 - Horn Switch | |



Component Location

Park Brake Lever (1)

Raise to set park/emergency brake. Lower lever to release.

Brush Swing LT Switch (2)

INCREMENTAL (Push Button) Controls brush swing to the left.

Brush Lift/Float Control (3)

FORWARD/BACK (Rocker Switch) Controls brush lift and float.

Brush Swing RT Switch (4)

INCREMENTAL (Push Button) Controls brush swing to the right.

Joystick / Transmission Selector Lever (5)

Controls speed and direction of broom travel. Reverse position activates the backup alarm.

Brush FWD/REV Control (6)

FORWARD/BACK (Rocker Switch) Controls forward and reverse rotation of brush.

Horn Switch (7)

Press and hold to sound the horn.

Brush Watering System (8)

Press to activate brush watering system.

Beacon Light Switch (9)

Controls cab-mounted strobe beacon light. Warns traffic of slow moving equipment.

Rear Lights Switch (10)

Activates rear work lights.

Front Lights Switch (11)

Activates front work lights.

Brush Down Pressure Control (12)

(LEFT/RIGHT knob) Controls hydraulic pressure suspending the brush.

Throttle Control Knob (13)

(PUSH/PULL and LEFT/RIGHT knob) Controls engine RPM, with center push-button.

HEAT & AIR CONDITIONING CONTROLS




Figure 5-4

- 1 - Heater Control Knob**
- 2 - Blower Fan Control**
- 3 - Air Conditioning Control**



Component Location

Heater Control Knob (1)

(LEFT/RIGHT knob) Clockwise rotation to adjust heat.

Blower Fan Control (2)

(4-Position knob) Controls blower fan for heater and air conditioning.

Air Conditioning Control (3)

(LEFT/RIGHT knob) Clockwise rotation to control temperature.

WINDSHIELD WIPER, DEFROST & DOME LIGHT CONTROLS




Figure 5-5

- 1 - Windshield Wiper and Washer Knob
- 2 - Option
- 3 - Defroster Fan
- 4 - Option
- 5 - Dome Light



Component Location

Windshield Wiper and Washer Knob (1)

(HIGH/LOW wiper with push-to-wash) Controls front windshield wiper and washer.

Option (2)

(HIGH/LOW wiper with push-to-wash) Controls rear windshield wiper and washer.

Defroster Fan (3)

(HIGH/MED/LOW knob) Controls front cab-mounted windshield defroster fan.

Option (4)

(HIGH/MED/LOW knob) Controls rear cab-mounted windshield defroster fan.

Dome Light (5)

ON/OFF (Push Button) Lights cab interior with push button switch on top.

DEFROSTER FAN




Figure 5-6

1 - Front Cab Windshield Defroster Fan

Front Cab-Mounted Windshield Defroster Fan (1)

Directed toward front window to defrost the windshield.

HYDRAULIC BRUSH LIFT LOCK




Figure 5-7

1 - Hydraulic Brush Lift Lock

Hydraulic Brush Lift Lock (1)

Locks the brush in the raised position to prevent damage during shipping. When valve handle is perpendicular to hose, lift cylinder is locked. Rotate valve parallel to hose to unlock.



Section 6

OPERATION

Before operating the LB Performance Model FB-90 Broom, read the following safety information and review Safety, Section 2.

⚠ DANGER The safety messages that follow have **DANGER level hazards**.

- Never allow anyone who is not properly trained to operate the LB Performance Model FB-90 Broom. Only authorized personnel who are properly trained can operate the broom.
- Do not operate a broom that requires repairs or scheduled maintenance. Put an information tag on the instrument panel that says "DO NOT OPERATE." Remove the key from the ignition switch. Repair all damage at once and perform routine maintenance. Minor damage can result in major system failure.

PRE-OPERATION

Before starting or operating the LB Performance Model FB-90 Broom, it is important to READ, UNDERSTAND, and FOLLOW all Operating instructions, Danger, Warning, and Caution messages in this section, as well as all Safety information contained in Section 2 of this manual. The following pre-operation checklist is provided to ensure efficient and safe operation of the broom.

Pre-Operation Checklist

Check the following areas before operating the LB Performance Model FB-90 Broom and each time thereafter:

1. Recommended fluid types and required quantities are listed in Specifications, Section 4 of this manual. Replace fluids as detailed in the Periodic Maintenance Schedule on page 7-4 of this manual. Check the following:
 - Check ENGINE OIL. Add if low. Be careful not to overfill.
 - Check HYDRAULIC OIL RESERVOIR. Add if low.
 - Check ENGINE DIESEL FUEL TANK. Fill if low.
 - Check ENGINE COOLANT LEVEL at radiator. Fill if low.
 - Check BRAKE FLUID at Brake Master Cylinder. Fill to 1" below top.
2. Check the Engine Air Filter Indicator. Clean or replace filters if indicator shows red or 50.8 cm (20 in.) of restriction.
3. Check engine belts and hoses for wear or fraying. Replace any that show signs of wear, cuts or abrasion.

4. Check park/emergency brake adjustment. See Axles and Brakes on page 7-19, for adjustment instructions.
5. Disengage the hydraulic brush lift lock. (Figure 5-7)
6. Check Tire Pressure. Maintain even pressure in all four tires at 345 kPa (3.45 bar, 50 psi).
7. Make sure cab windows are clean and pressurizer air filters are clean.
8. Check the broom for loose bolts.
9. Check for signs of leaking hoses. Refer to Hydraulic System Checks on page 7-19.
10. Check engine manufacturer's manual for pre-operation information.

STARTING THE ENGINE

Preliminary

Before starting the engine:

1. Check fuel level.
2. Check fuel lines, and tank for leaks.
3. Check engine crankcase oil level.

NOTICE Engine malfunction and failure can result from inadequate oil levels. Add oil whenever necessary.

4. Check hydraulic oil level. Oil level is determined by sight gauge on the hydraulic tank on the left side of unit.
5. Refer to engine operator's manual for instructions when starting engine for the first time. Follow engine manufacturer's recommendations for fuel and oil.

Engine Start-Up & Operation

⚠ WARNING Death or serious injury can result from an operator unfamiliar with the LB Performance Model FB-90 Broom. Know the location and function of the controls before operation. See Component Location, Section 5.

1. Place the Transmission Selector Lever (Figure 5-3, 5) in the neutral position. A Neutral Start Switch has been installed to prevent operation of the engine starter when the transmission is not in neutral.
2. Apply the park/emergency brake (Figure 5-3, 1).

⚠ WARNING

Death or serious injury can result by starting the LB Performance Model FB-90 Broom when not in neutral. Be sure the park brake is applied and the Transmission Selector Lever (Figure 5-3, 5) is in the neutral position before starting the broom. Sudden movement of the broom can throw an operator from the broom.

3. Set the Engine Throttle (Figure 5-3, 13) to one-half speed by holding the center button depressed and pulling on the knob.
4. Turn the Ignition Switch key (Figure 5-2, 4) to activate the engine starter. As soon as the engine starts, release the switch.

NOTICE

Starter can be damaged by continuously cranking. Do not crank engine for more than 30 seconds at a time. Allow starter to cool down for two minutes between attempts. If engine will not start refer to Troubleshooting, Section 8 or engine operation manual for solutions. If problem persists contact your LB Performance Dealer.

5. As soon as the engine starts, move the Engine Throttle (Figure 5-3, 13) to idle by holding the button depressed and pushing the knob fully down.

NOTICE

LB Performance Model FB-90 Broom may be damaged if oil pressure is not shown after broom startup. If no oil pressure is shown on the gauge in 15 seconds, shut down the engine and determine the cause.

6. Check the gauges on the instrument panel (Figure 5-1) for proper readings, and make the necessary corrections.
7. Adjust the position of the seat and mirrors for the operator's convenience.
8. When the engine is warm and running properly, fasten the seat belt and familiarize yourself with the operation of the controls.

⚠ WARNING

Death or serious injury can result if seat belt is not worn. Always wear a seat belt when operating the LB Performance Model FB-90 Broom.

NOTICE

Engine may suffer damage from extended idling. Never idle the engine for more than 10 minutes.

NOTICE

Drive system and brakes may be damaged if operated with the park/emergency brake engaged. Before moving the LB Performance Model FB-90 Broom, be sure the park/emergency brake is released.

Stopping the Engine

1. Throttle back to idle by pressing and holding either THROTTLE (Figure 5-3, 13) switch in the down position until idle speed is reached.
2. Apply Park Brake.
3. Turn ignition key on instrument panel counter-clockwise (CCW) to the OFF position and remove key.

System Controls

⚠ WARNING

Death or serious injury can result from an operator unfamiliar with the LB Performance Model FB-90 Broom. Know the location and function of the controls before operation. See Component Location, Section 5.

Engine Throttle

The Engine Throttle (Figure 5-3, 13) is a knob with a center push-button. It is located on the control panel to the right of the driver's seat.

Hold the button down while pulling or pushing the knob to increase or decrease throttle. Once the button is released the operator can fine-tune the engine RPM by turning the knob clockwise to increase throttle or counterclockwise to decrease throttle.

When first operating the LB Performance Model FB-90 Broom, set the throttle to 1/2 or 3/4 open until you are familiar with the functions of the controls.

Transmission Selector Lever

The hydrostatic Transmission Selector Lever (Figure 5-3, 5) is on the control panel on the operator's right side. With some experience, an operator should be able to operate this control along with the throttle to make the forward or reverse movement smooth and fluid-like. Placing the joystick in reverse activates the Back Up Alarm.

Service Brake Pedal

The foot-operated Service Brake Pedal (Figure 5-2, 6) is on the right side of the steering wheel console. The service brake may be overpowered by the hydrostatic drive. Always return the Transmission Selector Lever (Figure 5-3, 5) to neutral as the service brakes are applied.

Steering Wheel

The Steering Wheel (Figure 5-2, 1) is located in front of the operator's seat. Remember that steering takes priority over brush operations (rotation, lift and swing) when both are attempted at the same time.

Stopping & Braking

Most operators seldom use the foot brake. Instead they use the throttle and hydrostatic transmission to slow down, stop and change directions.

The operator must become accustomed to using the hydrostatic transmission to assist in braking. This is best done by moving the Transmission Selector Lever (Figure 5-3, 5) into the neutral position before applying the service brake.

⚠ WARNING Death or serious injury may result if sufficient stopping distance is not available. Familiarize yourself with the LB Performance Model FB-90 Broom, its braking system, and the job site before operation.

⚠ WARNING A runaway LB Performance Model FB-90 Broom may cause death or serious injury. Before dismounting from the broom, place the Transmission Selector Lever in neutral, turn off all accessories, set the park brake, shut OFF the engine, and remove the ignition key.

BRUSH OPERATION

Brush operation controls are located on the broom control console (Figure 5-3). The LB Performance Model FB-90 Broom is equipped with the following brush operating controls:

Brush Swing Switches

The Brush Swing Switches (Figure 5-3, 2 & 4) are the push button switches to the far left and right on the joystick. Push the switches in gradual momentary adjustments to swing the brush left or right. Hold the button down to move the brush to its full swing position.

Brush Lift/float Control Switch

The Brush Lift/Float Control Switch (Figure 5-3, 3) is the forward/back switch located at the left center of the joystick. It has three positions:

1. Up - Pushing fully forward lifts the brush carrier. When pressure on the switch is released, the switch automatically returns to the HOLD position.

2. Center - This position holds or "locks" the brush carrier at the height used in the last UP operation of the Brush Lift/Float Control Switch.
3. Down - Pushing back on the switch activates float mode. When pressure is released the switch returns to center, but float is maintained until the UP switch is pressed.

Brush Down Pressure Control

The Brush Down Pressure Control (Figure 5-3, 12) controls the amount of hydraulic pressure needed to keep the brush suspended over the work surface. Turn the valve clockwise to increase pressure and counterclockwise to decrease pressure.

NOTICE Brush damage will result from excessive down pressure. For best results, operate in the FLOAT position. Use the Brush Down Pressure Control knob to correct excessive down force.

NOTE: It is important to understand that by decreasing the hydraulic pressure suspending the brush, you are increasing the down force. Brush "down force" control only works with the Brush Lift/Float Control Switch in the DOWN, or FLOAT position.

Brush Forward/Reverse Control Switch

The Brush Forward/Reverse Control Switch (Figure 5-3, 6) is the forward/back switch located at the right center of the joystick. It has three positions:

1. Down - This is the normal sweeping position. Pushing the switch down causes debris to be pushed out in front of the brush.
2. Off - The center position turns the brush rotation OFF.
3. Up - Pushing forward on the switch pushes debris to the rear of the brush.

Brush Speed

Brush speed is controlled by changing the engine's RPM. This is done by adjusting the Engine Throttle (Figure 5-3, 13).

SWEEPING GUIDELINES

For best sweeping results, observe the following guidelines:

4. Sweep only with the tips of the brush bristles. This will provide maximum “flick” sweeping action. Control of sweeping action can be obtained by using the Brush Down Pressure Control knob.
5. For most normal sweeping operations, the FLOAT position works best. Practice will help the operator achieve the most effective operation of the brush.
6. For heavy sweeping, slow the ground speed and increase the brush RPM by increasing the engine RPM. The right combination of ground speed and brush speed will correct ineffective sweeping.
7. To get an ideal brush height setting, sprinkle some sand under the brush. Place the transmission in neutral and set the park brake. Engage the brush by moving the Brush Forward/Reverse Control Switch (Figure 5-3, 6).
8. Move the Brush Forward/Reverse Control Switch to center, the OFF position. When the brush is raised, there should be a 2” to 4” wide clean swath under the entire length of the brush.

NOTICE Brush may be damaged if stored improperly. Ensure brush is completely raised and safety stop is engaged during storage to prevent a flat spot from forming on the brush bristles.

DUST SUPPRESSION SYSTEM

In certain conditions, it may be necessary to sweep using the Dust Suppression System to control dust. This system consists of one 150 gallon poly tank, an electric pump, and corrosion resistant nozzles and piping system. The pump is turned on by a switch on the side panel (Figure 5-3, 8).

TRANSPORTING THE BROOM

When transporting the LB Performance Model FB-90 Broom on a flat bed vehicle, the vehicle must be capable of carrying the broom safely in all driving situations.

1. Clean the broom using a pressure washer. Remove all loose gravel, mud or debris from wheels, frame, and brush.
2. Make sure the combined height of the truck, trailer and loaded broom meet height restrictions for the local area, including bridges, overpasses, and overhead obstructions.

3. Park the transport vehicle on a level surface and set the park brake.
4. Install chocks or blocks against truck and trailer wheels.
5. Use a ramp or loading dock. Make sure the ramp weight capacity will support the broom and has a low angle of rise to the trailer bed.
6. Load the broom on the trailer bed by driving straight on, centered on the trailer. The broom center-line must be over the center-line of the trailer.
7. Set the park brake and block broom wheels in both directions to prevent rolling.
8. Using the Brush Swing Switches (Figure 5-3, 2 & 4), center the brush.
9. Using the Brush Lift/Float Control Switch (Figure 5-3, 3), raise the brush to its full upright position.
10. Engage the hydraulic brush lift lock (Figure 5-7).

WARNING Death or serious injury can result from the LB Performance Model FB-90 Broom breaking loose during transport. Ensure broom is properly secured to transport trailer.

NOTICE LB Performance Model FB-90 Broom damage can result from broom breaking loose during transport. Ensure broom is properly secured to transport trailer.

NOTE: Fasten chains or cables to broom frame. Do not place chains or cables over or against hydraulic lines, hoses or electrical harnesses.

11. Secure the broom to the trailer using the four tie-downs located on each side at the front and rear of the broom’s main frame (Figure 6-1).
12. Idle the engine at 1/2 speed (RPM) for 3 to 5 minutes.
13. Place engine throttle at slow idle.
14. Place ignition switch in the OFF position and remove the key.
15. Cover the exhaust opening with heavy gauge plastic to prevent dust and moisture from entering the engine.

NOTE: Remove the plastic cover from the exhaust before operating the broom.

Broom Tie Downs




Figure 6-1



Section 7

MAINTENANCE

GENERAL INFORMATION

This section gives the necessary procedures for routine and general maintenance on the LB Performance Model FB-90 Broom. Before starting any Maintenance program on the broom, it is important to READ, UNDERSTAND, and FOLLOW all Maintenance instructions, Danger, Warning, and Caution messages in this section, as well as all information contained in Safety, Section 2.

 DANGER Death or serious injury can result if maintenance instructions, Danger, Warning, and Caution messages are not observed.

NOTE: By following a careful service and maintenance program for your broom, you will ensure many years of trouble free operation.

PROPERLY MAINTAINED EQUIPMENT IS SAFE EQUIPMENT! The user of this product is responsible for inspecting the broom daily, and for having parts replaced or repaired when continued use would cause damage or excessive wear to other parts. General daily inspection of the broom should include inspection for missing guards, loose bolts, fluid leaks, worn or damaged hoses and debris or dirt accumulations which could cause a potential service or safety problem.

ROUTINE MAINTENANCE

General Information

Maintenance must be a planned program that includes periodic LB Performance Model FB-90 Broom inspection and lubrication procedures.

The maintenance program must be done based on the broom's "Operating Hours" recorded on the hour meter, or on a "Periodic Schedule" which is done at daily, weekly, monthly or yearly intervals.

NOTE: When performing any routine maintenance such as 50, 100, 250, 500, or 1000 hours, always include previous routine maintenance hours to the higher hourly schedule.

Broom Lubrication

Proper lubrication is necessary to maintain the LB Performance Model FB-90 Broom at top efficiency. Refer to Periodic Maintenance Schedule on page 7-4.

PERIODIC MAINTENANCE

Periodic Maintenance Schedule

Table 7-1 Periodic Maintenance Schedule

System	Item	10 hour Daily	Initial 50 hours Weekly	Initial 100 hours	100 hours Monthly	250 hours Quarterly	500 hours Semi Annually
Engine Oil and Filter	Check oil level	X					
	Replace engine oil and oil filter cartridge		X			X	
Engine Air Filters	Check primary air filter		X				
	Check secondary air filter		X				
	Replace primary air filter				X		
	Replace engine air filter					X	
Engine Belts	Check drive belts				X	X	
Cooling	Check coolant level	X					X
	Replace coolant						X
Fuel	Check engine fuel filter	X					
	Replace engine fuel filter						X
Hydraulic	Check hydraulic oil level	X					
	Check hydraulic return filter	X					
	Check hydraulic charge filter	X					
	Replace hydraulic oil			X			X
	Replace hydraulic return oil filter			X			X
	Replace hydraulic charge filter			X			X
	Clean hydraulic strainer			X			
	Replace hydraulic strainer						X
Chassis and Running Gear	Lubricate driveshaft lubrication fittings	X					
	Lubricate steering axle pivot				X		
	Lubricate steering axle king pins				X		
	Lubricate steering axle tie rods				X		
	Lubricate drive shaft				X		
	Replace transfer case oil			X			X
	Replace drive axle oil			X			X
	Re-pack steering axle bearings						X
Brakes	Check brake fluid at master cylinder	X					
	Check brake linings						X
Brush Watering System	Check, clean as needed	X					
	Check watering system strainer, clean as needed	X					
Lighting	Check and repair as needed	X					

TORQUE SPECIFICATIONS

General Information

This section of the Operations and Maintenance Manual contains standard torque specifications that may be used on your machine, where applicable. The proper torquing of bolted connections, where applicable, is an essential part of good preventive maintenance, helping to keep bolts tight, increases joint strength, and improves the fatigue resistance of bolted connections.

Refer to the Maintenance Instructions in Section 5 of this manual and the Shop Maintenance Manual for specific requirements. See your authorized dealer

for assistance, if required. For maximum machine life and performance, use only genuine manufacturer's replacement parts where available. Metric Fasteners



WARNING The following Table lists torque values for standard hardware and are intended as a guide for average application involving typical stresses and machined surfaces. Values are based on physical limitations of clean, plated and lubricated hardware. In all cases, when an individual torque value is specified, it should be followed instead of values given in this table.



CAUTION Replace original equipment with hardware of equal grade.

Table 7-2 Torque Specifications For Metric Fasteners

NOMINAL SIZE & PITCH	CLASS 8.8 (GRADE 5 EQUIVALENT)				CLASS 10.9 (GRADE 8 EQUIVALENT)			
	TORQUE FT. LBS.		TORQUE N•m		TORQUE FT. LBS.		TORQUE N•m	
	Dry	Lubed	Dry	Lubed	Dry	Lubed	Dry	Lubed
M4 x 0.7	2.27	1.70	3.07	2.30	2.27	2.31	4.17	3.13
M5 x 0.8	4.58	3.43	6.20	4.65	6.22	4.67	8.43	6.33
M6 x 1	7.75	5.83	10.5	7.90	10.60	7.97	14.3	10.8
M8 x 1.25	18.89	14.17	25.6	19.2	18.95	19.26	34.8	26.1
M10 x 1.25	39.11	29.52	53.0	40.1	53.87	40.59	73.0	55.0
M12 x 1.75	64.94	48.71	88.0	66.0	88.56	66.42	120.0	90.0
M14 x 2	103.32	77.49	140.0	105.0	140.22	107.01	190.0	145.0
M16 x 2	162.36	121.77	220.0	165.0	221.40	166.05	300.0	225.0
M20 x 2.5	317.34	236.16	430.0	320.0	428.04	321.03	580.0	435.0
M24 x 3	516.12	409.59	740.0	555.0	754.38	557.19	1010.0	755.0
M27 x 3	797.04	597.78	1080.0	810.0	1084.86	811.80	1470.0	1100.0
M30 x 3.5	1084.86	811.80	1470.0	1100.0	1476.00	1107.00	2000.0	1500.0

Inch Fasteners

⚠ WARNING The following Table lists torque values for standard hardware and are intended as a guide for average application involving typical stresses and machined surfaces. Values are based on physical limitations of clean, plated and lubricated

hardware. In all cases, when an individual torque value is specified, it should be followed instead of values given in this table.

⚠ CAUTION Replace original equipment with hardware of equal grade.

Table 7-3 Torque Specifications For Standard Inch Fasteners

SIZE	THREAD	CAPSCREWS: SAE GRADE 5				CAPSCREWS: SAE GRADE 8			
		TORQUE FT. LBS.		TORQUE N•m		TORQUE FT. LBS.		TORQUE N•m	
		Dry	Lubed	Dry	Lubed	Dry	Lubed	Dry	Lubed
1/4	20 UNC	8	6	11	9	12	9	16	12
	28 UNF	10	7	13	10	14	10	19	14
5/16	18 UNC	17	13	24	18	25	18	33	25
	24 UNF	19	14	26	20	27	20	37	28
3/8	16 UNC	31	23	42	31	44	33	59	44
	24 UNF	35	26	47	36	49	37	67	50
7/16	14 UNC	49	37	67	50	70	52	95	71
	20 UNF	55	41	75	56	78	58	105	79
1/2	13 UNC	75	57	100	77	105	80	145	110
	20 UNF	85	64	115	86	120	90	165	120
9/16	12 UNC	110	82	145	110	155	115	210	155
	18 UNF	120	91	165	125	170	130	230	175
5/8	11 UNC	150	115	205	155	210	160	285	215
	18 UNF	170	130	230	175	240	180	325	245
3/4	10 UNC	265	200	360	270	375	280	510	380
	16 UNF	295	225	405	300	420	315	570	425
7/8	9 UNC	430	320	580	435	605	455	820	615
	14 UNF	475	355	640	480	670	500	905	680
1	8 UNC	645	485	875	655	910	680	1230	925
	14 UNF	720	540	980	735	1020	765	1380	1040
1-1/8	7 UNC	795	595	1080	805	1290	965	1750	1310
	12 UNF	890	670	1210	905	1440	1080	1960	1470
1-1/4	7 UNC	1120	840	1520	1140	1820	1360	2460	1850
	12 UNF	1240	930	1680	1260	2010	1500	2730	2050
1-3/8	6 UNC	1470	1100	1990	1490	2380	1780	3230	2420
	12 UNF	1670	1250	2270	1700	2710	2040	3680	2760
1-1/2	6 UNC	1950	1460	2640	1980	3160	2370	4290	3210
	12 UNF	2190	1650	2970	2230	3560	2670	4820	3620

Hydraulic Fittings

Tightening Flare Type Tube Fittings

1. Check the flare and flare seat for defects that might cause leakage.
2. Align tube with fitting before tightening.
3. Lubricate connection and hand tighten swivel nut until snug.

4. To prevent twisting the tube(s), use two wrenches. Place one wrench on the connector body and with the second, tighten the swivel nut to the torque shown in **Table 7-4. Torque Specifications For Flare Type Tube Fittings**.

NOTE: The torque values shown are based on lubricated connections as in assembly.

Table 7-4 Torque Specifications For Flare Type Tube Fittings

TUBE SIZE OD	NUT SIZE (ACROSS FLATS)	TORQUE VALUE		RECOMMENDED TURNS TO TIGHTEN (AFTER FINGER TIGHTENING)	
		(N•m)	(lb-ft)	(N•m)	(lb-ft)
3/16	7/16	8	6	1	1/6
1/4	9/16	12	9	1	1/6
5/16	5/8	16	12	1	1/6
3/8	11/16	24	15	1	1/6
1/2	7/8	46	34	1	1/6
5/8	1	62	46	1	1/6
3/4	1 1/4	102	75	3/4	1/8
7/8	1 3/8	122	90	3/4	1/8

Full Torque Nut Coupling Installation

The only completely reliable method of creating a consistent leak free, long lasting connection is to ensure that the coupling is brought to the proper torque.

The best method of ensuring a coupling is brought to the proper torque is to use a torque wrench with crowfoot. To ensure the proper torque is met, use the flats method of torque verification. Flats method may be used alone in situations where a torque wrench is inaccessible or unavailable.

There are 7 steps involved in proper coupling installation:


5. Determine the correct torque value for your coupling.

NOTE: Only use the torque values specified from the manufacturer, do not use SAE torque recommendations.

The minimum torque values are adequate for sealing in most applications, and the maximum torque values should never be exceeded.

6. Calculate the correct torque wrench setting using (see **Equations** in Section 7).

NOTE: The most straight forward method of determining the correct torque setting is to multiply the desired torque by the length of the wrench from the center of the handle to the center of the drive (L) divided by the length of the wrench from the center of the handle to the crowfoot center (LA), (**Figure 4-3**).



Torque Wrench - Crowfoot

Figure 7-1

NOTE: Torque Wrench Setting = Desired Torque * L / LA

7. Ensure that the seal face and threads are clean and in good condition. Do not lubricate coupling threads.

NOTE: O-Rings should be lubricated with light oil, but threads should be completely dry unless making pipe thread connections (interference seal).

Attach the male end of the hose onto the equipment first, since it may be necessary to rotate the entire hose assembly to tighten the male threads. Then route the hose into position while avoiding twisting the hose.


8. Hand tighten the connection by bringing seal face in contact and rotating the nut by hand until it stops.

NOTE: By definition hand tight is 0.3-1 ft-lb or when the seal faces are touching and with the threads engaged the hex can no longer be rotated by hand.

9. Mark a line across the coupling nut and backup hex for flats method verification of coupling torque (**Figure 7-4**).
10. Apply a wrench to the backup hex to prevent the coupling and hose from moving while tightening the nut with a torque wrench.

NOTICE Failure to retain the backup hex during installation will also result in additional clamp load force that could cause damage to the seal face.

NOTE: The coupling nut must be in motion for an accurate torque reading. If the nut is stopped before final torque value is achieved, it must be loosened and retightened until the torque is attained while the nut is in motion.



Flats Method Tightening

Figure 7-2

1 - Mark Line on Nut

2 - Example 2 Flats difference

11. If a torque wrench cannot fit into the coupling area or if it is unavailable, flats method may be used to ensure that the coupling is properly tightened, as shown in **Figure 7-2**.

NOTE: The mark placed on the nut and backup hex after hand tightening should have rotated 1 to 1.5 flats during final tightening. At this point in time, if desired, the nut and backup hex may be marked to indicate if the coupling loosens over time.

Table 7-5 Torque Specifications For US Style Coupling Terminations

JIC, SAE 45°, ORFS, O-Ring Boss, Gates Adapterless and MegaSeal										
Dash Size	JIC 37°, SAE 45° & MegaSeal (steel)		JIC 37°, SAE 45° & Mega-Seal (steel)		Flat Face O-Ring Seal (Steel)		SAE O-Ring Boss (Steel) & Gates Adapterless ≤ 4000 PSI		SAE O-Ring Boss (Steel) & Gates Adapterless > 4000 PSI	
1/16 Inch	ft-Lb		ft-Lb		ft-Lb		ft-Lb		ft-Lb	
	Min	Max	Min	Max	Min	Max	Min	Max	Min	Max
-3									8	10
-4	10	11	5	6	10	12	14	16	14	16
-5	13	15	7	9					18	20
-6	17	19	12	15	18	20	24	26	24	26
-8	34	38	20	24	32	40	37	44	50	60
-10	50	56	34	40	46	56	50	60	72	80
-12	70	78	53	60	65	80	75	83	125	135
-14					65	80			160	180
-16	94	104	74	82	92	105	111	125	200	220
-20	124	138	75	83	125	140	133	152	210	280
-24	156	173	79	87	150	180	156	184	270	360
-32	219	243	158	175						

Table 7-6 Torque Specifications For DIN 24, DIN 60, and Inverted Cone Style Coupling Terminations

DIN 24, DIN 60, and Inverted Cone			
Size		Torque	
mm		ft-Lb	
Light Series Tube OD	Heavy Series Tube OD	Min	Max
6		7	15
8		15	26
10	8	18	30
12	10	22	33
14	12	26	37
15	14	30	52
	16	30	52
18	20	44	74
22	25	59	89
28	30	74	111
	38	74	162
35		133	184
42		148	221

Table 7-7 Torque Specifications For 4-Bolt Flange Connections

4-Bolt Flanges		
Dash Size	Bolt Size	Torque
1/16 Inch	Inch	ft-Lb
-8	0.31	17
-12	0.38	26
-16	0.44	43
-20	0.50	65
-24	0.63	130
-32	0.75	220
1. Align faces and finger tighten bolts before applying final torque in a pattern. The seal faces must be parallel with even bolt tension to seal properly. 2. Torque values apply to bolts which are plated or coated in light engine oil. 3. Before assembly lubricate O-Ring with light oil (SAE 10W or 20W).		

Table 7-8 Torque Specifications For SAE Male Flareless Assembly (MFA)

SAE Male Flareless Assembly (MFA)
After hand tight rotate nut one full turn (8 flats)

Table 7-9 Torque Specifications For NPTF Dry Seal Pipe Threads

NPTF	
Dash Size	Max Torque
1/16 Inch	ft-Lb
-2	20
-4	25
-6	35
-8	45
-12	55
-16	65
-20	80
-24	95
-32	120
- The torque values obtained from tightening pipe threads can vary considerably depending on thread condition. Adequate sealing can occur at values much lower than the maximum values listed above. Only enough torque to achieve adequate sealing should be used. - When using a male tapered pipe thread with a female straight or parallel pipe thread, maximum values are 50% of those listed in the table. - If thread sealant is used, maximum values shown should be decreased by 25%.	

Table 7-10 Torque Specifications For BSP 30° Inverted Cone and JIS Coupling Terminations


BSP 30° Inverted Cone and JIS		
Dash Size	Torque	
mm	ft-Lb	
1/16 Inch	Min	Max
-2	7	9
-4	11	18
-6	19	28
-8	30	36
-10	37	44
-12	50	60
-16	79	95
-20	127	152
-24	167	190
-32	262	314

Table 7-11 Flats Method Values For Selected Terminations

Flats Method Values		
Termination Type	Dash Size	Flats
	1/16 Inch	
JIC	4	1.5 - 1.75
JIC	6	1.0 - 1.5
JIC	8	1.5 - 1.75
JIC	10	1.0 - 1.5
JIC	12	1.0 - 1.5
JIC	16	.75 - 1.0
JIC	20	.75 - 1.0
JIC	24	.75 - 1.0
JIC	32	.75 - 1.0
JIS	4	.5 - 1.5
- Seal faces must be in contact and the fitting fully hand tightened before marking flats. - Flats method is most accurate for the first assembly cycle, for multiple disassembly/assembly cycles torque values are more reliable. - Tightening 2 flats or more is analogous to sever over torque and may damage seal faces.		

Determining Torque Setting

There are several methods of determining the correct setting on the torque wrench when using a crowfoot. All of the methods involve making the setting proportional to the effective change in length of the wrench multiplied by the desired final torque.



Measurements Needed

Figure 7-3

L = Distance from center of torque wrench handle to the center of socket drive

E = Distance from center of socket drive to the center of crowfoot

LA = Distance from center of torque wrench handle to the center of crowfoot

LH = Distance from center of torque wrench handle to the center of crowfoot, when mounted at 90°

TD = Desired torque at the fitting

TS = Torque setting indicated on wrench

Equations

Equation 1

Torque setting if the crowfoot is placed in line with respect to the wrench:

$$TS = TD * L / LA$$

or

$$TS = TD * L / (L+E)$$

Equation 2

Torque setting if the crowfoot is placed at 90° with respect to the wrench

$$TS = TD * L / LH$$

or

$$TS = TD * L / \sqrt{(L^2 + E^2)}$$

Equation 3

To estimate the crowfoot size (E)

$$E = \text{Drive Size} * 0.5 + \text{Distance between Drive \& Open End} + \text{Wrench Size} * 0.5774$$

MAINTENANCE SCHEDULE

General Information

Preventive maintenance on the LB Performance Model FB-90 Broom will provide years of trouble-free operation. Adjustments can be performed in the field with ordinary hand tools. Engine preventive maintenance, other than oil, air, and fuel filter changes, is not covered in this section. Refer to the engine manufacturer's manual for engine service information.

NOTE: Changing oil and cleaning the broom should only be done in a designated area that can contain the oil and chemicals involved in any maintenance requirement. These by-products should be discarded in accordance with environmental regulations.

CAUTION LB Performance Model FB-90 Broom damage can occur if replacement fastener is not identical to original. Do not substitute fasteners of any kind unless the fasteners are equal in size and grade to original equipment. See pages 7-7 and 7-8 for torque specifications.

NOTE: When performing any routine maintenance such as 50, 100, 250, 500, or 1000 hours, always include previous routine maintenance hours to the higher hourly schedule.

Preparing The Broom For Maintenance

When performing maintenance, perform the following steps before leaving the operator's seat, unless the maintenance procedure instructs otherwise.

1. Park the LB Performance Model FB-90 Broom on a flat even surface.
2. Place transmission selector lever in neutral.
3. Engage park brake.
4. Turn off broom drive.
5. Run engine at 1/2 speed (RPM) for 3 to 5 minutes.
6. Reduce engine speed to slow idle.
7. Lower all attachments to ground level.
8. Place ignition key in OFF position.

WARNING Death or serious injury can result if engine is running during maintenance. If the engine must be running to service a component, place transmission in neutral, apply park brake, block wheels, and use extreme caution.

Checks And Adjustments

1. Check the LB Performance Model FB-90 Broom for indications of oil leakage around oil lines, hoses, and fittings.
2. Tighten fittings as necessary. Replace hoses and fittings as needed. See pages 7-5 and 7-6 for torque specifications.
3. Check and empty the precleaner bowl. Clean the bowl and dry with a lint free cloth.
4. Check air intake hoses from the engine to the air cleaner assembly, and from the air cleaner assembly to the precleaner. Replace worn or damaged hoses and tubes. Tighten or replace loose and damaged clamps.

ENGINE MAINTENANCE

WARNING Death or serious injury can result from entanglement in moving parts. Do not service the LB Performance Model FB-90 Broom while in motion or while engine is running. If the engine must be running to service a component, place transmission in neutral, apply park brake, block wheels, and use extreme caution.

In addition to the following maintenance recommendations, consult the engine manufacturer's manual for detailed instructions. A copy of this manual was provided with your LB Performance Model FB-90 Broom at the time of its shipment from the factory. If additional copies are needed, they can be obtained from your LB Performance Dealer.

Neutral Start System

A Neutral Start Switch has been installed to prevent operation of the engine starter when the transmission is not in neutral. To check this system:

1. Set the park brake.
2. Place transmission selector lever in the forward position.
3. Turn ignition key to START. Starter must not crank the engine. If starter cranks engine, release key. Do not operate LB Performance Model FB-90 Broom.
4. Repeat test with the transmission in reverse.

CAUTION Death or serious injury can result from starting the LB Performance Model FB-90 Broom when not in neutral. Do not operate broom if starter cranks the engine while transmission is in any gear except neutral. See your LB Performance Dealer for Neutral Start System repair.

- Place transmission in neutral and turn ignition switch to START. Starter should crank engine.

Cold Weather Starting

In cold weather, it may be necessary to use the glow plugs as a starting aid. Use the following steps.

- Turn the ignition key to the ACC position and wait 3 to 5 seconds.
- Turn the key to start the engine.

Engine Belts

- Check the diesel engine belt(s) for excessive wear, fraying, and cracking every 250 service hours. Auxiliary V-belt drives should be inspected every 100 hours.
- Adjust engine belt(s) as required to provide proper tension. Consult the engine manufacturer's manual for correct tensioning instructions and specifications.
- Your LB Performance Model FB-90 Broom is equipped with an air conditioner with a V-belt drive. For proper operation, it is important to keep this belt tensioned properly.

⚠ DANGER Death or serious injury can result from entanglement in moving parts. Always shut down engine before adjusting belts.

- When installing new belts, always shorten the distance between pulley centers so the belt can be installed without force. Never roll the belt over a pulley and never pry it with a tool such as a screw driver. This will damage and shorten belt life.

⚠ CAUTION Death or serious injury can result from entanglement in moving parts. Keep belt guards in place at all times.

Fuel and Fluids

Keep the fuel tank full to prevent condensation from forming. Fill the fuel tank at the end of each day.

Fuel Requirements

Use clean, good quality ASTM No. 2-O or No. 2-D climatized diesel fuel. If the LB Performance Model FB-90 Broom will be used often in cold weather (below 20° F), blended fuels or No. 1 diesel fuel is recommended to prevent gelling of the fuel filters. Using No. 1 diesel fuel may reduce the engine performance by approximately 10%.

NOTICE LB Performance Model FB-90 Broom system can be damaged by the use of contaminated fuel. Water or dirt can cause severe damage to engine components.

Caterpillar Fuel Filter And Water Separator

Caterpillar diesel engine injection systems use fuel for lubrication of close tolerance internal engine parts. Proper maintenance of the fuel filters and the fuel tank is required for continued top performance, and to prevent damage to internal engine components.

The engine fuel filter and water separator are located on the left side of the engine. A drain valve is provided on the bottom of the water separator (Figure 7-4).




Figure 7-4

NOTE: Turn valve counter clockwise to drain. Turn valve clockwise to close.

- Before operating the engine, use the valve to drain a small quantity of fuel from the water separator into a clean, clear container.

NOTE: This is a necessary daily routine to prevent damage to internal engine components.

- If water or contaminants are found in the fuel you drained, DO NOT attempt to start the engine. Continue to drain fuel into the container until it runs clear.
- If large amounts of contamination are found, drain the fuel tank until the lines run clear. Replace the filters. Fill new filters with fresh clean fuel and install.

The engine manufacturer's manual provided with your LB Performance Model FB-90 Broom contains more detailed information on fuel system maintenance procedures.

Crankcase Oil

1. Check the engine crankcase oil level daily, prior to each day's use of the LB Performance Model FB-90 Broom. Park the broom on a level surface when checking the oil to assure accurate measurements. When checking oil while the engine is warm, wait until the engine has been OFF for at least five minutes. This allows oil to drain back to the crankcase.
2. The oil dipstick is located on the side of the engine. If the oil measures below the "L" mark on the dipstick, add a small amount of 15W-40 oil. After adding oil, recheck the level with the dipstick and make sure it doesn't measure above the "H" mark.

NOTICE Engine can be damaged from operation with inadequate oil levels. Never operate the engine with the oil level below the "L" (Low) mark or above the "H" (High) mark.

3. Engine crankcase oil and oil filter should be changed after the first 50 hours of service and every 250 hours or every 3 months thereafter.

Brake Master Cylinder

Check fluid level daily and fill to 25 mm (1 in.) below top with D.O.T. 3 approved commercial brake fluid. Check hydraulic system for leaks if the brake cylinder is frequently low.




Figure 7-5

- 1 - Air Restriction Indicator
- 2 - Primary Element Assembly
- 3 - Cover Assembly

Air Intake System

The heavy-duty engine air cleaner is mounted inside the engine compartment. A restriction indicator is mounted on the outlet side of the air cleaner assembly housing, near the large inlet tube to the engine (Figure 7-5, 1).

1. Prior to daily operation, inspect all air intake system components for damage, cracked hoses or loose clamps.

NOTE: To prolong engine life and prevent dust and contaminants from entering the engine, check hoses and hose clamps daily. Replace cracked hoses and tighten loose hose clamps.

2. Inspect the restriction indicator (Table 7-5, 1) several times daily during operation. If the red indicator flag on the restriction indicator is visible, the air cleaner element must be replaced.

NOTE: Be sure to clean the inside of the air cleaner body assembly BEFORE removing the safety element to prevent introducing contaminants into the system.

- Before replacing any new element to the air filter housing, wipe the inside of the housing with a damp cloth. Reset the restriction indicator. Be sure not to introduce any contaminants into the engine intake tube.
 - When replacing body assembly or rubber adaptors, torque the T-clamp bolts to 5.65 N•m (50 lb-in.).
3. DO NOT replace the filter elements until the maintenance interval has been reached or the restriction indicator flag is visible.
 4. Replace the primary filter elements monthly or every 100 service hours. Replace the safety element quarterly or every 250 hours.
 5. The air precleaner should not require maintenance or service unless visible damage is apparent.

NOTICE Engine can be damaged if operated without an air cleaner. Never operate engine without an air cleaner as destruction of internal engine components will occur.

Radiator and Coolant

NOTICE Engine damage can occur if radiator is blocked. Failure to check radiator for damage can cause overheating and premature failure of the engine and its components.

1. Check the engine radiator daily for rocks and debris.

WARNING Serious injury can result from flying debris. Wear eye protection when using compressed air.

2. Use compressed air to remove rocks or debris from the radiator.

WARNING Serious injury can result from hot coolant coming into contact with skin causing serious burns. Do not remove the radiator cap when engine is hot. Add coolant to the radiator only when the engine is stopped and fully cooled.

3. Check radiator coolant level prior to each day's use of the LB Performance Model FB-90 Broom. When the engine is cold, the coolant level should cover the radiator core. When the engine is warm, the coolant level should be at the bottom of the filler tube.
4. Refill the cooling system when necessary with 50% water and 50% ethylene-glycol antifreeze.
5. Seasonally, or after every 500 service hours, flush the cooling system. Any good commercial automotive cooling system cleaning solution can be used.

Prepare the coolant as recommended by the engine manufacturer and refill according to the previous procedure.

Battery

The LB Performance Model FB-90 Broom is factory equipped with a maintenance-free battery that is sized to provide efficient starting for the diesel engine on the broom. With proper care, the battery will provide years of trouble-free service.

CAUTION Death or serious injury can result from electric shock. When welding on the LB Performance Model FB-90 Broom, always turn the broom off and remove the battery ground (-) cable.

1. Starting an engine depends heavily upon good cranking speed. It is important that the battery is fully charged and that all cables and terminals are clean and properly connected to the battery.

NOTE: A maintenance free battery should rarely require additional electrolyte.

2. Keep the top of the battery clean. When necessary, wash with a baking soda solution (1 part baking soda to 4 parts water) and rinse with fresh water. DO NOT allow the soda solution to enter the battery cells.
3. Inspect the cables, clamps and hold-down bracket regularly. Clean and apply a light coating of grease when needed. Replace corroded or damaged parts.

CAUTION Death or serious injury can result from electric shock. When servicing the battery, always disconnect the battery ground (-) cable first. Always reconnect the positive (+) battery cable first.

4. If the battery becomes discharged repeatedly, check the electrical charging system. If the engine is difficult to start or the battery seems weak, clean and check the terminal connections. If the problem continues, use a battery tester and check voltage and current draw.

- Shut down engine and remove ignition key.
- Place the positive (red) multimeter lead on the positive (+) battery terminal, and the negative (black) multimeter lead on the grounded (-) battery terminal.
- With the multimeter set at 12 VDC, the battery must show a charge of at least 12 volts. If necessary, charge the battery or perform a load test.
- Start the engine.
- With an operator in the operator's seat, check the battery charge level. The multimeter should read at least 13.5 volts.
- If the multimeter does not indicate minimum charge, check the broom's charging system.

WARNING Death or serious injury can result from explosions due to explosive gas around the battery. Sparks or flame can ignite this gas causing an explosion. Always shut off the battery charger before disconnecting cables from the battery terminals.

WARNING Always wear eye protection when servicing batteries. Caustic solutions can cause serious eye injuries.

5. If the broom is to be stored for more than 30 days, remove the battery from the broom and store it in a cool, dry place. During storage, keep the battery fully charged and check the level of the electrolyte regularly.

CAUTION When removing or replacing the battery, always disconnect the battery ground (-) cable first. Always reconnect the positive (+) battery cable first.

NOTE: When replacing the battery, discard the old battery properly.

The alternator supplies electrical current for charging the battery and electrical power to the electronic controls. The built-in regulator controls the voltage output. If the wires must be disconnected from the alternator, mark them so they can be reconnected properly.

NOTICE Never polarize an alternator. Never ground alternator terminals or circuits.

NOTICE Always disconnect the battery before disconnecting or connecting the alternator. Never disconnect the alternator with it operating. Be sure wiring is properly connected before connecting the battery.

ELECTRICAL MAINTENANCE

CAUTION When servicing the electrical system, always disconnect the battery ground (-) cable first. Always reconnect the positive (+) battery cable first.

The LB Performance Model FB-90 Broom electrical system is protected from overload damage by fuses. If an electrical component fails to operate, check the fuse panel first to make sure that a fuse is not blown. The fuse panel is located on the right hand side of the broom behind the panel (Figure 7-6, 1).




Figure 7-6

1 - Fuse Box Panel

Fuses that blow may be replaced but will continue to blow until the cause of the overload is found and corrected. Refer to Figure 7-7 for replacement fuse sizes.

NOTICE Damage to the electrical system and fire can occur from improper fuse replacement. Always replace a blown fuse with the same rating as specified. Never replace with a higher amperage rating.




Figure 7-7

- 1 - Fuel Pump - 15 A**
- 2 - Fan - 10 A**
- 3 - Heater and A/C - 25 A**
- 4 - Water Pump - 15 A**
- 5 - Wipers - 15 A**
- 6 - Joystick / Backup 10 A**
- 7 - Work Lights - 10 A**
- 8 - Horn/Broom - 10 A**
- 9 - Brake Lights - 10 A**
- 10 - Lights - 15 A**
- 11 - Turn Signals / Hazards - 10 A**
- 12 - Beacon - 5 A**

Lighting

1. Inspect lights daily for proper operation.
2. If a light or group of lights does not function:
 - Check the fuse panel for a blown fuse (Figure 7-7).
 - Examine all visible wiring connections, making sure that they are securely fastened.
 - If the light(s) still does not work, remove the lens from the light and inspect the bulb(s), replacing any that appear damaged or discolored.
 - Check lighting mounts for proper grounds.
 - If the trouble is not located, inspect the wiring harnesses for damage. Wiring schematics are provided in Electrical, Section 9 to assist in troubleshooting the LB Performance Model FB-90 Broom's electrical system.
3. If broken wires are found, it is recommended that they be soldered together and covered by a shrink wrap type of plastic covering (preferred) or electrician's tape to prevent contamination of the solder joint by moisture.
4. After making repairs to a wiring harness on the broom, always replace or repair the protective loom which covers the wiring to prevent future damage to the wiring harness. Examine the routing of the harness and make sure it is not subjected to the type of excessive movement which causes broken wiring.

HYDRAULIC SYSTEM MAINTENANCE

⚠ WARNING Death or serious injury can result from entanglement in moving parts. Do not service the LB Performance Model FB-90 Broom while it is in motion or while the engine is running. If the engine must be running to service a component, place transmission in neutral, apply park brake, block wheels, and use extreme caution.

Your LB Performance Model FB-90 Broom consists of a variable displacement Sauer/Danfoss Series 90 pump and motor which provide drive power for the brush. A gear-type hydraulic pump is directly connected to the Sauer/Danfoss pump, and provides operational pressure for the power steering, brush lift, brush swing and brush drive.

A 25 gallon hydraulic reservoir and filter(s) complete the Hydraulic System (Figure 7-8). This manual contains general system maintenance guidelines. Detailed service and maintenance information is available directly from the hydraulic component manufacturers.

Hydraulic Fluid

Your LB Performance Model FB-90 Broom was factory filled with All-Weather All-Temp VG32 hydraulic oil, a multi-grade anti-wear oil for use in equipment where wide temperature ranges are encountered. Its features include excellent pour point depression, high viscosity index, and resistance to oxidation, foaming and corrosion, as well as protection against pump component wear. It is highly recommended for use in mobile and other hydraulic equipment in heavy-duty all-weather service. It meets the FMC Hi-Performance, Hydraulic Oil Grade 22-32 requirements.

Citgo A/W All-Temp VG32 has a pour point of -30° F (-34° C) and a maximum hydraulic reservoir temperature of 160° F (72° C). It will lose one half its life for every 20° F (-7° C) rise in the ambient temperature. Oil life above 200° F (94° C) is in excess of 1000 hours. However, hydraulic oil maintenance intervals should be followed.

Contact your authorized dealer for more details on hydraulic oils, or if you are considering an alternative oil due to availability or climate.

NOTICE LB Performance Model FB-90 Broom performance can be affected if the wrong hydraulic oil is used. Use only as indicated by Lubricant Types on page 4-6.

Hydraulic Oil Requirements

NOTICE Substandard performance or hydraulic component failure can occur if mixed manufacturers or grade weights of hydraulic oil are used. Use only as indicated by Lubricant Types in the Specifications section.

1. Be sure hydraulic oil selection is compatible with your hydraulic system.
2. Be sure to use mineral base hydraulic oil.
3. Be sure hydraulic oil selection assistance is from a reputable supplier.

Hydraulic oil must provide anti-wear properties that meet or exceed those found in the API (American Petroleum Institute) classification SD, SE or CC crank case oil.

Hydraulic oil viscosity must not fall below 70 SUS (13 cs) in the reservoir under the most adverse conditions. The best viscosity rating is 80-300 SUS (17 cs-65 cs). The viscosity rating at the lowest expected start-up temperature should not exceed 10,000 SUS (2158 cs).

Hydraulic oil must have rust and oxidation inhibitors that will maintain chemical stability. When changing the hydraulic oil with oil other than the specific factory fill oil, the hydraulic system must be completely drained. Be sure to purge or drain all hoses, cylinders, valves, motors and pumps of hydraulic oil. All hydraulic oil filters must also be changed at this time.

Hydraulic Reservoir

The hydraulic reservoir is located on the right side of the LB Performance Model FB-90 Broom. The fill cap is on top of the reservoir. The hydraulic reservoir has a sight gauge on the right side used to monitor hydraulic oil levels (Figure 7-8, 1).

1. Check the level of hydraulic oil prior to each day's operation of the broom. Hydraulic oil should be visible in the sight gauge (Figure 7-8, 1). If not, fill the tank until oil is visible in the sight gauge.
2. The fill cap strainer (Figure 7-8, 2) should be cleaned each time hydraulic oil is added or changed.




Figure 7-8

- 1 - Sight Gauge
- 2 - Fill Cap Strainer
- 3 - Fill Cap
- 4 - Drain Plug
- 5 - Suction Strainers

NOTICE LB Performance Model FB-90 Broom performance can be affected if foreign material enters the hydraulic system. Use extreme caution when removing the filler cap to ensure no foreign material enters the tank.

3. The filler cap (Figure 7-8, 3) should be padlocked, when possible, to eliminate tampering.
4. Condensation that may build up in the hydraulic system is capable of clogging the filter elements. This can lead to insufficient hydraulic fluid at the pump which will degrade performance. Clogged filter elements can damage the hydraulic pump and other system components.
5. Warm the hydraulic system to 100° F (38° C) and check filter indicators on the return filter and the charge filter. The filters are located on the left side of the broom. If the filter indicators are in the RED, the filter elements should be replaced. See Periodic Maintenance Schedule on page 7-4.

NOTE: Use only genuine LB Performance replacement parts. Other parts could be substandard and cause hydraulic system failure. The use of other than approved filter elements will void the warranty on hydraulic components.

6. Drain and replace hydraulic oil and filter after the first 100 hours of service, and after every 500 hours of service or annually, whichever comes first. Drain the hydraulic oil by removing the plug (Figure 7-8, 4). For convenience, a customer supplied drain hose can be attached to drain fluid into a container.
7. The suction strainer (Figure 7-8, 5) should be removed and cleaned at the 500 hour service interval or whenever the hydraulic oil is changed.

Hydraulic System Checks

Before each day's use, inspect the LB Performance Model FB-90 Broom for hydraulic leaks. Check weekly to make sure that all hose fittings are secure and tight.

⚠ WARNING Hydraulic fluid under pressure will pierce the skin and cause serious injury. Never use your hand to locate hydraulic leaks, use a piece of wood or cardboard to locate leaks. If hydraulic oil has pierced the skin, get immediate medical attention.

⚠ WARNING Hydraulic fluid under pressure will pierce the skin and cause serious injury. Always wear eye protection when inspecting for leaks in the hydraulic system.

1. If leaking fluid is found, it is probably on the pressure side of the hydraulic system. Find and repair the leaking component before starting the broom.
2. Leaks on the suction side of the hydraulic system are more difficult to find. This condition is serious since air or dirt introduced into the hydraulic system causes rapid component wear and eventual failure. Some symptoms of suction leakage are:
 - Foaming of hydraulic oil
 - Sluggish hydraulic system operation
 - Unusual noise in hydraulic pump or motor
 - If a suction side leak is suspected, verify that all reservoir connectors and fittings are properly tightened.
 - If the problem persists, replace the defective hose assembly or fitting.

⚠ WARNING Temporary repairs to hydraulic hoses will fail and can cause serious injury. Never attempt to repair hydraulic hoses with tape, clamps, or cements.

3. The operator should inspect the broom during operation for hydraulic leaks which may only be noticeable while the unit is running.

Pumps And Motors

The hydraulic pump and motor generally require no regularly scheduled maintenance. Frequent inspection for leaks will indicate the need for service of these components.

Adjusting Priority Relief Valve

The priority flow divider in the hydraulic manifold is set to supply the power steering with approximately 5 GPM (19 LPM) of hydraulic flow. This flow goes to the steering circuit before any other circuit.

The Priority Relief Valve controls the maximum operating pressure for the power steering and brush lift and swing circuits. The Priority Relief Valve is located on the top of the valve assembly, attached to the rear of the cab panel.

The following are signs that the Priority Relief Valve needs adjusting:

- Total or partial loss of steering functions or hard steering
- Constant noise from hydraulic pump when using steering or brush lift and swing
- Hydraulic oil overheating

If it becomes necessary to readjust the Priority Relief Valve setting, follow these steps:

⚠ WARNING Death or serious injury can result experienced technician perform this procedure.

1. Remove the hose from the manifold at port ST.
2. Plumb a 0-34474 kPa (0-345 bar, 0-5000 psi) pressure gauge into the manifold at port ST (Table 7-6, 1). Parts needed for this, including a pressure gauge, can be obtained from your LB Performance Dealer.
3. Start the engine and warm the hydraulic oil to at least 100° F.
4. Set the park brake and be sure the transmission is in neutral. Use the foot brake as an extra precaution.




Figure 7-9

1 - ST Port

2 - Relief Pressure Locknut

5. Increase engine speed to 2500 RPM.
6. The pressure gauge should read 10342 kPa +/- 345 (103 bar +/- 3, 1500 psi +/- 50).
7. Adjust relief pressure by removing the locknut (Table 7-9, 2), and turning the adjusting screw clockwise to increase pressure, counterclockwise to decrease pressure.

NOTE: Turn the adjusting screw in 1/8 turn increments, and repeat steps until correct pressure is obtained.

Adjusting Brush Drive Relief Valve

The Brush Drive circuit gets the remaining hydraulic flow after the priority flow divider supplies the power steering. A Brush Drive Relief Valve protects the brush drive circuit. The Brush Drive Relief Valve is located on the top of the valve assembly, attached to the rear of the cab panel.

Adjust the relief valve if:

- Brush stalls frequently
- Brush lacks sweeping power
- There is a constant noise while sweeping

To adjust the Brush Drive Relief Valve:

⚠ WARNING Death or serious injury can result from improper valve adjustments. Have an experienced technician perform this procedure.

1. Remove hose from manifold port M1 (Figure 7-10, 1).
2. Plumb a 0 to 5000 psi pressure gauge into manifold port M1 (Table 7-10, 1). Parts needed for this, including a pressure gauge, can be obtained from your LB Performance Dealer.




Figure 7-10

1 - M1 Port

2 - Relief Pressure Locknut

3. Start the engine and warm the hydraulic oil to at least 100° F.
4. Set the park brake and be sure the transmission is in neutral. Use the foot brake as an extra precaution.
5. Increase engine speed to 2500 RPM.
6. Using the Brush FWD/REV Control, turn the brush motor ON to engage the control valve.
7. The pressure gauge should read 16547 kPa+/- 345 (165 bar +/- 3, 2400 psi +/- 50).
8. Turn the brush motor OFF.
9. Adjust relief pressure by removing locknut (Table 7-10, 2), and turning the adjusting screw clockwise to increase pressure and counterclockwise to decrease pressure.

NOTE: Turn the adjusting screw in 1/8 turn increments, and repeat steps until correct pressure is obtained.

BROOM SYSTEM MAINTENANCE

⚠ WARNING Death or serious injury can result from entanglement in moving parts. Do not service the LB Performance Model FB-90 Broom while it is in motion or while the engine is running. If the engine must be running to service a component, place transmission in neutral, apply park brake, block wheels, and use extreme caution.

Grease the brush core shaft pillow block bearing and brush lift pivot bushings daily using a multi-purpose grease.

Grease the brush swing bearings with a multi-purpose grease every 250 hours.

Brush Watering System

1. Clean the water system strainer daily to prevent nozzle clogging.
2. Inspect the water system daily to confirm operation of both nozzles.
3. If a nozzle becomes plugged, remove it, clean the nozzle slots, and replace. Be careful not to ream the nozzle opening, as spray pattern will be affected.
4. At the end of each operating season (or more often if required), flush out the line and nozzles.
5. For storage in temperatures below freezing, make sure the water tank, strainer, pump and all lines are completely drained to prevent damage from freezing.

CHASSIS & RUNNING GEAR MAINTENANCE

⚠ WARNING Death or serious injury can result from entanglement in moving parts. Do not service the LB Performance Model FB-90 Broom while it is in motion or while the engine is running. If the engine must be running to service a component, place transmission in neutral, apply park brake, block wheels, and use extreme caution.

Drive Shaft

1. Check the drive-shaft daily for wear and loose bolts.
2. Grease the drive-shaft universal joints and slip yoke every 100 hours of service using a multi-purpose grease.

Tires and Wheels

1. Check tires with an accurate gauge prior to each day's use. Tires should be inflated to 345 kPa (3.4 bar, 50 psi) when tires are cold. Repair or replace damaged tires to provide safe operation of the LB Performance Model FB-90 Broom.

NOTICE LB Performance Model FB-90 Broom damage can result if broom is operated with less than four wheels and tires installed. Never operate the broom with less than four wheels and tires installed.

⚠ WARNING Serious injury can result from over inflating the tires. Never exceed tire manufacturer's maximum recommended inflation pressure. Tires should be inflated to 345 kPa (3.4 bar, 50 psi) when tires are cold.

2. Protect tires from contact with petroleum products and chemicals.

NOTICE LB Performance Model FB-90 Broom damage can result if broom is towed with the drive shaft connected. The drive shaft must be removed prior to towing, unless equipped with gearbox disconnect.

3. Wheel lug nuts should be checked for tightness weekly. Torque to 115 N•m (85 lb-ft).
4. Visually inspect the wheels for damage prior to each day's use of the broom. Replace bent or cracked wheels.

Axles and Brakes

⚠ WARNING Death or serious injury can result from improperly supporting a raised LB Performance Model FB-90 Broom. Do not lie under the broom while it is supported only by a jack. Use jack-stands on a solid surface to prevent tipping of the broom when it is raised. Block the remaining wheels to prevent rolling of the broom when it is raised.

1. Grease king pin bushings, tie rod ends, steering cylinder rod end and steering axle pivot bushings every 100 hours of service with a good quality chassis lube.
2. Steering axle wheel bearings should be removed, inspected, and repacked with a high quality axle bearing grease after every 500 service hours or seasonally.
3. To reinstall bearings and hub, tighten the retaining nut until the wheel drags during hand rotation. Then back off the nut 1/8 of a turn and bend over the locking tab or install the cotter pin, depending on the design configuration.
4. Check the lube level in the drive axle every 500 hours or seasonally. The lube should be at the plug hole. Add if necessary.
5. Inspect and adjust brake pad linings in brake drums after every 500 hours of operation or seasonally. Remove wheel and hub. Inspect brake pad linings for excessive wear and proper operation. Linings should be replaced if they are 1/16" thick or less in the thinnest spot.

NOTICE LB Performance Model FB-90 Broom damage can occur from improper brake adjustments. Have adjustments done by a qualified technician.

6. Check brake fluid level daily. When filling the brake fluid reservoir, only fill to 1 inch below the top of the fill neck. To prevent fluid from leaking out of the cap vent hole, locate the hole toward the rear of the LB Performance Model FB-90 Broom when replacing the cap.

Adjusting Park Brake (Method 1)

1. Loosen screw (Table 7-11, 1).
2. Rotate knob (Table 7-11, 2) clockwise to tighten brake cable; counter-clockwise to loosen.
3. When desired tension is reached, retighten screw (Table 7-11, 2).

Adjusting Park Brake (Method 2)

CAUTION Serious injury to you or others could result from an improper adjustment. This procedure should only be performed by a qualified service technician.

1. Loosen jam nuts that lock the bracket against the brake cable.
2. Turn threads until all the slack is out of the park brake cable.
3. Retighten the jam nuts.




Figure 7-11

- 1 - Screw
2 - Knob

STORAGE

Preparing For Long Term Storage

A stored LB Performance Model FB-90 Broom requires as much periodic maintenance as a broom at work. Stored broom must receive periodic scheduled maintenance.

1. Clean the broom, especially paint chipped areas to prevent rusting.
2. Inspect the broom thoroughly and repair worn or damaged parts.
3. Retract all hydraulic cylinders, as far as possible.
4. Coat with grease or rust inhibitor all exposed cylinder rods, seals, and o-rings to prevent cracking.

NOTICE Some rust inhibitors can destroy painted surfaces. Do not spray rust inhibitor on painted surfaces.

5. Lubricate all grease points. Make sure all grease cavities are filled with grease. See Periodic Maintenance Schedule on page 7-4 for complete list.
6. Remove alternator belt.
7. Remove the battery and store in a cool, dry place.
8. Check air filter restriction gauge. Clean the air cleaner assembly and pre-cleaner. Replace air filter elements if restricted.
9. Top up all fluid levels to minimize condensation forming inside the tanks.
10. Check engine oil level and fill as necessary.
11. Perform specific gravity test on engine coolant. Drain and replace or fill coolant reservoir as needed to prevent freeze damage.
12. Check hydraulic oil sight gauge and fill as necessary.
13. Inspect all air and hydraulic hoses, couplers, fittings and cylinders. Tighten any loose fittings and replace any hoses that are worn.
14. Check all safety decals. Replace any decals that are damaged or illegible. Refer to Decal Installation on page 7-25.
15. Use the hydraulic broom lift lock to secure broom in the raised position (Figure 7-12). This will prevent a flat spot from forming on the broom bristles.




Figure 7-12

1 - Hydraulic Brush Lift Lock

16. Place transmission lever in neutral, idle the engine a few minutes before shutting it down, and set the park/emergency brake.
17. If possible, raise and support broom with tires off the ground, or park broom on a hard surface to prevent tires from freezing to ground.
18. Remove ignition key, lock any optional panels, cab doors, and spare tire. Cover seat with plastic, and place a DO NOT OPERATE tag on the steering wheel.
19. Store broom in a dry, protected area. If stored outside, cover with waterproof material.

Periodic Maintenance During Storage

If a LB Performance Model FB-90 Broom will not be used for more than two months, refer to Periodic Maintenance Schedule on page 7-4 , and follow procedures for 100-Hours interval, as well as these preventive maintenance procedures:

1. Keep battery fully charged and check the level of the electrolyte regularly.
2. Check for water in hydraulic fluid. Any broom that is stored for an extended period in a climate that has a wide range of temperatures and/or humidity, will develop condensation on the inside of the tank walls. Check the hydraulic fluid on a regular basis for possible moisture contamination.

NOTICE

Hydraulic oil that is contaminated, must be drained, the filter elements replaced and the tank refilled with LB Performance approved fluid. Failure to do this could result in premature failure of the pumps and/or motors.

3. Start and run the engine until it is warm. Cycle all hydraulic and/or hydrostatic functions until all components are warm and the hydraulic fluid is up to operating temperature.
4. After the broom is warmed up, grease all pivot points.

Removing Broom From Storage

1. Follow steps above in Periodic Maintenance During Storage.
2. Refer to Periodic Maintenance Schedule on page 7-4 , check all fluid levels, belt tensions, and bolt torques.
3. Replace alternator belt.
4. Replace battery. Refer to Battery on page 7-15 for additional instructions.
5. Clean grease or rust inhibitor from all exposed cylinder rods, seals, and o-rings.
6. Disengage hydraulic broom lift lock.

DECAL INSTALLATION

1. Be sure that the installation area is clean and dry. Use hot soapy water and dry the area thoroughly before installing decals.
2. Determine the exact position by taking measurements and test fitting before you remove the backing paper.
3. For decals with no top protection paper, determine the decal location and remove the smallest portion of the split backing paper.
4. Align the decal over the specified area and carefully press the small portion with the exposed adhesive backing into place.
5. Peel back the remaining paper and carefully smooth the remaining portion of the decal in place.
6. Small air pockets can be pierced with a pin and smoothed out using the piece of decal backing paper.
7. If the decal has a protective top paper, use hot soapy water on the surface to which the decal is being applied. Leave wet. After determining the location, remove the backing paper and soak the decal in clean soapy water before application. This will help prevent air bubbles in the finished decal.
8. Smooth the decal into place with a sponge and check for air bubbles. Small air pockets may be pierced with a pin and smoothed out. When the decal is completely smoothed out, carefully remove the top paper.



NOTES



Section 8

TROUBLESHOOTING

GENERAL INFORMATION

The troubleshooting chart below identifies the most common symptoms of failure. Use this chart to help identify the failed component.

For specific engine and hydraulic problems not covered here, see the Engine or Hydraulic Pump and/or Motor Manufacturer's manual.

NOTICE ANY UNAUTHORIZED REPAIR WILL VOID THE WARRANTY. Do not attempt to service or repair major components such as the engine, hydrostatic pump or motor unless authorized to do so by your LB Performance Dealer.

TROUBLESHOOTING CHARTS

Table 8-1. Troubleshooting

SYMPTOM	CAUSE	REMEDY
Engine doesn't crank.	Battery weak or dead.	Charge or replace battery.
	Neutral start switch not activated.	Put direction control lever in neutral.
	Faulty ignition switch.	Replace.
	Faulty start solenoid.	Replace.
	Faulty starter.	Repair or replace.
Engine cranks but won't start.	No fuel in tank.	Add fuel to tank.
	No voltage to fuel shutoff solenoid.	Voltage should be 9 volts with the ignition switch in the ON or START position.
	No fuel to injector pump.	Check fuel supply system.
	Fuel connections loose on suction side of injector pump.	Tighten all fuel filter fittings and connections from fuel tank to injector pump.
	Fuel filter plugged or restricted.	Replace fuel filter.
	Intake or exhaust system restricted.	Check for and remove restrictions.
Engine difficult to start, or won't start.	Engine cranking speed too low.	Clean battery terminal connections. Charge or replace battery.
	Insufficient fuel supply to injector nozzles.	Check fuel system. Clean or replace fuel filter.
	Fuel solenoid defective.	Check/replace defective fuel solenoid. See engine manufacturer's manual.
Engine difficult to start, or won't start (continued).	Fuel filter plugged.	Replace fuel filter.
	Air in the fuel system.	Check for air leaks in the low pressure side of the fuel system. Prime fuel system. See engine manufacturer's manual.
	Fuel supply contaminated.	Verify by operating engine with a known fuel quality.
	Intake air system restricted.	Check for and remove restrictions.

SYMPTOM	CAUSE	REMEDY
Broom doesn't move with engine running, or moves in one direction only.	Park brake engaged.	Release park brake.
	Broom rotation control valve is bypassing oil at low pressure.	Repair or replace relief valve cartridge(s).
	Damaged hydrostatic pump.	Repair or replace hydrostatic pump.
	Damaged hydrostatic motor.	Repair or replace hydrostatic motor.
Broom jerks when operating in Forward or Reverse.	Fast movement of direction control handle.	Move handle slowly when changing speed and/or direction.
	Park brake not disengaged.	Release park brake. Check for binding park brake cable(s).
	Engine speed set too low.	Run engine at higher RPM.
	Low hydraulic fluid level.	Fill reservoir with correct fluid until visible in sight gauge.
	Air leaking into hydraulic system.	Tighten or replace hoses, fittings and/or filter(s).
	Hydrostatic pump is malfunctioning.	Repair or replace pump.
Engine power output is low.	Operating engine at high altitude.	De-rate engine power output for altitudes above 10,000 feet.
	Air intake piping restricted.	Remove restrictions.
	Air cleaner element dirty.	Clean or replace air cleaner elements
	Fuel suction line or filter restricted.	Check fuel line for restrictions. Replace fuel filter element(s).
	Fuel return system restricted.	Correct restricted fuel return system.
	Fuel quality poor.	Verify by operating with a known fuel quality.
	Fuel transfer pump malfunctioning.	Replace fuel transfer pump. See engine manufacturer's manual.
	Throttle improperly adjusted.	Adjust throttle controls.
	Injector malfunctioning.	Replace injector. See engine manufacturer's manual.
Engine won't shut off.	Electrical wiring fault supplying power to fuel solenoid when key is in OFF position.	Repair wiring.
	Faulty diode in engine wire harness at alternator.	Check diode wire connection and/or replace diode.
	Injection pump fuel solenoid inoperative.	Check solenoid for defects or foreign material inhibiting proper operations.
	Engine operating on fumes drawn into air intake.	Locate and isolate the source of fumes.
	Low idle set too high.	Set idle to specifications.

Troubleshooting



SYMPTOM	CAUSE	REMEDY
Brush stalls or lacks power.	Brush drive relief valve set too low or defective.	Adjust relief valve to 2500 psi. Replace if defective. See Pumps And Motors on page 7-16.
	Sweeping with too much down pressure.	See Brush Down Pressure Control on page 6-4.
	Ground speed too fast.	Pull back on joystick and increase engine RPM to increase brush speed.
Steering is difficult.	Low hydraulic fluid level.	Add fluid to proper level. See Hydraulic System Maintenance on page 7-14.
	Hydraulic filters contain contamination.	Check filter(s) for contamination and replace if necessary. See Hydraulic System Maintenance on page 7-14.
	Hydraulic pump priority relief valve set incorrectly.	Check relief valve setting. It should be 1500 psi. Adjust setting if necessary. See Pumps And Motors on page 7-16.
	Worn hydraulic pump.	Check for worn pump and repair or replace.
	Worn steering orbital motor.	Check for worn steering orbital motor and repair or replace.
	Worn steering cylinder.	Repair or replace steering cylinder.
Hydraulic system overheats (temperature above 200° F).	Low hydraulic fluid level.	Fill with correct fluid until visible in sight gauge.
	Defective temperature gauge or sender giving wrong temperature reading.	Replace gauge or sender.
	Brush drive relief valve set too low or defective.	Adjust relief valve to 2500 psi. Replace if defective. See Pumps And Motors on page 7-16.
	Excessive ambient air temperature and high duty cycle.	Operate broom at slower ground speed and maximum engine RPM during hot weather.
	Plugged fins on fluid cooler.	Clean fins and correct any other problems with cooling air flow.
	Hydrostatic pump bypass valve defective or open.	Repair or replace. If valve is open, turn valve clockwise until seated and torque to 9.5-14 Nm (7-10 lb-ft). Over torquing will damage valve.
	Worn hydrostatic pump.	Repair or replace.

SYMPTOM	CAUSE	REMEDY
Engine oil pressure is low.	Electrical power not being supplied to gauge.	Check fuse.
	Incorrect oil level. Too high or too low.	Check for leaks. Add or drain engine oil. Check dipstick calibration.
	Oil filter plugged.	Change oil filter.
	Oil diluted with fuel.	Replace fuel injector, fuel transfer pump and/or injection pump.
	Oil diluted with coolant.	See authorized engine repair facility.
	Incorrect oil specifications	Change oil. Check oil specifications. See Engine Maintenance on page 7-9. See engine manufacturer's manual.
	Oil pressure sender or gauge malfunctioning.	Replace oil pressure sender or gauge.
	Coolant level too low.	Add coolant.
Engine coolant temperature above normal.	Radiator fins damaged or obstructed.	Inspect radiator fins. Clean, repair or replace.
	Collapsed or restricted radiator hose.	Inspect hoses. Replace if necessary.
	Loose fan drive belt.	Check belt tension and tighten if necessary.
	Cooling fan shroud damaged or missing.	Inspect shroud. Repair, replace or install as needed.
	Incorrect or malfunctioning radiator cap.	Check the radiator cap. Replace if necessary.
	Temperature gauge or sender malfunctioning.	Repair or replace sender and/or gauge.
	Thermostat stuck in closed position.	Test thermostat. Replace if necessary.
	Dirt, scale or rust in the cooling system.	Clean cooling system.
Alternator not charging.	Loose wiring or faulty connection.	Repair or replace loose wiring or connector.
	Diode at alternator loose or faulty.	Tighten connection or replace diode.
	Alternator belt loose or broken.	Adjust or replace belt.
	Alternator malfunctioning.	Replace alternator.
Instrument gauges don't work.	Faulty gauge or sender.	Replace gauge or sender.
	Alternator not charging.	Repair wiring or replace alternator.
	Faulty wiring.	Replace wiring or connector.




NOTES




Section 9


SCHEMATICS

NOTES





NOTES		NEW RELEASE	
ALL WIRING 16 GA UNLESS NOTED OTHERWISE		DESCRIPTION: SCHEMATIC,ELEC,CHAL V,TIER 3	
E5 "F" DENOTES CONNECTION MATE & "S" DENOTES SHEET MATING CONNECTION IS LOCATED		PART NO. 1000952	REV. A
		PART WT. LBS	SHEET 1 OF 6













Section 10

ILLUSTRATED PARTS LIST (IPL)

Illustrated Parts List (IPL)



Introduction

This Illustrated Parts List (IPL), as part of the Component Maintenance Manual, is intended for use in identifying and requisitioning replacement parts.

Numerical Index

A numerical index is provided to supplement the detailed parts list. Part number arrangement begins at the extreme left-hand position and continues from left to right, one position at a time. The order of precedence is as follows: Letters A through Z; Numerals 0 through 9. The alpha "O" shall be considered as a numeric zero. Each part number provides a reference to its appearance in the IPL by figure and item number.

Equipment Designator Index

If equipment designators are used in place of part numbers at any place in the IPL, an Equipment Designator Index is provided listing all equipment designators listed in the illustrated parts list.

Detailed Parts List

How to Use the IPL

1. The item number corresponds to the item number shown for the part in the illustration.
2. Parts with item numbers (•) are not illustrated.
3. Parts with Quantities of (AR) are "As Required".
4. Part quantities listed are for one component or subcomponent. For example, if the parts list shows two platform assemblies, the quantities shown for the parts in the platform assembly is for one platform assembly.
5. If standard parts (those with AN, MS, NAF, NAS prefixes) are used the standard part number is listed in the part number column.
6. When a Vendor Code cannot be obtained from the H4-1 and H4-2 Cataloging Handbook, the manufacturer's full name and address is included in the parts list. Government standard parts, such as, AN, MS, NAF, and NAS parts are not identified with a Vendor Code.
7. If a company other than LB Performance is referred to as the original manufacturer of some other parts, these parts may carry the original manufacturers part number or a LB Performance part number. These manufacturers are identified by an appropriate vendor code following the nomenclature. If the part number in the part number column is a LB Performance part number, the original manufacturer's part number is given after his vendor code. Vendor codes are in accordance with the current issue of Cataloging Handbook "Commercial and Government Entity" (H4-1 and H4-2) and are preceded by the capital letter "V".



Illustrated Parts List (IPL)

Quick Reference Guide - Kubota Filters and Service Items

Item No.	Part Number	Qty.	Description	Remarks
•	987912SRV	1	Kit, Filter	
•	72543	1	Filter Assy, Hyd Return	
•	34463	1	Filter Assy, Hyd Charge	
•	38385-01	1	Air Filter, Primary	
•	38385-02	1	Air Filter, Safety	
•	38653-01	1	Filter Element, Cab Air	
•	986537-03	1	Filter, Oil	
•	982080-02	1	Filter, Fuel	
•	986537-31	1	Filter, Fuel Pre-Filter	
•	1001166-03	1	Starter	
•	1001166-04	1	Alternator	
•	1001166-05	1	Engine Belt	
•	34464	1	Filter, Hydraulic	
•	1005513	1	Kit, Decal, Ops and Decorative	

Illustrated Parts List (IPL)



Frame




Figure 10-1



Illustrated Parts List (IPL)

Frame Parts List

Item No.	PartNumber	Qty.	Description	Remarks
1	1001033	1	Frame,W/m	
2	620520	32	Nut,Lug	.500-20
3	35339	4	U-bolt,DriveAxle	
4	987451	1	Cover	Front
5	987211	1	RearCabMount,W/m	
6	987681	2	ToolboxLid,W/m	
7	1005464	4	Tire&Wheel	225/75R16
8	26259	1	DriveAxleAssy	(SeeFigure10-2)
9	38518	1	Driveshaft	(SeeFigure10-3)
10	27060	1	AxleAssy,Steering	(SeeFigure10-4)
11	987455	2	Plate,TankCover	
12	1005517	1	Bulkhead,Hydraulic,Mount	
•	91464	AR	Oil,GearLube,Ls	Purchase Locally
•	81002	4	CapScrew,HexHead	.500-13x1.00,Gr8
•	81141	4	Washer,Flat	SAE,500,Hardened
•	80040	8	Nut,Hex	.500-13
•	80164	12	Washer,Lock	.500
•	81141	8	Washer,Flat	SAE,500,Hardened
•	81113	8	CapScrew,HexHead	.500-13x1.50,Gr8
•	80168	12	Washer,Lock	.750
•	80061	8	Nut,Hex	.750-16
•	80698	8	Washer,Flat	SAE,750
•	80460	4	CapScrew,HexHead	.750-16x2.00,Gr5
•	80185	10	CapScrew,HexHead	.250-20x1.00,Gr5
•	80970	20	Washer,Flat	SAE,250
•	80160	10	Washer,Lock	.250
•	80036	10	Nut,Hex	.250-20

Illustrated Parts List (IPL)



Drive Axle Assembly




Figure 10-2



Illustrated Parts List (IPL)

Drive Axle Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	26983	1	Drive Axle, W/m	
•	38300-01	1	Housing, Axle	
•	38300-02	1	Seal, Pinion	
•	38300-03	1	Yoke, End	
•	38300-04	1	Bearing, Differential	
•	38300-05	1	Seal, Hub Bearing	
•	38300-06	1	Bearing, Wheel Hub, Inner	
•	38300-07	1	Bearing, Outer Wheel	
•	38300-08	1	Hub & Drum Assy	
•	38300-09	1	Axle, Flanged Drive	
•	38300-10	1	Kit, Drive Gear and Pinion	
•	38300-11	1	Kit, Differential Case	
•	38300-12	1	Brake, Cyl	
•	38300-13	1	Brake, Cylinder, RH	
•	38300-14	1	Brake Shoe & Lining Kit	
•	38300-15	1	Gasket	
•	38300-16	1	Stud Wheel	
•	38300-17	1	Kit, Brake Shoe LH	
•	38300-18	1	Kit, Brake Shoe RH	
2	38329	1	Lever, Park Brake	
3	38330	1	Lever, Park Brake	
4	38342	2	Cable, Park Brake	

Illustrated Parts List (IPL)



Drive Shaft Assembly




Figure 10-3



Illustrated Parts List (IPL)

Drive Shaft Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
•	38518	1	Drive Shaft Assy	
1	38518-01	2	Universal Joint	
2	38518-02	1	Slip Yoke	
3	38518-03	1	Stub Shaft	
4	38518-04	1	Tube Yoke	
5	38518-05	1	Tubing	
6	38518-06	1	U-bolt Kit	
7	38518-07	1	Flange Yoke	
8	38518-08	1	Flange	1.26 x 14 Spline
9	38518-09	1	Hardware Kit	
10	38518-10	1	Set Screw	.375-16 x 1.00
•	38518-11	1	Strap, Bolt Kit	

Illustrated Parts List (IPL)



Axle Assembly, Steering




Figure 10-4



Illustrated Parts List (IPL)

Axle Assembly, Steering Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	81184	2	Cap Screw, Hex Head	1.000-8x8.0, Gr5
2	80359	2	Nut, Flexloc	1.000-8, Full, Lt
3	16935	1	Sleeve, Steering Cyl Mount	
4	38303	2	Hub Assy, Wheel	8 On 6.50
•	38303-02	1	Hub, Wheel, Idler	
•	610210	1	Bearing Cone	
•	340180	1	Bearing Cone, Wheel Hub	Outer
•	38303-05	1	Bearing Cup	
•	33187	1	Seal	
•	620200	1	Dust Cap	635 Tandem Axle
•	38303-03	1	Wheel Stud	1/2-20
•	38303-01	1	Bearing Kit	
•	38303-04	1	340170 Bearing Cup Wheel	Outer Race
•	38303-06	1	Bearing Cup, Wheel Hub	Outer
•	38303-07	1	Bearing Cup, Wheel Hub	Inner
•	620520	8	Nut, Lug	.500-20
5	27051	1	Steering Axle, W/m	
6	27056SRV	1	Spindle, W/m	R.H.
7	27059SRV	1	Spindle, W/m	L.H.
8	20724SRV	1	Shaft, Pivot, Front Axle, W/m	
9	27053	1	Tie Rod Tube	
10	21113	1	Nut, Hex, Jam	1.00-16, R.H.
11	21114	1	Nut, Hex, Jam	1.00-16, L.H.
12	80149	4	Washer, Flat	USS 1.000
13	33684	3	Fitt, Lube, Str	02mp, Short, Zerk
14	31713	2	Nut, Spindle	6bf
15	80332	2	Pin, Cotter	.125x1.50
16	80144	1	Washer, Flat	USS .500
17	80839	1	Cap Screw, Hex Head	.750-10x5.00, Gr5
18	80357	1	Nut, Flexloc	.750-10, Full, Lt
19	80147	1	Washer, Flat	USS .750
20	71627	1	Cap Screw, Hex Head	.500-13x1.50, Gr5
21	36754	1	Cyl, Hyd, Steering	2.00x10.75x1.00 Rod
•	36754-03	AR	Kit, Seal, Cylinder	
22	36755	1	Ball Joint, Steering Cyl End	
23	36756	1	Ball Joint	R.H.
24	36757	1	Ball Joint	L.H.
25	80354	1	Nut, Flexloc	.500-13, Full, Lt

Illustrated Parts List (IPL)



Brush Head Frame




Figure 10-5



Illustrated Parts List (IPL)

Brush Head Frame Parts List

Item No.	Part Number	Qty.	Description	Remarks
•	989272	1	Assy, Brush	Complete 7 Foot
•	1001739	1	Screw, Hfh	Complete 8 Foot
1	989272-21	8	Pin, L Inch	1/4
2	989272-25	18	Screw, Hfh	Cl10.9, M6-1 X 20
3	989272-35	8	Washer, Lock	M10
4	989272-43	6	Washer, Fender	Cl8.8, M6
5	989272-66	1	Sheet, Hood	7 Ft
-	1004846	1	Cover, Brush	8 Ft
6	989272-63	1	Frame, Brush	7 Ft
7	989272-50	8	Screw, Hhc	Cl10.9, M10-1.5x16mm
8	989272-64	1	Sheet, Hood	L.H.
9	989272-65	1	Sheet, Hood	R.H.
10	989272-67	8	Stud, Mounting, Motor	

Core Assembly




Figure 10-6



Illustrated Parts List (IPL)

Core Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	989272-02	1	Section, Set, 36, Poly, 7'	
•	989272-86	1	Steel Only Wafer	Each
•	989272-87	1	Section Set, Poly/Wire 8'	Set
2	989272-33	6	Screw, Hhc	Cl10.9, M6-1x30mm
3	989272-77	1	Core	
4	989272-57	1	Plate, Hat, Core, 10	

Shaft Assembly




Figure 10-7



Illustrated Parts List (IPL)

Shaft Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	989272-35	10	Washer, Lock	M10
2	989272-36	6	Screw, Hhc	Cl10.9, M10-1.5 X 30mm
3	989272-38	4	Screw, Hhc	Cl10.9, M10-1.5 X 50mm
4	989272-41	1	Ring, Snap	
5	989272-42	4	Nut, Hex	Cl10, M10-105
6	989272-45	1	Ring, Retaining	2.75
7	989272-55	2	Bearing	1 1/4, 4 Bolt
8	989272-56	1	Hex Plate With Doubler	
9	989272-70	1	Plate, Mounting, Bearing	
10	989272-71	1	Hub, Hex	2 1/2, Single Motor

Illustrated Parts List (IPL)



Hydraulic Assemblies




Figure 10-8



Illustrated Parts List (IPL)

Hydraulic Assemblies Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	989272-03	2	Fitting, Adapter, Hp	7/8mor, 5/8mfs
2	989272-84	4	Hose Cradle	
3	989272-83	2	Cover Plate	
4	989272-12	2	Hose	.50 X 102 10ff 12md
5	989272-37	4	Screw, Hhc	Cl10.9, M10-1.5 X 35mm
6	989272-34	6	Washer, Flat	Cl8.8, M10
7	989272-35	6	Washer, Lock	M10
8	989272-85	2	Screw, Hhc	M8-1.25 X 65mm Cl10.9
9	989272-18	1	Quick Disconnect	8pp F 12mp
10	989272-20	1	Quick Disconnect	8pp M 12fp
11	989272-13	1	Hose	.38 X 47 6ff 8mb
12	03-1392	1	Valve Ball, Br	8fp-8fp
13	03-1022-7	1	Fitting	8mp-8mp 1/2ff-s
14	989272-17	1	Quick Disconnect	8pp F 8fp
15	989272-05	2	Fitting, 90° Elbow, Hp	9/16mor 3/8mfs
16	989272-04	1	Fitting, Vent, Hex W/screen	9/16-18mor
17	989272-09	1	Cylinder, Hydraulic, Brush Lift	2.5 Bore, 6.75 Stroke, 1.375 Rod
18	989272-16	1	Quick Disconnect	6pp F 6fp
19	989272-14	1	Hose	.38 X 39 6ff 6mb
20	989272-08	1	O-ring Face Seal	3/8 SAE6
21	989272-07	1	Plate Hydraulic Orifice	.046
22	989272-10	1	Cylinder, Hydraulic, Brush Swing	2 1/2 Bore, 7 1/5 Stroke, 1 3/8 Rod
23	03-2115	1	Fitting, 45° Elbow	9/16mor 3/8mfs
24	989272-15	1	Hose	.38 X 30 6ff 6mb
25	989272-19	1	Quick Disconnect	6pp M 6fp

Motor Mount Assemblies




Figure 10-9



Illustrated Parts List (IPL)

Motor Mount Assemblies Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	989272-11	16	Motor, Hydraulic, White	28.3 Cu In
2	989272-35		Washer, Lock	M10
3	989272-36	6	Screw, Hhc	CI10-9, M10-1.5 X 30mm
4	989272-39	4	Washer, Flat	CI8.8, M12
5	989272-40	4	Washer, Lock	M12
6	989272-45	14	Ring, Retaining	2.75
7	989272-46		Screw, Hhc	CI10.9, M12-1.75 X 65mm
8	989272-49	4	Nut, Hex	CI10.9, M12-1.75
9	989272-56	1	Hex Plate With Doubler	
10	989272-76	1	Hub, Hex	2 1/2 X 1 1/4, Tapered Bore X 3.56
11	989272-68	1	Plate, Mountng, Motor	
12	989272-69	1	Plate, Handle, Motor	

Brush Head Labels




Figure 10-10



Illustrated Parts List (IPL)

Brush Head Labels Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	1001709	1	Label	Logo
2	1001709	1	Label	Serial Number
3	1001709	2	Label	Tie Down Point
4	1001709	4	Label, Warning	Crush Hazard
5	1001709	1	Label, Warning	Misuse Hazard
6	1001709	1	Label, Warning	High Pressure Fluid Hazard
7	1001709	2	Label, Warning	Flying Objects And Entanglement
8	1001709	1	Label	Brush Pattern Adjustment

Illustrated Parts List (IPL)



Lift Linkage




Figure 10-11



Illustrated Parts List (IPL)

Lift Linkage Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	989272-23	8	Screw, Hhc	Gr8, 3/4-10 X 2 1/2
2	989272-75	2	Pin With Holes	1 1/4 X 4
3	989272-74	1	Rod, Adjustment	
4	989272-73	1	Tube, Adjustment	
5	989272-72	1	Toplink	5.81
6	989272-21	6	Pin, Lynch	1/4
7	989272-22	4	Pin, Cotter	Gr2, 5/32 X 1 1/2
8	989272-91	1	Mounting Plate	R.H.
•	989272-90	1	Mounting Plate	L.H.
9	989272-24	5	Pin, Klick	3/16 X 1 5/8
10	989272-28	1	Fitting, Zerk, Self Tapping	1/4-28
11	989272-27	8	Nut, Hex	3/4
12	989272-29	1	Nut, Hex, Hylock	Gr8, 7/16-14
13	989272-30	1	Screw, Hhc	Gr8, 7/16-14 X 2 1/2
14	989272-31	8	Washer, Flat	Gr8, 3/4
15	989272-44	2	Nut, Hex, Nylock	Gr8, 1-8
16	989272-47	4	Pin, Clevis	1 X 2
17	989272-26	8	Washer, Split	3/4
18	989272-48	2	Screw, Hhc	Gr8, 1-8 X 7 1/2
19	989272-54	1	Pin, Clevis	1 X 5
20	989272-78	1	Mounting	Weld Back Plate
21	989272-58	2	Arm	
22	989272-59	2	Pivot	Upper
23	989272-89	1	W/m, Hyd Cyl Mount	
24	989272-61	1	Pin With Holes	1.25 X 15.53
25	989272-62	1	Bushing With Hole	2 X 1.26 X 7.22

Illustrated Parts List (IPL)



Water Spray Tank And Mounting




Figure 10-12



Illustrated Parts List (IPL)

Water Spray Tank And Mounting Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	27100SRV	1	Mount W/m, Water Tank	
2	81027	6	Cap Screw, Hex Head	.750-10x3.50, Gr8
3	80043	6	Nut, Hex	.750-10
4	81154	12	Washer, Flat	SAE .750, Hardened
5	871071601	4	Washer, Lock	#10
6	1005443	1	Tank, Water, 150gal	Black
•	33238-01	AR	Pipe, Bulkhead	1.25 Fp, Pvc
•	33238-02	AR	Pipe, Bulkhead	12 Fp, Pvc
•	33238-03	AR	Cover, 10 Inch, Vented, Raven	
7	12488SRV	2	Tank Strap W/m	
8	81155	14	Washer, Flat	SAE.375, Hardened
9	33594-01	7	Clamp, Loop	.50 Od, Rem Cushion
10	70459	1	Fitt, Str	08mp-12mp
11	33238-05	1	Pipe, Plug	1.50, Sq Head, Mi
12	80038	18	Nut, Hex	.375-16
13	36926	1	Strainer Assy	
14	38579	20	Hose	06, Low Pressure, Push-on
15	70319	1	Fitt, 90°	08mp-08hb, Poly
16	33163	6	Clamp, Hose	# 08
17	1004598	1	Pump, Water, Diaphragm	
18	36730-02	1	Port Kit	08 Barb X 90, Epdm
19	80891	4	Mach Scr, Ph	#10-32x1.00
20	80494	4	Nut, Hex	#10-32
21	80995	4	Washer, Flat	USS #10
22	80036	7	Nut, Hex	.250-20
23	26484	4	Bracket, Spray Pipe	
•	27824	1	Wiring Harness	Lights, Tail, Extension
•	36341	1	Fuse	15 Amp, Atc
•	871111602	2	Clamp, Insulated Band	3/4"
•	28369	1	Wire Harness	Water Pump
•	35077	4	U-bolt	.250-20, 1.00iw, 1.75il
•	80224	10	Cap Screw, Hex Head	.375-16 X 1.25, Gr5

Illustrated Parts List (IPL)



Dust Suppression System




Figure 10-13



Illustrated Parts List (IPL)

Dust Suppression System Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	38579	20	Hose	06, Low Pressure, Push On
2	1001616-01	6	Clamp, Spring	5/8 Hose
3	36882	1	Valve, Check	08hb, 5 Psi,poly
4	1001616-02	1	Grommet, Rubber	
5	1001616-03	2	Hose, Clear, Vinyl	3/8" X 1.75'
6	1001616-04	1	Fitting, Barb, Tee, Nylon	3/8"
7	1001616-05	2	Nozzle, Elbow, Without Clamp	
8	1001616-06	2	Nozzle, Cap, Nylon	
9	1001616-07	2	Nozzle, Tip, Brass	
10	1001616-08	2	O-ring	#8 Face Seal
•	1001616	1	Dust Suppression (Complete Kit)	
•	1001616-09	1	Nozzle, Tee	

Illustrated Parts List (IPL)



Engine Subassembly, Kubota




Figure 10-14

Engine Subassembly, Kubota Parts List

Item No.	Part Number	Qty.	Description	Remarks
•	1002184	1	Assy, Engine, Kubota	
1	1001166-40	1	Guard, Belt, Kub	
2	1002184-07	1	Spacer, Engine Fan, Kub	
3	1002184-08	1	Fan, Kub	
4	1001166-16	1	AC Mount	
5	1002184-09	1	AC Rear Stay	
6	1001166-41	1	AC Front Stay	
7	1002184-10	1	Belt, A/C Comp, Kub	
8	1000867-10	1	Drive Pulley	
9	1002184-03	1	Guard, Fan, Kub	
10	1002184-02	1	Shroud, Rad, Kub	
11	1002184-06	1	Plate, Support, Rad	
12	1002184-01	1	Radiator/Cooler Assy, Kub	
13	1002184-05	1	Plate, Support, Cooler	
14	1002184-04	1	Rad Cap	
15	986537-21	1	Upper Rad Hose	
16	1001166-15	1	Lower Rad Hose	
17	1002184-17	1	Plate, Fuel Pump, BRKT, Kub	
18	1002184-23	1	Mount, Engine, RH	
19	1002184-18	1	Pump, Fuel, Kub	
20	1002184-22	1	Mount, Engine, Rear, Kub	
21	1002184-19	1	BRKT, Throttle, Kub	
22	1002184-16	1	Pipe, Exh, W/m Kubota	
23	1002184-11	1	Tube, Air Intake, Kub	
24	1002184-12	1	Adptr, Rubber, 1.25 ID x 2.00 ID	
25	1002184-13	1	Adptr, Rubber, 2.0" ID, 2.5" Long	
26	986537-24	1	Alumn Reducer	
27	1002184-14	1	Adptr, Rubber, 3.0" ID, 3.0" Long	
28	1002184-15	1	Tube, Air Intake, 3" Elbow	
29	1002184-14	1	Adptr, Rubber, 3.0" ID, 3.0" Long	
30	1002184-15	1	Tube, Air Intake, 3" Elbow	
31	171170	1	Rubber Elbow, 3.5" to 3.0"	
32	1002184-21	1	Plate, Pump Mount, Kub	Includes 1002184-29, -30
•	1002184-29	1	Flex Plate & Coupling, SAE #4 14T	
•	1002184-30	1	Pump Mount Plate, Semi SAE#4	
33	1002184-22	1	Mount, Engine, Rear, Kub	
34	1002184-20	1	Relay Mount Plate	
35	1002184-24	1	Front Mount Foot	
36	1002184-25	1	Harness, Engine, Kub	

Illustrated Parts List (IPL)



Engine Subassembly, Kubota (continued)




Figure 10-14

Engine Subassembly, Kubota Parts List (continued)

Item No.	Part Number	Qty.	Description	Remarks
37	1002184-26	1	Solenoid, 80 Amp, Kub	
38	984286-13	1	Oil Pressure Fitting	
•	1001166-03	1	Starter	
•	1001166-04	1	Alternator	
•	1001166-05	1	Engine Belt, Kub	
•	1001166-09	1	Glow Plugs	
•	1001753	1	Block Heater	
•	986537-31	1	Fuel Pre-Filter	
•	1001166-13	1	Coolant Reserve Tank	
•	1001166-42	1	Manual, Operators, Kub	
•	1001166-43	1	Manual, Service, Kub	
•	1001166-44	1	Manual, Workshop, Kub	
•	1001166-45	1	Manual, Parts, Kub	
•	99552	1	Pipe, Red, 08FP - 06FP, MI	
•	983185	1	Brkt, Throttle, Cable	Kub
•	72689	1	Fitt, Test 06MB - 02DP	
•	72136	1	Cable, Battery, Pos, 60"	Eye/Eye
•	6274	1	Fitt, Str 06MP - 06FPX	Adapter
•	5804	1	Cable, Battery, Neg, 13"	Eye/Eye
•	400020	1	Cable, Battery, Neg, 16"	
•	1001758	1	Mount, Isolator, Axial 480#	
•	1000495	1	W/m, Bracket, Pump Cable	
•	1002282	1	Plate, Rad Shroud, Kub	
•	33146-6	1	Battery, 12V, 1000 CCA	Buy Locally, Not Shown
•	72313	1	Battery Hold Down	Not Shown
•	1002184-27	1	Sender, Press, 0-100 Psi, 02Mp 240	Faria Gauge
•	1002184-28	1	Sender, Temp, 100-250 F, 06 Mp 450-29.5	Faria Gauge
•	35546	1	Valve, Heater Shutoff	Engine Shutdown
•	37005	1	Switch, Temp, 220 Deg F, No, 1/4	
•	37271	1	Loom, Split, Convolute, .625	
•	38321	1	Pump, Hyd, Piston, 4.57 Cir	

Exhaust Group




Figure 10-16



Illustrated Parts List (IPL)

Exhaust Group Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	34074	1	Muffler	2-1/2" Id Side Inlet
2	34033	2	Clamp, Air Cleaner Mount	6.5" id
5	33312	4	Clamp, Muffler	.3125 X 2.5
7	36117	1	Elbow, Exhaust, 90°	2.5" Od
•	38380	1	Hanger, Exhaust	
8	1002184-16	1	Pipe, Exh, W/m Kubota	

Illustrated Parts List (IPL)



Air Cleaner, Kubota




Figure 10-17



Illustrated Parts List (IPL)

Air Cleaner, Kubota Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	38385	1	Air Cleaner Assy	
•	38385-01	1	Filter Primary	
•	38385-02	1	Filter Secondary	
2	38386	1	Mounting Band	8.13 Id
6	99610	1	Pipe, Nipple	.125 Xclose
7	171220	1	Indicator, Air Filter Service	
8	987484	1	Elbow, Rubber, Cobra	4.0" X 4.0"
9	987485	1	Adapter, Rubber	4.0" X 3.5"
10	37587-2	1	Insert, Rubber	4.00 To 3.75
14	987488	1	Tube, Intake, W/m	
15	37587	1	Pre-cleaner	4.00 Id
•	846100266	1	Clamp, Muffler	
17	171190	1	Clamp, T-bolt	3.50 Nominal
19	953521243	2	Clamp, T-bolt	4.00 Nominal
•	38268	1	Clamp, T-Bolt	2.25 Nominal
•	984932	1	Insert	4x3.5, Reducer
•	80038	2	Nut, Hex	.375-16
•	80162	4	Washer, Lock	.375
•	80226	4	Cap Screw, Hex Head	.375-16x1.50, Gr5
•	80996	6	Washer, Flat	SAE, .375
•	987686	1	Connector	3.50" Id-od
23	1002184-11	1	Tube, Air Intake, Kub	
24	1002184-12	1	Adptr, Rubber, 1.25 ID x 2.00 ID	
25	1002184-13	1	Adptr, Rubber, 2.0" ID, 2.5" Long	
26	986537-24	1	Alumn Reducer	
27	1002184-14	1	Adptr, Rubber, 3.0" ID, 3.0" Long	
28	1002184-15	1	Tube, Air Intake, 3" Elbow	
29	1002184-14	1	Adptr, Rubber, 3.0" ID, 3.0" Long	
30	1002184-15	1	Tube, Air Intake, 3" Elbow	
31	171170	1	Rubber Elbow, 3.5" to 3.0"	

Illustrated Parts List (IPL)



Engine Cover Assembly




Figure 10-18



Illustrated Parts List (IPL)

Engine Cover Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
•	1005049	1	Group, Cover	
1	1001057	3	Ring, Recessed, Lifting	500#
2	1000890	1	Cover, Engine	
3	1000883	1	Plate, Cover	L.H.
4	160450	2	Latch, Engine Access Panel Door	
5	147-876	2	Weld Hinge	4"
6	1000882	1	Plate, Door	R.H.
7	1000884	1	Cover, Air Filter	
8	1001710	8	Bolt, Button Head	
9	P70036	1	Sign, SMV (Slow Moving Vehicle)	
•	1005513	1	Kit, Decal, Ops & Decorative	FB-90
•	35355	1	Plate, Serial Number, LeeBoy	
•	17898	1	Smv Sign Group	
•	4684102	24	Strip, Abrasive	4" X 60'roll, Blk
•	985234	1	Manual-pak Case	10.5 X 13.5 X 2.5

Illustrated Parts List (IPL)



Fuel Tank Assembly




Figure 10-19



Illustrated Parts List (IPL)

Fuel Tank Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	1000261	1	Tank W/m, Fuel	
2	1001401	1	Cover, Fuel Tank, W/m	
3	36105	1	Cap, Fuel, W/lock Lug	
4	38373	1	Sending Unit, Fuel Level	
5	99539	1	Pipe, Plug	16mp, Sq Head, Mi
6	33162	4	Clamp, Hose	# 06
7	72369	2	Fitt, 45°	04mp-05hb, Crimped
8	71812	8	Hose	05, Fuel, Non Push-on
•	984909-01	1	Filter Element	
•	987501	1	Mount, Fuel Lift Pump	

Radiator/cooler Assembly




Figure 10-20



Illustrated Parts List (IPL)

Radiator/cooler Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	1002184-01	1	Hose, Radiator	Upper
2	36745-06	1	Condensor Assembly	
3	1002282	1	Plate, Shroud, Rad	Kubota
7	230240	4	Clamp, Hose	#28 (2-1/8")
8	1001166-15	1	Hose, Flex	1.75 x 1.75 x 16.0
9	986537-21	1	Hose, Radiator	Upper
•	73150	1	Fitting, Straight	08mb-06fb
10	910150	1	Valve, Drain, Cock	.250 Npt

Illustrated Parts List (IPL)



Air Conditioning/Heater Group




Figure 10-21



Illustrated Parts List (IPL)

Air Conditioning/Heater Group Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	35546	2	Valve, Heater Shutoff	
2	33164	4	Clamp, Hose	# 10
3	80230	1	Cap Screw, Hex Head	.375-16 X 2.00, Gr5
4	80142	4	Washer, Flat	USS .375
5	80038	1	Nut, Hex	.375-16
7	71617	1	Cap Screw, Hex Head	.375-16 X 5.00, Gr5
8	1002184-10		A/C Belt	Kubota
9	36894	1	Clamp, Loop	2.00 Od, Plstc Cover
10	38653	1	Cab Air Cond/heater Kit	
11	33595	1	Clamp, Loop	1.00 Od, Rem Cushion
12	80221	1	Cap Screw, Hex Head	.375-16x1.00, Gr5
13	80162	2	Washer, Lock	.375
14	36745-07	1	Dryer, Air Conditioner	
15	36745-05	1	Compressor, Air Conditioner	
•	TF10199	12	Hose, Heater	.625 Id
•	35138	1	Conn, Sealed, Shroud	2-pin
•	36164	2	Term, Sealed Conn	16-14 Ga, Male
•	36166	1	Seal, Cable	18-16 Ga
•	37303	1	Fuse, Blade	25amp
•	38106	0.12	Refrigerant, Oil	
•	38105	0.09	Refrigerant	R134a Freon
•	80352	1	Nut, Flexloc	.375-16, Full, Lt
•	80192	16	Cap Screw, Hex Head	.250-20 X .75, Gr5
•	80140	2	Washer, Flat	USS .250
•	80160	2	Washer, Lock	.250
•	80350	8	Nut, Flexloc	.250-20, Full, Lt
•	81072	4	Cap Screw, Hex Head	.250-20 X 3.50, Gr5
•	80036	2	Nut, Hex	.250-20
•	81006	10	Washer, Flat	USS .188
•	80194	1	Cap Screw, Hex Head	.250-20 X 1.50, Gr5
•	80224	2	Cap Screw, Hex Head	.375-16 X 1.25, Gr5
•	80226	1	Cap Screw, Hex Head	.375-16 X 1.50, Gr5
•	80474	2	Washer, Flat	M10
•	80937	2	Cap Screw, Hex Head	M08 X 1.25 X 20mm, Cl12.9
•	1001875	1	Kit, Hose AC Heat, Kubota	
16	1001875-01	1	Hose, 89", A/C	
17	1001875-02	1	Hose, 80", A/C	
18	1001875-03	1	Hose, 55", A/C	
19	36745-04	1	Hose, 26.5", A/C	

Illustrated Parts List (IPL)



Cab Air Conditioning/Heater Kit (1 Of 2)




Figure 10-22



Illustrated Parts List (IPL)

Cab Air Conditioning/Heater Kit (1 Of 2) Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	38653-04	1	Housing	
2	36745-17	2	Louvers	
3	36745-25	1	Cover	Bottom
4	38653-01	1	Filter Element, Cab Air	
5	38653-05	1	Coil, Assy, Evap.	
6	N/A	22	Washer, Ext. Tooth	
7	N/A	26	Screw	1/4-20, Truss Head
8	38606-16	1	Grommet	
9	38606-15	1	Grommet	
10	38525-34	2	Grommet	
11	N/A	8	Bolt	1/4-20
12	38653-02	1	Louver Door	
13	80160	12	Washer, Lock	.250
14	80036	8	Nut, Hex	.250-20
15	36745-36	2	Fastener, Turn	1/4
16	37645-20	2	Knobs	
17	N/A	4	Screw, Whizlock	1/2-24,#10
18	N/A	8	Screw, Flat Head	3/4-#6
19	36745-21	3	Knobs	
20	38525-22	3	Nut, Mounting Control	
21	36749-03	1	Cable, Rotary Control	
22	36745-18	1	Switch, Fan	
23	36745-19	1	Cold Control	
24	36745-22	1	Decal	
25	36745-16	4	Louvers	
26	38653-09	3	Grommet	
27	38653-08	2	Grommet	
28	36745-13	1	Blower	
29	36745-26	1	Blower Plate	
30	36745-24	1	Cover	Top
31	36749-04	1	Cable, Rotary Control	
32	36745-29	1	Cover, Recirc.	
33	36745-30	1	Filter Holder, Recirc.	
34	36749-01	1	Valve, Water	
35	38653-07	1	Bracket, Coil	R.H.
36	38653-06	1	Bracket, Coil	L.H.
37	36749-02	1	Coil, Heater	

Illustrated Parts List (IPL)



Cab Air Conditioning/Heater Kit (2 Of 2)




Figure 10-23



Illustrated Parts List (IPL)

Cab Air Conditioning/Heater Kit (2 Of 2) Parts List

Item No.	Part Number	Qty.	Description	Remarks
•	36745-01	1	Hose, Comp-conden	13/32
•	36745-02	1	Hose, Comp-evapor	1/2
•	36745-03	1	Hose, Evapor-dryer	5/16
•	36745-04	1	Hose, Dryer-conden	5/16
•	36745-05	1	Compressor Assy	
•	36745-06	1	Condenser Coil Assy	
•	36745-07	1	Receiver Dryer	
•	36745-08	1	Clamp, Receiver Dryer	
•	36745-09	1	Switch, High Pressure	
•	36745-10	2	O-ring	#10
•	36745-11	2	O-ring	#8
•	36745-12	4	O-ring	#6
•	36745-32	1	Valve, Thermal Expansion	
•	36745-34	1	Switch, Low Pressure	

Illustrated Parts List (IPL)



Cab Frame, Glass And Door




Figure 10-24



Illustrated Parts List (IPL)

Cab Frame, Glass And Door Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	1000959	1	Cab, W/m	2 Door
2	35136-21	2	Plug, Hole	.312, Flush Mt, Plstc
3	80140	4	Washer, Flat	USS, .250
4	80192	4	Cap Screw, Hex Head	.250-20 X .75, Gr5
5	81275	18	Nut, Acorn	.250-20, Ss
6	36688-04	1	Glass, Window	Front
7	36688-17	18	Grommet	.250
8	36688-16	18	Bushing, Nylon	
9	81278	20	Washer, Flat	.250 X 1.00, Ss
10	81277	18	Csbhs	.250-20 X .88, Ss
11	36688-18	44	Seal, Window	
12	81282	6	Csbhs	.250-20 X 1.25, Ss
13	1000287	1	Floormat	
14	36688-07	2	Sill, Door	
15	987456	2	Plate, Cab Access Cover	
16	80352	4	Nut, Flexloc	.375-16, Full, Lt
17	80882	4	Cap Screw, Hex Head	.375-16 X 4.75, Gr8
18	36688-41	1	Assy, Door, Entrance	R.H.
•	36690R	1	Assy, Door	L.H.
19	36073	12	Washer	.80 X 3.25 X .188thick
20	36072	4	Mount, Rubber, Tube Form	
21	36688-15	1	Foam, Rear Panel	
22	36688-02	2	Glass, Window	Side
23	36688-05	1	Glass, Window	Rear
24	36688-12	1	Headliner	
•	1001718	1	Kit, Cab, Insulation	
•	38462	0.17	Adhesive, Aerosol Spray, Can	
•	35136-11	1	Plug, Hole	1.50, Flush Mt, Plstc
•	35136-17	1	Plug, Hole	3.50, Flush Mt, Plstc

Illustrated Parts List (IPL)



Cab Door Hold And Striker




Figure 10-25



Illustrated Parts List (IPL)

Cab Door Hold And Striker Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	35136-3	2	Plug, Hole	.375, Flush Mt, Plstc
2	35136-5	7	Plug, Hole	.625, Flush Mt, Plstc
3	80350	5	Nut, Flexloc	.250-20, Full, Lt
4	81278	20	Washer, Flat	.250 X 1.00, Ss
5	81277	6	Csbhs	.250-20 X .75, Ss
6	1000838	2	Door Hold	
•	1000835	1	T-Handle	Handle Only
•	984390	1	Bracket, Door Latch	Mounts to door
7	36688-49	2	Striker, External Thread	
8	80142	3	Washer, Flat	USS, .375
9	36688-52	3	Nut, Centerlock	.438-14
10	36688-08	1	Cover, Plastic	
11	80322	4	Screw, Self-tapping, Hex Head	.250-20 X .50

This diagram shows an exploded view of a metal cabinet assembly. The main cabinet body is shown with its front door open. Numbered callouts identify the following components:

- 1**: A long, thin metal strip or cable.
- 2**: Two screws, one located on the top edge of the cabinet and another on the bottom edge of the door.
- 3**: A small rectangular component, possibly a lock or latch, shown in an exploded view to the right of the cabinet.
- 4**: A horizontal metal bar or handle located at the top of the cabinet.
- 5**: A small circular component, possibly a knob or button, shown in an exploded view to the right of the cabinet.
- 6**: A small rectangular component, possibly a lock or latch, shown in an exploded view to the right of the cabinet.
- 7**: A small rectangular component, possibly a lock or latch, shown in an exploded view to the right of the cabinet.
- 8**: A vertical metal bar or handle located on the left side of the cabinet.
- 9**: A long, thin metal strip or cable, similar to component 1, but with a different shape.

LB Performance Model FB-90 Broom



Illustrated Parts List (IPL)

Windshield Wiper Panel Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	35550	3	Hose, Windshield Washer	.188id
2	36688-54	3	Grommet	.94id, 1.12hole, Snap In
3	35136-5	7	Plug, Hole	.625, Flush Mt, Plstc
4	35136-4	2	Plug, Hole	.500, Flush Mt, Plstc
5	853090	1	Switch, Wiper/washer	
6	80322	17	Scr, Slftpg, Hh	.250-20 X .50
7	36688-09	1	Cover, Side Access	
8	29262	1	Bracket, Fuse Block	
9	1001045	1	Wire Harness	Cab
•	21168	1	Defroster Fan Group, Single	
•	33271-5	.05	Wire	16 Ga, White
•	35425	1	Defroster Fan Assy	12 Volt
•	35426	1	Switch, Defroster Fan	
•	35465-06	1	Grommet, Insulation	.375id
•	36348	1	Term, Push-on	.25, M18-14, Slv
•	36739	1	Conn, 1 Way, Male, Locking	
•	36747	1	Fuse	4 Amp, Atc
•	70953	1	Conn, Male Terminal	
•	851390204	1	Term, Ring	16-14 Ga, #10 Stud
•	21169	1	Defroster Fan Group, Dual	
•	33271-5	1	Wire	16 Ga, White
•	35425	2	Defroster Fan Assy,	12 Volt
•	35426	2	Switch, Defroster Fan	
•	35465-06	2	Grommet, Insulation	.375id
•	36348	2	Term, Push-on	.25, M18-14, Slv
•	36739	1	Conn, 1 Way, Male, Locking	
•	36340	1	Fuse	10 Amp, Atc
•	70953	1	Conn, Male Terminal	
•	851390204	3	Term, Ring	16-14 Ga, #10 Stud

Illustrated Parts List (IPL)



Windshield Wiper Motor




Figure 10-27



Illustrated Parts List (IPL)

Windshield Wiper Motor Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	35136-5	7	Plug, Hole	.625, Flush Mt, Plstc
2	80350	5	Nut, Flexloc	.250-20, Full, Lt
3	80824	3	Nut, Hex	#10-24
4	871071601	6	Washer, Lock	#10
5	36688-43	6	Fastener, X-mas Tree	1.00 In
6	36695	1	Fuse Block	6 Gang, Atc
7	81281	2	Csbhs	10-24 X 1.50, Ss
8	151190	1	Blade, Wiper	
9	151180	1	Arm, Windshield Wiper	
10	151170	1	Motor, Windshield Wiper	
11	81277	6	Csbhs	.250-20 X .75, Ss
12	35136-4	2	Plug, Hole	.500, Flush Mt, Plstc
•	36340	1	Fuse	10 Amp, Atc
•	21166	1	Rear Windshield Wiper	
•	33744	1	Arm, Wiper	
•	33744-01	1	Blade, Wiper	
•	36741	1	Wiper Motor, 2-speed	
•	853090	1	Switch, Wiper/washer	
•	36747	1	Fuse	4 Amp, Atc
•	80140	1	Washer, Flat	USS,.250
•	80192	1	Cap Screw, Hex Head	.250-20 X .75, Gr5
•	80350	1	Nut, Flexloc	.250-20, Full, Lt
•	21167		Windshield Washer, Front Or Rear	
•	33745-1	1	Washer, Tank And Pump	
•	35465-07	1	Grommet, Insulation	.750id
•	36687	4	Csbhs	.312-18 X .75, Black Finish
•	36753	1	Washer Nozzle & Tee Kit	
•	80037	4	Nut, Hex	.312-18
•	80141	4	Washer, Flat	USS, .31 3
•	35550	11	Hose, Windshield Washer	.188id

Illustrated Parts List (IPL)



Entrance Door Assembly




Figure 10-28



Illustrated Parts List (IPL)

Entrance Door Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	27481	1	Bushing	.334 Id X .500 Od
2	36688-23SRV	1	Door, W/m	R.H.
3	36688-03	1	Glass, Door	Upper
4	36688-06	1	Glass, Door	Lower
5	36688-39	1	Hinge, Painted	Left
6	36688-25	1	Cam Latch	R.H.
7	36688-27SRV	1	Latch Cover W/m	R.H.
8	80824	1	Nut, Hex	#10-24
9	871052400	1	Mach Scr, R.H.	#10-24 X .50
10	80350	10	Nut, Flexloc	.250-20, Full, Lt
11	81106	4	Csbhs	.250-20 X .75, Ss
12	984390	1	Door Hold	
13	80160	6	Washer, Lock	.250
14	81262	1	Shldr Scr	.500 X .625 X .375-16
15	81279	7	Csbhs	.250-20 X 2.00, Ss
16	80322	5	Scr, Slftpg, Hh	.250-20 X .50
17	36688-31	1	Paddle Latch	
•	36688-32	1	Key, Paddle Latch	
18	36688-16	7	Bushing, Nylon	
19	36688-17	8	Grommet	.250
20	80351	1	Nut, Flexloc	.312-18, Full, Lt
21	81278	9	Washer, Flat	.250 X 1.00, Ss
22	36688-55	1	Knob, Inside Release	
23	80036	6	Nut, Hex	.250-20
24	81280	1	Csbhs	.312-18 X 2.25, Ss
25	80038	1	Nut, Hex	.375-16
26	73064	5	Rubber Strip, Sponge	.250 X .50
•	36688-18	14	Seal, Window	
•	19871	1	Seal, Door	
•	33707	.0011	Sealant, Silicone, Clear	

Illustrated Parts List (IPL)



Standard Seat




Figure 10-29



Illustrated Parts List (IPL)

Standard Seat Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	24511	1	Pedestal, Std Seat	
2	6576	1	Seat, Black, Plain	
3	14039	1	Seat Adjustment Lever Weldment	
4	80144	1	Washer, Flat	USS, .500
5	80237	4	Cap Screw, Hex Head	.438-14 X 1.50, Gr5
6	80143	4	Washer, Flat	USS, .438
•	80142	4	Washer, Flat	USS, .375
•	80162	4	Washer, Lock	.375
•	80226	4	Cap Screw, Hex Head	.375-16 X 1.50, Gr5
•	80233	2	Cap Screw, Hex Head	.437-14 X 1.00, Gr5
•	80353	2	Nut, Flexloc	.438-14, Full, Lt

Illustrated Parts List (IPL)



Optional Spring Seat




Figure 10-30



Illustrated Parts List (IPL)

Optional Spring Seat Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	25037	1	Pedestal, Spring Seat	
2	140600	1	Seat, Suspension, Low Profile	
3	360010B	1	Seat Assy, Black, W/armrest	
4	72527-01	1	Slider Set, Seat Base	Includes Seat (Item 3)
5	80237	4	Cap Screw, Hex Head	.438-14 X 1.50, Gr5
6	80143	4	Washer, Flat	USS, .438
7	80039	2	Nut, Hex	.438-14
9	80207	4	Cap Screw, Hex Head	.312-18 X .75, Gr5
10	80208	8	Cap Screw, Hex Head	.312-18 X 1.00, Gr5
11	80141	20	Washer, Flat	USS, .313
12	80351	8	Nut, Flexloc	.312-18, Full, Lt
13	730-3050	1	Seat Belt	12.0
•	37982	1	Seat Belt Tether Kit	
14	80233	2	Cap Screw, Hex Head	.438-14 X 1.00, Gr5
•	72527-03	4	Spacer, Seat Slide, Plastic	

Steering Wheel Assembly




Figure 10-31



Illustrated Parts List (IPL)

Steering Wheel Assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	300010	1	Cap, Steering Wheel	
2	300030	1	Steering Wheel	17.00, 36 Spline
3	33687	1	Turn Signal W/hazard	7-wire
•	1001046	1	Wiring, Harness, Trn Signal	
4	39146-14	1	Switch, Ignition	
•	982008-04	1	Key, Ignition, Kubota,300B	
5	1000065	1	Mount, Steering Column	
6	1001099	1	Steering Column Dash	Plate Only
7	1001711	2	Bolt	
8	1001100	1	Steering Column Body	Back Only
9	1001098	1	Steering Column Front	Front Only
10	39045	1	Steering Orbital	
•	1002551	1	Kit, Tilt Console Gas Spring	Not Shown, Includes Parts Below
•	1001421	1	Gas Spring, Locking, 125 lb	Not Shown
•	1001422	1	Release System, Gas Spring, Push Button	Not Shown
•	1002543	2	Bracket, Wtih Pin, Gas Spring	Not Shown
•	1002444	1	Hinge, Gas Spring	Not Shown
•	1002545	1	Bushing, Gas Spring Mount	Not Shown

Illustrated Parts List (IPL)



Control Handle And Throttle Linkage




Figure 10-32



Illustrated Parts List (IPL)

Control Handle And Throttle Linkage Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	26166SRV	1	Throttle Cable Assy	
•	350050	1	Clevis	.250-28
•	38532	1	Cable, Throttle, Vernier	3 X 75
•	38534	1	Clamp, Cable	40 Series
•	38535	1	Shim, Cable Clamp	40 Series
2	987662	1	Plate, Console, Needle Vlv, Cover	
3	1000552	1	Console, Side Cover	
4	1001042	1	Joystick	Wired Assy, includes items 5-8
5	1000191	1	Joystick Assembly	
6	989815	1	Joystick	Only Joystick
7	36085	1	Relay	
•	36086	1	Relay Mount	
•	37941	1	Switch, Limit	
8	1000190	1	Bracket	
9	1000188	1	Rubber Cover	Beneath Bracket
10	989816	1	Cable, Push/Pull - 54" Long	Drive Cable
•	80192	6	Cap Screw, Hex Head	.250-20 X .75, Gr5
•	80208	4	Cap Screw, Hex Head	.312-18 X 1.00, Gr5
•	80219	2	Cap Screw, Hex Head	.375-16 X .75, Gr5
•	80226	1	Cap Screw, Hex Head	.375-16 X 1.50, Gr5
•	80037	4	Nut, Hex	.312-18
•	80140	2	Washer, Flat	USS, .250
•	80161	4	Washer, Lock	.312
•	33963	1	Alarm, Back Up	

Illustrated Parts List (IPL)



Instrument Panel




Figure 10-33



Illustrated Parts List (IPL)

Instrument Panel Parts List

Item No.	Part Number	Qty.	Description	Remarks
•	1001047	1	Wiring Harness, Instrument Panel	Complete Assembly
1	1002032	1	Gauge, 3 in 1 Tach, Oil Press, Water Temp	
2	39140-21	1	Lights, Check Engine	
2a	39140-22	1	Lights, Park Brake	
3	1002034	1	Gauge, Volts	
4	39140-07	1	Hourmeter, Digital	
5	1002033	1	Gauge, Fuel	
6	39140-11	1	Rocker, Paddle, On-off-on	N.i., Dpdt
7	39140-13	1	Rocker, On-off	N.i., Spst
8	39140-14	4	Rocker, On-off	Amber, SPST
•	1001044	1	Wiring, Harness, Switch Panel Assy	Complete Assembly
9	1001040	1	Decal Kit, Joystick	
10	1000188	1	Rubber, Cover, Joystick	
•	720110	1	Horn	12v

Illustrated Parts List (IPL)



Fuse Panel Sub-assembly




Figure 10-34



Illustrated Parts List (IPL)

Fuse Panel Sub-assembly Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	1001003	1	Plate,Fuse Block,Chal\P	
2	36694	1	Fuse Block,10 Gang,Atc\P	
3	36695	1	Fuse Block,6 Gang,Atc\P	
4	720290	1	Solenoid,12V,Constant Duty\P	
5	985446	1	Conn,12-Pin,Plug,Ct06-12Sa\P	
6	983204	1	Conn,06-Pin,Soc,Dt04-6P \P	
7	71861-2	1	Wire,10Ga,Red\P	
8	71861-1	0.6	Wire,10Ga,White\P	
9	72116	1.25	Wire,14Ga,Brown\P	
10	35174	2.5	Wire,14Ga,Purple\P	
11	33271-15	1.17	Wire,16Ga,Brn/Yel\P	
12	71066	1.13	Wire,14Ga,Yellow\P	
13	71063	1.08	Wire,14Ga,Green\P	
14	71062	1.05	Wire,14Ga,Blue\P	
15	38519-12	1	Wire,14Ga,Red/Blk\P	
16	71065	3	Wire,14Ga,Red\P	
17	71064	1.25	Wire,14Ga,Black\P	
18	33271-19	1.21	Wire,16Ga,Gm/Yel\P	
19	985677	1.17	Wire,14Ga,Yel/Red\P	
20	34203	1	Wire,14Ga,Orange\P	
21	71862	0.96	Wire,14Ga,White\P	
22	36349	16	Term,Push-On,.25,Female,18- 14,Sl\P	
23	36340	6	Fuse,10Amp,Atc\P	
24	36342	1	Fuse,25Amp,Atc\P	
25	36746	2	Fuse,5 Amp,Atc\P	
26	36341	5	Fuse,15Amp,Atc\P\P \P\P\P\P	
•	1001043	1	Wiring Harness, Fuse Panel	Complete Assembly

Illustrated Parts List (IPL)



Lights And Mirrors




Figure 10-35



Illustrated Parts List (IPL)

Lights And Mirrors Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	6161	2	Light, Turn Signal	Amber
2	160040A	4	Work Light	
3	38840	1	Light, Dome	
4	851342007	2	Light, Turn/brake	Red
5	988781	1	Wire Harness	Rear/work Lights
6	35465-06	3	Grommet, Insulation	.375id
•	1001045	1	Wiring, Cab Harness	
•	27824	1	Wiring Harness	Ext, Lights, Tail
•	35213	1	Holder, Wire Tie, Adhesive Back	
•	36165	4	Term, Sealed Conn	16-14 Ga, Fem
•	36166	4	Seal, Cable	18-16 Ga
•	36340	1	Fuse	10 Amp, Atc
•	36349	7	Term, Push-on	.25, Fem, 18-14, SI
•	36746	1	Fuse	5 Amp, Atc
•	70953	6	Conn, Male Terminal	
•	72135	2	Term, Ring	12-10 Ga, .500 Stud
•	851390204	3	Term, Ring	16-14 Ga, #10 Stud
7	38687	1	Light, Strobe	Amber, 8j, 80sfpm
•	21176	1	Mount, Warning Light Group	
8	16962	1	Mount, Riser, Strobe Light	
•	35465-06	2	Grommet, Insulation	.375id
•	36746	1	Fuse	5 Amp, Atc
•	80140	4	Washer, Flat	USS, .250
•	80141	4	Washer, Flat	USS, .313
•	80161	4	Washer, Lock	.312
•	80192	4	Cap Screw, Hex Head	.250-20 X .75, Gr5
•	80202	4	Cap Screw, Hex Head	.312-18 X .50, Gr5
•	80350	4	Nut, Flexloc	.250-20, Full, Lt
•	25703	1	Mirror Group	7 X 16, West Coast
9	38057	1	Mirror	7 X 16, West Coast
•	80219	2	Cap Screw, Hex Head	.375-16 X .75, Gr5
•	80142	4	Washer, Flat	USS, .375
•	80352	2	Nut, Flexloc	.375-16, Full, Lt
10	35425	1	Fan	
•	35426	1	Switch, Fan, 3 spd	
•	1000705	1	Opt, Radio, Am/fm, W/spk'r / Antenna	
•	1002022	1	Mount, Radio, 2 Speaker	
•	1002021	1	Antenna, Am/fm	
•	1002022-01	1	Speaker, 4.5"	Each
•	988662	1	Radio, Dual, WB/AM/FM/CD	Weather Band

10

Illustrated Parts List (IPL)



Park Brake




Figure 10-36



Illustrated Parts List (IPL)

Park Brake Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	34299	1	Lever, Brake	12 In Handle
2	36797	1	Cable, Park Brake	68.25
3	6427	1	Clevis	.313-24 Unf W/pin
4	21217	1	Bracket, Brake Lever	
5	21218	1	Mount, Brake Switch	
6	27503	1	Wire Harness	Park Brake
7	951091224	1	Switch, Safety Start	
8	38359	1	Brake Cable Equalizer	
•	80208	4	Cap Screw, Hex Head	.312-18 X 1.00, Gr5
•	80214	2	Cap Screw, Hex Head	.312-18 X 2.25, Gr5
•	80351	3	Nut, Flexloc	.312-18, Full, Lt
•	80141	6	Washer, Flat	USS, .313
•	80161	6	Washer, Lock	.312

Illustrated Parts List (IPL)



Hydraulic Brake




Figure 10-37



Illustrated Parts List (IPL)

Hydraulic Brake Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	28649	1	Bracket, Brake Pedal/cylinder	
2	38314	1	Master Cyl, Brake	
3	28647	1	Pushrod, Brake	
4	28650SRV	1	Brake Pedal, W/m	
5	38277	1	Fitt, Master Cyl Adaptor	
6	33953-15	1	Brake Line	.188 X 15
7	39059	2	Fitt, Str	02mp-03iff, Brass
8	33557	1	Fitt, Tee	02fm, Brass
9	32131	1	Switch, Stop Lamp, Hyd Type, No	
10	33953-20	2	Brake Line	.188 X 20
11	33949	1	Fitt, Tee	03iff, Brass
12	33953-40	1	Brake Line	.188 X 50
•	871111605	2	Clamp, Insulated Band	1/2"
•	80226	2	Cap Screw, Hex Hea	.375-16 X 1.50, Gr5
•	71620	2	Cap Screw, Hex Hea	.375-16 X 3.00, Gr5
•	80038	2	Nut, Hex	.375-16
•	80093	1	Nut, Hex, Jam	.500-20
•	80095	1	Nut, Hex, Jam	.625-18
•	80162	2	Washer, Lock	.375

Illustrated Parts List (IPL)



Brush Hydraulics And Manifold




Figure 10-39



Illustrated Parts List (IPL)

Brush Hydraulics And Manifold Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	989272-13	1	Hose	.38 X 47 6ff 8mb
2	989272-14	1	Hose	.38 X 39 6ff 6mb
3	989272-15	1	Hose	.38 X 30 6ff 6mb
4	989272-16	1	Quick Disconnect	6pp F 6fp
5	989272-17	1	Quick Disconnect	8pp F 8fp
6	989272-18	1	Quick Disconnect	8pp F 12mp
7	989272-19	1	Quick Disconnect	6pp M 6fp
8	989272-20	1	Quick Disconnect	8pp M 12fp
9	987521-09	1	Hose	6mk3k-6fjx-(Be)-21"
10	987521-06	1	Hose	6mk3k-6mp-6fjx90m-1 25"
11	987521-05	1	Hose	6mk3k-6fjx-6fjx90m-1 35"
12	987521-07	1	Hose	12mk3k-12fjx-12fjx-0s-1 71"
13	987521-08	1	Hose	12mk3k-12fjx-12fjx-0s-1 72"
14	987521-43	2	Fitting, Straight	6400-6-6
15	986972	1	Manifold, Hyd, Brush Control	
16	987521-40	1	Fitting, Straight	6400-12-12
17	987521-11	1	Hose	6m3k-6fjx-(Be)-90"
18	987521-15	1	Hose	12g2-12fjx-(Be)-40"
19	03-1022-7	1	Fitting	8mp-8mp 1/2ff-s
20	03-1392	1	Valve Ball, Br	8fp-8fp
•	1002298	1	Hose Kit	CAT

Illustrated Parts List (IPL)



Steering Orbitrol And Manifold




Figure 10-40

Steering Orbitrol And Manifold Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	987521-11	1	Hose	6m3k-6fjx-(Be)-90"
2	987521-43	11	Fitt, Str	6400-6-6
3	39045	1	Motor, Hyd, Power Steering	
4	987521-13	1	Hose	6m3k-6fjx-(Be)-1 29"
5	987521-35	2	Fitt, Str	6801-12-10
6	987521-48	2	Fitt, Tee	6602-12-12-12
7	987521-06	1	Hose	6mk3k-6mp-6fjx90m-1 25"
8	987521-05	1	Hose	6mk3k-6fjx-6fjx90m-1 35"
9	987521-34	2	Fitt, 90°	6400-12-10
10	987521-16	1	Hose	16g1-1 6fjx-1 2fjx-86"
11	987521-50	2	Fitt, 90°	6500-12-12
12	987521-49	2	Fitt, Reducer	2406-12-8
13	987521-08	1	Hose	12mk3k-1 2fjx-1 2fjx90s-1 72
14	987521-07	1	Hose	12mk3k-1 2fjx-1 2fjx90s-1 71
15	987521-14	1	Hose	6mk3k-6fjx-(Be)-1 29"
16	987521-12	1	Hose	6m3k-6fjx-8fjx-90"
17	987521-10	1	Hose	6mk3k-6fjx-6fjx90s-96"
18	986972	1	Manifold, Hyd, Brush Control	
•	1002298-01	1	Hose Kit	Kubota

Illustrated Parts List (IPL)



Hydrostatic Pump And Motor




Figure 10-41



Illustrated Parts List (IPL)

Hydrostatic Pump And Motor Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	987521-31	1	Fitt, 90°	2501-20-20
2	987521-30	1	Fitt, 90°	2501-16-20
3	987521-23	1	Hose	16gmv-16fjx-(Be)-49"
4	987521-37	2	Fitt, 90°	6801-12-12
5	987521-39	4	Fitting	16fhhs
6	987521-24	1	Hose	16g6k-16flh90-16fjx90-48"
7	987521-42	2	Fitt, 90°	16flh6k-16mj90
8	987521-32	2	Fitt, 90°	2501-6-8
9	38323	1	Pump, Hyd, Gear	2.3 Cir, Cw
10	38514	1	Motor, Hyd, Drive	100cc
11	987521-13	1	Hose	6m3k-6fjx-(Be)-129
12	987521-14	1	Hose	6mk3k-6fjx-(Be)-129
13	987521-25	1	Hose	16g6k-16flh90-16fjx-52"
14	987521-21	1	Hose	12g1-12fjx-(Be)-29"
15	987521-29	1	Fitt, Str	6801-12-16
16	987521-15	1	Hose	12g2-12fjx-(Be)-40"
17	987521-28	1	Fitt, 90°	6801-20-20
18	987521-38	1	Fitt, 90°	6801-16-16
19	987521-22	1	Hose	20gmv-20fjx-(Be)-44
•	1001642	1	Hose Kit, Chal V	
•	80038	4	Nut, Hex	.375-16
•	80162	16	Washer, Lock	.375
•	80221	16	Cap Screw, Hex Head	.375-16 X 1.00, Gr5
•	80996	20	Washer, Flat	SAE, .375
•	91500	AR	Oil, Hyd	Iso68, Purchase Locally

Illustrated Parts List (IPL)



Hydraulic Filter And Cooler Hoses




Figure 10-42



Illustrated Parts List (IPL)

Hydraulic Filter And Cooler Hoses Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	72543	1	Filter Assy, Hyd Return	
•	38327-01	1	Filter Element	
•	25646	1	Support, Filter	(For 72543)
2	987521-60	2	Pipe Plug	5406-hhp-16
3	34463	1	Filter Assy, Hyd Return	
•	34464	1	Filter Element	
•	15984	1	Support, Filter	
4	987521-57	2	Fitt, Tee	2605-16-16-16
5	987521-26	1	Hose	16g2-1 6fjx-(Be)-33"
6	987521-56	2	Fitt, 90°	6801-16-20
7	987521-17	1	Hose	16g1 -1 6fjx-(Be)-86"
8	987521-55	2	Fitt, Str	6400-10-12
9	987521-36	2	Fitt, Str	6400-10-10
10	987521-20	1	Hose	10g2-1 0fjx-1 0fjx90m-45"
11	987521-19	1	Hose	10g2-1 0fjx-1 0fjx90m-45"
12	987521-27	2	Fitt, 45°	6802-16-16
13	987521-18	1	Hose	12g2-1 2fjx-1 2fjx90m-28"
14	987521-16	1	Hose	16g1 -1 6fjx-1 2fjx-86"
15	987521-40	3	Fitt, Str	6400-12-12
•	1001642	1	Hose Kit, Chal V	
•	80038	4	Nut, Hex	.375-16
•	80162	16	Washer, Lock	.375
•	80221	16	Cap Screw, Hex Head	.375-16 X 1.00, Gr5
•	80996	20	Washer, Flat	SAE, .375
•	91500	AR	Oil, Hyd	Iso68, Purchase Locally
•	38482	1	U-bolt	.375-16, 4.00iw, 3.00il
•	37271	6	Loom, Split, Convuluted	.625

Illustrated Parts List (IPL)



Hydraulic Tank




Figure 10-43



Illustrated Parts List (IPL)

Hydraulic Tank Parts List

Item No.	Part Number	Qty.	Description	Remarks
1	500070	1	Gauge, Sight Level/temp	
2	80787	4	Cap Screw, Hex Head	.250-20 X 2.50, Gr5
3	987527	1	Cap W/strainer	5 Psi
4	1000206	1	Cover Plate, Hydraulic Tank	
5	80350	4	Nut, Flexloc	.250-20
6	1000260	1	Hydraulic Tank	
7	33148	2	Strainer, Suct	2hpt, 25gpm, 100me

Illustrated Parts List (IPL)



ALPHABETICAL PARTS INDEX

Description	Part Number	Figure Number	Item Number
340170 Bearing Cup Wheel	38303-04	10-4	•
A/C Belt	1002184-10	10-21	•
AC Front Stay	1001166-41	10-14	6
AC Mount	1001166-16	10-14	4
AC Rear Stay	1002184-09	10-14	5
Adapter, Rubber	987485	10-17	9
Adhesive, Aerosol Spray, Can	38462	10-24	•
Adhesive, Aerosol Spray, Can	38462	10-27	•
Adptr, Rubber, 1.25 ID x 2.00 ID	1002184-12	10-14	24
Adptr, Rubber, 1.25 ID x 2.00 ID	1002184-12	10-17	24
Adptr, Rubber, 2.0" ID, 2.5" Long	1002184-13	10-14	25
Adptr, Rubber, 2.0" ID, 2.5" Long	1002184-13	10-17	25
Adptr, Rubber, 3.0" ID, 3.0" Long	1002184-14	10-14	27
Adptr, Rubber, 3.0" ID, 3.0" Long	1002184-14	10-17	27
Adptr, Rubber, 3.0" ID, 3.0" Long	1002184-14	10-14	29
Adptr, Rubber, 3.0" ID, 3.0" Long	1002184-14	10-17	29
Adptr, Rubber, Insert	38830	10-17	11
Air Cleaner Assy	38385	10-17	1
Air Filter, Primary	38385-01	QR	•
Air Filter, Safety	38385-02	QR	•
Alarm, Back Up	33963	10-32	•
Alternator	1001166-04	10-14	•
Alumn Reducer	986537-24	10-14	26
Alumn Reducer	986537-24	10-17	26
Antenna, Am/fm	1002021	10-35	•
Arm	989272-58	10-11	21
Arm, Windshield Wiper	151180	10-27	9
Arm, Wiper	33744	10-27	•
Assy, Door	36690R	10-24	•
Assy, Door, Entrance	36688-41	10-24	18
Assy, Engine, Kubota	1002184	10-14	•
Axle Assy, Steering	27060	10-1	10
Axle, Flanged Drive	38300-09	10-2	•
Ball Joint	36756	10-4	23
Ball Joint	36757	10-4	24
Ball Joint, Steering Cyl End	36755	10-4	22
Battery Hold Down	72313	10-14	•
Battery, 12V, 1000 CCA	33146-6	10-14	•



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Bearing	989272-55	10-7	7
Bearing Cone	610210	10-4	•
Bearing Cone, Wheel Hub	340180	10-4	•
Bearing Cup	38303-05	10-4	•
Bearing Cup, Wheel Hub	38303-06	10-4	•
Bearing Cup, Wheel Hub	38303-07	10-4	•
Bearing Kit	38303-01	10-4	•
Bearing, Differential	38300-04	10-2	•
Bearing, Outer Wheel	38300-07	10-2	•
Bearing, Wheel Hub, Inner	38300-06	10-2	•
Belt, A/C Comp, Kub	1002184-10	10-14	7
Blade, Wiper	151190	10-27	8
Blade, Wiper	33744-01	10-27	•
Block Heater	1001753	10-14	•
Blower	36745-13	10-22	28
Blower Plate	36745-26	10-22	29
Bolt	N/A	10-22	11
Bolt	1001711	10-31	7
Bolt, Button Head	1001710	10-18	8
Bracket	1000190	10-32	8
Bracket, Brake Lever	21217	10-35	4
Bracket, Brake Pedal/cylinder	28649	10-36	1
Bracket, Coil	38653-07	10-22	35
Bracket, Coil	38653-06	10-22	36
Bracket, Door Latch	984390	10-25	•
Bracket, Fuse Block	29262	10-26	8
Bracket, Spray Pipe	26484	10-12	23
Bracket, With Pin, Gas Spring	1002543	10-31	•
Brake Cable Equalizer	38359	10-35	8
Brake Line	33953-15	10-36	6
Brake Line	33953-20	10-36	10
Brake Line	33953-40	10-36	12
Brake Pedal, W/m	28650	10-36	4
Brake Shoe & Lining Kit	38300-14	10-2	•
Brake, Cyl	38300-12	10-2	•
Brake, Cylinder, RH	38300-13	10-2	•
Brkt, Throttle, Cable	983185	10-14	•
BRKT, Throttle, Kub	1002184-19	10-14	21
Bulkhead, Hydraulic, Mount	989824	10-1	12
Bushing	27481	10-28	1

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Bushing With Hole	989272-62	10-11	25
Bushing, Gas Spring Mount	1002545	10-31	•
Bushing, Nylon	36688-16	10-24	8
Bushing, Nylon	36688-16	10-28	18
Cab Air Cond/heater Kit	38653	10-21	10
Cab, W/m	1000959	10-24	1
Cable, Battery, Neg, 13"	5804	10-14	•
Cable, Battery, Neg, 16"	400020	10-14	•
Cable, Battery, Pos, 60"	72136	10-14	•
Cable, Park Brake	38342	10-2	4
Cable, Park Brake	36797	10-35	2
Cable, Push/Pull - 54" Long	989816	10-32	10
Cable, Rotary Control	36749-03	10-22	21
Cable, Rotary Control	36749-04	10-22	31
Cable, Throttle, Vernier	38532	10-32	•
Cam Latch	36688-25	10-28	6
Cap Screw, Hex Hea	80226	10-36	•
Cap Screw, Hex Hea	71620	10-36	•
Cap Screw, Hex Head	81002	10-1	•
Cap Screw, Hex Head	81113	10-1	•
Cap Screw, Hex Head	80460	10-1	•
Cap Screw, Hex Head	80185	10-1	•
Cap Screw, Hex Head	81184	10-4	1
Cap Screw, Hex Head	80839	10-4	17
Cap Screw, Hex Head	71627	10-4	20
Cap Screw, Hex Head	81027	10-12	2
Cap Screw, Hex Head	80224	10-12	•
Cap Screw, Hex Head	80230	10-21	3
Cap Screw, Hex Head	71617	10-21	7
Cap Screw, Hex Head	80221	10-21	12
Cap Screw, Hex Head	80192	10-21	•
Cap Screw, Hex Head	81072	10-21	•
Cap Screw, Hex Head	80194	10-21	•
Cap Screw, Hex Head	80224	10-21	•
Cap Screw, Hex Head	80226	10-21	•
Cap Screw, Hex Head	80192	10-24	4
Cap Screw, Hex Head	80882	10-24	17
Cap Screw, Hex Head	80192	10-27	•
Cap Screw, Hex Head	80237	10-29	5
Cap Screw, Hex Head	80226	10-29	•



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Cap Screw, Hex Head	80233	10-29	•
Cap Screw, Hex Head	80192	10-32	•
Cap Screw, Hex Head	80208	10-32	•
Cap Screw, Hex Head	80219	10-32	•
Cap Screw, Hex Head	80226	10-32	•
Cap Screw, Hex Head	80192	10-35	•
Cap Screw, Hex Head	80202	10-35	•
Cap Screw, Hex Head	80219	10-35	•
Cap Screw, Hex Head	80208	10-35	•
Cap Screw, Hex Head	80214	10-35	•
Cap Screw, Hex Head	80221	10-41	•
Cap Screw, Hex Head	80221	10-42	•
Cap Screw, Hex Head	80787	10-43	2
Cap Screw, Hex Head	80226	10-17	•
Cap Screw, Hex Head	80802	10-20	5
Cap Screw, Hex Head	80937	10-21	•
Cap Screw, Hex Head	80237	10-30	5
Cap Screw, Hex Head	80207	10-30	9
Cap Screw, Hex Head	80208	10-30	10
Cap Screw, Hex Head	80233	10-30	14
Cap W/strainer	987527	10-43	3
Cap, Fuel, W/lock Lug	36105	10-19	3
Cap, Steering Wheel	300010	10-31	1
Clamp, Air Cleaner Mount	34033	10-16	2
Clamp, Cable	38534	10-32	•
Clamp, Hose	33163	10-12	16
Clamp, Hose	33162	10-19	6
Clamp, Hose	33164	10-21	2
Clamp, Hose	230240	10-20	7
Clamp, Insulated Band	871111602	10-12	•
Clamp, Insulated Band	871111605	10-36	•
Clamp, Loop	33594-01	10-12	9
Clamp, Loop	36894	10-21	9
Clamp, Loop	33595	10-21	11
Clamp, Muffler	846100266	10-17	•
Clamp, Muffler	33312	10-16	5
Clamp, Receiver Dryer	36745-08	10-23	•
Clamp, Spring	1001616-01	10-13	2
Clamp, T-Bolt	38268	10-17	•
Clamp, T-bolt	171190	10-17	17

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Clamp, T-bolt	953521243	10-17	19
Clevis	350050	10-32	•
Clevis	6427	10-35	3
Coil, Assy, Evap.	38653-05	10-22	5
Coil, Heater	36749-02	10-22	37
Cold Control	36745-19	10-22	23
Compressor Assy	36745-05	10-23	•
Compressor, Air Conditioner	36745-05	10-21	15
Condenser Assy	36745-06	10-23	•
Condensor Assembly	36745-06	10-20	2
Conn, 1Way, Male, Locking	36739	10-33	•
Conn, 1Way, Male, Locking	36739	10-33	•
Conn, Male Terminal	70953	10-33	•
Conn, Male Terminal	70953	10-33	•
Conn, Male Terminal	70953	10-35	•
Conn, Sealed, Shroud	35138	10-21	•
Conn,06-Pin,Soc,Dt04-6P \P	983204	10-34	6
Conn,12-Pin,Plug,Ct06-12Sa\P	985446	10-34	5
Connector	987686	10-17	•
Console, Side Cover	1000552	10-32	3
Coolant Reserve Tank	1001166-13	10-14	•
Core	989272-77	10-6	3
Cover	987451	10-1	4
Cover	36745-25	10-22	3
Cover	36745-24	10-22	30
Cover Plate	989272-83	10-8	3
Cover Plate, Hydraulic Tank	1000206	10-43	4
Cover, 10 Inch, Vented, Raven	33238-03	10-12	•
Cover, Air Filter	1000884	10-18	7
Cover, Engine	1000890	10-18	2
Cover, Fuel Tank, W/m	1001401	10-19	2
Cover, Plastic	36688-08	10-25	10
Cover, Recirc.	36745-29	10-22	32
Cover, Side Access	36688-09	10-26	7
Csbhs	81277	10-24	10
Csbhs	81282	10-24	12
Csbhs	81277	10-25	5
Csbhs	81281	10-27	7
Csbhs	81277	10-27	11
Csbhs	36687	10-27	•



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Csbhs	81106	10-28	11
Csbhs	81279	10-28	15
Csbhs	81280	10-28	24
Cyl, Hyd, Steering	36754	10-4	21
Cylinder, Hydraulic	989272-09	10-8	17
Cylinder, Hydraulic	989272-10	10-8	22
Decal	36745-22	10-22	24
Decal Kit, Joystick	1001040	10-33	9
Defroster Fan Assy	35425	10-33	•
Defroster Fan Assy,	35425	10-33	•
Defroster Fan Group, Dual	21169	10-33	•
Defroster Fan Group, Single	21168	10-33	•
Door Hold	1000838	10-25	6
Door Hold	984390	10-28	12
Door, W/m	36688-23	10-28	2
Drive Axle Assy	26259	10-1	8
Drive Axle, W/m	26983	10-2	1
Drive Pulley	1000867-10	10-14	8
Drive Shaft Assy	38518	10-3	•
Driveshaft	38518	10-1	9
Dryer, Air Conditioner	36745-07	10-21	14
Dust Cap	620200	10-4	•
Dust Suppression (Complete Kit)	1001616	10-13	•
Elbow, Exhaust, 90°	36117	10-16	7
Elbow, Rubber, Cobra	987484	10-17	8
Engine Belt, Kub	1001166-05	10-14	•
Fan	35425	10-35	10
Fan, Kub	1002184-08	10-14	3
Fastener, Turn	36745-36	10-22	15
Fastener, X-mas Tree	36688-43	10-27	5
Filter Assy, Hyd Charge	34463	QR	•
Filter Assy, Hyd Return	72543	QR	•
Filter Assy, Hyd Return	72543	10-42	1
Filter Assy, Hyd Return	34463	10-42	3
Filter Element	984909-01	10-19	•
Filter Element	38327-01	10-42	•
Filter Element	34464	10-42	•
Filter Element, Cab Air	38653-01	QR	•
Filter Element, Cab Air	38653-01	10-22	4
Filter Holder, Recirc.	36745-30	10-22	33

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Filter Primary	38385-01	10-17	•
Filter Secondary	38385-02	10-17	•
Filter, Fuel	982080-02	QR	•
Filter, Fuel Pre-Filter	986537-31	QR	•
Filter, Fuel/water, Element,	984909-01	QR	•
Filter, Oil	986537-03	QR	•
Filter, Oil	984909-02	QR	•
Fitt, 45°	72369	10-19	7
Fitt, 45°	987521-27	10-42	12
Fitt, 90°	70319	10-12	15
Fitt, 90°	987521-34	10-40	9
Fitt, 90°	987521-50	10-40	11
Fitt, 90°	987521-31	10-41	1
Fitt, 90°	987521-30	10-41	2
Fitt, 90°	987521-37	10-41	4
Fitt, 90°	987521-42	10-41	7
Fitt, 90°	987521-32	10-41	8
Fitt, 90°	987521-28	10-41	17
Fitt, 90°	987521-38	10-41	18
Fitt, 90°	987521-56	10-42	6
Fitt, Lube, Str	33684	10-4	13
Fitt, Master Cyl Adaptor	38277	10-36	5
Fitt, Reducer	987521-49	10-40	12
Fitt, Str	70459	10-12	10
Fitt, Str	39059	10-36	7
Fitt, Str	987521-43	10-40	2
Fitt, Str	987521-35	10-40	5
Fitt, Str	987521-29	10-41	15
Fitt, Str	987521-55	10-42	8
Fitt, Str	987521-36	10-42	9
Fitt, Str	987521-40	10-42	15
Fitt, Str 06MP - 06FPX	6274	10-14	•
Fitt, Tee	33557	10-36	8
Fitt, Tee	33949	10-36	11
Fitt, Tee	987521-48	10-40	6
Fitt, Tee	987521-57	10-42	4
Fitt, Test 06MB - 02DP	72689	10-14	•
Fitting	03-1022-7	10-8	13
Fitting	03-1022-7	10-37	19
Fitting	987521-39	10-41	5



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Fitting	03-1022-7	10-39	19
Fitting, 45° Elbow	03-2115	10-8	23
Fitting, 90° Elbow, Hp	989272-05	10-8	15
Fitting, Adapter, Hp	989272-03	10-8	1
Fitting, Barb, Tee, Nylon	1001616-04	10-13	6
Fitting, Straight	987521-43	10-37	14
Fitting, Straight	987521-40	10-37	16
Fitting, Straight	73150	10-20	•
Fitting, Straight	987521-43	10-39	14
Fitting, Straight	987521-40	10-39	16
Fitting, Vent, Hex W/screen	989272-04	10-8	16
Fitting, Zerk, Self Tapping	989272-28	10-11	10
Flange	38518-08	10-3	8
Flange Yoke	38518-07	10-3	7
Floormat	1000287	10-24	13
Fluid, Brake	90707	10-36	•
Foam, Rear Panel	36688-15	10-24	21
Frame, Brush	989272-63	10-5	6
Frame, W/m	1001033	10-1	1
Front Mount Foot	1002184-24	10-14	35
Fuel Pre-Filter	986537-31	10-14	•
Fuel/water Separator Pump	984909-13	10-19	9
Fuse	36341	10-12	•
Fuse	36340	10-27	•
Fuse	36747	10-27	•
Fuse	36747	10-33	•
Fuse	36340	10-33	•
Fuse	36340	10-35	•
Fuse	36746	10-35	•
Fuse	36746	10-35	•
Fuse Block	36695	10-27	6
Fuse Block,10 Gang,Atc\P	36694	10-34	2
Fuse Block,6 Gang,Atc\P	36695	10-34	3
Fuse, Blade	37303	10-21	•
Fuse,10Amp,Atc\P	36340	10-34	23
Fuse,15Amp,Atc\P\ P\ P\ P\ P	36341	10-34	26
Fuse,25Amp,Atc\P	36342	10-34	24
Fuse,5 Amp,Atc\P	36746	10-34	25
Gas Spring, Locking, 125 lb	1001421	10-31	•
Gasket	38300-15	10-2	•

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Gauge, 3 in 1 Tach, Oil Press, Water Temp	1002032	10-33	1
Gauge, Fuel	1002033	10-33	5
Gauge, Sight Level/temp	500070	10-43	1
Gauge, Volts	1002034	10-33	3
Glass, Door	36688-03	10-28	3
Glass, Door	36688-06P	10-28	4
Glass, Window	36688-04P	10-24	6
Glass, Window	36688-02P	10-24	22
Glass, Window	36688-05P	10-24	23
Glow Plugs	1001166-09	10-14	•
Grommet	38606-16	10-22	8
Grommet	38606-15	10-22	9
Grommet	38525-34	10-22	10
Grommet	38653-09	10-22	26
Grommet	38653-08	10-22	27
Grommet	36688-17	10-24	7
Grommet	36688-54	10-26	2
Grommet	36688-17	10-28	19
Grommet, Insulation	35465-07	10-27	•
Grommet, Insulation	35465-06	10-33	•
Grommet, Insulation	35465-06	10-33	•
Grommet, Insulation	35465-06	10-35	6
Grommet, Insulation	35465-06	10-35	•
Grommet, Rubber	1001616-02	10-13	4
Group, Cover	1005049	10-18	•
Guard, Belt, Kub	1001166-40	10-14	1
Guard, Fan, Kub	1002184-03	10-14	9
Hanger, Exhaust	38380	10-16	•
Hardware Kit	38518-09	10-3	9
Harness, Engine, Kub	1002184-25	10-14	36
Headliner	36688-12	10-24	24
Hex Plate With Doubler	989272-56	10-7	8
Hex Plate With Doubler	989272-56	10-9	9
Hinge, Gas Spring	1002444	10-31	•
Hinge, Painted	36688-39	10-28	5
Holder, Wire Tie, Adhesive Back	35213	10-35	•
Horn	720110	10-33	•
Hose		10-37	21
Hose		10-39	21
Hose	989272-12	10-8	4



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Hose	989272-13	10-8	11
Hose	989272-14	10-8	19
Hose	989272-15	10-8	24
Hose	38579	10-12	14
Hose	38579	10-13	1
Hose	71812	10-19	8
Hose	989272-13	10-37	1
Hose	989272-14	10-37	2
Hose	989272-15	10-37	3
Hose	987521-09	10-37	9
Hose	987521-06	10-37	10
Hose	987521-05	10-37	11
Hose	987521-07	10-37	12
Hose	987521-08	10-37	13
Hose	987521-11	10-37	17
Hose	987521-15	10-37	18
Hose	987521-11	10-40	1
Hose	987521-13	10-40	4
Hose	987521-06	10-40	7
Hose	987521-05	10-40	8
Hose	987521-16	10-40	10
Hose	987521-08	10-40	13
Hose	987521-07	10-40	14
Hose	987521-14	10-40	15
Hose	987521-12	10-40	16
Hose	987521-10	10-40	17
Hose	987521-23	10-41	3
Hose	987521-24	10-41	6
Hose	987521-13	10-41	11
Hose	987521-14	10-41	12
Hose	987521-25	10-41	13
Hose	987521-21	10-41	14
Hose	987521-15	10-41	16
Hose	987521-22	10-41	19
Hose	987521-26	10-42	5
Hose	987521-17	10-42	7
Hose	987521-20	10-42	10
Hose	987521-19	10-42	11
Hose	987521-18	10-42	13
Hose	987521-16	10-42	14

10

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Hose	989272-13	10-39	1
Hose	989272-14	10-39	2
Hose	989272-15	10-39	3
Hose	987521-09	10-39	9
Hose	987521-06	10-39	10
Hose	987521-05	10-39	11
Hose	987521-07	10-39	12
Hose	987521-08	10-39	13
Hose	987521-11	10-39	17
Hose	987521-15	10-39	18
Hose Cradle	989272-84	10-8	2
Hose Kit, Chal V	1001642	10-37	•
Hose Kit, Chal V	1001642	10-40	•
Hose Kit, Chal V	1001642	10-41	•
Hose Kit, Chal V	1001642	10-42	•
Hose Kit, Chal V	1002298	10-39	•
Hose, Clear, Vinyl	1001616-03	10-13	5
Hose, Comp-conden	36745-01	10-23	•
Hose, Comp-evapor	36745-02	10-23	•
Hose, Dryer-conden	36745-04	10-23	•
Hose, Evapor-dryer	36745-03	10-23	•
Hose, Flex	988352	10-20	8
Hose, Heater	TF10199	10-21	•
Hose, Radiator	1002184-01	10-20	1
Hose, Radiator	170071A	10-20	9
Hose, Windshield Washer	35550	10-26	1
Hose, Windshield Washer	35550	10-27	•
Hourmeter, Digital	39140-07	10-33	4
Housing	38653-04	10-22	1
Housing, Axle	38300-01	10-2	•
Hub & Drum Assy	38300-08	10-2	•
Hub Assy, Wheel	38303	10-4	4
Hub, Hex	989272-76	10-9	10
Hub, Hex	989272-71	10-7	10
Hub, Wheel, Idler	38303-02	10-4	•
Hydraulic Tank	1000260	10-43	6
Indicator, Air Filter Service	171220	10-17	7
Insert	984932	10-17	•
Insert, Rubber	37587-2	10-17	10
Joystick	989815	10-32	6



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Joystick	1001042	10-32	4
Joystick Assembly	1000191	10-32	5
Key, Paddle Latch	36688-32	10-28	•
Kit, Brake Shoe LH	38300-17	10-2	•
Kit, Brake Shoe RH	38300-18	10-2	•
Kit, Cab, Insulation	1001718	10-24	•
Kit, Console Parts	1001216	10-31	•
Kit, Decal, Ops & Decorative	1005513	10-18	•
Kit, Differential Case	38300-11	10-2	•
Kit, Drive Gear and Pinion	38300-10	10-2	•
Kit, Filter, Chal V	987912	QR	•
Kit, Seal, Cylinder	36754-03	10-4	•
Kit, Tilt Console Gas Spring	1002551	10-31	•
Knob, Inside Release	36688-55	10-28	22
Knobs	37645-20	10-22	16
Knobs	36745-21	10-22	19
Label	1001709	10-10	1
Label	1001709	10-10	2
Label	1001709	10-10	3
Label	1001709	10-10	8
Label, Warning	1001709	10-10	4
Label, Warning	1001709	10-10	5
Label, Warning	1001709	10-10	6
Label, Warning	1001709	10-10	7
Latch Cover W/m	36688-27	10-28	7
Latch, Engine Access Panel Door	160450	10-18	4
Lever, Brake	34299	10-35	1
Lever, Park Brake	38329	10-2	2
Lever, Park Brake	38330	10-2	3
Light, Dome	38840	10-35	3
Light, Strobe	38687	10-35	7
Light, Turn Signal	6161	10-35	1
Light, Turn/brake	851342007	10-35	4
Lights, Check Engine	39140-21	10-33	2
Lights, Park Brake	39140-22	10-33	2a
Loom, Split, Convuluted	37271	10-42	•
Loom, Split, Convuluted, .625	37271	10-14	•
Louver Door	38653-02	10-22	12
Louvers	36745-17	10-22	2
Louvers	36745-16	10-22	25

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Lower Rad Hose	1001166-15	10-14	16
Mach Scr, Ph	80891	10-12	19
Mach Scr, R.H.	871052400	10-28	9
Manifold, Hyd, Brush Control	986972	10-37	15
Manifold, Hyd, Brush Control	986972	10-40	18
Manifold, Hyd, Brush Control	986972	10-39	15
Manual, Operators, Kub	1001166-42	10-14	•
Manual, Parts, Kub	1001166-45	10-14	•
Manual, Service, Kub	1001166-43	10-14	•
Manual, Workshop, Kub	1001166-44	10-14	•
Manual-pak Case	985234	10-18	•
Master Cyl, Brake	38314	10-36	2
Mirror	38057	10-35	9
Mirror Group	25703	10-35	•
Motor, Hyd	38514	10-41	10
Motor, Hyd, Power Steering	39045	10-40	3
Motor, Hydraulic, White	989272-11	10-9	1
Motor, Windshield Wiper	151170	10-27	10
Mount W/m, Water Tank	27100	10-12	1
Mount, Brake Switch	21218	10-35	5
Mount, Engine, Rear, Kub	1002184-22	10-14	20
Mount, Engine, Rear, Kub	1002184-22	10-14	33
Mount, Engine, RH	1002184-23	10-14	18
Mount, Fuel Lift Pump	987501	10-19	•
Mount, Isolator, Axial 480#	1001758	10-14	•
Mount, Radio, 2 Speaker	1002022	10-35	•
Mount, Riser, Strobe Light	16962	10-35	8
Mount, Rubber, Tube Form	36072	10-24	20
Mount, Steering Column	1000065	10-31	5
Mount, Warning Light Group	21176	10-35	•
Mounting	989272-78	10-11	20
Mounting Band	38386	10-17	2
Mounting Plate	989272-91	10-11	8
Mounting Plate	989272-90	10-11	•
Muffler	34074	10-16	1
Nozzle, Cap, Nylon	1001616-06	10-13	8
Nozzle, Elbow, Without Clamp	1001616-05	10-13	7
Nozzle, Tee	1001616-09	10-13	•
Nozzle, Tip, Brass	1001616-07	10-13	9
Nut, Acorn	81275	10-24	5



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Nut, Centerlock	36688-52	10-25	9
Nut, Flexloc	80359	10-4	2
Nut, Flexloc	80357	10-4	18
Nut, Flexloc	80354	10-4	25
Nut, Flexloc	80352	10-21	•
Nut, Flexloc	80350	10-21	•
Nut, Flexloc	80352	10-24	16
Nut, Flexloc	80350	10-25	3
Nut, Flexloc	80350	10-27	2
Nut, Flexloc	80350	10-27	•
Nut, Flexloc	80350	10-28	10
Nut, Flexloc	80351	10-28	20
Nut, Flexloc	80353	10-29	•
Nut, Flexloc	80350	10-35	•
Nut, Flexloc	80352	10-35	•
Nut, Flexloc	80351	10-35	•
Nut, Flexloc	80350	10-43	5
Nut, Flexloc	80351	10-30	12
Nut, Hex	80040	10-1	•
Nut, Hex	80061	10-1	•
Nut, Hex	80036	10-1	•
Nut, Hex	989272-42	10-7	5
Nut, Hex	989272-49	10-9	8
Nut, Hex	989272-27	10-11	11
Nut, Hex	80043	10-12	3
Nut, Hex	80038	10-12	12
Nut, Hex	80494	10-12	20
Nut, Hex	80036	10-12	22
Nut, Hex	80038	10-21	5
Nut, Hex	80036	10-21	•
Nut, Hex	80036	10-22	14
Nut, Hex	80824	10-27	3
Nut, Hex	80037	10-27	•
Nut, Hex	80824	10-28	8
Nut, Hex	80036	10-28	23
Nut, Hex	80038	10-28	25
Nut, Hex	80037	10-32	•
Nut, Hex	80038	10-36	•
Nut, Hex	80038	10-41	•
Nut, Hex	80038	10-42	•

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Nut, Hex	80038	10-17	•
Nut, Hex	80038	10-20	•
Nut, Hex	80039	10-30	7
Nut, Hex, Hylock	989272-29	10-11	12
Nut, Hex, Jam	21113	10-4	10
Nut, Hex, Jam	21114	10-4	11
Nut, Hex, Jam	80093	10-36	•
Nut, Hex, Jam	80095	10-36	•
Nut, Hex, Nylock	989272-44	10-11	15
Nut, Lug	620520	10-1	2
Nut, Lug	620520	10-4	•
Nut, Mounting Control	38525-22	10-22	20
Nut, Spindle	31713	10-4	14
Oil Pressure Fitting	984286-13	10-14	38
Oil, Gear Lube, Ls	91464	10-1	•
Oil, Hyd	91500	10-41	•
Oil, Hyd	91500	10-42	•
Opt, Radio, Am/fm, W/spk'r / Antenna	1000705	10-35	•
O-ring	1001616-08	10-13	10
O-ring	36745-10	10-23	•
O-ring	36745-11	10-23	•
O-ring	36745-12	10-23	•
O-ring Face Seal	989272-08	10-8	20
Paddle Latch	36688-31	10-28	17
Pedestal, Spring Seat	25037	10-30	1
Pedestal, Std Seat	24511	10-29	1
Pin With Holes	989272-75	10-11	2
Pin With Holes	989272-61	10-11	24
Pin, Clevis	989272-47	10-11	16
Pin, Clevis	989272-54	10-11	19
Pin, Cotter	80332	10-4	15
Pin, Cotter	989272-22	10-11	7
Pin, Klick	989272-24	10-11	9
Pin, L Inch	989272-21	10-5	1
Pin, Lynch	989272-21	10-11	6
Pipe Plug	987521-60	10-42	2
Pipe, Bulkhead	33238-01	10-12	•
Pipe, Bulkhead	33238-02	10-12	•
Pipe, Exh, W/m Kubota	1002184-16	10-14	22
Pipe, Exh, W/m Kubota	1002184-16	10-16	8



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Pipe, Nipple	99610	10-17	6
Pipe, Plug	33238-05	10-12	11
Pipe, Plug	99539	10-19	5
Pipe, Red, 08FP - 06FP, MI	99552	10-14	•
Pivot	989272-59	10-11	22
Plate Hydraulic Orifice	989272-07	10-8	21
Plate, Cab Access Cover	987456	10-24	15
Plate, Console, Needle Vlv, Cover	987662	10-32	2
Plate, Cover	1000883	10-18	3
Plate, Door	1000882	10-18	6
Plate, Fuel Pump, BRKT, Kub	1002184-17	10-14	17
Plate, Handle, Motor	989272-69	10-9	12
Plate, Hat, Core, 10	989272-57	10-6	4
Plate, Mounting, Bearing	989272-70	10-7	9
Plate, Mountng, Motor	989272-68	10-9	11
Plate, Pump Mount, Kub	1002184-21	10-14	32
Plate, Rad Shroud, Kub	1002282	10-14	•
Plate, Serial Number, LeeBoy	35355	10-18	•
Plate, Shroud, Rad	1002282	10-20	3
Plate, Support, Cooler	1002184-05	10-14	13
Plate, Support, Rad	1002184-06	10-14	11
Plate, Tank Cover	987455	10-1	11
Plate, Fuse Block, Chalp	1001003	10-34	1
Plug, Hole	35136-21	10-24	2
Plug, Hole	35136-11	10-24	•
Plug, Hole	35136-17	10-24	•
Plug, Hole	35136-3	10-25	1
Plug, Hole	35136-5	10-25	2
Plug, Hole	35136-5	10-26	3
Plug, Hole	35136-4	10-26	4
Plug, Hole	35136-5	10-27	1
Plug, Hole	35136-4	10-27	12
Port Kit	36730-02	10-12	18
Pre-cleaner	37587	10-17	15
Pump, Fuel, Kub	1002184-18	10-14	19
Pump, Hyd, Gear	38323	10-41	9
Pump, Hyd, Piston, 4.57 Cir	38321	10-14	•
Pump, Water, Diaphram	1004598	10-12	17
Pushrod, Brake	28647	10-36	3
Quick Disconnect	989272-18	10-8	9

10

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Quick Disconnect	989272-20	10-8	10
Quick Disconnect	989272-17	10-8	14
Quick Disconnect	989272-16	10-8	18
Quick Disconnect	989272-19	10-8	25
Quick Disconnect	989272-16	10-37	4
Quick Disconnect	989272-17	10-37	5
Quick Disconnect	989272-18	10-37	6
Quick Disconnect	989272-19	10-37	7
Quick Disconnect	989272-20	10-37	8
Quick Disconnect		10-37	22
Quick Disconnect	989272-16	10-39	4
Quick Disconnect	989272-17	10-39	5
Quick Disconnect	989272-18	10-39	6
Quick Disconnect	989272-19	10-39	7
Quick Disconnect	989272-20	10-39	8
Quick Disconnect		10-39	22
Rad Cap	1002184-04	10-14	14
Radiator/Cooler Assy, Kub	1002184-01	10-14	12
Radio, Dual, WB/AM/FM/CD	988662	10-35	•
Rear Cab Mount, W/m	987211	10-1	5
Rear Windshield Wiper	21166	10-27	•
Receiver Dryer	36745-07	10-23	•
Reducer, Rubber	987486	10-17	13
Refrigerant	38105	10-21	•
Refrigerant, Oil	38106	10-21	•
Relay	36085	10-32	7
Relay Mount	36086	10-32	•
Relay Mount Plate	1002184-20	10-14	34
Release System, Gas Spring, Push Button	1001422	10-31	•
Ring, Recessed, Lifting	1001057	10-18	1
Ring, Retaining	989272-45	10-9	6
Ring, Retaining	989272-45	10-7	6
Ring, Snap	989272-41	10-7	4
Rocker, On-off	39140-13	10-33	7
Rocker, On-off	39140-14	10-33	8
Rocker, Paddle, On-off-on	39140-11	10-33	6
Rod, Adjustment	989272-74	10-11	3
Rubber Cover	1000188	10-32	9
Rubber Elbow, 3.5" to 3.0"	171170	10-14	31
Rubber Elbow, 3.5" to 3.0"	171170	10-17	31



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Rubber Strip, Sponge	73064	10-28	26
Rubber, Cover, Joystick	1000188	10-33	10
Scr, Slftpg, Hh	80322	10-26	6
Scr, Slftpg, Hh	80322	10-28	16
Screw	N/A	10-22	7
Screw, Flat Head	N/A	10-22	18
Screw, Hfh	989272-25	10-5	2
Screw, Hhc	989272-50	10-5	7
Screw, Hhc	989272-33	10-6	2
Screw, Hhc	989272-36	10-7	2
Screw, Hhc	989272-38	10-7	3
Screw, Hhc	989272-37	10-8	5
Screw, Hhc	989272-85	10-8	8
Screw, Hhc	989272-36	10-9	3
Screw, Hhc	989272-23	10-11	1
Screw, Hhc	989272-30	10-11	13
Screw, Hhc	989272-48	10-11	18
Screw, Hhc	989272-46	10-9	7
Screw, Self-tapping, Hex Head	80322	10-25	11
Screw, Whizlock	N/A	10-22	17
Seal	33187	10-4	•
Seal, Cable	36166	10-21	•
Seal, Cable	36166	10-35	•
Seal, Door	19871	10-28	•
Seal, Hub Bearing	38300-05	10-2	•
Seal, Pinion	38300-02	10-2	•
Seal, Window	36688-18	10-24	11
Seal, Window	36688-18	10-28	•
Sealant, Silicone, Clear	33707	10-27	•
Sealant, Silicone, Clear	33707	10-28	•
Seat Adjustment Lever Weldment	14039	10-29	3
Seat Assy, Black, W/armrest	360010B	10-30	3
Seat Belt	730-3050	10-30	13
Seat Belt Tether Kit	37982	10-30	•
Seat, Black, Plain	6576	10-29	2
Seat, Suspension, Low Profile	140600	10-30	2
Section Set, Poly/Wire 8'	989272-87	10-6	•
Section, Set, 36, Poly	989272-02	10-6	1
Sender, Temp Gauge	984909-12	10-14	•
Sending Unit, Fuel Level	38373	10-19	4

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Set Screw	38518-10	10-3	10
Shaft, Pivot, Front Axle, W/m	20724	10-4	8
Sheet, Hood	989272-66	10-5	5
Sheet, Hood	989272-64	10-5	8
Sheet, Hood	989272-65	10-5	9
Shim, Cable Clamp	38535	10-32	•
Shldr Scr	81262	10-28	14
Shroud, Rad, Kub	1002184-02	10-14	10
Sign, SMV (Slow Moving Vehicle)	P70036	10-18	9
Sill, Door	36688-07	10-24	14
Sleeve, Steering Cyl Mount	16935	10-4	3
Slider Set, Seat Base	72527-01	10-30	4
Slip Yoke	38518-02	10-3	2
Smv Sign Group	17898	10-18	•
Solenoid, 80 Amp, Kub	1002184-26	10-14	37
Solenoid, 12V, Constant Duty\IP	720290	10-34	4
Spacer, Engine Fan, Kub	1002184-07	10-14	2
Spacer, Seat Slide, Plastic	72527-03	10-30	•
Speaker, 4.5"	1002022-01	10-35	•
Spindle, W/m	27056	10-4	6
Spindle, W/m	27059	10-4	7
Starter	1001166-03	10-14	•
Steel Only Wafer	989272-86	10-6	•
Steering Axle, W/m	27051	10-4	5
Steering Column Body	1001100	10-31	8
Steering Column Dash	1001099	10-31	6
Steering Column Front	1001098	10-31	9
Steering Wheel	300030	10-31	2
Strainer Assy	36926	10-12	13
Strainer, Suct	33148	10-43	7
Strap, Bolt Kit	38518-11	10-3	•
Striker, External Thread	36688-49	10-25	7
Strip, Abrasive	4684102	10-18	•
Stub Shaft	38518-03	10-3	3
Stud Wheel	38300-16	10-2	•
Stud, Mounting, Motor	989272-67	10-5	10
Support, Filter	25646	10-42	
Support, Filter	15984	10-42	
Switch, Defroster Fan	35426	10-33	•
Switch, Defroster Fan	35426	10-33	•



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Switch, Fan	36745-18	10-22	22
Switch, Fan, 3 spd	35426	10-35	•
Switch, High Pressure	36745-09	10-23	•
Switch, Ignition	39146-14	10-31	4
Switch, Limit	37941	10-32	•
Switch, Low Pressure	36745-34	10-23	•
Switch, Safety Start	951091224	10-35	7
Switch, Stop Lamp, Hyd Type, No	32131	10-36	9
Switch, Temp, 220 Deg F, No, 1/4	37005	10-14	•
Switch, Wiper/washer	853090	10-26	5
Switch, Wiper/washer	853090	10-27	•
Tank Strap W/m	12488	10-12	7
Tank W/m, Fuel	1000261	10-19	1
Tank, Water, 150gal	1005443	10-12	6
Tank, Water, 150gal	33238	10-12	•
Term, Push-on	36348	10-33	•
Term, Push-on	36348	10-33	•
Term, Push-on	36349	10-35	•
Term, Ring	851390204	10-33	•
Term, Ring	851390204	10-33	•
Term, Ring	72135	10-35	•
Term, Ring	851390204	10-35	•
Term, Sealed Conn	36164	10-21	•
Term, Sealed Conn	36165	10-35	•
Term,Push-On,.25,Female,18- 14,SMP	36349	10-34	22
T-Handle	1000835	10-25	•
Throttle Cable Assy	26166	10-32	1
Tie Rod Tube	27053	10-4	9
Tire & Wheel	340010A	10-1	7
Toolbox Lid, W/m	987681	10-1	6
Toplink	989272-72	10-11	5
Tube Yoke	38518-04	10-3	4
Tube, Adjustment	989272-73	10-11	4
Tube, Air Intake, 3" Elbow	1002184-15	10-14	28
Tube, Air Intake, 3" Elbow	1002184-15	10-17	28
Tube, Air Intake, 3" Elbow	1002184-15	10-14	30
Tube, Air Intake, 3" Elbow	1002184-15	10-17	30
Tube, Air Intake, Kub	1002184-11	10-14	23
Tube, Air Intake, Kub	1002184-11	10-17	23
Tube, Intake, W/m	987488	10-17	14

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Tubing	38518-05	10-3	5
Turn Signal W/hazard	33687	10-31	3
U-bolt	35077	10-12	•
U-bolt	38482	10-42	•
U-bolt Kit	38518-06	10-3	6
U-bolt, Drive Axle	35339	10-1	3
Universal Joint	38518-01	10-3	1
Upper Rad Hose	986537-21	10-14	15
Valve Ball, Br	03-1392	10-8	12
Valve Ball, Br	03-1392	10-37	20
Valve Ball, Br	03-1392	10-39	20
Valve, Check	36882	10-13	3
Valve, Drain, Cock	910150	10-20	•
Valve, Heater Shutoff	35546	10-14	•
Valve, Heater Shutoff	35546	10-21	1
Valve, Thermal Expansion	36745-32	10-23	•
Valve, Water	36749-01	10-22	34
W/m, Bracket, Pump Cable	1000495	10-14	•
W/m, Hyd Cyl Mount	989272-89	10-11	23
Washer	36073	10-24	19
Washer Nozzle & Tee Kit	36753	10-27	•
Washer, Ext. Tooth	N/A	10-22	6
Washer, Fender	989272-43	10-5	4
Washer, Flat	81141	10-1	•
Washer, Flat	81141	10-1	•
Washer, Flat	80698	10-1	•
Washer, Flat	80970	10-1	•
Washer, Flat	80149	10-4	12
Washer, Flat	80144	10-4	16
Washer, Flat	80147	10-4	19
Washer, Flat	989272-34	10-8	6
Washer, Flat	989272-39	10-9	4
Washer, Flat	989272-31	10-11	14
Washer, Flat	81154	10-12	4
Washer, Flat	81155	10-12	8
Washer, Flat	80995	10-12	21
Washer, Flat	80142	10-21	4
Washer, Flat	80140	10-21	•
Washer, Flat	81006	10-21	•
Washer, Flat	80474	10-21	•



Illustrated Parts List (IPL)

Description	Part Number	Figure Number	Item Number
Washer, Flat	80140	10-24	3
Washer, Flat	81278	10-24	9
Washer, Flat	81278	10-25	4
Washer, Flat	80142	10-25	8
Washer, Flat	80140	10-27	•
Washer, Flat	80141	10-27	•
Washer, Flat	81278	10-28	21
Washer, Flat	80144	10-29	4
Washer, Flat	80143	10-29	6
Washer, Flat	80142	10-29	•
Washer, Flat	80140	10-32	•
Washer, Flat	80140	10-35	•
Washer, Flat	80141	10-35	•
Washer, Flat	80142	10-35	•
Washer, Flat	80141	10-35	•
Washer, Flat	80996	10-41	•
Washer, Flat	80996	10-42	•
Washer, Flat	80996	10-17	•
Washer, Flat	81155	10-20	•
Washer, Flat	80143	10-30	6
Washer, Flat	80143	10-30	8
Washer, Flat	80141	10-30	11
Washer, Lock	80164	10-1	•
Washer, Lock	80168	10-1	•
Washer, Lock	80160	10-1	•
Washer, Lock	989272-35	10-5	3
Washer, Lock	989272-35	10-7	1
Washer, Lock	989272-35	10-8	7
Washer, Lock	989272-40	10-9	5
Washer, Lock	871071601	10-12	5
Washer, Lock	80162	10-21	13
Washer, Lock	80160	10-21	•
Washer, Lock	80160	10-22	13
Washer, Lock	871071601	10-27	4
Washer, Lock	80160	10-28	13
Washer, Lock	80162	10-29	•
Washer, Lock	80161	10-32	•
Washer, Lock	80161	10-35	•
Washer, Lock	80161	10-35	•
Washer, Lock	80162	10-36	•

Illustrated Parts List (IPL)



Description	Part Number	Figure Number	Item Number
Washer, Lock	80162	10-41	•
Washer, Lock	80162	10-42	•
Washer, Lock	989272-35	10-9	2
Washer, Lock	80162	10-17	•
Washer, Lock	80162	10-20	•
Washer, Split	989272-26	10-11	17
Washer, Tank And Pump	33745-1	10-27	•
Weld Hinge	147-876	10-18	5
Wheel Stud	38303-03	10-4	•
Windshield Washer, Front Or Rear	21167	10-27	•
Wiper Motor, 2-speed	36741	10-27	•
Wire	33271-5	10-33	•
Wire	33271-5	10-33	•
Wire Harness	28369	10-12	•
Wire Harness	1001045	10-26	9
Wire Harness	988781	10-35	5
Wire Harness	27503	10-35	6
Wire,10Ga,Red\IP	71861-2	10-34	7
Wire,10Ga,White\IP	71861-1	10-34	8
Wire,14Ga,Black\IP	71064	10-34	17
Wire,14Ga,Blue\IP	71062	10-34	14
Wire,14Ga,Green\IP	71063	10-34	13
Wire,14Ga,Orange\IP	34203	10-34	20
Wire,14Ga,Purple\IP	35174	10-34	10
Wire,14Ga,Red/Blk\IP	38519-12	10-34	15
Wire,14Ga,Red\IP	71065	10-34	16
Wire,14Ga,White\IP	71862	10-34	21
Wire,14Ga,Yel/Red\IP	985677	10-34	19
Wire,14Ga,Yellow\IP	71066	10-34	12
Wire,16Ga,Brn/Yel\IP	33271-15	10-34	11
Wire,16Ga,Grn/Yel\IP	33271-19	10-34	18
Wire,14Ga,Brown\IP	72116	10-34	9
Wiring Harness	27824	10-12	•
Wiring Harness	27824	10-35	•
Wiring, Cab Harness	1001045	10-35	•
Wiring, Harness, Switch Panel Assy	1001044	10-33	•
Wiring, Harness, Trn Signal	1001046	10-31	•
Work Light	160040A	10-35	2
Yoke, End	38300-03	10-2	•



Illustrated Parts List (IPL)



500 Lincoln County Parkway Ext.

Lincolnton, North Carolina 28092

Phone: (704) 745-BLAW (2529) - Fax Sales: (704) 745-2530

www.blawknoxpaving.com

Printed in the U.S.A.